


TB525EC 41EDT52C966
Engine Assembly




TB525EC 41EDT52C966
Engine Assembly

Page 2 of 4

Ref #	Part Number	Qty	S/P/F	Description
1	753-06134	1		Engine Cover Assembly (Incl. Ref No. 2 & 3)
2	710-04194	1	/P	Cover Screw
3	791-181003	1	/P	Screw
4	753-05901	1		Rocker Cover
5	753-05902	1		Rocker Cover O-Ring
6	753-06311	1		Cylinder Assembly (Incl. Ref No. 3 & 5)
7	753-05408	1	/P	Oil Plug (Incl. Ref No. 8)
8	791-182290	1		Oil Plug O-Ring
9	753-06111	1		Crankcase Cover
10	753-05238	1		Crankcase Cover O-ring
11	753-06313	1		Crankcase Assembly (Incl. Ref No. 10)
12	753-06221	1		Flywheel Assembly
13	753-05264	1		Lead Wires
14	753-05243	1	S	Module Assembly
15	753-05244	1		Muffler Gasket
16	753-05245	1		Muffler Assembly (Incl. Ref No. 15 & 17)
17	753-05246	1	S	Muffler Screw
18	794-00043	1	/P	Spark Plug
19	753-05247	1		Insulator Gasket
20	712-04099	1	/P	Nut
21	753-05249	1		Insulator
22	753-05366	1	/P	Carburetor Gasket
23	753-06220	1		Carburetor
24	791-181751	1		O-Ring
25	753-05252	1		Air Cleaner Cover Assembly (Incl. Ref No. 26)
26	753-05254	1		Air Filter
27	710-04517	1	/P	Screw
28	753-06240	1		Fuel Tank Assembly w/Fuel Lines (Incl. Ref No. 29)
29	753-1229	1		Fuel Cap
30	753-05259	1		Fuel Tank Pads
31	753-06314	1		Starter Housing Assembly (Incl. Ref No. 3)
32	753-06281	1		Clutch Assembly
33	753-05263	1		Clutch Cover (Incl. Ref No. 2)
34	791-182519	1		Anti-Rotation Screw
35	753-04003	1		Clamp Screw
36	791-180217	1	S	Nut
37	791-181025	1		Rocker Cover Screw
	753-05297	1	/P	Spark Arrestor Assembly Not Shown
	753-06317	1		Shortblock Assembly Not Shown (Incl. Ref No. 3-6, 8, 10, 11 & 18)

TB525EC 41EDT52C966
General Assembly



TB525EC 41EDT52C966
General Assembly

Page 4 of 4

Ref #	Part Number	Qty	S/P/F	Description
1	753-04234	1		Throttle Housing Assembly (Incl. Ref No. 2-4)
2	791-182690	1		Throttle Trigger Spring
3	753-04119	1	/P	Throttle Trigger
4	791-182405	1	/P	Switch
5	753-05266	1		Throttle Cable Assembly
6	753-04236	1	/P	Upper Drive Shaft Housing Assembly
7	753-06039	1		D-Handle Assembly (Incl. Ref No. 8)
8	753-06040	1		Bolt
9	753-1190	1	/P	Split boom Coupler (Incl. Ref No. 10-13)
10	791-182057	1		Screw
11	791-181617	1		Bolt
12	791-181618B	1	/P	Adjustment Knob (Incl. Ref No. 13)
13	712-04018A	1	/P	Knob Retaining Nut
14	791-182387	1		Lower Drive Shaft Housing Assembly (Incl. Ref No. 16)
15	791-153597	1		Lower Clamp Assembly (Incl. Ref No. 19)
16	791-181852	1	/P	Lower Flexible Drive Shaft
17	791-181858	1	/P	Shield Mounting Screw
18	753-05050	1		Bushing Housing Assembly
19	791-145569	1	/P	Anti-Rotation Screw
20	791-181659	1	/P	Shield Assembly (Incl. Ref No. 21)
21	753-06048	1	/P	Blade Assembly
22	753-05034	1	/P	Adapter
23	753-06129	1		Spool Assembly