

**WIRING DIAGRAM (400 Manual Transmission)**  
**Harness (p/n 0486-096 - FIS)**  
**Harness (p/n 0486-100 - ACT)**

NOTES  
 1. CONNECTORS VIEWED FROM MATING SURFACE SIDE.  
 2. ● MALE PIN TERMINAL  
 ○ FEMALE RECEPTACLE TERMINAL

- 1 SWITCH, BRAKE PRESSURE
- 2 SPEEDOMETER
- 3 LIGHTS, INDICATOR
- 4 CONTROL, LEFT HAND
- 5 SWITCH, BRAKE HANDLE
- 6 SWITCH, KEY
- 7 CONNECTOR, REAR ACCESSORY
- 8 TAILLIGHT
- 9 COIL, IGNITION
- 10 CDI
- 11 RELAY, STARTER
- 12 MOTOR, STARTER
- 13 BATTERY, 12V
- 14 RELAY, NEUTRAL
- 15 REGULATOR/RECTIFIER
- 16 MAGNETO
- 17 CONNECTOR, SWITCHED ACCESSORY
- 18 BOX, FUSE
- 19 SWITCH, FOOT BRAKE
- 20 DIODE ASSEMBLY
- 21 SWITCH, REVERSE
- 22 LIGHT, TEMP. - SWITCH
- 23 MOTOR, FAN
- 24 FAN, TEMP.- SWITCH
- 25 DIODE, FAN
- 26 SWITCH, GEAR
- 27 HEADLIGHT, LOW-BEAM LEFT
- 28 HEADLIGHT, HIGH-BEAM LEFT
- 29 HEADLIGHT, LOW-BEAM RIGHT
- 30 HEADLIGHT, HIGH-BEAM RIGHT
- 31 CONNECTOR, FRONT ACCESSORY

