Arctic Cat® Snowmobile Installation Instructions - Service Parts Kit

Sheave Adjuster Update Kit (p/n 0637-291)

■ NOTE: Read these instructions thoroughly and carefully before beginning the installation process. Retain these instructions for future reference.

Application: 2005 Firecat Models (excluding those with reverse) and 2004/2005 ZR 900

Kit includes:		
p/n	QTY	DESCRIPTION
0648-762	1	Sheave Adjuster
1623-572	1	Vented Cap Screw (3/8-16 x 4 1/2 in.)
8051-272	1	Spring Lock Washer
		(0.382 x 0.683 x 0.094 in.)
8050-277	1	Flat Washer $(3/8-1.0 \times 0.063 \text{ in.})$
1653-370	1	Instructions

Installing Sheave Adjuster

- 1. Remove the driven pulley access panel.
- 2. Engage the brake lever lock; then using a 13/16 in. socket and Drive Belt Replacement Tool (p/n 0644-435) provided with the snowmobile, remove the existing sheave adjuster.
- 3. Remove the 0-ring securing the washers to the sheave adjuster; then remove the washers. Retain the 0-ring and washers. Discard the sheave adjuster.
- 4. Install the existing washers and 0-ring onto new Sheave Adjuster (p/n 0648-762).

- 5. Using a 9/16 in. socket, remove the cap screw and washers securing the driven pulley to the gear case input shaft. Discard the cap screw and washers.
- 6. Place new Spring Lock Washer (p/n 8051-272) onto new Cap Screw (p/n 1623-572); then place new Flat Washer (p/n 8050-277) onto the cap screw. Insert the cap screw w/ washers into the gear case input shaft. Tighten to 4.4 kg-m (32 ft-lb).

CAUTION

Do not apply any type of Loctite to Cap Screw (p/n 1623-572). The cap screw is designed with a vented slot which must remain unobstructed for venting purposes.

- 7. Install the driven pulley access panel.
- 8. Disengage the brake lever lock.

■ NOTE: Refer to Service Bulletin 2006-1-04 for warranty-related information.