




Ref #	Part Number	Qty	S/P/F	Description
1	3470-032	1		Cleaner, Air - Assembly (inc. 2-17)
2	3470-014	1		Filter
3	3470-015	1		Holder
4	3470-016	1		Stopper, Holder
5	0693-505	1		Screw
6	3470-026	1		Tube, Outlet
7	3470-025	1		Fitting, Elbow
8	3402-334	1		Plug, Breather
9	3423-313	2		Clip
10	3423-727	1		Clamp, Tube
11	3423-726	1		Clamp, Tube
12	3470-017	1		Trap, Flame
13	3470-012	1	S	Cap, Air Cleaner (inc. 14)
14	3470-013	1		Gasket
15	3470-027	1		Joint, Inlet
16	3470-028	1		Duct, Inlet
17	3423-503	1		Clamp
18	3004-377	1	S/P	Screw, Cap
19	3004-507	2	S	Screw, Cap



Ref #	Part Number	Qty	S/P/F	Description
1	3445-034	1	/P	Battery
2	3406-003	1		Protector
3	3445-036	1	S	Protector
4	3445-037	1		Protector
5	3445-035	1		Protector, Battery
6	3445-039	1		Cable, Starter Motor/Starter Relay (inc. 7)
7	3545-018	1		Cap, Terminal
8	3445-040	1		Cable, Battery/Starter Relay (inc. 9)
9	3445-019	1		Cap, Terminal
10	3445-041	1		Cable, Battery/Ground




Ref #	Part Number	Qty	S/P/F	Description
1	2506-459	1		Panel, Body
2	0423-494	2		Rivet, Reinstallable
3	2406-130	1		Fender, Rear - Right
3	2406-131	1		Fender, Rear - Left
4	0423-459	4		Clip, Mounting
5	8476-616	12		Screw, Machine
6	8050-212	12	/P	Washer
7	0624-250	12		Nut, Lock
8	1506-306	1		Bracket, Mounting - Rear Fender - Right
8	1506-305	1		Bracket, Mounting - Rear Fender - Left
9	0423-357	4		Nut, Stamped
10	1506-410	4		Clamp, Foot Guard
11	0423-419	6		Screw, Machine
12	1506-411	1		Guard, Foot - Right
12	1506-412	1		Guard, Foot - Left
13	1406-447	1		Panel, Trim - Right
13	1406-448	1		Panel, Trim - Left
14	0423-489	10		Nut, Stamped
15	2406-128	1		Fender, Front - Right
15	2406-129	1		Fender, Front - Left
16	1506-301	1		Bracket, Mounting - Front Fender - Right
16	1506-302	1		Bracket, Mounting - Front Fender - Left
17	0623-269	2		Clip, Retaining
18	2506-463	1		Cover, Tank




Ref #	Part Number	Qty	S/P/F	Description
1	3502-032	1	S	Chain, Camshaft Drive
2	3402-848	1		Guide, Cam Chain - No. 1
3	3402-930	1		Guide, Cam Chain - No. 2
4	3402-849	1		Tensioner, Cam Chain
5	3423-561	1		Bolt
6	3423-142	1		Washer
7	3502-019	1		Adjuster, Tensioner - Assembly (inc. 8-10)
8	3402-850	1		Gasket
9	3402-933	1		Plug
10	3402-932	1		Spring
11	3402-137	1		Gasket, Adjuster
12	3004-475	2	S	Bolt
13	3402-929	1		Retainer, Cam Chain Guide No.1
14	3423-018	1		Screw






Ref #	Part Number	Qty	S/P/F	Description
	3402-931	1		Shim, Tappet - Set
1	3502-015	1		Camshaft, Intake
2	3502-031	1		Camshaft, Exhaust
3	3402-877	2		Valve, Intake
4	3402-878	2		Valve, Exhaust
5	3402-726	4		Spring, Valve
6	3402-934	4		Retainer, Spring
7	3402-879	8		Cotter, Valve
8	3402-880	4		Seat, Spring
9	3402-078	4		Seal, Oil
10	3402-851	4		Tappet
11	3402-852	AR		Shim, Tappet - 2.30 mm
11	3402-853	AR		Shim, Tappet - 2.35 mm
11	3402-854	AR		Shim, Tappet - 2.40 mm
11	3402-855	AR		Shim, Tappet - 2.45 mm
11	3402-856	AR		Shim, Tappet - 2.50 mm
11	3402-857	AR		Shim, Tappet - 2.55 mm
11	3402-858	AR		Shim, Tappet - 2.60 mm
11	3402-859	AR		Shim, Tappet - 2.65 mm
11	3402-860	AR		Shim, Tappet - 2.70 mm
11	3402-861	AR		Shim, Tappet - 2.75 mm
11	3402-862	AR		Shim, Tappet - 2.80 mm
11	3402-863	AR		Shim, Tappet - 2.85 mm
11	3402-864	AR		Shim, Tappet - 2.90 mm
11	3402-865	AR		Shim, Tappet - 2.95 mm
11	3402-866	AR		Shim, Tappet - 3.00 mm
11	3402-867	AR		Shim, Tappet - 3.05 mm
11	3402-868	AR		Shim, Tappet - 3.10 mm
11	3402-869	AR		Shim, Tappet - 3.15 mm
11	3402-870	AR		Shim, Tappet - 3.20 mm
11	3402-871	AR		Shim, Tappet - 3.25 mm
11	3402-872	AR		Shim, Tappet - 3.30 mm
11	3402-873	AR		Shim, Tappet - 3.35 mm
11	3402-874	AR		Shim, Tappet - 3.40 mm
11	3402-875	AR		Shim, Tappet - 3.45 mm
11	3402-876	AR		Shim, Tappet - 3.50 mm




Ref #	Part Number	Qty	S/P/F	Description
1	3470-035	1		Carburetor Assembly (inc. 2-58)
2	3423-567	1		Washer
3	4505-118	1		Ring
4	4505-119	1		E-Ring
5	4505-145	1		Spring
6	3423-709	1		O-Ring
7	4505-123	1		Holder
8	4505-130	1		Diaphragm
9	4505-126	1		Valve, Piston
10	4505-146	1		Ring
11	4505-124	1		Spring
12	4505-143	1		Washer
13	4505-117	1		Jet Needle 5E26-1
14	3423-568	1		O-Ring
15	3423-566	1		Washer
16	4505-152	1		Adjuster
17	4505-113	1		Spring
18	4505-071	1		Main Jet - 130
19	4505-140	1		Ring
20	4505-141	1		Holder, Jet
21	4505-136	1		Jet
22	4505-110	1		Pin
23	4505-116	1		Needle Valve Assembly
24	4505-111	1		O-Ring
25	4505-114	1		Needle Jet P-0M
26	4505-120	1		Starter Plunger Assembly
27	4505-121	1		Spring
28	3423-565	1		O-Ring
29	3470-011	1		Cap
30	4505-122	1		Holder, Guide
31	4505-153	1		Cover, Diaphragm
32	4505-144	1		Diaphragm Assembly
33	4505-129	1		Cover Assembly
34	4505-125	1		Spring
35	3423-570	2		Screw
36	3423-564	2		Screw
37	4505-133	4		Screw
38	3423-563	1		Screw
39	0694-025	1		Screw
40	3423-571	1		Screw
41	4505-109	1		Float Assembly
42	4505-135	1		Pilot Jet - 22.5
43	4505-142	1		Pipe
44	3004-645	3	S/P	Screw
45	4505-148	1		O-Ring
46	4505-127	1		Cover
47	3423-572	1		Nut
48	4505-134	1		Starter Jet - 60
49	4505-150	1		Hose
50	4505-112	1		Spring
51	3423-573	1		Washer
52	4505-137	1		Screw, Adjust - Assembly
53	4505-151	1		Screw

Ref #	Part Number	Qty	S/P/F	Description
54	4505-147	1		Guide, Cable
55	3423-569	1		O-Ring
56	4505-149	1		Hose
57	0693-784	1		Hose
58	4505-157	1	S	Plug
59	4505-155	1		Sensor Assembly
60	4505-156	1		Screw
61	3004-787	1		Clamp, Drain Hose




Ref #	Part Number	Qty	S/P/F	Description
1	3446-394	1		Rod, Clutch Push
2	3402-940	1		Spacer, Primary Driven Gear
3	3402-939	1		Gear, Primary Driven
4	3423-619	1		Washer
5	3446-392	1		Hub, Sleeve
6	3423-688	1		Washer, Lock
7	3423-254	1		Nut
8	3446-395	1		Pin, Clutch Release
9	3402-043	1	/P	Bearing, Pressure Disc
10	3423-774	1		Seat, Washer
11	3423-775	1		Washer
12	3446-360	1		Plate, Drive - No. 2
13	3446-427	7		Plate, Driven
14	3446-359	7		Plate, Drive - No. 1
15	3446-332	1		Plate, Drive
16	3446-393	1		Disc, Pressure
17	3423-848	6	S/P	Spring
18	3423-776	6		Bolt
19	3402-972	1		Bearing, Clutch Release - Lower
20	3446-396	1		Camshaft, Clutch Release
21	3402-973	1		Bearing, Clutch Release - Upper
22	3423-765	1		Washer, Clutch Release
23	3402-974	1		Seal, Clutch Release Arm
24	3402-941	1		Retainer, Clutch Release Oil Seal
25	3402-890	1	S	Stopper, Clutch Release Camshaft
26	3446-361	1		Arm, Clutch Release
27	3423-328	1	S	Bolt, Clutch Release Arm






Ref #	Part Number	Qty	S/P/F	Description
1	3405-037	2		Grip, Handlebar
2	3405-042	1		Case, Throttle (inc. 3-9)
3	3405-035	1		Cap
4	3423-582	1		Gasket
5	3423-581	3		Screw
6	3405-036	1		Holder
7	3423-580	2		Bolt
8	3004-853	1	S/P	Nut
9	1691-018	1		Screw
10	3402-886	1		Lever, Front Brake
11	3423-583	1		Bolt, Pivot
12	3423-748	1		Nut
13	3409-037	1		Switch, Stop (inc. 14)
14	3423-750	1		Screw
15	3509-010	1	S	Switch, Control - Assembly (inc. 16-19)
16	3409-009	1		Lever, Choke
17	3409-010	1		Cover, Choke
18	3423-196	1		Screw
19	3423-197	1		Screw
20	3446-419	1		Lever, Clutch - Assembly (inc. 21-37)
21	3409-041	1		Switch, Clutch
22	3402-964	1		Lever
23	3423-751	1		Bolt, Pivot
24	3423-746	1		Washer
25	3423-623	2	S	Nut
26	3502-025	1		Holder
27	3004-507	2	S	Bolt
28	3402-963	2		Nut, Adjuster
29	3423-749	2		Bolt, Adjuster
30	3402-968	1		Lock, Parking Brake
31	3423-745	1		Bolt, Parking Brake Lock
32	3423-747	1		Washer
33	3402-965	1		Spacer
34	3402-966	1		Spring, Return
35	3402-967	1		Knob, Parking Brake Lock
36	3423-753	1		Screw, Parking Brake Lock Knob
37	3423-752	1		Washer
38	3406-019	1		Cover, Clutch Lever




Ref #	Part Number	Qty	S/P/F	Description
1	3423-666	1		Nut
2	3423-698	1		Washer
3	3406-137	1		Gear, Driven
4	3406-138	1	/P	Race, Driven Gear - Inner
5	3423-106	2	/P	Pin, Driven Gear
6	3402-090	4		Spring, Driven Gear
7	3402-900	2		Bearing
8	3423-047	1		Pin, Inner Driven Gear Race
9	3402-925	1		Balancer, Crank


2007 ATV 400 DVX TONY STEWART EDITION (A2007DVI2AUSX)  
CRANKCASE ASSEMBLY



Ref #	Part Number	Qty	S/P/F	Description
	0462-039	1		Complete Engine Assembly (ELTZ400K)
1	3502-028	1		Crankcase Set (inc. 2-11)
2	3423-088	2		Pin, Dowel
3	3423-098	7	S	Bolt
4	3423-097	8		Bolt
5	3423-706	1		Plug, Oil Gallery
6	3402-894	1		Gasket
7	3402-918	1		Jet, Oil Gallery
8	3423-051	1		O-Ring
9	3402-919	1		Separator, Oil - No. 1
10	3402-920	1		Separator, Oil - No. 2
11	3423-435	4		Screw, Separator
12	3402-404	1		Plug, Oil Drain
13	3402-011	1		Gasket
14	3446-391	1		Pipe, Oil - Inner - No. 1
15	3446-356	1		Pipe, Oil - Inner - No. 2
16	3423-709	3		O-Ring
17	3423-710	1		O-Ring
18	3005-514	1		Bolt
19	3423-391	1		Bolt
20	3423-737	2		Spacer, Engine Mounting
21	3423-457	2	S	Nut




Ref #	Part Number	Qty	S/P/F	Description
1	3403-017	1	S	Cover, Clutch
2	3446-357	1		Gasket, Clutch Cover
3	3423-540	1		Plug, Oil Gallery
4	3402-436	1	/P	Gasket, Oil Gallery Plug
5	3423-610	4		Pin
6	3423-162	16	S	Bolt
7	3003-290	2	/P	Gasket
8	3423-098	4	S	Bolt
9	3423-112	1	S	Plug, Oil Gallery
10	3402-011	1		Gasket
11	3423-705	1		Plug, Oil Gallery
12	3004-339	1	S/P	Bolt, Oil Level
13	3402-009	1	/P	Gasket
14	3409-042	1		Cover, Magneto
15	3409-023	1		Gasket, Magneto Cover
16	3402-898	1		Plug, Crank Hole
17	3423-061	1		O-Ring
18	3402-012	1		Gasket
19	3402-040	1	/P	Plug
20	3409-022	1		Cover, Starter Idle Gear
21	3423-713	1		O-Ring
22	3423-328	3	S	Bolt
23	3435-098	1		Cover, Engine Sprocket
24	3006-094	2	S	Bolt
25	3423-672	2		Washer
26	3402-962	1		Plate, Chain Guide







Ref #	Part Number	Qty	S/P/F	Description
1	3502-029	1	S	Crankshaft Assembly (inc. 2-6)
2	3502-012	1		Rod, Connecting
3	3502-014	1		Pin
4	3406-139	1		Bearing
5	3402-922	1		Crankshaft - Right
6	3402-923	1		Crankshaft - Left
7	3402-926	1	/P	Gear, Balancer Drive
8	3423-047	1		Pin
9	3402-904	2		Bearing
10	3402-910	1		Seal, Oil - Right
11	3402-952	1		Retainer, Oil Seal - Right
12	3004-552	1	S	Screw
13	3502-030	1		Sprocket, Cam Chain Drive
14	3406-140	1		Gear, Primary Drive
15	3423-253	1		Nut
16	3423-684	1		Washer
17	3006-890	1		Key
18	3402-846	1		Piston
19	3502-011	1		Ring Set, Piston
20	3402-847	1		Pin, Piston
21	3003-439	2	/P	Circlip



Ref #	Part Number	Qty	S/P/F	Description
1	3402-844	1		Cylinder
2	3423-089	2	S	Bolt, Stud
3	3004-488	2	S/P	Nut
4	3402-845	1		Gasket, Cylinder
5	3423-088	2		Pin, Dowel
6	3502-010	1		Tank, Oil Return
7	3423-600	1		Bolt
8	3406-002	1		Hose, Breather
9	3410-013	1		Hose, Breather
10	3006-855	4		Clamp, Hose
11	3410-014	1		Hose, Breather
12	3423-724	2		Clamp, Hose
13	3403-013	1	/P	Gasket Set




Ref #	Part Number	Qty	S/P/F	Description
1	3402-839	1		Head, Cylinder - Assembly (inc. 2-4)
2	3423-043	4	/P	Pin
3	3423-611	6	S	Bolt
4	3423-764	2	S	Bolt
5	3402-840	4		Guide, Valve
6	3402-841	1		Gasket, Cylinder Head
7	3423-088	2		Pin, Dowel
8	3423-429	2		Bolt
9	3423-637	4		Bolt
10	3423-675	4		Washer
11	3004-339	1	S/P	Plug, Oil Gallery
12	3003-290	1	/P	Gasket
13	3423-558	1		Bolt
14	3423-559	1		Washer
15	0217-708	1		Spark Plug (NGK CR7E)
16	3413-024	1		Cover, Thermostat
17	3413-025	1		Thermostat
18	3423-328	2	S	Bolt
19	3470-030	1		Pipe, Intake
20	3402-235	1		Clamp, Intake Pipe
21	3402-916	1	S	Clamp, Intake Pipe
22	3423-847	1		Bolt
23	3423-457	1	S	Nut



2007 ATV 400 DVX TONY STEWART EDITION (A2007DVI2AUSX)  
CYLINDER HEAD COVER


Page 31 of 105

Ref #	Part Number	Qty	S/P/F	Description
1	3423-646	2		Bolt
2	3423-680	2		Washer
3	3423-647	1		Bolt
4	3423-560	1		Cushion
5	3403-016	1		Cover, Cylinder Head
6	3402-843	1		Gasket







Ref #	Part Number	Qty	S/P/F	Description
1	1411-175	1		Decal, Graphic - Front
2	1411-166	1		Decal, Graphic - Front Fender - Right
2	1411-167	1		Decal, Graphic - Front Fender - Left
3	0411-744	1		Reflector, Front - Amber - Right
3	0411-745	1		Reflector, Front - Amber - Left
4	0411-759	1		Decal, Warning - Pre-Ride
5	1411-168	1		Decal, Graphic - Rear Fender - Right
5	1411-169	1		Decal, Graphic - Rear Fender - Left
6	0411-762	1		Decal, "Arctic Cat"
7	0411-696	1		Decal, Warning - Tire Pressure/Passenger
8	0411-746	1		Reflector, Rear - Red - Right
8	0411-747	1		Reflector, Rear - Red - Left
9	0411-218	1		Decal, Warning - General
10	1411-577	1		Decal, Warning - Off-Road Only
11	1411-170	1		Decal, Graphic - Side - Right
11	1411-171	1		Decal, Graphic - Side - Left
12	1411-172	2		Decal, Graphic - Tank - Upper




Ref #	Part Number	Qty	S/P/F	Description
1	3409-025	1		Relay, Starter (inc. 2-3)
2	3409-038	1		Cover, Starter Relay
3	3530-044	1		Fuse - 20 Amp
4	3423-020	2	/P	Bolt, Starter Motor
5	3409-027	1	S	Rectifier
6	0693-982	2		Bolt
7	3409-043	1		CDI
8	3530-027	1		Coil, Ignition
9	3004-377	1	S/P	Bolt
10	3409-029	1		Cap, Spark Plug
11	3409-031	1		Cover, Spark Plug Cap
12	3430-009	1	/P	Seal, High Tension Wire
13	3409-030	1		Seal, Spark Plug Cap



Ref #	Part Number	Qty	S/P/F	Description
1	3512-008	1	S	Pipe, Exhaust
2	3412-003	1		Gasket, Exhaust Pipe
3	3004-301	2	S	Bolt, Stud
4	3423-176	2	S	Nut
5	3412-006	1		Cover, Exhaust Pipe
6	3412-004	1		Connector, Muffler
7	3512-006	1		Body, Muffler (inc. 8-12 and one No. 13)
8	3423-740	1		Clamp
9	3423-739	1		Spacer
10	3423-645	3		Bolt
11	3412-009	1	S	Arrester
12	3412-005	1		Gasket
13	3423-613	3		Bolt
14	0694-024	2		Washer
15	3423-694	2		Spacer
16	3423-718	2		Cushion
17	3423-715	3		Cushion, Exhaust Pipe Cover
18	3423-661	3		Screw
19	3423-574	3		Washer
20	3423-575	3		Spacer, Exhaust Pipe Cover




Ref #	Part Number	Qty	S/P/F	Description
1	3406-009	1		Footrest - Right
2	3406-010	1		Footrest - Left
3	3423-636	4		Bolt
4	3406-136	1	/P	Support, Mudguard - Right
5	3406-164	1	/P	Support, Mudguard - Left
6	3423-633	2		Bolt
7	3406-148	1		Grip, Front
8	3004-630	4	S	Bolt
9	3406-149	1		Grip, Rear
10	3006-544	4	S	Bolt
11	3406-070	1		Guard, Foot - Right
11	3406-071	1		Guard, Foot - Left
12	3423-661	8		Bolt
13	3423-690	8		Washer
14	3436-017	1		Kit, Tool
15	3436-019	1		Wrench, Spanner
16	3436-020	1		Gauge, Air Pressure
17	3436-018	1		Wrench, Hex
18	8424-502	4		Nut
19	2506-412	1		Bracket, Reflector - Rear - Right
19	2506-413	1		Bracket, Reflector - Rear - Left
20	4606-877	2		Reflector, Rear
21	0423-371	4		Screw, Machine
22	4606-878	2		Reflector, Front
23	2506-389	2		Bracket, Reflector - Front






Ref #	Part Number	Qty	S/P/F	Description
1	3406-146	1		Frame
2	3406-147	1		Rail, Seat
3	3423-779	2		Bolt
4	3423-638	2		Bolt
5	3406-105	1		Plate, Mounting - Engine - Right
6	3406-106	1		Plate, Mounting - Engine - Left
7	3006-544	4	S	Bolt
8	3406-107	1		Plate, Mounting - Engine - Upper
9	3004-630	4	S	Bolt
10	3406-006	1		Protector, Engine
11	3423-653	2		Bolt
12	3406-104	1	S	Plate, Battery
13	3004-377	2	S/P	Bolt
14	3446-381	1		Roller, Chain Control
15	3423-631	1		Bolt
16	3423-696	2		Washer
17	3406-013	2		Cap, Seat Rail
18	3406-016	2		Cushion, Seat Mount - Front
19	0423-534	2		Grommet, Taillight
20	1506-413	1	/P	Bracket, Mounting - Reverse Switch
21	0423-419	2		Screw, Machine
22	8424-602	2	/P	Nut




Ref #	Part Number	Qty	S/P/F	Description
1	3406-023	1		Caliper, Brake - Right (inc. 2-15)
1	3406-030	1		Caliper, Brake - Left (inc. 2-15)
2	3406-021	2		Piston Set (inc. 3)
3	3406-022	2		Seal Set, Piston
4	3406-036	2		Spring, Pad
5	3406-043	2		Boot
6	3423-584	2		Pin
7	3406-035	2		Washer
8	3406-024	2		Pin, Slide
9	3406-034	2		Spring
10	3406-042	2		Plug, Dust
11	3406-033	2		Boot
12	3406-037	4		Pin
13	3406-027	1		Bracket - Right
13	3406-040	1		Bracket - Left
14	3406-025	2		Valve, Bleed
15	3406-026	2		Cap, Bleed Valve
16	3406-031	1		Pad, Brake - Set - Right (inc. 17)
16	3406-032	1		Pad, Brake - Set - Left (inc. 17)
17	3406-041	1		Shim - Right
17	3406-082	1		Shim - Left
18	3423-784	4		Bolt




2007 ATV 400 DVX TONY STEWART EDITION (A2007DVI2AUSX)  
FRONT BRAKE HOSE ASSEMBLY

Page 45 of 105

Ref #	Part Number	Qty	S/P/F	Description
1	3423-719	3		Bolt
2	3006-112	6		Washer
3	3406-153	1	S	Hose, Front Brake - No. 1
4	3406-154	1		Hose, Front Brake - No. 2
5	3423-754	1		Clamp, Hose No. 2 - Right
6	3423-755	1		Clamp, Hose No. 2 - Left
7	3004-339	2	S/P	Bolt
8	3406-155	1		Brakeline, Front
9	3423-328	1	S	Bolt
10	3423-780	1		Clamp, Front Brakeline
11	3406-119	1		Cover, Front Brakeline




Ref #	Part Number	Qty	S/P/F	Description
1	3406-046	1	S	Master Cylinder Assembly (inc. 2-9)
2	3406-045	1		Piston Set
3	3406-048	1		Diaphragm
4	3406-088	1		Cap
5	3423-598	2		Screw, Cap
6	3406-049	1		Holder
7	3423-585	2		Bolt
8	3406-120	1		Separator
9	3406-121	1		Plate






Ref #	Part Number	Qty	S/P/F	Description
1	3405-051	2		Shock Assembly - Front
2	3423-641	2		Bolt
3	3423-640	2		Bolt
4	3423-457	4	S	Nut
5	3405-052	1	/P	A-Arm - Lower Right
5	3405-053	1		A-Arm - Lower Left
6	3405-054	1		A-Arm - Upper Right
6	3405-055	1		A-Arm - Upper Left
7	3406-093	4		Bearing
8	3406-094	4		Bearing
9	3405-020	8		Seal, Dust - Lower A-Arm
10	3406-101	16		Seal, Dust - Inner
11	3406-112	4		Spacer
12	3406-111	8		Spacer
13	3423-634	8		Bolt
14	3423-457	8	S	Nut
15	3423-617	8		Washer



Ref #	Part Number	Qty	S/P/F	Description
1	3406-165	2		Cover, Brake Disc
2	3406-028	2		Disc, Brake
3	3423-455	6		Bolt
4	3423-649	6		Bolt, Brake Disc
5	3405-059	2		Shim, Front Axle
6	3403-205	2		Spacer, Front Axle
7	3402-914	2		Seal, Dust - Inner
8	3402-893	2		Bearing, Wheel Hub - Inner
9	3405-023	2		Spacer, Wheel Hub Bearing
10	3405-058	2		Hub, Wheel
11	3402-899	2		Bearing, Wheel Hub - Outer
12	3402-913	2		Seal, Dust - Outer
13	3402-895	2		Spacer, Front Axle
14	3405-022	2		Plate, Wheel Hub
15	3406-017	2		Tire, Front
16	3406-151	2		Wheel, Front
17	3423-788	8	/P	Nut, Wheel
18	3003-156	2	S/P	Washer
19	3423-622	2		Nut, Wheel Hub
20	3423-608	2		Pin, Cotter
21	3406-008	2		Valve Assembly




Ref #	Part Number	Qty	S/P/F	Description
1	3570-005	1		Tank, Gas
2	3470-018	1		Cap, Gas Tank
3	3470-022	1		Hose, Breather
4	3470-033	1		Hose, Breather
5	3406-109	1		Cushion, Front
6	3406-110	2		Cushion, Side
7	3003-787	2		Clamp
8	3423-673	1		Washer, Seat Hook
9	3423-691	1		Spacer
10	3423-096	1	S	Screw
11	3423-743	2		Cushion, Rear
12	3423-693	2		Spacer
13	3423-655	2		Bolt
14	3470-036	1		Valve, Shut-Off - Assembly
15	3470-037	1	/P	Hose, Gasline
16	3423-722	2		Clamp, Hose
17	3423-328	2	S	Bolt
18	3006-599	2		Gasket
19	3470-029	1		Cover, Air Cleaner Inlet Duct




Ref #	Part Number	Qty	S/P/F	Description
1	3446-397	1		Fork, Gear Shift - No. 1
2	3446-398	1		Fork, Gear Shift - No. 2
3	3446-399	1		Fork, Gear Shift - No. 3
4	3402-958	1		Shaft, Gear Fork - No. 1
5	3446-031	2	/P	Retainer, Shift Cam Bearing
6	3402-953	1		Cam, Gear Shift (inc. 7)
7	3423-114	1	/P	Pin, Shift Cam
8	3446-369	1		Pin, Shift
9	3446-370	1		Shaft, Reverse Lock
10	3402-954	1		Shifter, Gear Shift Cam
11	3446-371	1		Pawl, Gear Shift - No. 1
12	3446-372	1		Pawl, Gear Shift - No. 2
13	3446-373	1		Spring, Reverse Lock
14	3402-955	1		Lifter, Gear Shift Pawl
15	3402-132	1		Roller, Gear Cam Shifter
16	3423-708	2		Pin, Shift Pawl
17	3402-907	1		Bearing, Shift Cam - Left
18	3402-911	1		Seal, Reverse Lock
19	3446-389	2		Spring, Shift Pawl Return
20	3423-370	2		Screw, Shift Cam Bearing
21	3423-018	2		Screw, Shift Pawl Lifter
22	3402-186	1	/P	Bearing, Shift Cam - Right
23	3402-956	1		Stopper, Shift Cam
24	3402-957	1		Plate, Shift Cam Stopper
25	3423-652	1		Bolt, Cam Stopper Arm
26	3446-374	1		Spring, Shift Cam
27	3423-615	1		Washer, Shift Cam
28	3402-959	1		Shaft, Gear Shift
29	3402-960	1		Stopper, Gear Shift Arm
30	3402-068	1	/P	Seal, Oil - Gear Shift Shaft
31	3446-390	1		Spring, Gear Shift Shaft Return
32	3423-700	1		Washer, Gear Shaft
33	3423-546	2		Circlip, Gear Shaft
34	3423-678	1		Washer
35	3402-385	1		Bearing
36	3423-695	2		Spacer
37	3446-418	1		Lever, Gear Shift (inc. 38)
38	3446-376	1		Rubber, Gear Shift Lever
39	3004-341	1	S/P	Bolt, Gear Shift Lever
40	3509-006	1		Base Assembly
41	3423-044	2		Contact
42	3423-273	1		O-Ring
43	3402-087	2		Spring
44	3423-418	2		Bolt

2007 ATV 400 DVX TONY STEWART EDITION (A2007DVI2AUSX)  
HANDLEBAR ASSEMBLY







Ref #	Part Number	Qty	S/P/F	Description
1	3405-024	1		Handlebar
2	3405-025	1	S	Pod, Indicator Light
3	3423-735	2		Clip
4	3405-032	1		Bracket, Mounting - Right
5	3405-033	1		Bracket, Mounting - Left
6	3405-026	2		Balancer Set, Handlebar (inc. 7-12)
7	3423-660	2		Screw
8	3405-029	2		Expander
9	3423-672	2		Washer
10	3405-030	2		Expander
11	3405-031	2		Spacer
12	3423-668	2		Nut
13	3487-002	1		Cable, Clutch
14	3487-003	1		Cable, Throttle
15	3445-038	1		Cable, Starter
16	3423-714	1		Washer
17	3406-113	1		Guide, Cable
18	3423-627	2		Bolt
19	3487-004	1		Cable, Parking Brake
20	3406-114	1		Guide, Parking Brake Cable
21	3423-730	1		Clamp
22	3406-115	1		Stopper, Cable
23	3423-728	1		Clamp
24	3423-729	1		Clamp
25	3008-044	3		Cable Tie



Ref #	Part Number	Qty	S/P/F	Description
1	0509-023	1		Housing, Headlight
2	0609-252	1		Bulb, Headlight - Low Beam
3	0409-055	2		Bulb, Headlight - High Beam
4	0423-488	1		Bolt, Carriage
5	0486-146	1		Harness, Adapter - Headlight
6	1406-480	1		Bracket, Mounting - Headlight
7	0423-357	2		Nut, Stamped
8	0423-501	2		Screw, Self-Tapping
9	0123-802	2		Washer
10	0423-447	2		Grommet
11	0423-487	2		Washer, Shoulder
12	0423-060	1		Clip, Tinnerman
13	8424-502	1		Nut, Lock
14	0623-301	1	/P	Screw, Self-Tapping
15	8408-616	2		Screw, Cap
16	0509-022	1		Taillight Assembly (inc. 17-19)
17	0509-025	1		Housing, Taillight
18	0409-056	1		Bulb, Taillight
19	0409-057	1		Socket, Taillight
20	1406-790	4		Pad, Taillight
21	0486-138	1		Harness, Adapter - Taillight




Ref #	Part Number	Qty	S/P/F	Description
1	3420-011	1	S	Light, Indicator - Assembly (inc. 2-7)
2	3409-034	3		Socket
3	3409-039	3		Ring
4	3420-005	1		Lens, Neutral
5	3420-006	1		Lens, Reverse
6	3420-007	1		Lens, Water Temperature
7	3420-009	3		Bulb, Indicator Light



2007 ATV 400 DVX TONY STEWART EDITION (A2007DVI2AUSX)  
LEFT REAR WHEEL ASSEMBLY

Page 63 of 105

Ref #	Part Number	Qty	S/P/F	Description
1	3446-421	1	S	Hub, Rear Sprocket
2	3446-422	1	S	Sprocket, Rear - 40T
3	3423-683	4		Washer
4	3423-642	4		Bolt
5	3423-852	1		Washer
6	3423-851	1		Washer
7	3423-850	1		Nut, Rear Axle
8	3406-166	1		Hub, Wheel
9	3406-072	1		Tire, Rear
10	3406-160	1		Wheel, Rear
11	3423-788	4	/P	Nut, Wheel
12	3423-685	1		Washer
13	3423-667	1		Nut, Wheel Hub
14	3423-609	1		Pin, Cotter
15	3406-008	1		Valve Assembly






2007 ATV 400 DVX TONY STEWART EDITION (A2007DVI2AUSX)  
MAGNETO ASSEMBLY

Page 65 of 105


Ref #	Part Number	Qty	S/P/F	Description
1	3409-026	1		Stator Assembly
2	3430-060	1		Rotor Assembly
3	3430-061	1		Clamp, Magneto Lead
4	3005-564	3	S	Bolt
5	3003-307	3		Bolt
6	3423-742	1		Nut
7	3004-540	1	/P	Key




2007 ATV 400 DVX TONY STEWART EDITION (A2007DVI2AUSX)  
OIL PUMP ASSEMBLY

Page 67 of 105


Ref #	Part Number	Qty	S/P/F	Description
1	3502-020	1		Pump, Oil - Assembly
2	3402-881	1		Gear, Driven
3	3423-046	2		Pin
4	3423-443	1		Washer
5	3423-184	1	S	Circlip
6	3004-520	3	S/P	Screw
7	3502-022	1		Rotor Set, Oil Pump
8	3502-023	1		Strainer, Oil Pump
9	3004-376	2	S/P	Bolt
10	3470-008	1		Filter, Oil
11	3423-270	1		O-Ring
12	3402-885	1		Cap, Oil Filter
13	3423-277	1		O-Ring
14	3402-238	1		Spring
15	3423-328	3	S	Bolt
16	3402-917	1		Spring
17	3402-891	1		Ball
18	3402-883	1		Seat, Oil Check Valve
19	3402-935	1		Gear, Idle - Oil Pump
20	3402-936	1		Shaft
21	3423-358	2	S	Circlip



Ref #	Part Number	Qty	S/P/F	Description
1	3410-019	1		Hose, Oil Tank - Right
2	3410-020	1		Hose, Oil Tank - Left
3	3423-720	1		Bolt, Union
4	3006-113	2		Gasket, Oil Hose Union
5	3004-512	3	S	Bolt
6	3423-744	2		Cushion, Oil Tank
7	3423-711	3		O-Ring, Oil Hose
8	3008-199	3	/P	Pin, Oil Tank Hose
9	3410-018	1		Hose, Oil Overflow
10	3423-723	2		Clamp, Hose
11	3470-009	1		Gauge, Oil Level
12	3423-055	1		O-Ring, Oil Level Gauge
13	3004-705	1	S	Plug, Oil Drain
14	3402-436	1	/P	Gasket, Oil Drain Plug
15	3502-021	1		Tank, Oil
16	3423-657	2		Bolt, Oil Tank
17	3423-716	2		Cushion, Oil Tank
18	3423-692	2		Spacer, Oil Tank
19	3406-074	1		Decal, Oil Level
20	3402-882	1		Protector, Oil Tank
21	3423-423	2		Clip




Ref #	Part Number	Qty	S/P/F	Description
1	3413-026	1		Radiator
2	3413-028	1		Cover, Radiator
3	3423-657	3		Bolt
4	3423-692	3		Spacer
5	3423-716	3		Cushion
6	3409-024	1		Switch, Radiator Fan (inc. 7)
7	3423-576	1		O-Ring
8	3413-035	1		Fan, Radiator
9	3423-741	3		Nut
10	3004-339	3	S/P	Bolt
11	3409-035	1		Switch, Temperature
12	3402-937	1		Boot, Radiator Fan






Ref #	Part Number	Qty	S/P/F	Description
1	3413-029	1		Hose, Radiator Inlet
2	3413-030	1		Hose, Radiator Outlet
3	3006-324	4		Clamp
4	3413-031	1		Reservoir (inc. 5)
5	3413-032	1		Cap, Reservoir
6	3423-654	2		Screw
7	3413-034	1		Hose, Inlet
8	3423-480	2		Clip
9	3413-033	1		Hose, Overflow
10	3413-027	1		Cap




Ref #	Part Number	Qty	S/P/F	Description
1	3406-076	1		Caliper Assembly, Rear (inc. 2-24)
2	3406-078	1		Piston Set (inc. 3)
3	3406-077	1		Seal Set
4	3406-036	1		Spring, Pad
5	3406-043	1		Boot
6	3423-584	1		Bolt
7	3406-035	1		Washer
8	3423-762	1		Pin
9	3406-033	2		Boot
10	3406-034	1		Washer
11	3406-128	1		Bracket
12	3406-038	2		Pin
13	3406-039	1		Washer
14	3406-025	1		Valve, Bleed
15	3406-026	1		Cap, Bleed Valve
16	3406-129	1		Actuator, Parking Brake
17	3406-080	1		Gasket
18	3423-763	2		Bolt
19	3423-592	1		O-Ring
20	3406-081	1		Boot
21	3406-130	1		Arm
22	3423-760	1		Bolt
23	3423-593	1		Nut
24	3423-595	1		Spring
25	3406-075	1		Pad Set
26	3423-789	2		Bolt




2007 ATV 400 DVX TONY STEWART EDITION (A2007DVI2AUSX)  
REAR BRAKE PEDAL ASSEMBLY

Page 77 of 105

Ref #	Part Number	Qty	S/P/F	Description
1	3406-007	1		Pedal, Brake
2	3423-712	2		O-Ring
3	3423-601	1		Bolt
4	3423-674	1		Washer
5	3423-623	1	S	Nut
6	3502-024	1		Spring, Return



Ref #	Part Number	Qty	S/P/F	Description
1	3406-083	1		Master Cylinder Assembly (inc. 2-9)
2	3406-084	1		Piston Set (inc. 3)
3	3402-887	1		Boot
4	3406-089	1		Rod, Push
5	3402-970	1		Yoke
6	3423-599	2		Nut
7	3406-090	1		Fitting, Elbow
8	3423-596	1		Circlip
9	3423-597	1		O-Ring
10	3423-628	2		Bolt
11	3406-132	1		Reservoir (inc. 12-14)
12	3406-085	1		Diaphragm
13	3406-086	1		Plate
14	3406-087	1		Cap
15	3423-112	1	S	Bolt
16	3410-015	1		Hose - Reservoir/Master Cylinder
17	3004-193	2		Clamp, Hose
18	3402-969	1		Hose, Brake
19	3423-719	2		Bolt, Union
20	3006-112	4		Washer
21	3423-703	1		Pin
22	0693-556	1		Washer
23	3423-606	1		Pin, Cotter
24	3423-790	1		Clamp, Brake Hose
25	3423-600	1		Bolt
26	3406-091	1		Guide, Hose






Ref #	Part Number	Qty	S/P/F	Description
1	3406-061	1		Arm, Front (inc. 2 and four No. 3)
2	3406-095	1		Bearing
3	3406-096	6	/P	Bearing
4	3423-626	3		Fitting, Grease
5	3406-060	1		Spacer
6	3406-063	6		Seal, Dust
7	3423-591	1		Bolt
8	3423-670	3		Nut
9	3406-065	1		Spacer
10	3406-066	6		Spacer
11	3423-590	1		Bolt
12	3406-100	2		Seal
13	3406-068	1		Spacer, Rear
14	3406-067	1		Guard, Front Arm
15	3423-662	2		Screw
16	3406-163	1		Arm, Rear (inc. two No. 3)
17	3406-064	1		Spacer
18	3423-589	1		Bolt
19	3423-457	2	S	Nut
20	3423-588	1		Bolt, Upper
21	3406-158	1		Shock Assembly - Rear
22	3423-856	1		Bolt, Lower


No  
Diagram  
Available  
  
Parts List  
Only

Ref #	Part Number	Qty	S/P/F	Description
	0436-541	1		A-Arm Guard Kit
	0436-544	1		Bars Kit - Nerf/Black Web
	0436-540	1		Bumper Kit (Front)
	0436-014	1	/P	Flag Kit
	0436-545	1		Frame Guard Kit (Side)
	0436-722	1		Handguard Kit - Black
	0436-720	1		Handguard Kit - Green
	0436-721	1		Handguard Kit - Red
	0436-724	1		Headlight Cover - Chrome
	0436-723	1		Headlight Cover - Smoke
	2257-681	1		Illustrated Parts Manual
	2257-612	1		Manuel d'utilisation (F)
	0436-005	1	S	Oil - 10W-40
	0436-003	1	S	Oil - 5W-30
	2257-611	1		Operator's Manual (E)
	0436-690	1		Shock Cover - Green
	0436-689	1		Shock Cover - Red
	0436-542	1		Skid Plate Kit (Center)
	0436-543	1		Skid Plate Kit (Rear)
	0436-042	1		Tire Repair Kit - Deluxe
	0436-685	1		Trailerable Cover



Ref #	Part Number	Qty	S/P/F	Description
1	3502-026	1		Knob, Reverse Lock - Assembly
2	3423-603	1	S	Screw
3	3006-700	1		Nut
4	3423-734	2		Clip
5	3423-604	1		Bolt
6	3406-116	1	S	Bracket, Reverse Cable


2007 ATV 400 DVX TONY STEWART EDITION (A2007DVI2AUSX)  
RIGHT REAR WHEEL ASSEMBLY



2007 ATV 400 DVX TONY STEWART EDITION (A2007DVI2AUSX)  
RIGHT REAR WHEEL ASSEMBLY


Page 87 of 105

Ref #	Part Number	Qty	S/P/F	Description
1	3423-609	1		Pin, Cotter
2	3423-667	1		Nut, Wheel Hub
3	3423-685	1		Washer
4	3406-008	1		Valve Assembly
5	3423-788	4	/P	Nut, Wheel
6	3406-072	1		Tire, Rear
7	3406-160	1		Wheel, Rear
8	3406-166	1		Hub, Wheel
9	3423-687	1		Washer
10	3423-849	1		Nut, Rear Axle
11	3446-420	1	S	Axle, Rear
12	3406-079	1		Disc, Brake
13	3423-649	4		Bolt
14	3406-099	2		Seal, Dust
15	3406-092	2		Bearing, Rear Axle
16	3406-134	1	/P	Housing, Rear Axle Bearing
17	3406-127	1		Spacer, Rear Axle Bearing






Ref #	Part Number	Qty	S/P/F	Description
	1506-300	1		Complete Seat Assembly
1	1506-297	1		Cover, Seat
2	1506-298	1		Foam, Seat
3	1506-359	1		Latch, Seat
4	1506-299	1		Base, Seat (inc. 5)
5	0406-877	3	/P	Bumper, Seat
6	0624-528	AR	/P	Staple - 5/16 in.
7	0624-094	AR		Staple - 1/4 in.



2007 ATV 400 DVX TONY STEWART EDITION (A2007DVI2AUSX)  
STARTER CLUTCH ASSEMBLY

Page 91 of 105


Ref #	Part Number	Qty	S/P/F	Description
1	3402-924	1		Gear, Starter Idle - No. 1
2	3423-699	2		Washer
3	3423-358	1	S	Circlip
4	3423-738	1		Pin
5	3445-032	1		Limitter, Starter Idle Gear
6	3402-125	2		Bushing
7	3423-616	2	S	Washer
8	3445-031	1		Clutch, Starter (inc. 9)
9	3402-222	1		Bearing
10	3423-226	6		Bolt




2007 ATV 400 DVX TONY STEWART EDITION (A2007DVI2AUSX)  
STARTER MOTOR ASSEMBLY

Page 93 of 105

Ref #	Part Number	Qty	S/P/F	Description
1	3445-033	1		Motor, Starter (inc. 2-10)
2	3402-671	1		Brush Terminal Set
3	3008-164	1		O-Ring
4	3402-672	1		Brush Holder Set
5	3008-551	2		Brush Spring
6	3423-497	2		O-Ring
7	3008-099	1		Washer Set
8	3423-536	2		Through-Bolt (inc. 9)
9	3423-496	2		O-Ring
10	3423-272	1		O-Ring
11	3004-756	2	S	Bolt
12	3423-195	1	/P	Nut




Ref #	Part Number	Qty	S/P/F	Description
1	3405-046	1	S	Post, Steering
2	3405-014	2		Seal, Dust - Steering Post Holder
3	3405-013	2	/P	Holder, Steering Post
4	3423-602	2		Bolt
5	3423-055	1		O-Ring
6	3405-038	1		Bushing, Steering Post
7	3405-047	1	S	Seal, Dust - Steering Post -Upper
8	3405-057	1	/P	Seal, Dust - Steering Post - Lower
9	3423-676	1		Washer
10	3423-624	1		Nut
11	3423-607	1	S	Pin, Cotter
12	3405-050	1		Clamp, Handlebar - Lower
13	3423-781	2		Bolt, Handle Holder
14	3423-782	2		Washer, Handle Holder
15	3423-341	2		Nut
16	3405-049	2		Clamp, Handlebar - Upper
17	3004-498	4	S	Bolt
18	3423-682	4		Washer







Ref #	Part Number	Qty	S/P/F	Description
1	3406-156	1		Arm, Swing (inc. 2-3)
2	3406-133	2		Bearing
3	3406-053	2		Bushing
4	3406-102	4		Seal, Bearing
5	3406-052	2		Spacer
6	3406-054	2		Cover, Dust
7	3423-618	2		Washer, Thrust
8	3406-051	1		Shaft, Pivot
9	3423-785	1		Nut
10	3423-786	1		Washer
11	3406-055	1		Slide, Chain
12	3423-656	3		Bolt
13	3446-383	1		Plate, Chain Adjuster
14	3423-650	1		Bolt, Chain Adjuster
15	3423-679	1		Washer, Chain Adjuster Nut
16	3423-190	1	S	Circlip
17	3423-757	1		Nut, Chain Adjuster
18	3423-643	2		Bolt
19	3423-644	2		Bolt
20	3423-677	4		Washer
21	3423-586	1		Plate
22	3423-587	1		Plate
23	3406-056	1		Guard, Swing Arm - Assembly (inc. 24-27)
24	3406-057	1		Guard, Swing Arm
25	3406-058	1		Slide, Chain - Swing Arm Guard
26	3423-671	3		Washer
27	3423-704	3		Rivet
28	3423-756	3		Bolt
29	3423-648	2		Bolt
30	3004-278	2	S/P	Washer
31	3406-123	1		Cap, Swing Arm
32	3406-124	1		Boot, Chain Adjuster Bolt




Ref #	Part Number	Qty	S/P/F	Description
1	3405-009	2		Tie Rod
2	3405-043	1		Knuckle, Steering - Right
2	3405-044	1		Knuckle, Steering - Left
3	3423-681	4		Washer, Rod End Lock
4	3405-045	2	S	End, Knuckle - Upper
5	3405-008	2		Ball Joint - Left
6	3405-007	2		Ball Joint - Right
7	3423-664	2		Nut, Tie Rod - Left
8	3423-620	4	S	Nut
9	3423-665	2		Nut, Tie Rod - Right
10	3423-607	4	S	Pin, Cotter
11	3004-417	4	S/P	Washer
12	3423-681	4		Washer, Wave
13	3423-620	4	S	Nut
14	3423-607	4	S	Pin, Cotter
15	3423-193	2	S/P	Circlip



Ref #	Part Number	Qty	S/P/F	Description
1	3402-942	1		Countershaft
2	3402-943	1		Gear, 2nd Drive - 18T
3	3446-362	1		Gear, 3rd Drive - 21T
4	3446-363	1		Gear, 4th Drive - 23T
5	3446-364	1		Gear, 5th Drive - 26T
6	3423-689	1		Washer
7	3423-702	2		Washer
8	3402-382	2		Washer
9	3402-975	1		Bearing, Countershaft - Left
10	3423-066	5	/P	Circlip
11	3402-976	1		Bearing, Countershaft - Right
12	3435-099	1		Driveshaft
13	3446-365	1		Gear, 1st Driven - 33T
14	3446-366	1		Gear, 2nd Driven - 30T
15	3402-944	1		Gear, 3rd Driven - 26T
16	3402-945	1		Gear, 4th Driven - 23T
17	3402-946	1		Gear, 5th Driven - 22T
18	3402-950	1		Gear, Reverse Driven - 28T
19	3402-951	1		Dog, Reverse
20	3446-380	1		Bushing, 3rd Driven Gear
21	3423-036	2		Washer
22	3446-273	1	/P	Bushing, Reverse Driven Gear
23	3003-320	1	/P	Bearing, Driveshaft - Right
24	3402-195	1		Washer
25	3423-421	1	/P	Washer
26	3402-903	1		Bearing, Driveshaft - Left
27	3402-912	1		Seal, Oil - Driveshaft
28	3402-915	1		Bushing, 1st Driven Gear
29	3402-230	1		Bushing, 2nd Driven Gear
30	3446-377	1		Sprocket, Driveshaft - 14T
31	3446-416	1		Chain Assembly (inc. 32)
32	3446-417	1		Joint Set
33	3446-367	1		Retainer, Countershaft - Right
34	3423-018	2		Screw
35	3446-368	1		Retainer, Driveshaft Oil Seal
36	3423-659	2		Bolt, Retainer
37	3402-947	1		Shaft, Reverse Idle
38	3402-948	1		Gear, Reverse Idle - 24T
39	3402-949	1		Bushing, Reverse Idle Gear
40	3402-209	1		Washer
41	3423-701	1		Washer
42	3423-686	1		Washer, Wave
43	3423-518	1		Circlip
44	3423-651	2		Bolt
45	3402-961	1		Plate, Sprocket



Ref #	Part Number	Qty	S/P/F	Description
1	3413-036	1	S	Pump, Water (inc. 2-12)
2	3406-141	1		Gasket
3	3423-769	3		Bolt
4	3423-770	2		Screw
5	3423-771	1		Pin
6	3406-142	1		O-Ring
7	3406-143	1		Seal, Oil
8	3423-772	1		Washer
9	3423-773	1		Pin
10	3406-144	1		O-Ring
11	3005-909	1	/P	Seal, Water Pump Shaft
12	3413-037	1		Impeller/Shaft
13	3423-629	3		Bolt
14	3423-630	1		Bolt
15	3004-521	1	/P	O-Ring
16	3423-184	1	S	Circlip
17	3413-021	1		Gear, Water Pump Driven





Ref #	Part Number	Qty	S/P/F	Description
1	3509-008	1		Harness, Main
2	3423-731	1		Clamp
3	3402-237	1		Clamp
4	3423-732	3		Clamp
5	0693-564	1		Clamp
6	3423-733	2		Clamp
7	3008-044	3		Clamp
8	3509-009	1		Switch, Ignition
9	3409-045	1	/P	Switch, Brakelight
10	3423-736	1		Spring
11	3409-040	1		Fuse Box - Cooling Fan (inc. 12)
12	3530-043	2		Fuse - 10 Amp
13	3409-007	1	/P	Key, Blank (Type C)
13	3409-011	1		Key, Blank (Type D)
13	3409-012	1		Key, Blank (Type E)
13	3409-013	1		Key, Blank (Type F)
14	0409-013	1		Cover, Key
15	3423-777	1		Clamp
16	3423-778	1		Clamp