



2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
AIR INTAKE ASSEMBLY



2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
AIR INTAKE ASSEMBLY

Page 2 of 58


Ref #	Part Number	Qty	S/P/F	Description
1	3305-183	4		Screw, Self-Tapping
2	3305-758	1		Cover, Air Silencer
3	3305-173	1		Seal
4	3305-177	1		Silencer, Air
5	3303-709	1		Clamp, Hose (inc. 6)
6	3304-117	1		Screw, Machine
7	3303-064	1	/P	Catch, Oil
8	3303-052	1		Clamp, Hose
9	3305-170	1		Hose
10	3303-352	1		Clamp, Hose
11	3303-350	2		Clamp, Hose
12	3305-171	1		Hose
13	3303-609	2		Clamp, Hose
14	3305-185	1		Hose, Drain
15	3305-182	1		Plug, Drain
16	3304-003	2		Screw, Cap
17	3305-179	1		Fitting, Elbow
18	3305-180	1		Grommet
19	3305-184	1		Screw, Self-Tapping
20	3305-175	2		Plate
21	3305-172	1		Filter, Air
22	3305-174	2		Screen



2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
CAM CHAIN ASSEMBLY

Page 4 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	3304-932	1		Guide, Chain
2	3304-924	1		Chain, Cam
3	3304-930	1		Tensioner, Chain
4	3303-035	1		Gasket
5	3303-677	1		Tensioner Assembly
6	3304-002	2	/P	Screw, Cap
7	3304-100	1	/P	O-Ring
8	3304-006	1		Screw, Adjuster
9	3304-931	1		Adjuster, Tension (inc. 10)
10	3303-301	1	/P	O-Ring




2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
CARBURETOR ASSEMBLY

Page 6 of 58

Ref #	Part Number	Qty	S/P/F	Description
	3305-058	1		Complete Carburetory Assembly
1	3305-059	1		Seal, Cap
2	3305-064	1		Adjuster, Cable
3	3304-217	1		Gasket
4	3306-431	1		Spring
5	3304-454	1		Clip, Spring
6	3306-430	1		Jet Needle - Assembly (inc. 6-7)
7	3304-240	1		E-Clip
8	3304-456	1		Needle Jet
9	3304-232	1		Spring, Compression
10	3304-455	1		Screw, Stop
11	3305-057	1		Spring, Torsion
12	3305-053	1		Lever, Choke
13	3304-429	1		Screw, Machine
14	3305-055	1		Bracket, Choke Cable
15	3305-054	1		Clamp, Retaining
16	5507-117	3	/P	Screw, Machine
17	3305-056	1		Plate, Cover - Diaphragm
18	3305-063	1		O-Ring
19	3304-238	1		O-Ring
20	3304-242	1		Valve, Float
21	3304-249	1		Clip, Float Valve
22	3304-451	1		Pin, Float Arm
23	3304-444	1		Float, Set
24	3304-219	1		Gasket, Float Chamber
25	3304-220	1		Chamber, Float - Assembly
26	3304-239	1		O-Ring
27	3304-243	1		Screw, Drain
28	3304-428	3		Screw, Machine
29	3304-452	1		Clamp, Hose
30	3305-922	1		Hose, Drain
31	3305-050	1		Slow Jet
32	3304-447	1		Holder, Needle Jet
33	3304-441	1		Main Jet - 98
34	3304-214	1		Holder, Main Jet

2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
CLUTCH ASSEMBLY




2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
CLUTCH ASSEMBLY

Page 8 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	3304-986	1		Pulley, Driven - Assembly (inc. 2-21)
2	3304-981	1		Clutch, Centrifugal - Assembly (inc. 3-8)
3	3304-054	3		Ring, Retaining
4	3304-983	1		Plate, Clutch
5	3304-984	3		Spring
6	3304-985	3		Weight, Clutch
7	3303-780	3		Roller
8	3304-982	1		Plate, Clutch
9	3304-994	1		Nut
10	3304-988	1		Face, Driven - Fixed (inc. 11-13)
11	3304-996	1		Bearing
12	3304-149	1		Ring, Retaining
13	3304-070	1		Bearing
14	3304-997	2		Seal
15	3304-990	3		Pin, Guide
16	3303-787	3		Guide, Roller
17	3304-989	1		Face, Driven - Movable
18	3304-619	2		O-Ring
19	3304-992	1		Sleeve, Spring
20	3304-991	1		Spring
21	3304-973	1		Clutch, Outer
22	3304-995	1		Washer, Thrust
23	3303-334	2		Nut
24	3304-979	1		Plate, Ramp
25	3304-980	3		Slide
26	3304-978	6		Roller
27	3305-744	1		Collar
28	3305-745	1		Collar
29	3304-976	1		Face, Drive - Movable (inc. 30-31)
30	3304-160	1		Ring, Retaining
31	3304-977	1		Sleeve
32	3304-987	1	/P	Belt, Drive
33	3304-975	1		Sleeve
34	3304-974	1		Face, Drive
35	3304-993	1		Ratchet, Kick Starter


2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
CYLINDER HEAD ASSEMBLY



2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
CYLINDER HEAD ASSEMBLY

Ref #	Part Number	Qty	S/P/F	Description
1	3304-012	1		Cap, Inspection
2	3304-099	1		O-Ring
3	3303-611	4		Screw, Cap
4	3304-914	1		Cover, Cylinder Head (inc. 5)
5	3304-915	1		Gasket
6	3303-342	6		Pin, Dowel
7	3303-332	4		Nut
8	3304-048	4	/P	Washer
9	3304-923	1		Plate, Stop
10	3304-942	2		Nut
11	3304-941	2		Screw, Adjuster
12	3304-926	1		Arm, Rocker - Exhaust
13	3304-921	1		Retainer, Camshaft
14	3304-925	1		Arm, Rocker - Intake
15	3304-929	1		Plate, Retaining
16	3304-944	1		Screw, Cap
17	3304-927	1		Shaft, Rocker Arm - Intake
18	3304-928	1		Shaft, Rocker Arm - Exhaust
19	3304-922	1		Camshaft
20	0217-796	1		Spark Plug D8EA
21	3304-940	4		Cotter, Valve
22	3304-937	2		Retainer, Valve Spring
23	3304-936	2		Spring, Valve - Inner
24	3304-935	2		Spring, Valve - Outer
25	3304-920	2		Seal, Valve Stem
26	3304-939	2		Seat, Valve Spring - Inner
27	3304-938	2		Seat, Valve Spring - Outer
28	3304-934	1		Valve, Exhaust
29	3304-933	1		Valve, Intake
30	3305-741	1		Head, Cylinder
31	3304-114	4		Bolt, Stud
32	3304-124	4		Nut
33	3304-916	1		Pipe, Intake (inc. 34)
34	3304-097	1		O-Ring
35	3304-918	2		Screw, Cap
36	3304-917	2		Bolt, Stud
37	3304-913	1		Gasket, Cylinder Head
38	3304-910	1		Cylinder
39	3304-911	1		Gasket, Cylinder


2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
ELECTRICAL AND WIRING HARNESS ASSEMBLY



2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
ELECTRICAL AND WIRING HARNESS ASSEMBLY

Page 12 of 58


Ref #	Part Number	Qty	S/P/F	Description
1	3305-748	1		Harness, Main (inc. 2-3)
2	3305-233	1		Fuse - 20 Amp
3	3303-837	1		Diode, Neutral
4	3304-654	4	/P	Nut, Lock
5	3303-836	1		Regulator, Voltage
6	3305-222	1		Coil, Ignition (inc. 7)
7	3305-223	1		Cap, Noise Suppression
8	3303-252	2		Screw, Cap
9	3305-727	1		CDI Unit
10	3305-939	1		Relay, Start-in-Gear
11	3305-225	1		Cable, Battery
12	3304-523	1		Relay, Lighting Control
13	3304-969	1		Harness, Ground
14	3303-857	1		Relay, Starter
15	3303-134	1	/P	Harness, Extension
16	3305-756	1		Switch, Ignition - Assembly (inc. 17-19)
17	3304-522	1		Cover, Key - "Arctic Cat"
18	3304-520	1		Key, Ignition - Set - Right-Side Cut
19	3304-521	1		Key, Ignition - Set - Left-Side Cut
20	3303-289	AR	/P	Tie, Cable



2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
EXHAUST ASSEMBLY

Page 14 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	3305-750	1		Pipe, Exhaust (inc. 2-8)
2	3304-686	2	/P	Screw, Cap
3	3304-140	2		Washer, Lock
4	3304-134	2		Washer
5	3303-727	4		Washer, Fiber
6	3303-730	1		Shield, Exhaust
7	3305-773	1		Washer
8	3305-769	2	/P	Screw, Cap
9	3305-188	1		Gasket, Exhaust
10	3305-187	2		Coupler, Exhaust
11	3305-186	1		Flange, Exhaust
12	3304-124	2		Nut
13	3305-749	2		Screw, Cap




2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
FRAME AND RELATED PARTS ASSEMBLY

Page 16 of 58


Ref #	Part Number	Qty	S/P/F	Description
1	3305-704	1		Frame, Main
2	3303-295	1		Seal, Oil
3	3303-347	1		Ring, Retaining
4	3303-392	1		Bearing
5	3305-104	1		Sleeve
6	3303-298	1		Seal, Oil
7	3305-239	2		Bracket, Mounting - Engine
8	3304-544	4		Screw, Cap
9	3304-654	4	/P	Nut, Lock
10	3305-237	1		Bracket, Mounting - Coil/Regulator
11	3304-184	1	/P	Screw, Cap
12	3305-705	2		Screw, Cap
13	3304-031	3	/P	Nut
14	3303-593	AR		Tie, Cable
15	3303-289	AR	/P	Tie, Cable
16	3305-242	2		Plug

2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
FRONT BODY PANEL AND HEADLIGHT ASSEMBLIES



2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
FRONT BODY PANEL AND HEADLIGHT ASSEMBLIES

Ref #	Part Number	Qty	S/P/F	Description
1	3306-235	1		Fender, Front (inc. 2-5)
2	1411-180	1		Decal, Reflector - Right
2	1411-181	1		Decal, Reflector - Left
3	1411-932	1	/P	Decal, Warning - General
4	1411-943	1		Decal, Pre-Ride Inspection
5	0411-836	1		Decal, Warning - Hill
6	2411-498	1		Decal, Side - Front Right
7	2411-478	1		Decal, Side - Rear Right
8	2411-479	1		Decal, Side - Left
9	3304-061	4	/P	Clip, U-Nut
10	3303-721	1		Grommet, Cover
11	3306-231	1	/P	Cover, Gas Tank (inc. 12-13)
12	1411-577	1		Decal, Warning - Not for Highways
13	1411-377	1		Decal, Warning - Age
14	3304-654	2	/P	Nut, Lock
15	3304-029	6	/P	Screw, Machine
16	3303-349	1		Clamp, Hose
17	3305-701	1		Hose, Fuel Drain
18	3304-650	3	/P	Screw, Self-Tapping
19	3305-926	1		Cover, CVT Air Filter Element
20	3305-096	1		Element, CVT Air Filter
21	3305-092	1		Guide, Shift Handle
22	3306-233	1		Cover, Front
23	2411-465	1		Decal, "Arctic Cat"
24	3304-651	7		Screw, Self-Tapping
25	3306-232	1		Grille, Front
26	3305-925	1		Support, Grille
27	3304-057	4	/P	Rivet, Reinstallable
28	3304-587	6	/P	Screw, Machine
29	3303-844	1		Headlight - Assembly - Right (inc. 28-30)
29	3303-845	1		Headlight - Assembly - Left (inc. 28-30)
30	3304-643	1		Lens, Headlight - Right
30	3304-644	1		Lens, Headlight - Left
31	3303-846	2	/P	Bulb, Headlight
32	3303-847	2		Bulb, Running Light
33	3304-645	6	/P	Screw, Self-Tapping
34	3306-148	1		Bumper, Front
35	3304-156	2		Clamp, Routing




2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
FRONT SUSPENSION ASSEMBLY

Page 20 of 58


Ref #	Part Number	Qty	S/P/F	Description
1	3305-208	1		A-Arm Assembly - Right (inc. 2)
1	3305-209	1		A-Arm Assembly - Left (inc. 2)
2	3303-965	4		Bushing
3	3304-182	4	/P	Screw, Cap
4	3304-031	4	/P	Nut
5	3306-238	2		Shock/Spring Assembly
6	3303-376	4	/P	Screw, Cap
7	3305-724	2		Pin, Cotter
8	3305-211	2		Nut, Lock
9	3305-107	2		Washer
10	3305-202	2		Screw, Cap
11	3305-198	1		Knuckle - Assembly - Right (inc. 12-15)
11	3305-203	1		Knuckle - Assembly - Left (inc. 12-15)
12	3305-201	4		Cap
13	3305-199	4		Bushing
14	3303-393	2		Fitting, Grease
15	3305-200	2		Axle

2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
FRONT WHEEL AND BRAKE ASSEMBLIES



2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
FRONT WHEEL AND BRAKE ASSEMBLIES

Ref #	Part Number	Qty	S/P/F	Description
1	3303-931	2		Cap, Wheel
2	3303-340	2		Pin, Cotter
3	3303-330	2		Nut, Lock
4	3305-124	2		Washer
5	3305-108	2		Spacer
6	3304-028	8		Nut, Lug
7	3305-112	2		Tire
8	3303-902	2	/P	Wheel - Assembly
9	3304-562	2		Stem, Valve
10	3305-109	2		Hub, Front - Assembly (inc. 11-14)
11	3305-126	8		Bolt, Stud
12	3303-468	4		Bearing
13	3303-456	2		Seal, Dust
14	3305-110	2		Spacer
15	3305-720	4	/P	Shoe, Brake
16	3305-116	4		Spring
17	3305-119	2		Cam, Brake
18	3305-117	2		Seal
19	3305-125	2		Seal
20	3305-114	1		Panel - Front - Right
20	3305-121	1		Panel - Front - Left
21	3305-118	2		Indicator, Wear
22	3305-120	1		Arm, Brake - Right
22	3305-122	1		Arm, Brake - Left
23	3303-611	2		Screw, Cap
24	3304-654	2	/P	Nut, Lock
25	3305-077	1		Cable, Brake - Right
25	3305-079	1		Cable, Brake - Left




2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
GAS TANK ASSEMBLY

Page 24 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	3305-397	4		Screw, Cap
2	3305-931	1		Pump, Fuel (inc. 3)
3	3305-930	1		Seal
4	3305-975	1		Cap, Gas Tank (inc. 5)
5	3304-169	1		Hose, Vent
6	3304-551	2	/P	Screw, Cap
7	3303-226	4		Insert
8	3304-647	2		Grommet
9	3304-654	2	/P	Nut, Lock
10	3303-406	2		Grommet
11	3305-734	1		Tank, Gas
12	3305-735	1		Hose Assembly (inc. 13-14)
13	3305-523	2		Clamp, Hose
14	3303-349	4		Clamp, Hose
15	3305-736	1		Hose Assembly (inc. 13-14)
16	3305-739	1		Hose Assembly (inc. 17)
17	3303-348	2		Clamp, Hose
18	3303-699	1	/P	Filter, Fuel
19	3305-738	1		Hose Assembly (inc. 14)
20	3303-057	1		Shut-Off, Fuel (inc. 21)
21	3304-120	2		Screw, Machine
22	3303-316	2		Screw, Machine
23	3303-058	1		Strainer, Fuel
24	3305-074	1		Bracket, Mounting - Fuel Shut-Off


2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
HANDLEBAR AND CONTROLS ASSEMBLY



2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
HANDLEBAR AND CONTROLS ASSEMBLY

Page 26 of 58


Ref #	Part Number	Qty	S/P/F	Description
1	3304-016	2		Screw, Cap
2	3305-541	2		End Cap, Handlebar
3	3305-905	2	/P	Grip, Handlebar
4	3305-714	1		Handlebar
5	3303-852	1	/P	Switch Assembly
6	3305-400	4		Screw, Cap
7	3305-715	1		Bracket, Instrument Pod
8	3303-954	2		Clamp, Handlebar - Upper
9	3303-955	2		Clamp, Handlebar - Lower
10	3304-136	2		Washer
11	3306-189	2		Nut
12	3304-029	2	/P	Screw, Machine
13	3306-199	1		Instrument Pod
14	3303-592	1		Rivet, Reinstallable
15	3305-072	1		Cable, Throttle
16	3303-839	AR		Tie, Cable
16	3303-289	AR	/P	Tie, Cable
17	3303-723	1		Cable, Choke
18	3305-923	1		Gauge, Speedometer
19	3304-645	3	/P	Screw, Self-Tapping



2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
HYDRAULIC HAND BRAKE ASSEMBLY

Page 28 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	3305-982	1	/P	Brake, Master Cylinder - Assembly (inc. 2-4)
2	3305-309	1		Diaphragm
3	3306-225	1		Plate, Diaphragm
4	3303-174	1	/P	Cover, Master Cylinder
5	3303-318	2		Screw, Machine
6	3305-983	1		Clamp, Handlebar
7	3304-551	2	/P	Screw, Cap
8	3305-993	1		Button, Park Brake
9	3305-992	1		Circlip
10	3305-991	1		Housing
11	3305-990	1		Spring
12	3305-989	1		Washer
13	3303-254	1	/P	Screw, Shoulder
14	3306-055	1	/P	Lever
15	3304-654	1	/P	Nut, Lock
16	3303-141	1	/P	Switch Assembly
17	3303-321	1		Screw, Machine
18	3305-076	1		Hose, Brake - Assembly
19	3303-284	4	/P	Washer, Crush
20	3303-257	2	/P	Bolt, Banjo-Fitting




2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
KICK STARTER AND COOLING DUCT ASSEMBLY

Page 30 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	3303-549	1	/P	Arm, Kick Starter (inc. 2-3)
2	3305-195	1		Washer
3	3305-247	1	/P	E-Clip
4	3304-551	1	/P	Screw, Cap
5	3305-235	1		Duct, Cooling
6	3303-635	1		Clamp w/Screw
7	3303-636	1		Clamp w/Screw
8	3305-234	1		Duct, Cooling

2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
LEFT CRANKCASE AND COVER ASSEMBLY




2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
LEFT CRANKCASE AND COVER ASSEMBLY

Page 32 of 58


Ref #	Part Number	Qty	S/P/F	Description
1	3304-888	1		Crankcase - Left (inc. 2)
2	3304-886	1		Retainer
3	3303-297	1	/P	Seal, Oil
4	3304-197	1		Bearing
5	3304-905	1		Bearing
6	3304-901	1		Seal, Oil
7	3304-005	2		Screw, Cap
8	3304-039	2		Retainer, Bearing
9	3304-008	2		Bolt, Stud
10	3303-465	1		Bearing
11	3304-907	2		Bearing
12	3304-158	1		Clamp, Wire
13	3303-381	3		Screw, Cap
14	3303-843	2		Retainer, Wire
15	3304-052	1	/P	Plug, Drain (inc. 16)
16	0	1	F	O-Ring
17	3303-691	1	/P	Screen, Filter
18	3303-692	1	/P	Spring
19	3304-096	1	/P	O-Ring
20	3303-021	1		Cap, Inspection
21	3304-205	1		Bearing, Ball
22	3304-063	1		Spring, Seat
23	3304-021	1		Washer
24	3304-109	1		Screw, Seat
25	3304-435	1		Screw, Cap
26	3304-895	1		Switch, Gear Shift (inc. 27)
27	3305-776	1	/P	O-Ring
28	3304-187	1		Screw, Cap
29	3303-591	1		Washer
30	3303-365	2		Screw, Cap
31	3304-903	2		Screw, Cap
32	3304-893	1		Gear, Kick Start Drive
33	3303-117	1		Spring
34	3303-272	1		Washer, Thrust
35	3304-900	1		Bearing
36	3304-894	1		Gear, Kick Start
37	3303-122	1		Spring
38	3303-121	1		Washer
39	3303-120	1		Spacer
40	3305-777	1		Washer
41	3303-345	1		Ring, Retaining
42	3303-391	3		Screw, Cap
43	3304-892	1		Gasket
44	3304-891	1		Plate, Cover
45	3304-890	1		Cover, Crankcase
46	3304-897	1		Bearing
47	3304-004	8		Screw, Cap

2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
PISTON AND CRANKSHAFT ASSEMBLY



2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
PISTON AND CRANKSHAFT ASSEMBLY

Ref #	Part Number	Qty	S/P/F	Description
1	3304-946	1		Ring Set, Piston
2	3304-947	1		Piston
3	3304-961	2		Circlip
4	3304-948	1		Pin, Piston
5	3304-945	1		Crankshaft Assembly
6	3304-960	1		Key
7	3304-959	2		Key
8	3304-962	1		Pin, Alignment
9	3304-950	1		Gear, Timing
10	3304-958	1		Washer
11	3304-956	1		Washer, Thrust
12	3303-694	1		Spring
13	3303-693	1		Oil Through
14	3304-036	1		Washer, Thrust
15	3304-954	1		Nut
16	3304-951	1		Shaft, Balancer
17	3304-949	1		Key
18	3304-953	1		Gear, Balancer
19	3304-952	1		Gear, Oil Pump Drive
20	3304-957	1		Washer
21	3304-955	1		Nut




2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
RACKS AND BUMPER ASSEMBLY

Page 36 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	3305-706	1		Rack, Rear
2	3304-543	10	/P	Screw, Cap
3	0411-814	1	/P	Decal, "Arctic Cat"
4	1411-444	1		Decal, Warning - Load - Rear
5	3305-707	1		Rack, Front
6	1411-201	1		Decal, Warning - Load - Front
7	3304-668	2		Nut
8	3305-708	1		Bumper


2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
REAR AXLE AND BRAKE ASSEMBLY



2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
 REAR AXLE AND BRAKE ASSEMBLY

Page 38 of 58


Ref #	Part Number	Qty	S/P/F	Description
1	3305-924	3		Screw, Self-Tapping
2	3305-069	1		Magnet, Speed Sensor
3	3305-068	1		Sensor, Speed
4	3305-722	1		Sprocket, Final Drive
5	3305-129	1		Retainer, Sprocket
6	3305-142	4		Screw, Cap
7	3304-031	4	/P	Nut
8	3305-132	1		Spacer
9	3305-133	1		Housing, Rear Axle (inc. 10-11)
10	3305-144	2		Seal
11	3305-145	2		Bearing
12	3303-281	3		Washer
13	3303-379	4		Screw, Cap
14	3305-131	1		Axle, Rear
15	3305-141	2		Nut
16	3305-127	1		Washer
17	1411-942	1		Decal, Warning - Towing
18	3303-253	3	/P	Screw, Cap
19	3303-162	1		Disc, Brake
20	3305-138	1		Bracket, Brake Disc
21	3303-568	1	/P	Caliper, Brake - Assembly (inc. 22-31)
22	3304-303	1		Cap, Bleed Valve
23	3304-302	1		Valve, Bleed
24	3304-333	1		Plug
25	3305-377	1	/P	Seal
26	3305-380	1	/P	Seal
27	3304-314	1	/P	Piston
28	3304-590	1		Boot
29	3304-591	1		Spring
30	3304-567	1	/P	Set, Brake Pad
31	3303-469	1	/P	Bracket, Brake Caliper
32	3303-256	2		Screw, Cap
33	3305-194	1		Adjuster, Chain - Assembly (inc. 34-36)
34	3304-125	1		Nut
35	3303-607	1	/P	Washer, Lock
36	3304-135	1	/P	Washer



2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
REAR BODY PANEL AND TAILLIGHT ASSEMBLIES

Page 40 of 58


Ref #	Part Number	Qty	S/P/F	Description
1	3306-237	1		Fender, Rear (inc. 2-6)
2	1411-178	1		Decal, Reflector - Right
2	1411-179	1		Decal, Reflector - Left
3	3305-164	1		Foil, Protective - Rear
4	3305-163	1		Foil, Protective
5	1411-805	1	/P	Decal, Warning - Tire/Load
6	1411-809	1	/P	Decal, Warning - Passenger
7	2411-482	1		Decal, Side - Upper Right
7	2411-483	1		Decal, Side - Upper Left
8	2411-480	1		Decal, Side - Lower Right
8	2411-481	1		Decal, Side - Lower Left
9	3304-409	1	/P	Screw, Cap
10	3305-238	1		Bracket, Mounting - Starter/Magneto Switch
11	3304-587	11	/P	Screw, Machine
12	3303-232	2		Grommet
13	3303-227	2		Grommet
14	3303-233	2		Insert
15	3304-586	2	/P	Screw, Cap
16	3304-156	2		Clamp, Wire
17	3304-651	2		Screw, Self-Tapping
18	3303-267	3		Clip, U-Nut
19	3304-061	5	/P	Clip, U-Nut
20	3305-703	16		Screw, Machine
21	3305-932	1	/P	Footwell - Right
21	3305-933	1	/P	Footwell - Left
22	3304-431	16	/P	Nut, Lock
23	3304-543	8	/P	Screw, Cap
24	3305-160	1		Support, Footwell - Right
24	3305-161	1		Support, Footwell - Left
25	3304-029	4	/P	Screw, Machine
26	3305-934	1		Fender, Lower - Right
26	3305-935	1		Fender, Lower - Left
27	3303-592	2		Rivet, Reinstallable
28	3305-732	1		Taillight - Assembly - Right (inc. 29-30)
28	3305-733	1		Taillight - Assembly - Left (inc. 29-30)
29	3303-849	2	/P	Bulb, Taillight
30	3305-217	2		Harness, Taillight
31	3304-645	8	/P	Screw, Self-Tapping



2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
 REAR SUSPENSION ASSEMBLY

Page 42 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	3306-239	1		Shock/Spring Assembly
2	3303-376	2	/P	Screw, Cap
3	3304-031	1	/P	Nut
4	3305-205	1		Fork - Assembly (inc. 5-11)
5	3303-192	2		Cap
6	3304-359	2		Bushing
7	3305-206	1		Sleeve
8	3303-393	1		Fitting, Grease
9	3304-358	1		Axle
10	3305-341	1		Screw, Cap
11	3304-594	1		Clamp, Routing
12	3305-130	1		Screw, Cap
13	3304-411	1		Nut
14	3305-936	1		Guard, Rear Suspension - Assembly (inc. 15-18)
15	3305-726	1		Guard, Chain
16	3305-725	1		Guard, Brake Disc
17	3305-774	4		Rivet
18	3305-773	4		Washer
19	3304-587	4	/P	Screw, Machine




2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
REAR WHEEL ASSEMBLY

Page 44 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	3303-931	2		Cap, Wheel
2	3304-340	2	S	Pin, Cotter
3	3304-129	2		Nut, Lock
4	3304-296	2		Hub, Wheel (inc. 5)
5	3304-014	8		Bolt, Carriage
6	3303-885	2		Tire
7	3303-883	2	/P	Wheel - Assembly
8	3304-562	2		Stem, Valve
9	3304-028	8		Nut, Lug


2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
RIGHT CRANKCASE AND COVER ASSEMBLY



2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
RIGHT CRANKCASE AND COVER ASSEMBLY

Page 46 of 58


Ref #	Part Number	Qty	S/P/F	Description
1	3303-381	3		Screw, Cap
2	3305-918	1		Cap, Crankcase Cover - Assembly
3	3304-971	1		O-Ring
4	3304-596	1		O-Ring
5	3304-012	1		Cap, Inspection
6	3304-099	1		O-Ring
7	3304-963	1		Cover, Crankcase (inc. one No. 8)
8	3304-065	2		Plug
9	3304-192	8		Screw, Cap
10	3303-387	1		Screw, Cap
11	3303-050	1		Gauge, Oil Level (inc. 12)
12	3304-102	1	/P	O-Ring
13	3303-342	6		Pin, Dowel
14	3304-964	1		Gasket
15	3304-965	1	/P	Rotor/Flywheel
16	3304-113	3		Screw, Machine
17	3304-967	1	/P	Stator
18	3304-118	2		Screw, Machine
19	3304-190	7		Screw, Cap
20	3304-904	2		Screw, Cap
21	3303-344	1		Ring, Retaining
22	3304-903	1		Screw, Cap
23	3304-514	1		Ring, Retaining
24	3304-889	1		Hose, Vent
25	3304-433	1		Clamp, Hose
26	3304-008	2		Bolt, Stud
27	3304-195	1		Bearing
28	3304-081	1		Seal, Oil
29	3304-972	2		Clamp, Routing
30	3304-884	1		Crankcase - Right (inc. one No. 8)
31	3304-699	1	/P	Bearing
32	3304-909	1		Bearing
33	3304-898	1	/P	Bearing
34	3304-425	1		Seal, Oil
35	3304-887	1		Gasket



2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
SEAT, BATTERY, AND TOOL KIT ASSEMBLIES

Page 48 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	3305-729	1		Seat Assembly (inc. 2-3)
2	3304-392	1		Latch, Seat
3	3305-929	2		Nut
4	3306-579	2		Bumper, Seat - Rear
5	3304-568	2		Bumper, Seat - Front
6	3305-730	1		Kit, Tool
7	3303-242	1		Retainer, Tool Kit
8	1441-797	1	F	Wrench, Spanner
9	3304-029	2	/P	Screw, Machine
10	3305-157	1		Cover, Battery (inc. 11)
11	3305-233	1		Fuse - 20 Amp
12	3445-034	1	/P	Battery




2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
SHIFT LEVER ASSEMBLY

Page 50 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	3303-823	1		Knob, Gear Shift
2	3304-401	1		Screw, Cap
3	3305-717	1		Rod, Gear Shift
4	3303-817	1		Pin, Gear Shift
5	3304-135	2	/P	Washer
6	3303-818	1		Spring
7	3303-819	1		Bracket, Gear Shift
8	3305-340	1	/P	Nut
9	3303-382	1	/P	Screw, Cap
10	3304-142	1		Pin, Cotter
11	3305-702	1		Screw, Cap
12	3305-090	1		Support, Fender
13	3303-332	4		Nut
14	3305-038	1		Cover, Gear Shift
15	3305-039	1		Lever, Gear Shift
16	3305-749	2		Screw, Cap
17	3303-970	1		Ball Joint, Tie Rod - Right
18	3304-125	1		Nut
19	3303-607	2	/P	Washer
20	3305-718	1		Tie Rod
21	3304-126	1		Nut
22	3303-972	1		Ball Joint, Tie Rod - Left
23	3305-036	1		Link, Gear Shift
24	3304-112	1		Screw, Cap


2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
STARTER MOTOR AND OIL PUMP ASSEMBLY



2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
STARTER MOTOR AND OIL PUMP ASSEMBLY

Page 52 of 58


Ref #	Part Number	Qty	S/P/F	Description
1	3304-999	1		Pump, Oil - Assembly (inc. 2-3)
2	3304-426	1		Screw, Machine
3	3304-144	1		Pin, Dowel
4	3303-385	2		Screw, Cap
5	3303-046	1		Sprocket
6	3304-654	1	/P	Nut, Lock
7	3305-002	1		Chain, Oil Pump
8	3305-003	1		Cover, Chain
9	3303-381	2		Screw, Cap
10	3305-012	1		Cable, Starter (inc. 11)
11	3305-252	1		Boot, Terminal
12	3305-011	1		Motor, Starter (inc. 13)
13	3304-104	1		O-Ring
14	3305-019	1		Screw, Machine
15	3303-382	2	/P	Screw, Cap
16	3305-005	1		Shaft, Reduction Gear
17	3305-004	1		Gear, Reduction
18	3305-009	1		Plate, Clutch
19	3305-008	3		Spring
20	3305-010	3		Roller, Starter
21	3305-015	3		Roller
22	3303-395	1		Pin, Spring
23	3305-020	3		Screw, Cap
24	3305-007	1		Clutch, Outer (inc. 19-20)
25	3305-006	1		Gear, Starter
26	3306-222	1	/P	Bearing
27	3305-014	1		Washer, Thrust
28	3305-013	1		Nut



2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
STEERING ASSEMBLY


Page 54 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	3305-103	1		Post, Steering
2	3305-496	1	/P	Bushing, Sleeve
3	3305-927	2		Block, Mounting - Steering Post
4	3304-649	2		Screw, Cap
5	3303-962	1		Clamp, Mounting Block
6	3304-130	4		Nut
7	3305-107	2		Washer
8	3304-032	1		Nut
9	3303-470	1		Pin, Cotter
10	3305-105	2		Tie Rod - Assembly (inc. 11-15)
11	3303-971	2		Ball Joint, Tie Rod - Right
12	3303-326	2		Nut, Hex - Right
13	3305-106	2		Tube, Tie Rod
14	3303-327	2		Nut, Hex - Left
15	3303-973	2		Ball Joint, Tie Rod - Left
16	3304-143	4		Pin, Cotter



2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
THROTTLE CONTROL ASSEMBLY

Ref #	Part Number	Qty	S/P/F	Description
	3305-979	1		Complete Throttle Control Assembly
1	3303-315	2		Screw, Machine
2	3303-207	1		Cover, Throttle Control
3	3303-209	1		Gasket
4	3303-397	1		Screw, Machine
5	3303-204	1		Housing, Throttle Control
6	3303-271	2		Nut
7	3303-208	2		Screw, Adjuster
8	3303-200	1		Lever, Throttle
9	3303-255	1		Screw, Shoulder
10	3305-980	1		Screw, Machine
11	3305-832	1		Nut
12	3303-262	1		Nut
13	3303-201	1		Retainer, Brake Cable
14	3303-202	1		Spacer
15	3305-344	1	/P	Screw, Cap
16	3306-054	1	/P	Lever, Brake
17	3303-140	1		Switch, Brake



2011 ATV 150 UTILITY CAT GREEN (A2011KYC2BUSZ)
TRANSMISSION ASSEMBLY

Page 58 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	3305-042	1		Chain, Drive
2	3305-030	1		Sprocket, Drive
3	3305-031	1		Plate, Retaining
4	3303-307	2		Screw, Cap
5	3303-381	2		Screw, Cap
6	3305-743	1		Cover, Chain
7	3304-147	1	/P	Ring, Retaining
8	3306-221	1		Shaft, Output
9	3304-513	1		Shaft, Shift Fork
10	3305-032	1		Fork, Shift
11	3305-035	1		Drum, Gear Shift - Assembly (inc. two No. 12 and 13-14)
12	3304-153	4		E-Ring
13	3304-412	4		Washer, Thrust
14	3305-034	2		Spring
15	3304-269	1	/P	Shaft, Gear Shift
16	3305-023	1		Shaft, Counterbalance
17	3305-021	1		Shaft, Main
18	3305-044	1		Washer, Thrust
19	3305-027	1		Gear, Reverse
20	3305-046	1		Bearing
21	3305-045	1		Washer, Splined
22	3304-638	1		Ring, Retaining
23	3305-029	1		Gear Select, Sliding
24	3303-275	2	/P	Washer, Thrust
25	3305-026	1		Gear, Forward
26	3305-024	1		Bushing
27	3305-028	1		Spacer
28	3305-022	1		Shaft, Drive
29	3303-344	1		Ring, Retaining