


2002 SBS 1000 (U2002SBM2AUSG)
AIR CLEANER ASSEMBLY

Page 1 of 63










2002 SBS 1000 (U2002SBM2AUSG)
AIR CLEANER ASSEMBLY

Page 2 of 63

Ref #	Part Number	Qty	S/P/F	Description
	3401-180	1		Complete Assembly
1	0	1	F	Body
2	3401-488	1		Filter
3	3401-489	1		Cover Assembly
4	3401-490	1		Valve, Vacuator
5	0	1	F	Plug
6	0	1	F	Marking

2002 SBS 1000 (U2002SBM2AUSG)
ALTERNATOR ASSEMBLY

Page 3 of 63



Assemblies include all parts shown in frames.


2002 SBS 1000 (U2002SBM2AUSG)
ALTERNATOR ASSEMBLY

Page 4 of 63

Ref #	Part Number	Qty	S/P/F	Description
23	808766	1		Flywheel
73	494439	1		Screen, Rotating
74	691647	1		Screw (Rotating Screen)
332	690887	1		Nut (Flywheel)
333	492341	1		Armature, Magneto
334	692066	1		Screw (Magneto Armature)
359	691077	1		Washer (Ground Terminal)
363	19203	1		Puller, Flywheel
373	691612	1		Nut (Ground Terminal)
474	691064	1		Alternator
507	691972	1		Insulator
520	691084	1		Terminal, Ground
529	690744	1		Grommet
578	692319	1		Wire Assembly
668	691500	1		Spacer
726	0	1	F	Gear, Ring (See Reference 23 for Service)
729	690586	1		Clip, Wire
851	493880	1		Terminal, Spark Plug
877	399916	1		Wire/Connector, Alternator
1119	691552	1		Screw

2002 SBS 1000 (U2002SBM2AUSG)
BLOWER HOUSING AND COVER ASSEMBLY

Page 5 of 63



Assemblies include all parts shown in frames.


2002 SBS 1000 (U2002SBM2AUSG)
 BLOWER HOUSING AND COVER ASSEMBLY

Page 6 of 63

Ref #	Part Number	Qty	S/P/F	Description
171	810056	1		Nut (Air Cleaner)
197	692539	1		Screw (Backplate)
284	93410	1		Screw (Control Wire Casing)
304	808408	1		Housing, Blower
305	692539	1		Screw (Blower Housing)
305A	692056	1		Screw (Blower Housing)
305B	692062	1		Screw (Blower Housing)
308	806547	1		Cover, Cylinder Head (Cylinder 1)
308A	806546	1		806546
322	692539	1		Screw (Cylinder Head Cover)
322A	692067	1		Screw (Cylinder Head Cover)
447	692539	1		Screw (Air Guide Cover)
573	690902	1		Plate, Back
638	691551	1		Washer (Cylinder Head Cover)
727	690714	1		Cover, Starter Drive
732	690688	1		Screw (Starter Drive Cover)
732A	692539	1		Screw (Starter Drive Cover)
865	690750	1		Cover, Air Guide
1036	806881	1		Label, Emissions
1046	692082	1		Plug, Blower Housing

2002 SBS 1000 (U2002SBM2AUSG)
BOX AND TAILGATE ASSEMBLY

Page 7 of 63




2002 SBS 1000 (U2002SBM2AUSG)
BOX AND TAILGATE ASSEMBLY

Page 8 of 63

Ref #	Part Number	Qty	S/P/F	Description
1	3401-035	1		Decal, Tailgate
2	3401-262	2		Knob, Push-On
3	3401-034	1		Decal, Box - Left
3	3401-032	1		Decal, Box - Right
4	3401-244	3		Brace, Box
5	3401-246	1		Shield, Heat
6	3401-101	18		Screw
7	3401-095	4		Screw, Cap
8	3401-200	1		Pivot Bracket Assembly - Left
9	3401-072	1		Nut, Push
10	3401-109	1		Washer
11	3401-250	1		Bracket, Prop Rod
12	3401-025	1		Shield, Heat
13	3401-048	1		Nut, Flange
14	3401-251	1		Rod, Prop
15	3401-236	1		Rod, Latch
16	3401-252	1		U-Bracket, Prop Rod
17	3401-097	2		Screw, Cap
18	3401-112	1		Spring
19	3401-080	2		Nut, Insert
20	3401-235	1		Bracket, Latch
21	3401-375	1		Pivot Bracket Assembly - Right
22	3401-234	1		Hook, Latch - Right

2002 SBS 1000 (U2002SBM2AUSG)
BRAKE ASSEMBLY


Page 9 of 63



2002 SBS 1000 (U2002SBM2AUSG)
BRAKE ASSEMBLY

Page 10 of 63

Ref #	Part Number	Qty	S/P/F	Description
1	3401-185	1		Brake Assembly - Right (inc. 2-4)
1	3401-184	1		Brake Assembly - Left (inc. 2-4)
2	3401-484	2		Kit, Shoe And Lining
3	3401-485	2		Spring Assembly
4	3401-486	1		Kit, Adjuster - Left
4	3401-487	1		Kit, Adjuster - Right



Assemblies include all parts shown in frames.


2002 SBS 1000 (U2002SBM2AUSG)
CARBURETOR AND FUEL PUMP ASSEMBLY

Page 12 of 63

Ref #	Part Number	Qty	S/P/F	Description
51	691694	1	F	Gasket, Intake
91	808964	1		Body, Upper Carburetor
94	808257	1	F	Kit, Idle Mixture
95	690718	1		Screw (Throttle Valve)
97	809007	1		Shaft, Throttle
98	808177	1		Kit, Idle Speed
102	692077	1	F	Gasket, Carburetor Body
104	690723	1	F	Pin, Float Hinge
105	692078	1	F	Valve, Float Needle
108	690719	1		Valve, Choke
109	809062	1		Shaft, Choke
110	806861	1		Washer (Choke Shaft)
117	806986	1		Jet, Main
119	690720	1		Screw (Upper to Lower Body)
125	809092	1		Carburetor
130	690726	1		Valve, Throttle
133	806961	1		Float, Carburetor
142	806987	1		Nozzle, Carburetor
187	691050	1		Line, Fuel
217	806862	1		Spring, Choke Return
231	690718	1		Screw (Choke Valve)
385	693169	1		Screw (Fuel Pump)
387	808656	1		Pump, Fuel
601	691038	1		Clamp, Hose
628	806660	1		Screw (Fuel Pump Bracket)
633	806131	1	F	Seal, Choke/Throttle Shaft
633A	690722	1	F	Seal, Choke/Throttle Shaft
788	691559	1		Bracket, Fuel Pump
807	805557	1	F	Spacer, Throttle
918	393815	1		Hose, Vacuum (Cut to Required Length)
947	692094	1		Solenoid, Fuel
1091	691561	1	F	Cap, Limiter
1139	806497	1		Washer (Fuel Pump Bracket)

2002 SBS 1000 (U2002SBM2AUSG)
CLUTCH ASSEMBLY


Page 13 of 63



2002 SBS 1000 (U2002SBM2AUSG)
CLUTCH ASSEMBLY

Page 14 of 63

Ref #	Part Number	Qty	S/P/F	Description
	3401-175	1		Complete Assembly
1	3401-411	6		Kit, Bolt And Nut, Pivot



Assemblies include all parts shown in frames.









2002 SBS 1000 (U2002SBM2AUSG)
CRANKCASE ASSEMBLY

Page 16 of 63

Ref #	Part Number	Qty	S/P/F	Description
12	691684	1	F	Gasket, Crankcase
18	808847	1		Cover, Crankcase
20	805049	1	F	Seal, Oil (PTO Side)
22	692540	1		Screw (Crankcase Cover)
276	690704	1		Washer, Sealing
439	692154	1	F	Seal, O-Ring (Crankcase Cover)
552	690701	1		Bushing, Governor Crank
552A	806686	1		Bushing, Governor Crank
615	691550	1		Retainer, Governor Shaft
616	806685	1		Crank, Governor (inc. 552A)
691	690680	1	F	Seal, Governor Shaft

2002 SBS 1000 (U2002SBM2AUSG)
CRANSKSHAFT, PISTON, AND OIL PUMP ASSEMBLY

Page 17 of 63



Assemblies include all parts shown in frames.

2002 SBS 1000 (U2002SBM2AUSG)

Page 18 of 63

CRANSKSHAFT, PISTON, AND OIL PUMP ASSEMBLY

Ref #	Part Number	Qty	S/P/F	Description
16	692163	1		Crankshaft
25	807619	1		Piston Assembly (Standard)
25	807807	1		Piston Assembly (0.010 Oversize)
25	807809	1		Piston Assembly (0.020 Oversize)
25	807811	1		Piston Assembly (0.030 Oversize)
26	807620	1		Ring Set (Standard)
26	807808	1		Ring Set (0.010 Oversize)
26	807810	1		Ring Set (0.020 Oversize)
26	807812	1		Ring Set (0.030 Oversize)
27	690683	1		Lock, Piston Pin
28	807621	1		Pin, Piston
29	807900	1		Rod, Connecting (Standard)
29	807809	1		Rod, Connecting (0.020 Undersize)
32	690698	1		Screw (Connecting Rod)
39	690745	1		Deflector, Oil
46	691557	1		Camshaft
146	691639	1		Key, Timing
239	690233	1		Switch, Oil Pressure
273	690681	1	F	Seal, O-Ring (Oil Pump)
377	808095	1		Key
468	690690	1	F	Seal, O-Ring (Oil Pump Screen)
479	692537	1		Screw (Oil Pump Screen)
596	691492	1		Screw (Oil Pump)
598	807625	1		Shim, End Play
650	692539	1		Screw (Oil Deflector)
741	691530	1		Gear, Timing
1017	690900	1		Screen, Oil Pump
1024	693185	1		Pump, Oil
1025	690689	1		Slider, Governor

2002 SBS 1000 (U2002SBM2AUSG)
CYLINDER HEAD AND COVER ASSEMBLY








Page 20 of 63

Ref #	Part Number	Qty	S/P/F	Description
5	808381	1		Head, Cylinder (Cylinder 1)
5A	808382	1		Head, Cylinder (Cylinder 2)
7	806085	1	F	Gasket, Cylinder Head
13	692059	1		Screw (Cylinder Head)
33	807681	1		Valve, Exhaust
34	807680	1		Valve, Intake
35	692084	1		Spring, Valve (Intake)
36	692084	1		Spring, Valve (Exhaust)
40	692058	1		Retainer, Valve
42	807683	1		Keeper, Valve
45	690977	1		Tappet, Valve
192	807623	1		Adjuster, Rocker Arm
276A	691766	1	F	Washer, Sealing
337	491055	1		Spark Plug
338	691312	1	F	Gasket, Oil Level Stick
383	19374	1		Wrench, Spark Plug
522	491832	1		Plug, Oil Level Stick/Fill
635	692076	1		Boot, Spark Plug
812	692055	1		Nut (Rocker Cover)
830	691544	1		Stud (Rocker Arm)
868	691963	1	F	Seal, Valve
871	692057	1		Bushing, Valve Guide
1022	806039	1	F	Gasket, Rocker Cover
1023	690758	1		Cover, Valve
1023A	691558	1		Cover, Valve
1026	691836	1		Rod, Push (Intake Valve)
1026	691758	1		Rod, Push (Exhaust Valve)
1029	691543	1		Arm, Rocker
1100	690973	1		Pivot, Rocker Arm

2002 SBS 1000 (U2002SBM2AUSG)

Page 21 of 63

CYLINDER, OIL FILTER, AND OIL LEVEL STICK ASSEMBLY



1019 LABEL KIT

Assemblies include all parts shown in frames.

2002 SBS 1000 (U2002SBM2AUSG)


Page 22 of 63

CYLINDER, OIL FILTER, AND OIL LEVEL STICK ASSEMBLY

Ref #	Part Number	Qty	S/P/F	Description
1	692178	1		Assembly, Cylinder
2	808534	1		Kit, Bushing/Seal (Magneto Side)
3	805101	1	F	Seal, Oil
8	808984	1		Assembly, Breather
9	807893	1	F	Gasket, Breather
10	690751	1		Screw (Breather Assembly)
15	690946	1		Plug, Oil Drain
287	692062	1		Screw (Oil Level Stick Tube)
523	693175	1		Oil Level Stick
524	693172	1	F	Seal, Oil Level Stick Tube
525	693173	1		Tube, Oil Level Stick
565	690682	1		Stud (Oil Filter Adapter)
572	690686	1		Baffle, Breather
718	690684	1		Pin, Locating
737	690679	1		Screw (Oil Filter Adapter)
816	690706	1		Washer (Oil Filter Adapter)
988	692063	1	F	Gasket, Oil Filter Adapter
1019	808036	1		Kit, Label
1027	492932	1		Filter, Oil
1028	808235	1		Adapter, Oil Filter

2002 SBS 1000 (U2002SBM2AUSG)
DASH ASSEMBLY


Page 23 of 63



2002 SBS 1000 (U2002SBM2AUSG)
DASH ASSEMBLY

Page 24 of 63

Ref #	Part Number	Qty	S/P/F	Description
1	3401-162	1		Hourmeter
2	3401-215	1		Point, Power
3	3401-216	1		Cap
4	3401-029	1		Switch, Ignition
5	3401-042	2		Key, Ignition
6	3401-217	1		Plug, Hole
7	3401-214	1		Light, Oil
8	3401-167	1		Switch




2002 SBS 1000 (U2002SBM2AUSG)
DRIVE TRAIN MOUNT ASSEMBLY

Page 26 of 63

Ref #	Part Number	Qty	S/P/F	Description
1	3401-220	1		Cable, Negative
1	3401-213	1		Cable, Positive
2	3401-101	2		Screw
3	3401-048	4		Nut, Flange
4	3401-191	1		Strap, Battery Hold-Down
5	3401-086	2		Nut, Jam
6	3401-082	2		Nut
7	3401-107	2		Washer, Lock - External Tooth
8	3401-069	4		Screw, Cap
9	3401-065	1		Solenoid
10	3401-170	1		Bracket, Component Mounting
11	3401-132	2		Nut, Lock
12	3401-208	1		Bracket, Ignition
13	3401-152	1		Relay
14	3401-096	2		Screw, Cap
15	3401-130	4		Nut, Lock
16	3401-153	2		Spacer
17	3401-099	4		Screw, Cap
18	3401-049	6		Nut, Flange
19	3401-111	2		Washer
20	3401-164	2		Mount, Isolation
21	3401-092	2		Screw, Cap
22	3401-180	1		Cleaner, Air
23	3401-098	2		Screw, Cap
24	3401-241	1		Hose, Breather
25	3401-056	2		Clamp, Hose
26	3401-196	1		Fitting, 90°
27	3401-054	1		Clamp, Hose
28	3401-019	1		Hose, Intake
29	3401-097	2		Screw, Cap
30	3401-166	1		Bracket, Mounting - Air Cleaner
31	3401-202	1		Cover, Electrical
32	3401-259	1		Decal, Information
33	3401-221	1		Harness, Main
34	3401-218	1		Battery (Wet)
35	3401-074	2		Nut, Flange

2002 SBS 1000 (U2002SBM2AUSG)
ENGINE AND CLUTCH ASSEMBLY

Page 27 of 63




2002 SBS 1000 (U2002SBM2AUSG)
ENGINE AND CLUTCH ASSEMBLY

Page 28 of 63

Ref #	Part Number	Qty	S/P/F	Description
1	3401-054	1		Clamp, Hose
2	3401-176	1		Hose, Intake
3	3401-174	1		Bracket, Cable
4	3401-154	1		Clamp, Cable
5	3401-129	1		Screw, Cap
6	3401-079	1		Insert
7	3401-255	1		Cable, Throttle
8	3401-182	1		Arm, Torque
9	3401-108	2		Washer
10	3401-313	2		Washer, Lock
11	3401-102	2		Screw, Cap
12	3401-187	1		Belt, Drive
13	3401-253	1		Clutch, Drive
14	3401-149	1		Washer
15	3401-192	1		Screw, Cap
16	3401-105	6		Washer, Lock
17	3401-012	1		Mount, Engine
18	3401-151	2		Screw, Cap
19	3401-179	1		Bracket, Cable Tie
20	3401-090	4		Screw, Cap
21	3401-161	1		Filter, Fuel
22	3401-146	1		Hose, Gasline
23	3401-058	3		Clamp
24	3401-021	1		Engine, Briggs & Stratton - Model 303447-1319-E1
25	3401-172	1		Bracket, Intake
26	3401-193	4		Screw
27	3401-055	1		Clamp, Hose
28	3401-013	1		Muffler, Engine
29	3401-014	1		Manifold, Engine
30	3401-015	1		Coupler, Exhaust
31	3401-016	4		Spring, Exhaust Coupler
32	3401-121	4		Screw
33	3401-074	1		Nut, Flange
34	3401-209	1		Conduit, Line - Fuel
35	3401-243	1		Ball, Stud
36	3401-219	1		Harness, Engine
37	3401-064	1		Positive Red Wire Assembly
38	3401-133	2		Nut, Lock
39	3401-048	5		Nut, Flange
40	3401-095	3		Screw, Cap
41	3401-010	1		Guard, Clutch
42	3401-049	3		Nut, Flange
43	3401-526	1		Screw, Cap
44	3401-107	1		Washer, Lock

358 ENGINE GASKET SET



Assemblies include all parts shown in frames.


2002 SBS 1000 (U2002SBM2AUSG)
ENGINE GASKET SET

Page 30 of 63

Ref #	Part Number	Qty	S/P/F	Description
3	805101	1		Seal, Oil (Magneto Side)
7	806085	1	F	Gasket, Cylinder Head
9	807893	1		Gasket, Breather
12	691684	1		Gasket, Crankcase
20	805049	1		Seal, Oil (PTO Side)
51	691694	1	F	Gasket, Intake
51A	692035	1	F	Gasket, Intake
163	692081	1		Gasket, Air Cleaner
273	690681	1		Seal, O-Ring (Oil Pump)
276A	691766	1	F	Washer, Sealing
338	691312	1	F	Gasket, Oil Level Stick
358	808390	1		Gasket Set, Engine
439	692154	1		Seal, O-Ring (Crankcase Cover)
468	690690	1		Seal, O-Ring (Oil Pump Screen)
524	693172	1		Seal, Oil Level Stick Tube
691	690680	1		Seal, Governor Shaft
868	691963	1	F	Seal, Valve
883	691613	1	F	Gasket, Exhaust
988	692063	1		Gasket, Oil Filter Adapter
1022	806039	1	F	Gasket, Rocker Cover

2002 SBS 1000 (U2002SBM2AUSG)
FRAME ASSEMBLY

Page 31 of 63




2002 SBS 1000 (U2002SBM2AUSG)
FRAME ASSEMBLY

Page 32 of 63

Ref #	Part Number	Qty	S/P/F	Description
1	3401-049	8		Nut, Flange
2	3401-228	1		Hitch, Light Duty
3	3401-099	4		Screw, Cap
4	3401-206	1		Decal, Information
5	3401-305	1		Washer
6	3401-207	1		Rear Frame Assembly (inc. 7)
7	3401-378	2		Decal, Warning
8	3401-205	1		Decal, Information - Boxlatch
9	3401-057	5		Clamp
10	3401-084	4		Screw, Cap
11	3401-075	4		Nut, Flange
12	3401-073	2		Ring, Retaining
13	3401-120	4		Screw, Cap
14	3401-156	1		Bumper, Rubber
15	3401-101	2		Screw
16	3401-198	1		Cover, Pedal
17	3401-204	1		Decal, Information - Brake
18	3401-076	2		Nut, Flange
19	3401-077	2		Screw, Cap
20	3401-232	1		A-Arm - Left (inc. two No. 21)
21	3401-379	4		Bushing
22	3401-131	2		Nut, Lock
23	3401-123	5		Screw, Cap
24	3401-106	4		Washer, Lock - Internal Tooth
25	3401-103	2		Screw, Cap
26	3401-231	1		A-Arm - Right (inc. two No. 21)
27	3401-066	2		Fitting, Grease
28	3401-376	1		Decal, Capacity
29	3401-299	11		Cable Tie
30	3401-531	1		Frame, Front
31	3401-303	1		Pivot Yoke Assembly
32	3401-095	4		Screw, Cap
33	3401-230	4		Washer
33	3401-312	1	F	Trim

2002 SBS 1000 (U2002SBM2AUSG)
FRONT TIRE AND STEERING ASSEMBLY

Page 33 of 63




2002 SBS 1000 (U2002SBM2AUSG)
FRONT TIRE AND STEERING ASSEMBLY

Page 34 of 63

Ref #	Part Number	Qty	S/P/F	Description
1	3401-406	2		Tire
2	3401-383	2		Wheel w/Bearings - Front (inc. 3-4)
3	3401-384	2		Spacer
4	3401-385	4		Bearing
5	3401-386	2		Stem, Valve
6	3401-131	2		Nut, Lock
7	3401-390	2		Washer, Thrust
8	3401-391	1		Spindle - Right
9	3401-392	2		Ball Joint - Right (inc. two No. 10)
10	3401-393	4		Nut
11	3401-394	2		Ball Joint - Left (inc. two No. 10)
12	3401-396	2		Tie Rod
13	3401-397	2		Nut, Jam
14	3401-398	2		Nut, Jam
15	3401-399	2		Sleeve, Kingpin
16	3401-067	2		Fitting, Grease
17	3401-066	2		Fitting, Grease
18	3401-400	2		Screw, Cap
19	3401-401	1		Spindle - Left
20	3401-402	4		Pin, Cotter
21	3401-230	2		Washer
22	3401-387	2		Washer
23	3401-388	2		Screw, Cap
24	3401-389	2		Cap, Dust

2002 SBS 1000 (U2002SBM2AUSG)
HOOD AND FENDER ASSEMBLY

Page 35 of 63




2002 SBS 1000 (U2002SBM2AUSG)
HOOD AND FENDER ASSEMBLY

Page 36 of 63

Ref #	Part Number	Qty	S/P/F	Description
1	3401-101	13		Screw
2	3401-048	16		Nut, Flange
3	3401-210	1		Fender Assembly - Left
3	3401-211	1		Fender Assembly - Right
4	3401-030	1		Hood Assembly
5	3401-068	4		Screw, Cap
6	3401-155	2		Headlight (inc. 7-8)
7	3401-527	1		Bulb, Headlight
8	3401-528	1		Lens, Headlight
9	3401-212	1		Dash Assembly (inc. 10-11)
10	3401-529	1		Decal, Warning
11	3401-530	1		Decal, Danger
12	3401-033	1		Decal
13	3401-110	12		Washer
14	3401-078	4		Screw
15	3401-240	1		Bumper
16	3401-256	4		Bracket, Headlight
17	3401-203	4		Screw, Cap
18	3401-052	2		End Cap
19	3401-097	6		Screw, Cap
20	3401-031	1		Decal, Hood

INTAKE MANIFOLD AND GOVERNOR CONTROL ASSEMBLY



Assemblies include all parts shown in frames.

2002 SBS 1000 (U2002SBM2AUSG)


Page 38 of 63

INTAKE MANIFOLD AND GOVERNOR CONTROL ASSEMBLY

Ref #	Part Number	Qty	S/P/F	Description
50	690754	1		Manifold, Intake
51	691694	1	F	Gasket, Intake Manifold
51A	692035	1	F	Gasket, Intake Manifold
54	690676	1		Screw (Intake Manifold)
122	690691	1		Spacer, Carburetor
163	692081	1	F	Gasket, Air Cleaner
209	691507	1		Spring, Governor
211	691553	1		Spring, Governed Idle
212	690712	1		Link, Governor
222	691570	1		Bracket, Control
227	690236	1		Lever, Governor Control
232	692073	1		Spring, Governor Link
265	691024	1		Clamp, Casing
267	692083	1		Screw (Casing Clamp)
505	690238	1		Nut (Governor Control Lever)
562	690239	1		Bolt (Governor Control Lever)
883	691613	1	F	Gasket, Exhaust
1054	280275	1		Cable Tie

2002 SBS 1000 (U2002SBM2AUSG)
PEDAL ASSEMBLY

Page 39 of 63




2002 SBS 1000 (U2002SBM2AUSG)
PEDAL ASSEMBLY

Page 40 of 63

Ref #	Part Number	Qty	S/P/F	Description
1	3401-177	2		Cable, Brake
2	3401-073	2		Ring, Retaining
3	3401-087	1		Nut
4	3401-181	1		Nut, Equalizer
5	3401-173	1		Bracket, Brake Rod
6	3401-171	1		Rod, Brake
7	3401-095	3		Screw, Cap
8	3401-022	1		Accelerator Pedal Assembly
9	3401-085	1		Screw, Cap
10	3401-011	2		Spring, Return - Pedal
11	3401-093	1		Screw, Cap
12	3401-186	1		Spring, Torsion
13	3401-023	1		Brake Pedal Assembly
14	3401-150	2		Bushing, Link - Steering
15	3401-260	1		Pedal, Park
16	3401-049	1		Nut, Flange
17	3401-118	5		Pin, Cotter
18	3401-024	1		Rod
19	3401-188	2		Pivot, Pedal
20	3401-242	2	/P	Screw
21	3401-195	1		Detent
22	3401-062	4		Bushing, Flange
23	3401-194	1		Pawl, Brake
24	3401-100	2		Screw, Cap
25	3401-067	2		Fitting, Grease
26	3401-081	3		Nut
27	3401-263	1		Base Assembly
28	3401-272	1		Washer
29	3401-297	1		Washer
30	3401-377	1		Insert

2002 SBS 1000 (U2002SBM2AUSG)
REAR TIRE AND TRANSAXLE ASSEMBLY

Page 41 of 63



2002 SBS 1000 (U2002SBM2AUSG)
 REAR TIRE AND TRANSAXLE ASSEMBLY

Page 42 of 63

Ref #	Part Number	Qty	S/P/F	Description
1	3401-175	1		Clutch, Driven
2	3401-403	1		Washer, Clutch
3	3401-404	1		Screw, Cap
4	3401-405	1		Transaxle
5	3401-048	8		Nut, Flange
6	3401-409	2		Pin, Cotter
7	3401-115	2		Pin, Cotter
8	3401-063	2		Pin, Clevis
9	3401-184	1		Brake - Left
9	3401-185	1		Brake - Right
10	3401-101	10		Screw
11	3401-017	2		Drum, Brake
12	3401-406	2		Tire
13	3401-407	2		Wheel - Rear
14	3401-386	2		Stem, Valve
15	3401-059	10		Nut, Lug
16	3401-410	2		Nut, Castle
17	0403-035	2	/P	Cap, Dust
18	3401-130	2		Nut, Lock
19	3401-127	1		Cable Tie
20	3401-113	2		Washer
21	3401-049	4		Nut, Flange
22	3401-053	1		R-Clamp
23	3401-099	4		Screw, Cap

No
Diagram
Available

Parts List
Only


2002 SBS 1000 (U2002SBM2AUSG)
RELATED ITEMS

Page 44 of 63

Ref #	Part Number	Qty	S/P/F	Description
	0436-421	1		Box Lift - Electronic
	0436-423	1		Brush Guard/Bumper
	0436-424	1		Bumper - Heavy Duty
	0436-418	1		Canopy, Hard - White
	0436-420	1		Hitch - Heavy Duty
	2256-598	1		Manual, Illustrated Parts
	2256-510	1	/P	Manual, Operator's
	0436-419	1		ROPS/Seat Belt (Rollover Protection System)
	0436-422	1		Shield, Operator
	0436-417	1		Stake Sides
	0436-426	1		Windshield - Folding
	0436-425	1		Windshield - Solid

2002 SBS 1000 (U2002SBM2AUSG)
REPLACEMENT STARTER MOTOR ASSEMBLY

Page 45 of 63




697

Assemblies include all parts shown in frames.

2002 SBS 1000 (U2002SBM2AUSG)
REPLACEMENT STARTER MOTOR ASSEMBLY

Page 46 of 63

Ref #	Part Number	Qty	S/P/F	Description
309A	0	1	F	Motor, Starter
310A	690323	1		Bolt
311A	497608	1		Brush Set
413	693587	1		Nut (Starter Motor)
510	496881	1		Drive, Starter
544A	693548	1		Armature, Starter
697	692062	1		Screw (Drive Cap)
797	691029	1		Nut (Brush Retainer)
797A	693167	1		Nut (Brush Retainer)
801A	808778	1		Cap, Dirve
802A	691286	1		Cap, End
803A	693547	1		Housing, Starter
1051	691124	1		Ring, Retaining
1090	691293	1		Retainer, Brush




2002 SBS 1000 (U2002SBM2AUSG)
SEAT-BASE ASSEMBLY

Page 48 of 63

Ref #	Part Number	Qty	S/P/F	Description
1	3401-199	2		Seat
2	3401-237	2		Bracket, Seat
3	3401-134	8		Screw, Cap
4	3401-009	1		Seat-Base Assembly
5	3401-190	1		Hose, Gasline
6	3401-058	1		Clamp
7	3401-197	1		Pipe, Stand
8	3401-145	1		Bushing
9	3401-165	1		Gas Tank Cap Assembly
10	3401-201	1		Gas Tank Assembly (inc. 11-13)
11	3401-380	1		Gauge, Gas
12	3401-381	1		Grommet
13	3401-382	1		Vent, Air
14	3401-183	1		Conduit, Protective
15	3401-238	2		Rubber Receptical Assembly
16	3401-239	2		Post, Holding
17	3401-071	2		Screw, Machine
18	3401-128	2		Rivet
19	3401-028	1		Mat, Floor
20	3401-144	1		Strapping, Web - 48 in.
21	3401-097	8		Screw, Cap
22	3401-157	4		Washer

2002 SBS 1000 (U2002SBM2AUSG)
SHIFTER ASSEMBLY

Page 49 of 63




2002 SBS 1000 (U2002SBM2AUSG)
SHIFTER ASSEMBLY

Page 50 of 63

Ref #	Part Number	Qty	S/P/F	Description
1	3401-178	1		Cable, Choke
2	3401-248	1		Plate, Shift
3	3401-117	2		Pin, Cotter
4	3401-261	1		Knob, Grip
5	3401-247	1		Lever, Shift
6	3401-049	2		Nut, Flange
7	3401-027	2		Cable, Shift
8	3401-011	1		Spring, Return - Pedal
9	3401-189	1		Detent
10	3401-060	1		Bearing
11	3401-132	1		Nut, Lock
12	3401-083	2		E-Ring
13	3401-094	2		Screw, Cap
14	3401-018	1		Bracket, Shift
15	3401-158	1		Microswitch
16	3401-257	1		Decal, Shift
17	3401-070	4		Screw
18	3401-242	4	/P	Screw
19	3401-126	1		Nut, Speed
20	3401-125	2		Screw, Machine
21	3401-160	1		Plunger, Seal

2002 SBS 1000 (U2002SBM2AUSG)
STARTER MOTOR ASSEMBLY

Page 51 of 63




2002 SBS 1000 (U2002SBM2AUSG)
STARTER MOTOR ASSEMBLY

Page 52 of 63

Ref #	Part Number	Qty	S/P/F	Description
309	691564	1		Motor, Starter
310	496880	1		Bolt (Starter Motor)
311	496887	1		Brush Set
510	496881	1		Drive, Starter
544	690855	1		Armature, Starter
697	692062	1		Screw (Drive Cap)
801	808777	1		Cap, Drive
802	496813	1		Cap, End
803	690854	1		Housing, Starter
1051	691124	1		Ring, Retaining

2002 SBS 1000 (U2002SBM2AUSG)
STEERING GEARBOX ASSEMBLY

Page 53 of 63




2002 SBS 1000 (U2002SBM2AUSG)
STEERING GEARBOX ASSEMBLY

Page 54 of 63

Ref #	Part Number	Qty	S/P/F	Description
	3401-229	1		Complete Assembly
1	3401-493	1		Gasket
2	3401-494	4		Screw, Cap
3	3401-495	1		Seal
4	3401-496	1		Sector, Gear
5	3401-497	1		Washer
6	3401-498	2		Bearing
7	3401-499	1		Spacer, Output Shaft
8	3401-500	1		Washer
9	3401-501	1		Screw, Locking
10	3401-502	2		Bearing
11	3401-503	1		Spacer, Input Shaft
12	3401-504	1		Washer
13	3401-505	1		Screw, Cap
14	3401-066	1		Fitting, Grease
15	3401-506	1		Cover, Steering Housing
16	3401-507	1		Housing, Steering
17	3401-510	1		Arm, Pitman
18	3401-508	1		Gear, Pinion
19	3401-509	1		Seal, Oil

2002 SBS 1000 (U2002SBM2AUSG)
TAILGATE ASSEMBLY

Page 55 of 63




2002 SBS 1000 (U2002SBM2AUSG)
TAILGATE ASSEMBLY

Page 56 of 63

Ref #	Part Number	Qty	S/P/F	Description
1	3401-511	1		Rod, Latch - Right
2	3401-512	1		Bracket, Tailgate Latch - Right
3	3401-513	1		Tailgate Assembly
4	3401-514	10		Screw
5	3401-515	2		Plate, Striker
6	3401-516	1		Rod, Latch - Left
7	3401-517	1		Bracket, Tailgate Latch - Left
8	3401-518	4		Screw
9	3401-519	4		Washer, Latch
10	3401-520	2		Spring
11	3401-521	2		Bracket, Pivot - Tailgate
12	3401-101	10		Screw
13	3401-522	1		Channel, Tailgate
14	3401-523	1		Box Assembly (inc. 15-16)
15	3401-524	1		Decal, Plate, No Riders
16	3401-525	4		Rivet

2002 SBS 1000 (U2002SBM2AUSG)
TRANSAXLE ASSEMBLY

Page 57 of 63



2002 SBS 1000 (U2002SBM2AUSG)
TRANSAXLE ASSEMBLY

Page 58 of 63

Ref #	Part Number	Qty	S/P/F	Description
	3401-405	1		Complete Assembly
1	3401-412	1		Case, Complete - Left
2	3401-413	1		Seal, Oil
3	3401-414	1		Seal, Oil
4	3401-415	1		Ring, Snap
5	3401-416	1		Spacer
6	3401-417	1		Shaft, Selector
7	3401-418	2		Seal, Oil
8	3401-419	4		Bolt, Flange
9	3401-420	2		Plug, Oil Check
10	3401-421	2		Gasket
11	3401-422	2		Plug, Oil Drain
12	3401-423	2		Gasket
13	3401-424	1		Plug, Oil Filler
14	3401-425	1		Case, Complete - Right
15	3401-426	1		Seal, Oil
16	3401-427	1		Shaft, Governor
17	3401-428	1		Fork, Governor
18	3401-429	1		Stopper
19	3401-430	4		Screw w/Washer
20	3401-431	1		Shaft, Input
21	3401-432	1		Base, Governor
22	3401-433	1		Pin, Lock
23	3401-434	1		Plate Unit, Governor
24	3401-435	1		Bearing
25	3401-436	1		Sleeve, Governor
26	3401-437	2		Bearing
27	3401-438	1		Spacer
28	3401-439	1		Gear
29	3401-440	1		Bracket, Wire
30	3401-441	1		Clutch, Pin
31	3401-442	1		Shaft, Center
32	3401-443	1		Gear, 47T
33	3401-444	2		Collar
34	3401-445	1		Gear
35	3401-446	6		Bolt, Flange
36	3401-447	1		Bearing
37	3401-448	1		Bearing
38	3401-449	2		Spacer
39	3401-450	1		Gear, 34T
40	3401-451	1		Countershaft
41	3401-452	1		Case, Differential
42	3401-453	2		Gear, Side - Differential
43	3401-454	2		Pinion, Differential
44	3401-455	1		Shaft, Differential
45	3401-456	1		Pin
46	3401-457	1		Bearing
47	3401-458	1		Bearing, Needle
48	3401-459	1		Gear, 62T
49	3401-460	6		Bolt
50	3401-461	1		Shaft, Axle - Left
51	3401-462	1		Shaft, Axle - Right
52	3401-463	1		Pin


2002 SBS 1000 (U2002SBM2AUSG)
TRANSAXLE ASSEMBLY

Page 59 of 63

Ref #	Part Number	Qty	S/P/F	Description
53	3401-464	1		Case, Axle - Left
54	3401-465	1		Case, Axle - Right
55	3401-466	4		Ring, Snap
56	3401-410	2		Nut, Castle
57	3401-468	2		Ring, Snap
58	3401-469	1		Shaft, Shift
59	3401-470	2		Alignment Pin
60	3401-471	1		Ball, Steel
61	3401-472	1		Spring
62	3401-473	1		Gasket
63	3401-474	1		Bolt
64	3401-475	1		Gasket
65	3401-476	6		Bolt, Flange
66	3401-477	1		Bolt, Flange
67	3401-482	2		Bolt, Flange
68	3401-478	1		Bolt
69	3401-479	2		Collar
70	3401-480	11		Nut, Flange
71	3401-481	2		Bracket, Axle
72	3401-005	1		Nut, Lock
73	3401-006	2		Washer, Spring
74	3401-007	2		Washer
75	3401-008	2		Hub
76	3401-026	1		Lever, Select
77	3401-483	10		Stud

2002 SBS 1000 (U2002SBM2AUSG)
UPPER STEERING ASSEMBLY

Page 60 of 63





2002 SBS 1000 (U2002SBM2AUSG)
UPPER STEERING ASSEMBLY

Page 61 of 63

Ref #	Part Number	Qty	S/P/F	Description
1	3401-122	1		Nut
2	3401-148	1		Washer, Lock
3	3401-168	1		Wheel, Steering (inc. 4)
4	3401-491	1		Cover, Steering Wheel
5	3401-229	1		Steering Gearbox Assembly
6	3401-147	1		Screw, Cap
7	3401-105	1		Washer, Lock
8	3401-227	1		Shaft, Steering
9	3401-088	3		Screw, Cap
10	3401-159	2		Bushing, Upper - Steering
11	3401-091	4		Bolt, Carriage
12	3401-224	1		Column, Steering
13	3401-051	1		Cover, Dust
14	3401-048	7		Nut, Flange
15	3401-036	1		Decal
16	3401-001	1		Collar (inc. 17)
17	3401-492	1		Set Screw

VALVE GASKET SET AND CARBURETOR OVERHAUL KIT



Assemblies include all parts shown in frames.

2002 SBS 1000 (U2002SBM2AUSG)

Page 63 of 63

VALVE GASKET SET AND CARBURETOR OVERHAUL KIT

Ref #	Part Number	Qty	S/P/F	Description
7	806085	1	F	Gasket, Cylinder Head
51	691694	1	F	Gasket, Intake
51A	692035	1	F	Gasket, Intake
94	808257	1		Kit, Idle Mixture
102	692077	1		Gasket, Carburetor Body
104	690723	1		Pin, Float Hinge
105	692078	1		Valve, Float Needle
121	809023	1		Overhaul Kit, Carburetor
276A	691766	1	F	Washer, Sealing
338	691312	1	F	Gasket, Oil Level Stick
633	806131	1		Seal, Choke/Throttle Shaft
633A	690722	1		Seal, Choke/Throttle Shaft
868	691963	1	F	Seal, Valve
883	691613	1	F	Gasket, Exhaust
1022	806039	1	F	Gasket, Rocker Cover
1091	691516	1		Cap, Limiter
1095	808392	1		Gasket Set, Valve