

No
Diagram
Available

Parts List
Only

1996 MONTEGO (96MTF-W-1996)
ACCESSORIES

Page 2 of 55


Ref #	Part Number	Qty	S/P/F	Description
	0678-280	0		Air Intake Grate - Yellow
	0678-132	0	S	Anchor Bag
	0678-051	0	S	Anchor w/Float and Mooring Rope
	0678-134	0		Bag, Hatch
	0678-063	0		Battery Charger Kit
	0678-008	0	S	Beach Dolly
	0678-139	0		Beach Dolly Hitch Kit
	0678-300	0	S	Cover, Super
	0678-301	0	S/P	Cover, Custom
	0678-239	0		Decal, Shark Attack
	0673-093	0	S	Fire Extinguisher
	0678-102	0		Flame Arrestor Kit
	0678-006	0	/P	Flush Kit
	0678-129	0	/P	Fold-Up Sharkstand
	0678-316	0		Gel-Coat Kit - Multi-Color
	0678-137	0		Grips, Handlebar - Purple
	0678-138	0		Grips, Handlebar - Teal
	0678-287	0		Grips, Handlebar - Yellow
	0678-083	0	S	Handlebar Bag - Purple
	0678-252	0	/P	Handlebar Bag - Red
	0678-087	0		Handlebar Bag - Silver
	0678-270	0		Hatch Bag Cooler
	0678-064	0		Horn Kit
	0678-058	0		Inlet Grate, 12 mm (6 in.) Anodized
	0678-059	0		Inlet Grate, 12 mm (6 in.)
	0678-076	0	/P	Inlet Grate, 12 mm (4 in.)
	0678-180	0		Lift Harness
	2255-382	0	/P	Manual, Operator's
	2255-420	0		Manual, Parts
	2255-468	0		Manual, Service
	0678-028	0		Mirror, Wing (Pair) - Black (Montego)
	0678-260	0		Mirror, Wing (Pair) - Red (Montego)
	0678-261	0		Mirror, Wing (Pair) - Purple (Montego)
	0678-027	0		Mirror, Wing (Pair) - White (Montego)
	0680-070	0	/P	Mirror - 3 in. x 5 in. - Black (Montego)
	0678-225	0		Mirror - 3 in. x 5 in. - Red (Montego)
	0678-226	0		Mirror - 3 in. x 5 in. - Purple (Montego)
	0680-068	0		Mirror - 3 in. x 5 in. - White (Montego)
	0678-056	0	S	Mooring Rope - Lavender
	0678-052	0	/P	Mooring Rope - Purple
	0678-054	0		Mooring Rope - Red
	0678-055	0		Mooring Rope - Silver
	0678-053	0		Mooring Rope - Teal
	0678-320	0	/P	Mounting Pod, Gauges - Black
	0678-321	0		Mounting Pod, Gauges - White
	0678-267	0	/P	Nose Cone - Purple
	0678-293	0	/P	Nose Cone - Red
	0678-292	0	/P	Nose Cone - Teal
	0678-189	0	/P	Nylon Rope - Purple
	0652-042	0		Paint, Touch-Up - Teal
	0678-035	0		Paint, Touch-Up - White
	0678-234	0		Passenger Handles - 8 in.
	0678-295	0		Passenger Handles - 12 in.

1996 MONTEGO (96MTF-W-1996)
ACCESSORIES

Page 3 of 55

Ref #	Part Number	Qty	S/P/F	Description
	0678-185	0		Plug Caddy - Purple
	0678-149	0		Plug Caddy - Rivet-On
	0678-140	0		Rear Grab Bar - Purple
	0678-084	0		Saddlebag - Purple
	0678-107	0		Saddlebag - Silver
	0678-248	0		Saddlebag Cooler
	0678-085	0		Seat Pouch - Purple
	0678-254	0		Seat Pouch - Red
	0678-086	0		Seat Pouch - Silver
	0678-224	0		Spark Plug Caps - Red
	0678-318	0		Speedometer Kit
	0678-135	0		Start/Stop Switch Lock
	0678-317	0		Tachometer Kit
	0678-045	0	/P	Tie Stake
	0678-105	0		Tool Kit
	0678-115	0		Tuned Pipe Kit

1996 MONTEGO (96MTF-W-1996)
BILGE PUMP ASSEMBLY




1996 MONTEGO (96MTF-W-1996)
BILGE PUMP ASSEMBLY

Page 5 of 55

Ref #	Part Number	Qty	S/P/F	Description
1	0673-377	2		Fitting, Outlet - Bilge
2	0612-456	3		Seal, Fitting
3	0673-378	3	S	Nut, Fitting
4	0624-018	6		Clamp, Hose
5	0610-202	0	/P	Hose, Bilge - 15 ft
6	0673-483	1		T-Connection
7	0673-012	1		Pump, Bilge
8	0624-037	1		Clamp
9	0673-435	1		Plate, Mounting - Bilge Pump
10	0612-456	1		Seal, Drain Plug
11	0624-021	2		Nut, Lock
12	0673-278	1		Retainer, Drain Plug
13	0673-404	1		Plug, Drain

1996 MONTEGO (96MTF-W-1996)
CARBURETOR




1996 MONTEGO (96MTF-W-1996)
CARBURETOR

Page 7 of 55

Ref #	Part Number	Qty	S/P/F	Description
	0670-542	1		Assembly
	0678-066	1		Carburetor Rebuild Kit
1	6505-689	4		Screw
2	6505-662	1		Cover
3	6505-663	1		Diaphragm Assembly
4	6505-692	1		Screw, Machine
5	6505-664	1		Arm
6	6505-669	1		Spring
7	6505-695	1		Screw, Machine
8	6505-682	1		Plate
9	6505-671	1		Needle Valve Assembly
10	0	1	F	Mixing Body
11	6505-681	1		Pin
12	6505-679	2		Screw, Machine
13	6505-680	1		Block, Metering
14	6505-677	1		Gasket
15	6505-694	1		Main Jet - 107.5
16	6505-793	1		Pilot Jet - 117.5
17	6505-701	1		Seal
18	6505-661	1		Washer
19	6505-660	1		Spring
20	6505-667	1		Adjuster
21	6505-659	1		Cap
22	6505-698	1		Cap
23	6505-699	1		Adjuster
24	6505-678	1		Spring
26	6505-700	1	S	O-Ring
27	6505-676	1		Filter
28	6505-665	1		S-Gasket
29	6505-656	1	/P	Diaphragm, Damper
30	6505-702	1		Screw Assembly
31	6505-697	1		Retainer
32	6505-651	1		Spring
33	0	2	F	Grommet
34	0	2	F	Valve
35	6505-655	1		Body Assembly, Diaphragm
36	6505-683	1		O-Ring
37	6505-654	1		Diaphragm, Pump
38	6505-652	1		Cover, Pump
39	6505-704	4		Screw w/Washer
40	6505-653	1		Gasket
41	6505-817	2		Bushing, Choke Shaft
42	6505-701	2		Seal, Choke Shaft
43	6505-822	1		Collar, Lock


1996 MONTEGO (96MTF-W-1996)
CRANKCASE



1996 MONTEGO (96MTF-W-1996)
CRANKCASE

Page 9 of 55


Ref #	Part Number	Qty	S/P/F	Description
1	3008-176	1		Crankcase Assembly (inc. 2-5)
1	3008-382	1	F	Crankcase Assembly (inc. 2-5)
2	3008-210	4	/P	Screw, Cap
3	3008-211	2	S	Screw, Cap
4	3008-212	8	/P	Screw, Cap
5	0691-729	2		Pin
6	3008-100	1		Bladder, Magneto Case
7	3008-105	2		Bushing, Pinion Shaft
8	3008-038	1		Clamp
9	0691-033	1	S	Hose, Vacuum
10	3008-039	2		Clamp, Hose



1996 MONTEGO (96MTF-W-1996)
CRANKSHAFT

Page 11 of 55


Ref #	Part Number	Qty	S/P/F	Description
1	3008-383	2	/P	Piston, Standard
1	3008-181	2		Piston, Optional (+ 0.010 in.)
1	3008-182	2		Piston, Optional (+ 0.020 in.)
2	3008-224	2	S	Ring Set, Standard
2	3008-183	2		Ring Set, Optional (+ 0.010 in.)
2	3008-184	2		Ring Set, Optional (+ 0.020 in.)
3	3003-338	2	S	Pin
4	3003-433	2	/P	Bearing
5	3003-439	4	/P	Snap Ring
6	3008-063	1	S	Crankshaft Assembly (inc. 7-20)
7	3008-062	2		Connecting Rod
8	3008-064	1	S	Crank, Pin
9	3008-065	1		Crankshaft, Right
10	3008-066	1		Crankshaft, Center
11	3008-067	1		Wheel
12	3008-068	1		Crankshaft, Left
13	3008-069	1		Balancer
14	3008-070	1		Race, Center
15	3003-817	1	/P	Ring, Center
16	3008-019	1		Washer
17	3008-027	1		Bearing
18	3008-378	3	S	Bearing
18	3008-298	3	/P/F	Bearing
19	3008-029	2		Bearing
20	3004-372	3	S	Screw, Machine
21	3008-072	1		Spacer, Crankshaft
22	3008-031	1		Seal, Oil - Right
23	3008-032	1		Seal, Oil - Left
24	3008-033	1		Seal, Oil - Center
25	3003-216	1		C-Ring



1996 MONTEGO (96MTF-W-1996)
CYLINDER ASSEMBLY

Page 13 of 55


Ref #	Part Number	Qty	S/P/F	Description
1	3008-206	11	/P	Screw, Cap
1	3008-381	11	F	Screw, Cap
2	3008-059	1		Hook
3	0217-700	2		Spark Plug (BR9ES Solid)
4	3008-046	1		Head, Cylinder
4	3008-194	1	S/F	Head, Cylinder
5	3008-380	1	S	Gasket, Cylinder Head
6	3008-209	5	/P	Nut
7	3008-207	5	/P	Washer, Lock
8	3008-237	5	S	Washer
9	3008-377	1	/P	Plug
10	3008-326	1	/P	Cylinder
11	3008-358	2	/P	Clamp
12	3008-092	1		Fitting, Elbow
12	3008-361	1	F	Fitting, Straight
13	3008-050	1		Gasket, Cylinder
14	3008-394	1	/P	Stud
15	3008-208	1		Nut
16	3008-300	5		Stud
17	3008-013	1		Screw, Cap
18	3008-047	1		Zinc, Anode (inc. 17)
19	3008-216	3		Screw, Cap
20	3008-089	1		Cap, Thermostat
21	0624-016	2		Clamp, Hose
22	3008-230	1		Gasket, Thermostat
23	0673-374	1		Outlet, Water
24	0612-360	1		Seal, Outlet
25	0673-378	1	S	Nut, Outlet
26	0610-268	0		Hose, Water
27	3008-146	2		Pin



1996 MONTEGO (96MTF-W-1996)
DECAL AND FOOTPAD ASSEMBLY

Page 15 of 55


Ref #	Part Number	Qty	S/P/F	Description
1	0614-178	1		Decal, Hood - Right
1	0614-179	1		Decal, Hood - Left
2	0614-154	1		Decal, USCG Exception
3	1611-605	1		Decal, Oil Filler
4	0773-621	1		Pad, Foot - Deck Assembly (inc. 5-7)
5	0673-961	1		Pad, Foot - Rear
6	0673-964	1		Pad, Foot - Front Right
6	0673-965	1		Pad, Foot - Front Left
7	0673-962	1		Pad, Foot - Right
7	0673-963	1		Pad, Foot - Left
8	0617-184	1		Foam, Deck - Right
10	0614-183	2		Decal, Deck - "Tigershark"
12	1611-866	1		Decal, Warning - Gas Vapors
14	0617-183	1		Foam, Deck - Left
15	0614-059	1		Decal, Common Sense
16	0614-066	1		Decal, USCG Exemption
17	0614-154	1		Decal, Caution - Uprighting
18	0614-241	1		Decal, Regulation
19	0614-182	1		Decal, Console
24	8060-230	34		Rivet
25	0673-952	34		Plug, Mushroom



1996 MONTEGO (96MTF-W-1996)
ELECTRICAL MODULE AND BATTERY

Page 17 of 55


Ref #	Part Number	Qty	S/P/F	Description
1	3008-335	1	S	Regulator Assembly (inc. 2)
1	3008-279	1	/P/F	Regulator Assembly (inc. 2)
2	3008-318	2	S	Screw, Regulator
3	3008-337	2		Washer, Regulator
4	3008-353	1	S	Unit, CDI
4	3008-338	1	S/F	Unit, CDI
5	3008-319	3		Screw, Cap
6	3008-282	1		Case
7	3008-340	1	S	Cover
7	3008-283	1	/P/F	Cover
8	3008-341	1	S	Cover
8	3008-284	1	/P/F	Cover
9	3008-342	1	S	Packing
9	3008-285	1	/P/F	Packing
10	0673-755	1		Vent, Hull - w/Hood
11	3008-124	3		Holder
12	3008-125	1		Holder
13	3008-379	4		Screw, Cap
14	3008-217	1		Screw, Cap
15	3008-330	1	S/P	Sensor - Assembly (inc. 16)
16	3008-134	1		Supporter
17	3008-219	3		Screw, Machine
18	3008-040	1		Clamp
19	0673-811	1		Pad, Battery
20	3008-336	1	/P	Base, Regulator
21	0624-052	4		Screw, Cap
22	0624-022	4		Washer
23	0670-295	1		Valve, Check
24	0623-502	1		Clamp
25	0645-179	1	S	Hose, Battery Vent
26	0673-454	1		Cover, Battery
27	0773-382	2	/P	Tiedown
28	0645-045	6		Cap, Battery
29	0645-157	1		Battery (inc. 25, 28, 30-31)
30	0645-323	1		Clamp, Hose - Battery
31	0623-063	1		Clamp



1996 MONTEGO (96MTF-W-1996)
ENGINE AND RELATED ASSEMBLY

Page 19 of 55

Ref #	Part Number	Qty	S/P/F	Description
1	0662-152	1		Engine
1	0662-174	1	F	Engine
2	0624-017	2		Washer
2	0624-017	1	F	Washer
3	3008-090	2	/P	Coupler, Engine
3	3008-090	1	/P/F	Coupler, Engine
4	0673-146	1		Insert, Damper - Coupler
5	0773-581	1	S	Damper, Coupler (inc. 4)
6	1611-608	1		Decal, Warning
7	0624-037	1		Clamp, Hose
8	0773-437	1	/P	Shield, Safety Coupler (inc. 6-7)
9	0624-027	10		Washer, Lock
10	0624-028	12		Washer
11	3008-239	1	/P	Plate, Engine Mount
11	3008-395	1	S/F	Plate, Engine Mount
12	3008-054	4		Damper, Engine
13	0624-087	8		Screw, Cap
14	0673-509	0		Shim, Engine Mount - 0.063 in.
15	1673-010	1	F	Washer
16	3008-449	1	/P/F	Coupler, Engine
17	3008-203	4	/P	Screw, Cap
18	3008-240	4		Screw, Cap
19	3008-021	4		Washer, Lock
20	3008-016	4		Washer
21	0624-015	0	/P	Shim - 1.5 mm
21	0624-014	0	/P	Shim - 0.5 mm



1996 MONTEGO (96MTF-W-1996)
EXHAUST ASSEMBLY


Page 21 of 55

Ref #	Part Number	Qty	S/P/F	Description
1	3008-200	1	/P	Hose, By-Pass
1	3008-355	1	/P/F	Hose, By-Pass
2	3008-039	2		Clamp
3	3008-215	3	/P	Screw, Cap
4	3008-025	1		Plug
5	3008-022	1		Gasket
6	3008-171	1		Pipe, Exhaust
6	3008-398	1	F	Pipe, Exhaust
7	3008-215	3	/P	Screw, Cap
7	3008-371	3	F	Screw, Cap
8	3008-385	1	/P	Gasket, Exhaust Pipe
9	3008-386	1	/P	Gasket, Exhaust Joint
10	3008-384	2	/P	Gasket, Exhaust Manifold
11	3008-204	1	/P	Manifold, Exhaust
12	3008-373	6	/P	Screw, Cap
13	3008-399	1	S	Expansion Chamber
14	3008-016	2		Washer
15	3008-188	2		Screw, Cap
16	0624-038	1		Clamp, Hose
17	0624-018	3		Clamp, Hose
18	0610-240	1		Hose, Exhaust - In
19	0673-309	1		Pad, Muffler
20	1673-088	1		O-Ring
21	0612-575	1	S	Outlet, Exhaust
22	0773-644	1	/P	Hose, Exhaust - Out
23	0712-205	1		Muffler
24	0773-382	2	/P	Tiedown
25	0612-576	1		Nut, Exhaust Outlet
26	3008-021	2		Washer, Lock
27	3008-372	2	F	Screw, Cap

1996 MONTEGO (96MTF-W-1996)
GAS TANK ASSEMBLY

Page 23 of 55

Ref #	Part Number	Qty	S/P/F	Description
1	0770-175	1		Tank, Gas - Assembly (inc. 2-5 and 14)
2	0670-564	3		Outlet, Gas Tank - Brass
3	1673-047	3		Ring, Compression
4	0610-008	0	/P	Hose, Gasline
5	0510-358	1	/P	Strainer, Gas Tank
6	0670-270	1		Neck, Filler
7	0670-271	1		Seal, Filler Neck
8	0624-120	19		Clamp, Hose
9	0610-107	0		Hose
10	0673-306	1		Pad, Gas Tank - Right
11	0670-551	1	/P	Cap, Gas Gauge
12	0670-304	1		Ring, Mounting - Filler Neck
13	0623-602	6	S	Rivet
14	1673-055	1		Tube, Drop - Main
15	0623-603	6		Washer, Backup
16	0624-037	3		Clamp, Hose
17	0710-091	1		Hose, Filler
18	0510-335	2	/P	Filter, Fuel
19	0773-383	2		Tiedown
20	0115-607	1	S	Fitting, Elbow
21	0109-332	1		T-Connection
22	0123-788	2	/P	Tie, Cable
23	0610-059	2		Valve, Check
24	0673-755	1		Vent, Fuel
25	0673-307	1	/P	Pad, Gas Tank - Left
26	0673-854	1		Reserve, Valve
27	0624-352	1		Nut, Jam
28	0624-351	1		Washer
29	0624-335	1		Nut
30	0673-855	1		Knob, Fuel
31	0687-052	1	/P	Cover, Boot
32	0624-343	1		Screw, Machine
33	0623-638	1		Washer, Nylon
34	1673-015	1		Plate, Fuel Reserve




1996 MONTEGO (96MTF-W-1996)
HANDLEBAR ASSEMBLY

Page 25 of 55

Ref #	Part Number	Qty	S/P/F	Description
1	0673-990	2	S	Grip, Handlebar
2	0773-018	1		Throttle, Assembly (inc. 3-8)
3	0605-234	1		Lever, Throttle
4	0605-236	1		Pin, Throttle Lever
5	0605-235	1		Housing, Throttle
6	0624-099	1		Washer
7	0624-113	1		C-Clip
8	0624-091	1		Screw, Machine
9	0624-056	4		Screw, Cap
10	0673-282	4		Cap, Steering Adjuster
11	0773-572	1		Handlebar
12	0687-054	1		Cable, Throttle
13	0624-250	4		Nut, Lock
14	0123-788	1	/P	Tie, Cable
15	0609-203	1		Tether, Switch Assembly (inc. 16-17)
16	0624-148	3		Screw, Machine
17	0609-243	1	S	Cord, Tether
18	0624-104	1		C-Clip
19	0773-508	1		Handlebar Pad - Assembly (inc. 20-22)
20	0605-253	1		Pad, Handlebar - Rear
21	0605-244	1		Pad, Handlebar - Front
22	0	1	F	Cover, Handlebar Pad
23	1673-095	1		Washer, Rubber - Handlebar
24	0624-257	2		Screw, Self-Tapping


1996 MONTEGO (96MTF-W-1996)
HATCH COVER AND STORAGE TRAY



1996 MONTEGO (96MTF-W-1996)
HATCH COVER AND STORAGE TRAY

Page 27 of 55


Ref #	Part Number	Qty	S/P/F	Description
1	0673-882	1		Latch, Hatch Cover
2	0673-877	1	S	Cover, Hatch
3	0624-004	3		Washer
4	0624-092	2		Screw, Cap
5	0773-638	1		Seal, Hatch
6	0624-112	1	/P	Screw, Machine
7	0624-182	2		Washer
8	0673-899	1		Rod, Hood Prop
9	0673-399	1		Spacer, Spring Rod
10	0624-083	1		Nut, Well
11	0624-036	2		Washer, Lock
12	0624-053	2	/P	Screw, Cap
13	0678-105	1		Kit, Tool
14	0673-250	1		Tray, Storage
15	0673-888	1		Grille, Hatch - Teal
16	0673-883	1		Plug, Fire Extinguisher
17	1673-060	2		Bumper, Grommet
18	0624-207	1		Clamp
19	0610-211	1		Hose, Air Intake
20	0624-200	2		Washer, Lock
21	0624-361	2		Retainer, Push-On
22	0773-661	2		Stock, Cord
23	0624-100	0		Staples
24	0773-662	2		Hose
25	0773-217	1		Tiedown
26	8061-708	1		Rivet



1996 MONTEGO (96MTF-W-1996)
HULL AND RELATED PARTS ASSEMBLY

Page 29 of 55

Ref #	Part Number	Qty	S/P/F	Description
1	0623-585	2		Clip, Retaining
2	0673-935	1	/P	Nose, Cone
3	0773-566	1		Hull/Deck - Assembly
4	0624-258	4		Nut, Hex
5	0673-657	2		Plate, Backing - Eyehook
6	0673-656	6		Plate, Backup - Eyehook
7	0624-259	4		Nut, Cone
8	0624-260	2		U-Bolt
9	0624-112	2	/P	Screw, Cap
10	0624-022	2		Washer
11	0673-871	1		Hinge, Hatch Assembly
12	0673-006	2		Plate, Nut
13	0624-184	4		Screw, Machine
14	0673-676	1		Plate, Ride
15	0624-030	8		Rivet
16	0673-994	1	S	Trim - Right
16	0673-954	1		Trim - Left
17	0623-619	2		Rivet
18	0673-952	2		Plug, Mushroom
19	0673-870	1		Plate, Hinge
20	0624-021	2		Nut, Lock
21	0124-054	2	/P	Snap Cap w/Washer
22	0624-115	2		Washer, Lock
23	0624-228	4		Washer
24	0773-384	1		Handle, Grab
25	1673-083	1		Gasket, Bow Eye - Stern
26	0624-068	44		Rivet
27	0673-975	1	/P	Cover, Rub Rail
28	0673-866	1	/P	Strike, Latch
29	0624-289	4		Screw, Cap
30	0624-223	1		Screw, Cap
31	0673-485	1		Stop, Steering
32	0624-008	1		Washer
33	0623-391	1		Washer, Rubber
34	0673-417	1		Plate, Backing
35	0624-009	1		Nut, Lock




1996 MONTEGO (96MTF-W-1996)
IGNITION COIL

Page 31 of 55

Ref #	Part Number	Qty	S/P/F	Description
1	3008-343	1	S	Coil Assembly, Ignition
2	3008-220	2		Screw, Cap
3	3003-023	2	/P/F	Washer
4	3008-334	2	/P	Grommet
5	3008-129	2	/P	Protector, Lead Wire
6	3008-045	1		Clip
7	3003-737	2	S	Cap Assembly, Spark Plug
8	3003-787	2		Tie, Cable

1996 MONTEGO (96MTF-W-1996)
IMPELLER DRIVE ASS'Y




1996 MONTEGO (96MTF-W-1996)
IMPELLER DRIVE ASS'Y

Page 33 of 55

Ref #	Part Number	Qty	S/P/F	Description
1	0673-661	1		Inlet, Pump
2	3008-100	1		Bladder, Case
3	0624-091	1		Screw, Machine
4	0624-186	13		Screw, Machine
5	0624-007	4		Screw, Cap
6	0624-265	4		Washer
7	0624-009	4		Nut, Lock
8	0675-120	1		Grate, Inlet
9	0624-022	2		Washer
10	0612-532	1		Seal, Pump Inlet
11	0624-183	8		Screw, Machine
12	0673-256	1		Spacer, Impeller
13	0673-505	1	S	Bearing
14	0624-044	1		Ring, Snap
15	0673-033	2		Seal, Rear
16	0673-363	1	/P	Driveshaft
17	0673-263	1	S	Impeller
18	0673-030	1		Bearing
19	0624-043	1		Ring, Snap
20	0673-031	1		Seal
21	0673-662	1	/P	Ring, Wear
22	0673-760	1		Venturi, Stator
23	0624-045	4		Screw, Cap
24	0624-027	4		Washer, Lock
25	0624-028	4		Washer
26	0624-084	1		Anode, Zinc
27	0673-038	1		Nozzle, Steering
28	0673-083	2		Bushing, Steering Nozzle
29	0624-036	2		Washer, Lock
30	0624-112	4	/P	Screw, Cap
31	0610-172	1		Fitting
32	0624-229	2		Screw, Cap
33	0670-118	1		Fitting, Outlet
34	0624-016	3		Clamp
35	0610-209	1		Hose, Formed
36	0673-700	1	F	Fitting, Pump
37	0123-811	1		Tie, Cable
38	3008-455	1		Clamp
39	0673-008	2		Plate, Nut
40	0673-009	1		Plate, Nut
41	0610-183	1		Hose, Water
41	0610-206	1	/P/F	Hose, Water
42	0624-021	13		Nut, Lock
43	0624-159	4		Washer
44	0673-464	1		Coupler
44	0673-564	1	F	Coupler
45	0610-106	0	/P	Hose
46	0624-016	2		Clamp
47	0673-493	1		O-Ring, Impeller

1996 MONTEGO (96MTF-W-1996)
IMPELLER DRIVE ASSEMBLY




1996 MONTEGO (96MTF-W-1996)
IMPELLER DRIVE ASSEMBLY

Page 35 of 55

Ref #	Part Number	Qty	S/P/F	Description
1	0673-661	1		Inlet, Pump
2	3008-100	1		Bladder, Case
3	0624-091	1		Screw, Machine
4	0624-186	13		Screw, Machine
5	0624-007	4		Screw, Cap
6	0624-265	4		Washer
7	0624-009	4		Nut, Lock
8	0675-120	1		Grate, Inlet
9	0624-106	2		Washer
10	0612-532	1		Seal, Pump Inlet
11	0624-183	8		Screw, Machine
12	0673-256	1		Spacer, Impeller - Driveshaft
13	0673-505	1	S	Bearing - Rear
14	0624-044	1		Ring, Snap
15	0673-033	2		Seal, Rear
16	0673-363	1	/P	Driveshaft
17	0773-103	1	/P	Impeller
18	0673-030	1		Bearing
19	0624-043	1		Ring, Snap
20	0673-031	1		Seal
21	0673-664	1		Ring, Wear
22	0673-760	1		Venturi, Stator
23	0624-045	4		Screw, Cap
24	0624-027	4		Washer, Lock
25	0624-028	4		Washer
26	0624-0841	1		Anode, Zinc
27	0673-038	1		Nozzle, Steering
28	0673-083	2		Bushing, Steering Nozzle
29	0624-036	2		Washer, Lock
30	0624-214	4		Screw, Cap
31	0610-172	1		Fitting
32	0624-229	2		Screw, Cap
33	0670-118	1		Fitting, Outlet
34	0624-016	3		Clamp
35	0610-209	1		Hose, Formed
36	0673-700	1		Fitting, Hull
37	0123-811	1		Tie, Cable
38	3008-455	1		Clamp
39	0673-008	2		Plate, Nut
40	0637-009	1	/P	Plate, Nut
41	0610-206	1	/P	Hose, Water
42	0624-021	13		Nut, Lock
43	0624-159	4		Washer
44	0673-564	1		Coupler
45	0610-106	0	/P	Hose
46	0624-016	2		Clamp
47	0673-493	1		O-Ring, Impeller
48	0673-364	1		Spacer, Impeller - Driveshaft


1996 MONTEGO (96MTF-W-1996)
INTAKE ASSEMBLY



1996 MONTEGO (96MTF-W-1996)
INTAKE ASSEMBLY

Page 37 of 55

Ref #	Part Number	Qty	S/P/F	Description
1	0624-046	2		Screw, Cap
2	3008-177	1		Cover, Spark Arrestor
3	3008-354	1	/P	Screen, Spark Arrestor
4	0673-044	1		Spark Arrestor - Lower
5	0624-053	4	/P	Screw, Cap
6	0673-389	1		Gasket, Spark Arrestor
7	0670-542	1		Carburetor
8	0624-061	2		Nut, Jam
9	0624-027	2		Washer, Lock
10	0624-028	2		Washer
11	0624-051	2		Bolt, Stud
12	0673-057	1		Gasket, Intake
13	3008-087	1	S	Valve, Check
14	3008-213	8	/P	Screw, Cap
15	0673-734	1		Manifold, Intake
16	3008-076	4	S	Gasket, Reed Valve
17	3008-073	2	S	Reed Valve Assembly (inc. 18-20)
18	3008-075	4		Valve, Reed
19	3004-506	12	/P	Screw, Cap
20	3008-074	4		Stopper, Reed Valve
21	3008-156	4	S	Bolt, Stud
21	3008-370	4	/P/F	Bolt, Stud
22	3008-158	4	/P	Nut
22	3008-214	4	F	Nut
23	0687-051	1	/P	Nut
24	0687-052	2	/P	Cover, Boot
25	0687-069	1		Cable, Choke
26	0624-268	1		Ring, Retaining
27	0123-811	0		Tie, Cable
28	0624-022	2		Washer
29	0624-036	8		Washer, Lock




1996 MONTEGO (96MTF-W-1996)
MAGNETO

Page 39 of 55


Ref #	Part Number	Qty	S/P/F	Description
1	3008-329	1	S	Stator
2	3008-111	1		Grommet
2	3008-362	1	/P/F	Grommet
3	3004-706	5	S/P	Screw, Cap
4	3004-484	3	S	Screw, Cap
5	3008-109	1		Holder
6	3008-331	1	/P	Clamp
7	3003-787	1		Clamp
8	3004-540	1	/P	Key
9	3008-108	1	S	Flywheel
10	3008-388	1	S	Screw, Cap
11	3008-017	1		Washer
12	3004-362	1	S/P	Washer, Lock
13	3008-110	1		Holder, Grommet
14	3008-118	1		Grommet

1996 MONTEGO (96MTF-W-1996)
MAGNETO CASE



1996 MONTEGO (96MTF-W-1996)
MAGNETO CASE


Ref #	Part Number	Qty	S/P/F	Description
1	3008-238	1	/P	Case, Magneto
2	3008-053	1		O-Ring
3	3008-213	6	/P	Screw, Cap
4	3008-146	2		Pin
5	3008-023	1		Plug



1996 MONTEGO (96MTF-W-1996)
OIL PUMP

Page 43 of 55


Ref #	Part Number	Qty	S/P/F	Description
1	3008-241	1	S	Oil Pump Assembly
1	3008-451	1	S/F	Oil Pump Assembly
2	3008-030	1		O-Ring
3	3008-035	1	/P	Hose
4	0624-291	2		Clamp
5	3008-242	1		Screw, Cap
6	3008-243	1		Screw, Cap



1996 MONTEGO (96MTF-W-1996)
OIL TANK ASSEMBLY

Page 45 of 55


Ref #	Part Number	Qty	S/P/F	Description
1	0670-541	1		Cap, Oil Gauge
2	0670-304	1		Ring, Mounting Filler Neck
3	0670-270	1		Neck, Filler
4	0670-271	1		Seal, Filler Neck
5	0624-037	3		Clamp, Hose
6	0710-171	1		Hose, Filler
7	0623-602	6	S	Rivet
8	0623-603	6		Washer
9	0610-263	0		Hose, Oil
10	0624-120	5		Clamp, Hose
11	0610-107	0		Hose
12	0510-335	2	/P	Filter, Fuel
13	0623-646	2		Clamp, Hose
14	0670-564	2		Outlet, Tank
15	0670-446	1		Tank, Oil
16	0623-063	3		Clamp
17	0773-383	2		Strap Assembly
18	0610-059	1		Valve, Check
19	0710-022	0	S	Hose, Oil Line
20	0673-985	1		Union, Coupler
21	0623-502	1		Clamp, Hose



1996 MONTEGO (96MTF-W-1996)
SEAT ASSEMBLY

Page 47 of 55


Ref #	Part Number	Qty	S/P/F	Description
	0773-564	1	/P	Complete Seat Assembly
1	0773-504	1	F	Strap, Seat - 33 in.
2	0773-624	1	F	Cover, Seat w/Silkscreen
3	0773-099	1	F	Foam, Seat
4	0773-499	1	F	Base, Seat
5	0773-623	0	F	Seal, Seat Base
6	0673-668	1		Catch, Seat
7	0624-263	0	F	Staple
8	0624-021	2	F	Nut, Lock
9	0624-036	2		Washer, Lock
10	0624-112	2	/P/F	Screw, Cap
11	0624-262	1		U-Bolt, Seat
12	0624-061	2		Nut, Jam
13	0624-125	4	/P	Washer
14	0624-090	2		Nut, Lock
15	0624-009	1		Nut, Lock
16	0624-022	2		Washer
17	0624-226	2	F	Screw, Cap
18	0623-585	3		Clip, Retainer
19	0610-242	1		Air Tube, Exhaust
20	0624-012	1		Washer, Lock
21	0623-391	1		Washer, Rubber
22	0673-026	1		Lever, Release - Seat Latch
23	0673-024	1	S	Cover, Latch - Seat
24	0673-025	1		Back, Latch - Seat
25	0673-023	1		Clip, Retaining
26	0624-159	2		Washer
27	0624-047	1		Nut, Jam
28	0624-289	2		Screw, Cap
29	1673-108	1	S	Stud, Latch - Seat
30	0624-126	1		Washer, Rubber
31	0624-182	2		Washer
32	0716-559	0	F	Trim, Seat
33	1673-096	2		Corner, Seat



1996 MONTEGO (96MTF-W-1996)
SENSOR ASSEMBLY

Page 49 of 55

Ref #	Part Number	Qty	S/P/F	Description
1	3008-352	1	S	Relay - Assembly
2	3008-348	1	S	Protector, Circuit Charge
2	3008-293	1	S/F	Protector, Circuit Charge
3	3008-351	1		Cap, Circuit Protector
4	3008-350	1	/P	Protector, Circuit Load
4	3008-295	1	S/F	Protector, Circuit Load
5	3008-349	1	S	Holder, Circuit Protector
5	3008-294	1	/P/F	Holder, Circuit Protector
6	3008-313	2		Screw, Cap




1996 MONTEGO (96MTF-W-1996)
STARTER MOTOR

Page 51 of 55

Ref #	Part Number	Qty	S/P/F	Description
1	3008-327	1	S	Starter Motor Assembly (inc. 2-11)
2	3008-094	1	/P	Terminal Set, Brush (inc. 3)
3	3008-164	1		O-Ring
4	3008-095	1	/P	Holder Set, Brush (inc. 5)
5	3008-096	4		Spring, Brush
6	3008-328	1	/P	Front Bracket Assembly (inc. 7)
7	3008-098	1	S	O-Ring
8	3008-099	2		Washer Set
9	3008-101	2	S	O-Ring
10	3008-103	1		Armature
11	3008-102	2		Screw, Cap
12	3008-104	1	S	Pinion Assembly
13	3008-009	2		Screw, Cap
13	3008-400	2	F	Screw, Cap
14	3008-014	1		Nut
15	3008-020	1		Washer
16	3008-165	1	/P	Relay
17	3008-140	1		Bracket
18	3008-313	2		Screw, Cap
19	3008-135	1	S	Tube
20	3008-193	2	S	Washer
20	3008-193	1	S/F	Washer
21	3008-221	1	F	Washer
22	3008-401	2	S/F	Washer

1996 MONTEGO (96MTF-W-1996)
STEERING POST ASSEMBLY





1996 MONTEGO (96MTF-W-1996)
STEERING POST ASSEMBLY

Page 53 of 55

Ref #	Part Number	Qty	S/P/F	Description
1	0624-186	6		Screw, Machine
2	0673-122	2		Bearing, Half-Steering Post
3	0624-021	6		Nut, Lock
4	0624-038	1		Clamp
5	0673-056	1		Seal, Bearing
6	0773-096	1	/P	Post, Steering
7	0717-052	0	/P	Foam, Neoprene Tape
8	0605-149	2		Bearing, Steering Post
9	0605-171	1		Housing, Bearing
10	0673-457	1		Bracket, Support
11	0773-095	1	/P	Bracket, Steering Cable
12	0624-125	1	/P	Washer
13	0624-229	1		Screw, Cap
14	0624-090	1		Nut, Lock
15	0624-192	2		Screw, Cap
16	0624-028	2		Washer
17	0673-028	2		End, Steering Cable
18	0624-107	2		Nut, Jam
19	0673-232	1	/P	Cable, Steering
20	0612-363	2		Seal, Rod
21	0612-364	2		Seal, Steering Cable
22	0624-106	4		Washer
23	0624-105	4		Nut, Jam
24	0705-064	1	/P	Housing, Bearing
25	0673-366	1		Spacer, Bearing Housing
26	0624-114	1		Nut, Lock
27	0624-115	1		Washer, Lock
28	0624-022	6		Washer

1996 MONTEGO (96MTF-W-1996)
WIRING HARNESS



1996 MONTEGO (96MTF-W-1996)
WIRING HARNESS

Page 55 of 55

Ref #	Part Number	Qty	S/P/F	Description
1	3008-044	1		Clamp
2	3008-332	2		Clamp
2	3008-357	2	F	Clamp
3	3008-346	1		Cable
4	3008-345	1	/P	Cable
5	3008-334	1	/P	Grommet
6	3008-154	1		Cable, Ground
7	3008-347	1		Harness, Wiring
7	3008-292	1	F	Harness, Wiring
8	0630-082	1		Fuse Holder, Waterproof
9	0630-084	1		Fuse, 3 AMP
10	0630-089	1		Fuse Holder, Blade (inc. 11-13)
11	0	1	F	Cover, Fuse Holder
12	0630-056	1		Fuse, 3 AMP
13	0	1	F	Body, Fuse Holder
14	0624-068	1		Clip, Retainer
15	3008-362	1	/P/F	Grommet