


1998 TS-R 770 (98DTA-1998)  
BILGE PUMP ASSEMBLY

Page 1 of 71




1998 TS-R 770 (98DTA-1998)  
BILGE PUMP ASSEMBLY

Page 2 of 71

| Ref # | Part Number | Qty | S/P/F | Description             |
|-------|-------------|-----|-------|-------------------------|
| 1     | 0673-377    | 1   |       | Fitting, Outlet - Bilge |
| 2     | 0612-456    | 2   |       | Seal, Fitting           |
| 3     | 0673-378    | 2   | S     | Nut, Fitting            |
| 4     | 0624-018    | 2   |       | Clamp, Hose             |
| 5     | 0710-201    | 1   |       | Hose, Bilge             |
| 6     | 0673-404    | 1   |       | Plug, Drain             |
| 7     | 1673-331    | 1   | S     | Pump, Bilge             |
| 8     | 0624-038    | 1   |       | Clamp                   |
| 9     | 1673-558    | 1   |       | Mount, Bilge Pump       |
| 10    | 0673-459    | 1   |       | O-Ring                  |
| 11    | 0624-250    | 1   |       | Nut, Lock               |
| 12    | 0673-278    | 1   |       | Retainer, Drain Plug    |
| 13    | 0610-059    | 1   |       | Valve, Check            |

1998 TS-R 770 (98DTA-1998)  
CARBURETOR

Page 3 of 71



1998 TS-R 770 (98DTA-1998)  
CARBURETOR

Page 4 of 71

| Ref # | Part Number | Qty | S/P/F | Description                                    |
|-------|-------------|-----|-------|------------------------------------------------|
|       | 0670-784    | 1   |       | Complete Assembly (inc. 1-37 & 40-47)          |
| 1     | 6505-915    | 8   |       | Screw, Machine (Mag & Center Carburetor)       |
| 1     | 6505-943    | 4   |       | Screw, Machine (PTO Carburetor)                |
| 2     | 6505-662    | 2   |       | Cover (Mag and Center Carburetor)              |
| 2     | 6506-021    | 1   |       | Cover (PTO Carburetor)                         |
| 3     | 6505-663    | 3   |       | Diaphragm Assembly                             |
| 4     | 6505-692    | 3   |       | Screw, Machine                                 |
| 5     | 6505-664    | 3   |       | Arm                                            |
| 6     | 6505-934    | 3   |       | Spring                                         |
| 7     | 6505-695    | 3   |       | Screw, Machine                                 |
| 8     | 6505-682    | 3   |       | Plate                                          |
| 9     | 6505-944    | 3   |       | Needle Valve Assembly                          |
| 10    | 0           | 3   | F     | Mixing Body                                    |
| 11    | 6505-681    | 3   |       | Pin                                            |
| 12    | 6505-679    | 6   |       | Screw, Machine                                 |
| 13    | 6505-680    | 3   |       | Block, Metering                                |
| 14    | 6505-677    | 3   |       | Gasket                                         |
| 15    | 6505-732    | 1   |       | Jet, High Speed - 105 (Mag Carburetor)         |
| 15    | 6505-743    | 1   |       | Jet, High Speed - 135 (Center Carburetor)      |
| 15    | 6505-737    | 1   |       | Jet, High Speed - 120 (PTO Carburetor)         |
| 16    | 6505-774    | 1   |       | Jet, Low Speed - 70                            |
| 17    | 6505-668    | 3   |       | Seal                                           |
| 18    | 6505-661    | 6   |       | Washer                                         |
| 19    | 6505-660    | 3   |       | Spring                                         |
| 20    | 6505-852    | 3   |       | Adjuster                                       |
| 21    | 6505-042    | 3   |       | O-Ring                                         |
| 22    | 6505-109    | 1   |       | Jet, Main Fixed (Mag Carburetor)               |
| 22    | 6505-394    | 2   |       | Jet, Pilot #95 (Center and PTO Carburetor)     |
| 23    | 6505-911    | 1   |       | Nut                                            |
| 24    | 6505-912    | 1   |       | Screw Assembly                                 |
| 25    | 6505-703    | 1   |       | Washer                                         |
| 26    | 6505-872    | 1   | /P    | O-Ring                                         |
| 27    | 6505-676    | 3   |       | Filter                                         |
| 28    | 6505-665    | 3   |       | S-Gasket                                       |
| 29    | 6505-848    | 3   |       | Cover Assembly                                 |
| 30    | 6505-853    | 12  |       | Screw, Machine                                 |
| 31    | 6505-678    | 1   |       | Spring                                         |
| 32    | 6505-913    | 1   |       | Bracket, Cable                                 |
| 33    | 6505-914    | 6   |       | Screw, Machine                                 |
| 34    | 6506-028    | 1   |       | Hose Assembly                                  |
| 35    | 6505-917    | 1   |       | Plate, Mounting                                |
| 36    | 6505-941    | 2   |       | Clip (PTO Carburetor)                          |
| 37    | 6505-942    | 1   |       | Hose (PTO Carburetor)                          |
| 38    | 0710-425    | 0   | /P    | Hose - 25 ft                                   |
| 39    | 0624-089    | 2   |       | Nut, Lock                                      |
| 40    | 6506-026    | 1   |       | Mag Carburetor Assembly (inc. 1-32)            |
| 40    | 6506-025    | 1   |       | Center Carburetor Assembly (inc. 1-22 & 27-30) |
| 40    | 6506-024    | 1   |       | PTO Carburetor Assembly (inc. 1-22 & 27-30)    |
| 41    | 6505-916    | 3   |       | Gasket                                         |
| 42    | 6505-919    | 1   |       | Rod Assembly (inc. 43-47, 53)                  |
| 43    | 6505-858    | 1   |       | Rod - End - Left                               |


1998 TS-R 770 (98DTA-1998)  
CARBURETOR

Page 5 of 71

| Ref # | Part Number | Qty | S/P/F | Description                |
|-------|-------------|-----|-------|----------------------------|
| 44    | 6505-922    | 1   |       | Rod - Center               |
| 45    | 6505-860    | 2   |       | Nut - Left                 |
| 46    | 6505-920    | 2   |       | Nut - Right                |
| 47    | 6505-921    | 2   | /P    | Adjuster, Throttle Linkage |
| 48    | 0624-289    | 2   |       | Screw, Cap                 |
| 49    | 0624-120    | 14  |       | Clamp                      |
| 50    | 0610-107    | 1   |       | Hose, Impulse              |
| 51    | 0670-573    | 1   |       | Pump, Fuel                 |
| 52    | 0624-022    | 2   |       | Washer                     |
| 53    | 6505-861    | 1   |       | Rod - End - Right          |

1998 TS-R 770 (98DTA-1998)  
CRANKCASE ASSEMBLY

Page 6 of 71



1998 TS-R 770 (98DTA-1998)  
CRANKCASE ASSEMBLY

Page 7 of 71

| Ref # | Part Number | Qty | S/P/F | Description                   |
|-------|-------------|-----|-------|-------------------------------|
| 1     | 3008-426    | 1   | /P    | Crankcase Assembly (inc. 2-5) |
| 2     | 3008-210    | 4   | /P    | Screw, Cap                    |
| 3     | 3008-211    | 2   | S     | Screw, Cap                    |
| 4     | 3008-212    | 8   | /P    | Screw, Cap                    |
| 5     | 3008-199    | 2   | /P    | Pin                           |
| 6     | 3008-100    | 1   |       | Bladder, Magneto Case         |
| 7     | 3008-105    | 2   |       | Bushing, Pinion Shaft         |
| 8     | 3008-546    | 1   |       | Clamp                         |
| 9     | 3008-200    | 1   | /P    | Hose, Vacuum                  |
| 10    | 3008-039    | 2   |       | Clamp, Hose                   |




1998 TS-R 770 (98DTA-1998)  
CRANKSHAFT ASSEMBLY

Page 9 of 71

| Ref # | Part Number | Qty | S/P/F | Description                      |
|-------|-------------|-----|-------|----------------------------------|
| 1     | 3008-412    | 2   | S     | Piston, Standard                 |
| 1     | 3008-414    | 2   |       | Piston, Optional (+ 0.010 in.)   |
| 1     | 3008-416    | 2   |       | Piston, Optional (+ 0.020 in.)   |
| 2     | 3008-413    | 2   |       | Ring Set, Standard               |
| 2     | 3008-415    | 2   |       | Ring Set, Optional (+ 0.010 in.) |
| 2     | 3008-417    | 2   |       | Ring Set, Optional (+ 0.020 in.) |
| 3     | 3008-482    | 2   | /P    | Pin                              |
| 4     | 3003-433    | 2   | /P    | Bearing                          |
| 5     | 3003-439    | 4   | /P    | Ring, Snap                       |
| 6     | 3008-428    | 1   |       | Crankshaft Assembly (inc. 7-20)  |
| 7     | 3008-427    | 2   |       | Connecting Rod                   |
| 8     | 3008-429    | 1   | /P    | Crank Pin                        |
| 9     | 3008-430    | 1   |       | Crankshaft, Right                |
| 10    | 3008-431    | 1   |       | Crankshaft, Center               |
| 11    | 3008-432    | 1   |       | Wheel, Crankshaft                |
| 12    | 3008-433    | 1   |       | Crankshaft, Left                 |
| 13    | 3008-069    | 1   |       | Balancer                         |
| 14    | 3003-606    | 1   |       | Race, Center                     |
| 15    | 3003-453    | 1   |       | Ring, Center                     |
| 16    | 3008-019    | 1   |       | Washer                           |
| 17    | 3008-421    | 4   | /P    | Bearing                          |
| 18    | 3008-495    | 1   | /P    | Washer                           |
| 19    | 3008-423    | 2   |       | Bearing                          |
| 20    | 3004-372    | 3   | S     | Screw, Machine                   |
| 21    | 3003-658    | 4   | /P    | Pin                              |
| 22    | 3008-072    | 1   |       | Spacer, Crankshaft               |
| 23    | 3003-367    | 2   |       | Seal, Oil                        |
| 24    | 3002-355    | 1   |       | Seal, Oil - Center               |
| 25    | 3003-359    | 1   |       | C-Ring                           |

1998 TS-R 770 (98DTA-1998)  
CYLINDER ASSEMBLY

Page 10 of 71




1998 TS-R 770 (98DTA-1998)  
CYLINDER ASSEMBLY

Page 11 of 71

| Ref # | Part Number | Qty | S/P/F | Description           |
|-------|-------------|-----|-------|-----------------------|
| 1     | 3008-381    | 10  |       | Screw, Cap            |
| 2     | 3008-459    | 1   | /P    | Screw, Cap            |
| 3     | 0217-709    | 2   |       | Spark Plug (BR9EYA)   |
| 4     | 3008-531    | 1   | /P    | Head, Cylinder        |
| 5     | 3008-538    | 1   | S     | Gasket, Cylinder Head |
| 6     | 3008-209    | 4   | /P    | Nut                   |
| 7     | 3008-207    | 4   | /P    | Washer, Lock          |
| 8     | 3008-237    | 4   | S     | Washer                |
| 9     | 1673-162    | 1   |       | T-Connection          |
| 10    | 3008-425    | 1   | /P    | Cylinder              |
| 11    | 3008-358    | 1   | /P    | Clamp                 |
| 12    | 1673-190    | 1   |       | Plug                  |
| 13    | 3008-411    | 1   |       | Gasket, Cylinder      |
| 14    | 3008-394    | 1   | /P    | Stud                  |
| 15    | 3008-208    | 1   |       | Nut                   |
| 16    | 3008-300    | 4   |       | Stud                  |
| 17    | 3008-013    | 1   |       | Screw, Cap            |
| 18    | 3008-047    | 1   |       | Zinc, Anode (inc. 17) |
| 19    | 3008-146    | 2   |       | Pin                   |
| 20    | 1673-170    | 1   |       | Jet Restrictor        |
| 21    | 0623-365    | 4   |       | Clamp, Hose           |
| 22    | 0624-016    | 4   |       | Clamp                 |
| 23    | 0710-191    | 0   |       | Hose, Water           |
| 24    | 0610-268    | 0   |       | Hose, Water           |

1998 TS-R 770 (98DTA-1998)  
DECAL AND FOOTPAD ASSEMBLY

Page 12 of 71



1998 TS-R 770 (98DTA-1998)


Page 13 of 71

## DECAL AND FOOTPAD ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                                |
|-------|-------------|-----|-------|--------------------------------------------|
| 1     | 0614-368    | 1   |       | Decal, Deck - Upper Starboard (770)        |
| 1     | 0614-369    | 1   |       | Decal, Deck - Upper Port (770)             |
| 2     | 0623-725    | 72  | /P    | Clip, Retaining                            |
| 3     | 0614-364    | 1   |       | Decal, Hull - Starboard "Tigershark" (770) |
| 3     | 0614-365    | 1   |       | Decal, Hull - Port "Tigershark" (770)      |
| 4     | 0614-370    | 1   |       | Decal, Deck - Lower Starboard (770)        |
| 4     | 0614-371    | 1   |       | Decal, Deck - Lower Port (770)             |
| 5     | 0614-438    | 1   |       | Decal, Deck - Lower Starboard - Aft (770)  |
| 5     | 0614-439    | 1   |       | Decal, Deck - Lower Port - Aft (770)       |
| 6     | 0617-259    | 1   |       | Foam, Deck - Left                          |
| 7     | 0614-350    | 1   |       | Decal, Regulation White (770)              |
| 8     | 0614-154    | 1   |       | Decal, Caution - Uprighting                |
| 9     | 0614-066    | 1   |       | Decal, USCG Exemption (770)                |
| 10    | 0614-059    | 1   |       | Decal, Common Sense (770)                  |
| 11    | 0614-308    | 1   |       | Decal, Console (770)                       |
| 12    | 0614-300    | 1   |       | Decal, Oil Filler                          |
| 13    | 1611-866    | 1   |       | Decal, Warning - Gas Vapors                |
| 14    | 0614-309    | 1   |       | Decal, Instrument Panel                    |
| 15    | 0617-258    | 1   |       | Foam, Deck - Starboard                     |
| 16    | 0614-405    | 1   |       | Decal, Warning Fuel (770)                  |
| 17    | 0773-847    | 1   |       | Pad, Foot - Assembly                       |
| 17    | 1673-246    | 1   |       | Pad, Foot - Forward Starboard              |
| 17    | 1673-247    | 1   |       | Pad, Foot - Forward Port                   |
| 18    | 1673-292    | 1   |       | Pad, Knee - Starboard                      |
| 18    | 1673-293    | 1   |       | Pad, Knee - Port                           |
| 19    | 1673-248    | 1   |       | Pad, Foot - Port                           |
| 20    | 1673-244    | 1   |       | Pad, Foot - Starboard                      |
| 20    | 1673-245    | 1   |       | Pad, Foot - Port                           |
| 21    | 0614-366    | 1   |       | Decal, Side - Starboard (770)              |
| 21    | 0614-367    | 1   |       | Decal, Side - Port (770)                   |
| 22    | 0614-363    | 1   |       | Decal, Crest (770)                         |
| 23    | 3611-003    | 1   |       | Decal, "Made In The U.S.A."                |

1998 TS-R 770 (98DTA-1998)  
ELECTRICAL MODULE AND BATTERY

Page 14 of 71



1998 TS-R 770 (98DTA-1998)


Page 15 of 71

## ELECTRICAL MODULE AND BATTERY

| Ref # | Part Number | Qty | S/P/F | Description                 |
|-------|-------------|-----|-------|-----------------------------|
| 1     | 3008-279    | 1   | /P    | Regulator Assembly (inc. 2) |
| 2     | 3008-479    | 2   |       | Screw, Regulator            |
| 3     | 3008-337    | 2   |       | Washer, Regulator           |
| 4     | 3008-566    | 1   |       | Unit, CDI (770)             |
| 5     | 3008-478    | 10  |       | Screw, Cap                  |
| 6     | 3008-465    | 1   |       | Case                        |
| 7     | 3008-283    | 1   | /P    | Cover                       |
| 8     | 3008-284    | 1   | /P    | Cover                       |
| 9     | 3008-285    | 1   | /P    | Packing                     |
| 10    | 0673-755    | 1   |       | Vent, Fuel                  |
| 11    | 3008-124    | 3   |       | Holder                      |
| 12    | 3008-125    | 1   |       | Holder                      |
| 13    | 3008-477    | 4   |       | Screw, Cap                  |
| 14    | 3008-217    | 1   |       | Screw, Cap                  |
| 15    | 3008-330    | 1   | S/P   | Sensor Assembly (inc. 16)   |
| 16    | 3008-134    | 1   |       | Supporter                   |
| 17    | 3008-219    | 3   |       | Screw, Machine              |
| 18    | 3008-040    | 1   |       | Clamp                       |
| 19    | 1673-363    | 1   | /P    | Pad, Battery                |
| 20    | 3008-336    | 1   | /P    | Base, Regulator             |
| 21    | 0624-290    | 4   |       | Screw, Cap                  |
| 22    | 0624-228    | 4   |       | Washer                      |
| 23    | 0670-295    | 1   |       | Valve, Check                |
| 24    | 0623-502    | 1   |       | Clamp                       |
| 25    | 0610-008    | 0   | /P    | Hose - 25 ft                |
| 26    | 1673-212    | 1   |       | Cover, Battery              |
| 27    | 0773-805    | 3   |       | Tiedown                     |
| 28    | 0645-045    | 6   |       | Cap, Battery                |
| 29    | 0645-232    | 1   | S     | Battery (inc. 28)           |
| 30    | 0624-323    | 1   |       | Clamp, Hose - Battery       |
| 31    | 0623-063    | 1   |       | Clamp                       |
| 32    | 0624-115    | 4   |       | Washer, Lock                |
| 33    | 3002-964    | 1   | /P    | Clamp                       |

1998 TS-R 770 (98DTA-1998)  
ENGINE AND RELATED ASSEMBLY

Page 16 of 71



1998 TS-R 770 (98DTA-1998)


Page 17 of 71

## ENGINE AND RELATED ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                                     |
|-------|-------------|-----|-------|-------------------------------------------------|
| 1     | 0662-129    | 1   | /P    | Engine                                          |
| 2     | 3008-054    | 2   |       | Damper, Engine                                  |
| 3     | 0624-149    | 8   |       | Nut                                             |
| 4     | 0673-508    | 0   | /P    | Shim, Engine Mount - 0.125 in.                  |
| 4     | 0673-509    | 0   |       | Shim, Engine Mount - 0.063 in.                  |
| 5     | 0624-014    | 0   | /P    | Shim - 0.5 mm                                   |
| 5     | 0624-015    | 0   | /P    | Shim - 1.5 mm                                   |
| 6     | 0624-406    | 4   |       | Washer                                          |
| 7     | 3008-203    | 4   | /P    | Screw, Cap                                      |
| 8     | 0624-421    | 4   |       | Screw, Cap                                      |
| 9     | 3008-456    | 2   |       | Mount, Engine                                   |
| 10    | 0624-028    | 8   |       | Washer                                          |
| 11    | 0608-176    | 1   |       | Plate, Engine Mount                             |
| 12    | 0624-447    | 1   |       | Washer                                          |
| 13    | 0675-174    | 1   |       | Coupler, Engine                                 |
| 14    | 0775-095    | 1   |       | Housing, Seal - Assembly (inc. 15-18, 20, & 26) |
| 15    | 0675-130    | 2   |       | Bearing                                         |
| 16    | 0675-169    | 2   | S     | Seal                                            |
| 17    | 0675-129    | 1   |       | Housing/Bearing - Floating                      |
| 18    | 0624-341    | 2   |       | Fitting, Grease                                 |
| 19    | 0624-463    | 1   |       | Clamp                                           |
| 20    | 0710-218    | 1   |       | Hose, Coupler                                   |
| 21    | 0624-012    | 4   |       | Washer, Lock                                    |
| 22    | 0624-390    | 2   |       | Clamp, Hose                                     |
| 23    | 0775-104    | 1   | S     | Guard, Coupler - Assembly (inc. 24)             |
| 24    | 0614-429    | 1   |       | Decal, Warning                                  |
| 25    | 0775-099    | 1   |       | Isolater, Clamp                                 |
| 26    | 1673-476    | 1   |       | Clamp, Shrink                                   |
| 27    | 0624-448    | 1   |       | Washer                                          |
| 28    | 0624-465    | 8   |       | Washer, Lock                                    |

1998 TS-R 770 (98DTA-1998)  
EXHAUST ASSEMBLY

Page 18 of 71




1998 TS-R 770 (98DTA-1998)  
EXHAUST ASSEMBLY

Page 19 of 71

| Ref # | Part Number | Qty | S/P/F | Description                |
|-------|-------------|-----|-------|----------------------------|
| 1     | 0612-789    | 1   | S     | Chamber, Expansion         |
| 2     | 0612-817    | 1   |       | Manifold, Exhaust          |
| 3     | 0612-813    | 1   | S     | Gasket, Expansion Chamber  |
| 4     | 3008-434    | 1   |       | Gasket, Exhaust Manifold   |
| 5     | 0612-916    | 1   | /P    | Bracket, Expansion Chamber |
| 6     | 0624-390    | 1   |       | Clamp, Hose                |
| 7     | 0624-344    | 1   |       | Screw, Cap                 |
| 8     | 0624-018    | 2   |       | Clamp, Hose                |
| 9     | 0624-402    | 9   |       | Screw, Cap                 |
| 10    | 0610-314    | 1   | /P    | Hose, Exhaust - Out        |
| 11    | 0712-231    | 1   |       | Resonator                  |
| 12    | 0624-383    | 5   |       | Stud                       |
| 13    | 0610-303    | 1   |       | Hose, Exhaust - In         |
| 14    | 0624-149    | 5   |       | Nut                        |
| 15    | 0624-028    | 14  |       | Washer                     |
| 16    | 0624-008    | 1   |       | Washer                     |
| 17    | 0624-027    | 14  |       | Washer, Lock               |
| 18    | 0624-012    | 1   |       | Washer, Lock               |
| 19    | 0673-377    | 1   |       | Outlet, Water              |
| 20    | 0612-676    | 1   |       | Gasket                     |
| 21    | 0612-762    | 1   | /P    | Outlet, Exhaust            |
| 22    | 0610-301    | 1   |       | Hose, Exhaust - Out        |
| 23    | 0712-227    | 1   |       | Muffler                    |
| 24    | 0773-805    | 2   |       | Tiedown, Rubber            |
| 25    | 0612-576    | 1   |       | Nut, Exhaust Outlet        |
| 26    | 0624-169    | 5   |       | Clamp, Hose                |
| 27    | 0676-002    | 1   |       | Fitting                    |
| 28    | 1673-101    | 1   | /P    | Fitting, Elbow             |
| 29    | 0676-003    | 2   |       | Plug                       |
| 30    | 0676-012    | 1   | S     | Plug, Drain                |
| 31    | 1673-363    | 1   | /P    | Pad, Muffler               |
| 32    | 0673-378    | 1   | S     | Nut, Outlet                |
| 33    | 0612-456    | 1   |       | Seal, Outlet               |
| 34    | 0710-191    | 0   |       | Hose                       |

1998 TS-R 770 (98DTA-1998)  
EXHAUST MANIFOLD ASSEMBLY

Page 20 of 71




1998 TS-R 770 (98DTA-1998)  
EXHAUST MANIFOLD ASSEMBLY

Page 21 of 71

| Ref # | Part Number | Qty | S/P/F | Description                    |
|-------|-------------|-----|-------|--------------------------------|
| 1     | 3008-047    | 1   |       | Zinc, Protection               |
| 2     | 3008-444    | 1   | /P    | Manifold, Exhaust - Assembly   |
| 3     | 3008-268    | 1   |       | Cover, Exhaust Manifold        |
| 4     | 3008-519    | 1   | /P    | Gasket, Exhaust Manifold Cover |
| 5     | 3008-520    | 1   | /P    | Cover, Protection Zinc         |
| 6     | 3008-407    | 3   | /P    | Gasket, Exhaust Manifold       |
| 7     | 3008-312    | 6   |       | Washer                         |
| 8     | 3008-250    | 1   |       | O-Ring, Protection Zinc Cover  |
| 9     | 3008-251    | 1   |       | Hose, Drain                    |
| 10    | 3008-527    | 3   |       | Hose, Cooling                  |
| 11    | 3008-037    | 2   | /P    | Clip, Drain Hose               |
| 12    | 3008-366    | 6   |       | Clip, Cooling Hose             |
| 13    | 3008-391    | 6   |       | Bolt, Stud                     |
| 14    | 3008-213    | 7   | /P    | Screw, Cap                     |
| 15    | 3008-392    | 6   |       | Washer, Lock                   |
| 16    | 3008-364    | 3   |       | Fitting                        |
| 17    | 3004-478    | 6   | S     | Nut                            |

1998 TS-R 770 (98DTA-1998)  
EXPANSION CHAMBER ASSEMBLY

Page 22 of 71



1998 TS-R 770 (98DTA-1998)


Page 23 of 71

## EXPANSION CHAMBER ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                |
|-------|-------------|-----|-------|----------------------------|
| 1     | 0612-802    | 1   | /P    | Chamber, Expansion         |
| 2     | 0612-801    | 1   | S     | Pipe, Head                 |
| 3     | 0612-804    | 1   | S     | Bracket, Expansion Chamber |
| 4     | 0624-008    | 5   |       | Washer                     |
| 5     | 0624-012    | 5   |       | Washer, Lock               |
| 6     | 0624-238    | 5   |       | Screw, Cap                 |
| 7     | 0624-028    | 10  |       | Washer                     |
| 8     | 0624-027    | 10  |       | Washer, Lock               |
| 9     | 0624-149    | 2   |       | Nut                        |
| 10    | 0624-313    | 8   | /P    | Screw, Cap                 |
| 11    | 0624-378    | 2   |       | Spacer                     |
| 12    | 0612-460    | 1   |       | Gasket, Manifold           |
| 13    | 0612-461    | 1   |       | Gasket, Expansion Chamber  |
| 14    | 0612-627    | 1   |       | Gasket, Tailpipe           |
| 15    | 0612-803    | 1   | S     | Pipe, Tail                 |
| 16    | 0624-169    | 1   |       | Clamp, Hose                |
| 17    | 0624-022    | 3   |       | Washer                     |
| 18    | 0624-036    | 3   |       | Washer, Lock               |
| 19    | 0624-314    | 3   |       | Screw, Cap                 |
| 20    | 1673-164    | 1   |       | Fitting, Brass             |
| 21    | 0624-016    | 6   |       | Clamp, Hose                |
| 22    | 0610-268    | 0   |       | Hose, Water - 25 ft        |
| 23    | 0673-378    | 1   | S     | Nut, Outlet                |
| 24    | 0612-456    | 1   |       | Seal, Outlet               |
| 25    | 0673-374    | 1   |       | Outlet, Water              |
| 26    | 0673-136    | 1   |       | T-Connection               |

1998 TS-R 770 (98DTA-1998)  
FUEL TANK ASSEMBLY

Page 24 of 71




1998 TS-R 770 (98DTA-1998)  
FUEL TANK ASSEMBLY

Page 25 of 71

| Ref # | Part Number | Qty | S/P/F | Description                                     |
|-------|-------------|-----|-------|-------------------------------------------------|
| 1     | 0770-239    | 1   |       | Tank, Fuel-Assembly (inc. 2,11,14,16,&20) (770) |
| 2     | 0670-564    | 1   |       | Outlet, Fuel Tank - Brass (770)                 |
| 3     | 0624-390    | 3   |       | Clamp, Hose                                     |
| 4     | 0670-398    | 1   | S/P   | Cap, Filler Neck (770)                          |
| 5     | 0670-428    | 1   | S     | Neck, Filler (770)                              |
| 6     | 0670-688    | 1   |       | Seal, Filler Neck                               |
| 7     | 0670-548    | 1   |       | Nut, Filler Neck                                |
| 8     | 0624-120    | 19  |       | Clamp, Hose (770)                               |
| 9     | 0710-425    | 0   | /P    | Hose, Fuel - 25 ft                              |
| 10    | 0624-312    | 5   |       | Screw, Cap                                      |
| 11    | 0670-755    | 1   |       | Tube, Drop - Reserve (770)                      |
| 12    | 1673-590    | 1   |       | Plate, Backing - Fuel Valve                     |
| 13    | 0670-474    | 1   |       | Gasket, Fuel Sensor                             |
| 14    | 0670-607    | 1   |       | Tube, Drop (770)                                |
| 15    | 0624-149    | 4   |       | Nut, Lock                                       |
| 16    | 0670-655    | 2   |       | Fitting, Outlet (770)                           |
| 17    | 0610-047    | 1   |       | Hose, Filler                                    |
| 18    | 0510-335    | 2   | /P    | Filter, Fuel                                    |
| 19    | 0624-125    | 8   | /P    | Washer                                          |
| 20    | 0115-607    | 1   | S     | Fitting, Elbow                                  |
| 21    | 0109-332    | 1   |       | T-Connection                                    |
| 22    | 0123-788    | 2   | /P    | Tie, Cable                                      |
| 23    | 0610-059    | 2   |       | Valve, Check                                    |
| 24    | 0673-755    | 1   |       | Vent, Fuel                                      |
| 25    | 0623-063    | 1   |       | Clamp, Hose                                     |
| 26    | 0670-710    | 1   |       | Valve, Fuel Reserve                             |
| 27    | 0624-428    | 1   |       | Screw, Machine                                  |
| 28    | 0623-693    | 1   |       | Washer                                          |
| 29    | 0623-687    | 1   |       | Nut                                             |
| 30    | 1673-274    | 1   |       | Knob, Fuel                                      |
| 31    | 0675-070    | 4   |       | Spacer, Fuel Tank                               |
| 32    | 0620-197    | 1   |       | Sender, Fuel Level                              |
| 33    | 0624-120    | 1   |       | Clamp, Hose (770)                               |

1998 TS-R 770 (98DTA-1998)  
HANDLEBAR ASSEMBLY

Page 26 of 71




1998 TS-R 770 (98DTA-1998)  
HANDLEBAR ASSEMBLY

Page 27 of 71

| Ref # | Part Number | Qty | S/P/F | Description                           |
|-------|-------------|-----|-------|---------------------------------------|
| 1     | 0673-990    | 2   | S     | Grip, Handlebar                       |
| 2     | 0773-018    | 1   |       | Throttle, Assembly (inc. 3-8)         |
| 3     | 0605-234    | 1   |       | Lever, Throttle                       |
| 4     | 0605-236    | 1   |       | Pin, Throttle Lever                   |
| 5     | 0605-235    | 1   |       | Housing, Throttle                     |
| 6     | 0624-099    | 1   |       | Washer                                |
| 7     | 0624-113    | 2   |       | C-Clip                                |
| 8     | 0624-132    | 1   |       | Screw, Machine                        |
| 9     | 0624-056    | 4   |       | Screw, Cap                            |
| 10    | 0673-282    | 4   |       | Cap, Steering Adjuster                |
| 11    | 0773-608    | 1   |       | Handlebar                             |
| 12    | 0687-076    | 1   |       | Cable, Throttle (770)                 |
| 13    | 0624-250    | 4   |       | Nut, Lock                             |
| 14    | 0123-788    | 0   | /P    | Tie, Cable                            |
| 15    | 0609-309    | 1   |       | Switch, Start/Trim/Bilge (inc. 16)    |
| 16    | 0624-148    | 3   |       | Screw, Machine                        |
| 17    | 0609-427    | 1   | S     | Cord, Tether                          |
| 18    | 0624-104    | 1   |       | C-Clip                                |
| 19    | 0773-848    | 1   |       | Handlebar Pad - Assembly (inc. 20-22) |
| 20    | 1673-242    | 1   |       | Pad, Handlebar                        |
| 21    | 0624-350    | 6   | S     | Screw, Cap                            |
| 22    | 0           | 1   | F     | Cover, Handlebar Pad                  |
| 23    | 1673-095    | 1   |       | Washer, Rubber - Handlebar            |
| 24    | 0624-216    | 2   |       | Rivet                                 |
| 25    | 1673-111    | 2   |       | Plug                                  |

1998 TS-R 770 (98DTA-1998)  
HATCH COVER AND STORAGE TRAY

Page 28 of 71



1998 TS-R 770 (98DTA-1998)


Page 29 of 71

## HATCH COVER AND STORAGE TRAY

| Ref # | Part Number | Qty | S/P/F | Description                          |
|-------|-------------|-----|-------|--------------------------------------|
| 1     | 0673-882    | 1   |       | Latch, Hatch Cover                   |
| 2     | 1673-041    | 1   |       | Cover, Hatch                         |
| 3     | 0624-004    | 2   |       | Washer                               |
| 4     | 0624-092    | 2   |       | Screw, Cap                           |
| 5     | 1673-567    | 1   | /P    | Seal, Hatch                          |
| 6     | 0623-685    | 5   |       | Rivet                                |
| 7     | 0773-217    | 1   |       | Tiedown, Tool Kit                    |
| 8     | 1673-046    | 1   |       | Tube, Fire Extinguisher              |
| 9     | 8060-633    | 6   | /P    | Rivet                                |
| 10    | 0406-208    | 1   |       | Lid, Storage Cover                   |
| 11    | 1673-146    | 1   |       | Seal                                 |
| 12    | 0406-205    | 1   | /P    | Ring, Mount                          |
| 13    | 0678-399    | 1   |       | Kit, Tool                            |
| 14    | 1673-566    | 1   | /P    | Tray, Storage                        |
| 15    | 0773-926    | 1   |       | Chain, Cover                         |
| 16    | 0673-973    | 1   |       | Seal, Storage Cover                  |
| 17    | 1673-155    | 1   |       | Gasket, Mounting - Storage Container |
| 18    | 0673-652    | 1   | /P    | Container, Storage                   |
| 19    | 0610-260    | 1   |       | Hose, Air Intake                     |
| 20    | 0624-200    | 2   |       | Washer, Lock                         |
| 21    | 0623-603    | 4   |       | Washer, Backup                       |
| 22    | 0614-431    | 1   |       | Decal, Storage Tray                  |
| 23    | 0624-115    | 3   |       | Washer, Lock                         |
| 24    | 0624-432    | 3   |       | Screw, Self-Tapping                  |
| 25    | 0614-392    | 1   |       | Decal, Hatch Cover - Starboard       |
|       | 0           | 1   |       | Decal, Hatch Cover - Port            |

1998 TS-R 770 (98DTA-1998)  
HULL AND RELATED PARTS ASSEMBLY

Page 30 of 71



1998 TS-R 770 (98DTA-1998)


Page 31 of 71

## HULL AND RELATED PARTS ASSEMBLY

| Ref # | Part Number | Qty | S/P/F | Description                |
|-------|-------------|-----|-------|----------------------------|
| 1     | 0773-924    | 1   |       | Hull/Deck - Assembly (770) |
| 2     | 0624-112    | 2   | /P    | Screw, Cap                 |
| 3     | 0624-022    | 2   |       | Washer                     |
| 4     | 1673-032    | 1   |       | Hinge, Hatch               |
| 5     | 1673-031    | 1   |       | Plate, Backing - Hinge     |
| 6     | 0624-250    | 2   |       | Nut, Lock                  |
| 7     | 1673-281    | 1   |       | Bushing, Boweye            |
| 8     | 1673-265    | 1   | S     | Nose, Cone                 |
| 9     | 0673-378    | 1   | S     | Nut, Boweye Bushing        |
| 10    | 0624-072    | 4   |       | Rivet                      |
| 11    | 1673-034    | 1   |       | Strike, Hatch Latch        |
| 12    | 0623-737    | 8   |       | Insert, Brass              |
| 13    | 0623-726    | 14  |       | Clip, Retainer             |
| 14    | 1673-266    | 1   |       | Grille, Vent - Starboard   |
| 14    | 1673-267    | 1   |       | Grille, Vent - Port        |
| 15    | 0624-005    | 2   | /P    | Nut, Lock                  |
| 16    | 0773-516    | 1   | /P    | Boweye                     |
| 17    | 0673-897    | 1   |       | Strap, Reinforcement       |
| 18    | 0624-299    | 2   |       | Washer, Sealing            |
| 19    | 0624-247    | 2   |       | Washer                     |
| 20    | 0624-089    | 4   |       | Nut, Lock                  |
| 21    | 1673-270    | 1   |       | Rail, Rub - Starboard      |
| 21    | 1673-271    | 1   |       | Rail, Rub - Port           |
| 22    | 0624-030    | 48  |       | Rivet                      |
| 23    | 1673-200    | 2   |       | Plate, Nut                 |
| 24    | 0775-073    | 1   | /P    | Plate, Ride                |
| 25    | 0624-184    | 2   |       | Screw, Machine             |
| 26    | 1673-582    | 1   | /P    | Sponson - Starboard        |
| 26    | 1673-583    | 1   | /P    | Sponson - Port             |
| 27    | 0124-065    | 8   |       | Washer, Snap Cap           |
| 28    | 0124-066    | 8   | S     | Cover, Snap Cap            |
| 29    | 0624-271    | 12  |       | Screw, Cap                 |
| 30    | 1673-285    | 1   |       | Cover, Rub Rail            |
| 31    | 0624-228    | 4   |       | Washer, Lock               |
| 32    | 1673-025    | 1   |       | Handle, Grab               |
| 33    | 0624-186    | 4   |       | Screw, Machine             |
| 34    | 0624-429    | 1   |       | U-Bolt                     |
| 35    | 0673-656    | 1   |       | Plate, Backing - Eyehook   |
| 36    | 1673-083    | 1   |       | Gasket, Eyehook            |
| 37    | 0624-258    | 2   |       | Nut, Lock                  |
| 38    | 0623-737    | 2   |       | Insert, Brass              |
| 39    | 0624-004    | 4   |       | Washer, Backup             |
| 40    | 0624-159    | 2   |       | Washer                     |
| 41    | 0624-099    | 2   |       | Washer                     |

1998 TS-R 770 (98DTA-1998)  
IGNITION COIL

Page 32 of 71




1998 TS-R 770 (98DTA-1998)  
IGNITION COIL

Page 33 of 71

| Ref # | Part Number | Qty | S/P/F | Description              |
|-------|-------------|-----|-------|--------------------------|
| 1     | 3008-532    | 1   |       | Coil Assembly, Ignition  |
| 2     | 3008-402    | 2   |       | Screw, Machine           |
| 3     | 3008-445    | 2   |       | Tube                     |
| 4     | 3008-334    | 2   | /P    | Grommet                  |
| 5     | 3008-129    | 2   | /P    | Protector, Lead Wire     |
| 6     | 3008-045    | 1   |       | Clip                     |
| 7     | 3003-737    | 2   | S     | Cap Assembly, Spark Plug |
| 8     | 0693-275    | 2   |       | Tie, Cable               |

1998 TS-R 770 (98DTA-1998)  
IMPELLER DRIVE ASSEMBLY


Page 34 of 71



1998 TS-R 770 (98DTA-1998)  
IMPELLER DRIVE ASSEMBLY

Page 35 of 71

| Ref # | Part Number | Qty | S/P/F | Description            |
|-------|-------------|-----|-------|------------------------|
| 1     | 0624-028    | 4   |       | Washer                 |
| 2     | 0675-078    | 1   |       | O-Ring                 |
| 3     | 0624-186    | 5   |       | Screw, Machine         |
| 4     | 1673-377    | 1   | S     | Bushing, Trim Ring     |
| 5     | 0624-182    | 4   |       | Washer, Sealing        |
| 6     | 0675-187    | 1   |       | Grommet, Seal          |
| 7     | 0675-193    | 1   |       | Driveshaft (770)       |
| 8     | 0673-618    | 2   | /P    | Bumper, Driveshaft     |
| 9     | 0675-184    | 1   |       | Venturi (770)          |
| 10    | 0675-163    | 1   | S     | Shaft, Rear - Impeller |
| 11    | 0675-085    | 1   |       | Spacer, Impeller       |
| 12    | 0675-084    | 1   |       | Spacer, Bearing        |
| 13    | 0675-127    | 1   |       | O-Ring                 |
| 14    | 0675-107    | 1   |       | Gasket, Pump           |
| 15    | 0673-291    | 3   |       | Bushing                |
| 16    | 0624-272    | 2   |       | Screw, Machine         |
| 17    | 0675-150    | 1   | S     | Ring, Trim             |
| 18    | 0624-125    | 4   | /P    | Washer                 |
| 19    | 0675-138    | 1   |       | Impeller (770)         |
| 20    | 0675-146    | 1   |       | Endcap, Stator         |
| 21    | 0675-224    | 1   | /P    | Stator                 |
| 22    | 0624-090    | 6   |       | Nut, Lock              |
| 23    | 0675-191    | 1   | /P    | Grate, Inlet           |
| 24    | 0624-273    | 2   |       | Screw, Machine         |
| 25    | 0775-023    | 1   | S     | Wear Ring              |
| 26    | 0673-786    | 2   |       | Bracket, Trim Ring     |
| 27    | 0675-119    | 1   | S     | Seal                   |
| 28    | 0624-008    | 4   |       | Washer                 |
| 29    | 0673-609    | 2   |       | Bearing, Stator        |
| 30    | 0673-608    | 2   |       | O-Ring                 |
| 31    | 0673-607    | 1   |       | O-Ring                 |
| 32    | 0624-386    | 4   |       | Screw, Cap             |
| 33    | 0624-417    | 6   |       | Stud                   |
| 34    | 0624-314    | 2   |       | Screw, Cap             |
| 35    | 0624-174    | 4   |       | Screw, Cap             |
| 36    | 0624-183    | 2   |       | Screw, Machine (770)   |
| 37    | 0624-026    | 2   |       | Screw, Cap             |
| 38    | 0624-084    | 1   |       | Anode, Zinc            |
| 39    | 0624-027    | 2   |       | Washer, Lock           |
| 40    | 0624-036    | 2   |       | Washer, Lock           |
| 41    | 0675-103    | 1   |       | Nozzle, Steering (770) |
| 42    | 0624-022    | 2   |       | Washer                 |
| 43    | 0624-012    | 4   |       | Washer, Lock           |
| 44    | 0624-250    | 5   |       | Nut, Lock (770)        |
| 45    | 0624-317    | 3   |       | Washer, Lock           |




1998 TS-R 770 (98DTA-1998)  
INSTRUMENT ASSEMBLY

Page 37 of 71

| Ref # | Part Number | Qty | S/P/F | Description                       |
|-------|-------------|-----|-------|-----------------------------------|
| 1     | 0620-193    | 1   |       | Gauge, Trim                       |
| 2     | 0620-190    | 1   | S     | Gauge, Fuel                       |
| 3     | 0620-191    | 1   |       | Tachometer (770)                  |
| 4     | 0620-189    | 1   |       | Speedometer                       |
| 5     | 0624-323    | 2   |       | Clamp                             |
| 6     | 0673-809    | 0   | /P    | Hose                              |
| 7     | 0673-348    | 1   |       | Nut, Pitot                        |
| 8     | 0673-349    | 1   |       | Seal, Pitot                       |
| 9     | 0673-362    | 1   | S     | Pitot                             |
| 10    | 0620-173    | 2   |       | Backclamp, Fuel Gauge/Trim Gauge  |
| 11    | 1673-387    | 1   | S     | Fitting, Restrictor - Speedometer |
| 12    | 0620-199    | 2   |       | Backclamp, Speedometer            |
| 12    | 0620-201    | 2   |       | Backclamp, Tachometer             |
| 13    | 0623-702    | 6   |       | Washer, Star                      |
| 14    | 0623-701    | 6   |       | Nut                               |
| 15    | 1673-399    | 1   |       | Seal, Bulkhead                    |
| 16    | 0123-788    | 1   | /P    | Tie, Cable                        |

1998 TS-R 770 (98DTA-1998)  
INTAKE ASSEMBLY

Page 38 of 71




1998 TS-R 770 (98DTA-1998)  
INTAKE ASSEMBLY

Page 39 of 71

| Ref # | Part Number | Qty | S/P/F | Description                            |
|-------|-------------|-----|-------|----------------------------------------|
| 1     | 0624-408    | 6   |       | Screw, Cap                             |
| 2     | 0624-022    | 6   |       | Washer                                 |
| 3     | 1673-255    | 1   |       | Cover, Sound Attenuator                |
| 4     | 0624-036    | 6   |       | Washer, Lock                           |
| 5     | 1673-375    | 1   |       | Base, Sound Attenuator - Mag Side      |
| 5     | 1673-403    | 1   |       | Base, Sound Attenuator - PTO Side      |
| 6     | 0624-112    | 6   | /P    | Screw, Cap                             |
| 7     | 3008-076    | 4   | S     | Gasket, Reed Valve                     |
| 8     | 0710-425    | 0   | /P    | Hose, Gas - 25 ft                      |
| 9     | 0624-380    | 8   |       | Clamp, Hose                            |
| 10    | 1606-038    | 2   |       | Plug                                   |
| 11    | 0624-027    | 4   |       | Washer, Lock                           |
| 12    | 1673-179    | 2   |       | Gasket, Sound Attenuator               |
| 13    | 0624-338    | 4   | /P    | Screw, Cap                             |
| 14    | 0624-397    | 6   |       | Stud                                   |
| 15    | 0624-028    | 4   |       | Washer                                 |
| 16    | 0670-876    | 1   |       | Carburetor Assembly (inc. Mag and PTO) |
| 16    | 6505-977    | 1   |       | Carburetor - Mag Side                  |
| 16    | 6505-976    | 1   |       | Carburetor - PTO Side                  |
| 17    | 0670-714    | 1   |       | Seal, Strip - Sound Attenuator         |
| 18    | 3008-213    | 6   | /P    | Screw, Cap                             |
| 19    | 3008-087    | 2   | S     | Valve, Check                           |
| 20    | 1673-090    | 2   |       | Gasket, Intake                         |
| 21    | 3008-214    | 4   |       | Nut                                    |
| 22    | 0670-725    | 2   | /P    | Manifold, Intake                       |
| 23    | 3008-483    | 2   |       | Reed Valve Assembly (inc. 24-26)       |
| 24    | 3004-422    | 12  |       | Screw, Cap                             |
| 25    | 3008-074    | 4   |       | Stopper, Reed Valve                    |
| 26    | 3008-075    | 4   |       | Valve, Reed                            |
| 27    | 0687-077    | 1   | /P    | Cable, Choke                           |
| 28    | 0687-051    | 1   | /P    | Nut                                    |
| 29    | 0624-057    | 2   |       | Nut                                    |
| 30    | 6505-855    | 2   |       | Screw, Machine                         |
| 31    | 6505-927    | 1   |       | Throttle Linkage (inc. 32-36)          |
| 32    | 6505-857    | 1   | S     | Adjuster, Throttle Linkage             |
| 33    | 6505-858    | 1   |       | End, Adjuster - Left                   |
| 34    | 6505-859    | 1   |       | Nut - Left                             |
| 35    | 6505-860    | 1   |       | Nut                                    |
| 36    | 6505-861    | 1   |       | End, Adjuster                          |
| 37    | 0624-155    | 2   |       | Screw, Cap                             |
| 38    | 1673-430    | 1   |       | Brace, Sound Attenuator - Dual         |
| 39    | 0624-200    | 2   |       | Washer, Lock                           |
| 40    | 0624-022    | 2   |       | Washer                                 |
| 41    | 0109-332    | 1   |       | T-Connection                           |
| 42    | 0623-640    | 1   |       | Washer, Nylon                          |

1998 TS-R 770 (98DTA-1998)  
MAGNETO

Page 40 of 71




1998 TS-R 770 (98DTA-1998)  
MAGNETO

Page 41 of 71

| Ref # | Part Number | Qty | S/P/F | Description           |
|-------|-------------|-----|-------|-----------------------|
| 1     | 3008-564    | 1   | /P    | Stator                |
| 2     | 3008-278    | 1   |       | Grommet               |
| 3     | 3004-706    | 5   | S/P   | Screw, Cap            |
| 4     | 3004-484    | 3   | S     | Screw, Cap            |
| 5     | 3008-109    | 1   |       | Holder                |
| 6     | 3008-331    | 1   | /P    | Clamp                 |
| 7     | 0693-275    | 1   |       | Clamp                 |
| 8     | 3004-540    | 1   | /P    | Key                   |
| 9     | 3008-565    | 1   |       | Flywheel              |
| 10    | 3008-388    | 1   | S     | Screw, Cap            |
| 11    | 3008-017    | 1   |       | Washer                |
| 12    | 3004-362    | 1   | S/P   | Washer, Lock          |
| 13    | 3008-110    | 1   |       | Holder, Grommet       |
| 14    | 3008-362    | 1   | /P    | Grommet, Magneto Lead |

1998 TS-R 770 (98DTA-1998)  
MAGNETO CASE

Page 42 of 71




1998 TS-R 770 (98DTA-1998)  
MAGNETO CASE

Page 43 of 71

| Ref # | Part Number | Qty | S/P/F | Description   |
|-------|-------------|-----|-------|---------------|
| 1     | 3008-238    | 1   | /P    | Case, Magneto |
| 2     | 3008-053    | 1   |       | O-Ring        |
| 3     | 3008-213    | 6   | /P    | Screw, Cap    |
| 4     | 3008-146    | 2   |       | Pin           |
| 5     | 3008-023    | 1   |       | Plug          |

1998 TS-R 770 (98DTA-1998)  
MAGNETO-SIDE CARBURETOR

Page 44 of 71




1998 TS-R 770 (98DTA-1998)  
MAGNETO-SIDE CARBURETOR

Page 45 of 71

| Ref # | Part Number | Qty | S/P/F | Description                                    |
|-------|-------------|-----|-------|------------------------------------------------|
|       | 0670-876    | 1   |       | Complete Assembly (inc. Mag & PTO Carburetors) |
| 1     | 6505-915    | 4   |       | Screw, Cap                                     |
| 2     | 6505-662    | 1   |       | Cover, Diaphragm                               |
| 3     | 6505-663    | 1   |       | Diaphragm Assembly                             |
| 4     | 6505-692    | 1   |       | Screw, Machine                                 |
| 5     | 6505-664    | 1   |       | Arm                                            |
| 6     | 6505-934    | 1   |       | Spring                                         |
| 7     | 6505-695    | 1   |       | Screw, Machine                                 |
| 8     | 6505-682    | 1   |       | Plate                                          |
| 9     | 6505-944    | 1   |       | Needle Valve Assembly                          |
| 10    | 0           | 1   | F     | Mixing Body                                    |
| 11    | 6505-681    | 1   |       | Pin                                            |
| 12    | 6505-679    | 2   |       | Screw, Machine                                 |
| 13    | 6505-680    | 1   |       | Block, Metering                                |
| 14    | 6505-677    | 1   |       | Gasket                                         |
| 15    | 6505-739    | 1   |       | Main Jet - 125                                 |
| 16    | 6506-023    | 1   |       | Jet, Low Speed - 57.5                          |
| 17    | 6505-668    | 1   |       | Seal                                           |
| 18    | 6505-661    | 1   |       | Washer                                         |
| 19    | 6505-660    | 1   |       | Spring                                         |
| 20    | 6505-852    | 1   |       | Adjuster                                       |
| 21    | 6506-020    | 1   |       | Hose Assembly                                  |
| 22    | 6505-911    | 1   |       | Nut                                            |
| 23    | 6505-923    | 1   |       | Bracket, Cable                                 |
| 24    | 6505-678    | 1   |       | Spring                                         |
| 25    | 6505-703    | 1   |       | Washer                                         |
| 26    | 6505-872    | 1   | /P    | O-Ring                                         |
| 27    | 6505-676    | 1   |       | Filter                                         |
| 28    | 6505-665    | 1   |       | S-Gasket                                       |
| 29    | 6505-953    | 1   |       | Main Jet - Fixed 85                            |
| 30    | 6505-912    | 1   |       | Screw Assembly                                 |
| 31    | 6505-042    | 1   |       | O-Ring                                         |
| 32    | 6505-656    | 1   | /P    | Diaphragm, Damper                              |
| 33    | 6505-652    | 1   |       | Cover, Pump                                    |
| 34    | 6505-938    | 4   |       | Screw w/Washer                                 |
| 35    | 6505-977    | 1   |       | Carburetor Assembly - Mag                      |
| 36    | 6505-653    | 1   |       | Gasket                                         |
| 37    | 6505-654    | 1   |       | Diaphragm, Pump                                |
| 38    | 6505-683    | 1   |       | O-Ring                                         |
| 39    | 0           | 2   | F     | Grommet                                        |
| 40    | 0           | 2   | F     | Valve                                          |
| 41    | 6505-924    | 1   |       | Body Assembly, Diaphragm                       |

1998 TS-R 770 (98DTA-1998)  
MUFFLER ASSEMBLY

Page 46 of 71




1998 TS-R 770 (98DTA-1998)  
MUFFLER ASSEMBLY

Page 47 of 71

| Ref # | Part Number | Qty | S/P/F | Description            |
|-------|-------------|-----|-------|------------------------|
| 1     | 0712-243    | 1   |       | Muffler                |
| 2     | 0610-290    | 1   |       | Hose, Exhaust - In     |
| 3     | 0773-805    | 2   |       | Tiedown, Muffler       |
| 4     | 0612-762    | 1   | /P    | Outlet, Exhaust        |
| 5     | 0624-169    | 3   |       | Clamp, Hose            |
| 6     | 0610-323    | 1   |       | Hose, Exhaust - Out    |
| 7     | 0612-576    | 1   |       | Nut, Exhaust Outlet    |
| 8     | 0612-676    | 1   |       | Gasket, Exhaust - Foam |

1998 TS-R 770 (98DTA-1998)  
OIL PUMP ASSEMBLY

Page 48 of 71




1998 TS-R 770 (98DTA-1998)  
OIL PUMP ASSEMBLY

Page 49 of 71

| Ref # | Part Number | Qty | S/P/F | Description       |
|-------|-------------|-----|-------|-------------------|
| 1     | 3008-435    | 1   |       | Oil Pump Assembly |
| 2     | 3008-030    | 1   |       | O-Ring            |
| 3     | 3008-035    | 2   | /P    | Hose              |
| 4     | 0624-291    | 4   |       | Clamp             |
| 5     | 3008-242    | 1   |       | Screw, Cap        |
| 6     | 3008-243    | 1   |       | Screw, Cap        |

1998 TS-R 770 (98DTA-1998)  
OIL TANK ASSEMBLY

Page 50 of 71




1998 TS-R 770 (98DTA-1998)  
OIL TANK ASSEMBLY

Page 51 of 71

| Ref # | Part Number | Qty | S/P/F | Description                |
|-------|-------------|-----|-------|----------------------------|
| 1     | 0670-580    | 1   | S     | Tank, Oil                  |
| 2     | 0624-046    | 3   |       | Screw, Cap (770)           |
| 3     | 0115-607    | 1   | S     | Outlet, Tank               |
| 4     | 0624-120    | 4   |       | Clamp, Hose                |
| 5     | 0710-425    | 0   | /P    | Hose, Gas - 25 ft          |
| 6     | 0610-059    | 1   |       | Valve, Check               |
| 7     | 0510-335    | 1   | /P    | Filter, Fuel               |
| 8     | 0124-045    | 2   | /P    | Clamp, Hose                |
| 9     | 0670-718    | 1   |       | Fitting, Tank              |
| 10    | 0610-008    | 0   | /P    | Hose, Oil - 25 ft          |
| 11    | 1673-336    | 1   |       | Filter, Oil                |
| 12    | 0624-019    | 2   |       | Clamp, Hose                |
| 13    | 0610-292    | 1   |       | Hose, Filler               |
| 14    | 0624-182    | 6   |       | Washer                     |
| 15    | 0624-036    | 3   |       | Washer, Lock               |
| 16    | 0670-697    | 1   |       | Filler, Oil - Assembly     |
| 17    | 0670-679    | 1   |       | Seal, Oil Filler           |
| 18    | 8060-633    | 3   | /P    | Rivet                      |
| 19    | 0623-603    | 3   |       | Washer                     |
| 20    | 0623-486    | 2   |       | Clamp, Hose                |
| 21    | 0610-018    | 0   | /P    | Hose, Oil - 15 ft          |
| 22    | 0620-196    | 1   | S     | Sensor, Oil Level          |
| 23    | 0609-237    | 1   |       | Seal, Grommet - Oil Sensor |
| 24    | 0670-877    | 1   |       | Oil Cap Assembly           |
| 25    | 0670-878    | 1   |       | Seal, Oil Cap              |

1998 TS-R 770 (98DTA-1998)  
PTO-SIDE CARBURETOR


Page 52 of 71



1998 TS-R 770 (98DTA-1998)  
PTO-SIDE CARBURETOR

Page 53 of 71

| Ref # | Part Number | Qty | S/P/F | Description                                    |
|-------|-------------|-----|-------|------------------------------------------------|
|       | 0670-876    | 1   |       | Complete Assembly (inc. Mag & PTO Carburetors) |
| 1     | 6505-943    | 4   |       | Screw, Cap                                     |
| 2     | 6506-021    | 1   |       | Cover, Diaphragm Assembly                      |
| 3     | 6505-663    | 1   |       | Diaphragm Assembly                             |
| 4     | 6505-692    | 1   |       | Screw, Machine                                 |
| 5     | 6505-664    | 1   |       | Arm                                            |
| 6     | 6505-934    | 1   |       | Spring                                         |
| 7     | 6505-695    | 1   |       | Screw, Machine                                 |
| 8     | 6505-682    | 1   |       | Plate                                          |
| 9     | 6505-944    | 1   |       | Needle Valve Assembly                          |
| 10    | 0           | 1   | F     | Mixing Body                                    |
| 11    | 6505-681    | 1   |       | Pin                                            |
| 12    | 6505-679    | 2   |       | Screw, Machine                                 |
| 13    | 6505-680    | 1   |       | Block, Metering                                |
| 14    | 6505-677    | 1   |       | Gasket                                         |
| 15    | 6505-739    | 1   |       | Main Jet - 125                                 |
| 16    | 6506-023    | 1   |       | Jet, Low Speed - 57.5                          |
| 17    | 6505-668    | 1   |       | Seal                                           |
| 18    | 6505-661    | 1   |       | Washer                                         |
| 19    | 6505-660    | 1   |       | Spring                                         |
| 20    | 6505-852    | 1   |       | Adjuster                                       |
| 21    | 6506-022    | 1   |       | Hose Assembly (inc. 33)                        |
| 22    | 6505-941    | 2   |       | Clip                                           |
| 23    | 6505-914    | 4   |       | Screw, Cap                                     |
| 24    | 6505-916    | 2   |       | Gasket                                         |
| 25    | 6505-926    | 1   |       | Flange                                         |
| 26    | 6505-042    | 1   |       | O-Ring                                         |
| 27    | 6505-676    | 1   |       | Filter                                         |
| 28    | 6505-665    | 1   |       | S-Gasket                                       |
| 29    | 6505-953    | 1   |       | Main Jet - Fixed 85                            |
| 30    | 6505-853    | 4   |       | Screw w/Washer                                 |
| 31    | 6505-976    | 1   |       | Carburetor Assembly - PTO                      |
| 32    | 6505-848    | 1   |       | Cover                                          |
| 33    | 6505-975    | 1   |       | Jet, Recharge                                  |



1998 TS-R 770 (98DTA-1998)  
 REED VALVE ASSEMBLY

Page 55 of 71

| Ref # | Part Number | Qty | S/P/F | Description                       |
|-------|-------------|-----|-------|-----------------------------------|
| 1     | 3008-534    | 3   | /P    | Valve, Reed - Assembly (inc. 2-4) |
| 2     | 3008-074    | 6   |       | Stopper, Reed Valve               |
| 3     | 3008-075    | 6   |       | Valve, Reed                       |
| 4     | 3004-506    | 18  | /P    | Screw, Reed Valve                 |
| 5     | 3008-076    | 3   | S     | Gasket, Reed Valve                |
| 6     | 0670-712    | 3   | S     | Manifold, Intake                  |
| 7     | 3008-220    | 12  |       | Screw, Cap                        |
| 8     | 3003-597    | 3   |       | Nozzle, Oil                       |
| 9     | 3008-370    | 6   | /P    | Stud                              |
| 10    | 3008-309    | 6   | S     | Nut                               |

No  
Diagram  
Available  
  
Parts List  
Only


1998 TS-R 770 (98DTA-1998)  
RELATED ITEMS

Page 57 of 71

| Ref # | Part Number | Qty | S/P/F | Description                         |
|-------|-------------|-----|-------|-------------------------------------|
|       | 0678-051    | 1   | S     | Anchor w/Float and Mooring Rope     |
|       | 0678-325    | 1   | /P    | Anchor Bag                          |
|       | 0678-063    | 1   |       | Battery Charger Kit                 |
|       | 0678-363    | 1   | /P    | Beach Dolly                         |
|       | 0678-380    | 1   |       | Buoy Set                            |
|       | 0678-359    | 1   |       | CDI Hi Rev (770R)                   |
|       | 0678-461    | 1   | /P    | Cover, Premium                      |
|       | 0673-093    | 1   | S     | Fire Extinguisher                   |
|       | 0678-274    | 1   |       | Flush Kit                           |
|       | 0678-469    | 1   |       | Fold-Up Sharkstand                  |
|       | 0678-410    | 1   |       | Footpad Kit                         |
|       | 0678-316    | 1   |       | Gel-Coat Kit - Multi-Color          |
|       | 0678-348    | 1   |       | Grease Gun Kit                      |
|       | 0678-136    | 1   |       | Grips, Handlebar - Red              |
|       | 0678-064    | 1   |       | Horn Kit                            |
|       | 0678-362    | 1   |       | Hourmeter                           |
|       | 0678-364    | 1   | /P    | Lanyard - Red                       |
|       | 0678-180    | 1   |       | Lift Harness                        |
|       | 2255-866    | 1   |       | Manual, Operator's                  |
|       | 2255-974    | 1   |       | Manual, Illustrated Parts           |
|       | 2255-947    | 1   |       | Manual, Service                     |
|       | 0678-358    | 1   |       | Mooring Rope - Black                |
|       | 0678-357    | 1   |       | Mooring Rope - Dark Blue            |
|       | 0678-052    | 1   | /P    | Mooring Rope - Purple               |
|       | 0678-054    | 1   |       | Mooring Rope - Red                  |
|       | 0678-053    | 1   |       | Mooring Rope - Teal                 |
|       | 0678-189    | 1   | /P    | Nylon Rope - Purple                 |
|       | 0652-041    | 1   |       | Paint, Touch-Up - Red               |
|       | 0678-035    | 1   |       | Paint, Touch-Up - White             |
|       | 0678-185    | 1   |       | Plug Caddy - Purple                 |
|       | 0678-149    | 1   |       | Plug Caddy - Rivet-On               |
|       | 0678-471    | 1   |       | PWC Lift                            |
|       | 0678-470    | 1   |       | Registration Letters - Carbon Fiber |
|       | 0678-360    | 1   |       | Registration Letters - Gold/Black   |
|       | 0678-361    | 1   |       | Registration Letters - Red/Black    |
|       | 0678-224    | 1   |       | Spark Plug Caps - Red               |
|       | 0678-135    | 1   |       | Start/Stop Switch Lock              |
|       | 0678-374    | 1   |       | StorTech(tm) Plug (770R)            |
|       | 0678-372    | 1   |       | Tiedown Strap - Red                 |
|       | 0678-105    | 1   |       | Tool Kit                            |
|       | 0678-476    | 1   |       | Value Pack, Medium                  |
|       | 0678-477    | 1   |       | Value Pack, Large                   |
|       | 0678-478    | 1   |       | Value Pack, X Large                 |

1998 TS-R 770 (98DTA-1998)  
SEAT ASSEMBLY

Page 58 of 71




1998 TS-R 770 (98DTA-1998)  
SEAT ASSEMBLY

Page 59 of 71

| Ref # | Part Number | Qty | S/P/F | Description                                   |
|-------|-------------|-----|-------|-----------------------------------------------|
|       | 0773-878    | 1   |       | Complete Seat Assembly (770)                  |
| 1     | 0773-905    | 1   |       | Strap, Seat                                   |
| 2     | 0773-923    | 1   |       | Cover, Seat w/Decal (770)                     |
| 3     | 0773-314    | 1   |       | Foam, Seat                                    |
| 4     | 1673-039    | 1   |       | Base, Seat                                    |
| 5     | 1673-396    | 1   |       | Seal, Seat Base                               |
| 6     | 0673-668    | 1   |       | Catch, Seat                                   |
| 7     | 0624-094    | 0   |       | Staple                                        |
| 8     | 0624-396    | 6   |       | Nut                                           |
| 9     | 0624-036    | 4   |       | Washer, Lock                                  |
| 10    | 0624-046    | 2   |       | Screw, Cap                                    |
| 11    | 0624-262    | 1   | F     | U-Bolt, Seat                                  |
| 12    | 0624-061    | 2   | F     | Nut                                           |
| 13    | 0624-125    | 2   | /P/F  | Washer                                        |
| 14    | 0624-090    | 2   | F     | Nut, Lock                                     |
| 15    | 0624-009    | 1   | F     | Nut, Lock                                     |
| 16    | 0624-022    | 2   |       | Washer                                        |
| 17    | 0624-272    | 2   |       | Screw, Machine                                |
| 18    | 0606-586    | 3   | F     | Clip, Retaining                               |
| 19    | 0610-261    | 1   | F     | Hose, Air Exhaust                             |
| 20    | 0673-752    | 1   | F     | Plate, Backing                                |
| 21    | 0624-159    | 1   |       | Washer                                        |
| 22    | 0673-026    | 1   |       | Lever, Release - Seat Latch                   |
| 23    | 0773-941    | 1   | /P    | Latch Assembly - Seat                         |
| 24    | 1673-397    | 1   | F     | Seal, Vent - Seat Base                        |
| 25    | 0673-023    | 1   |       | Clip, Retaining                               |
| 26    | 0624-013    | 1   | F     | Washer                                        |
| 27    | 0624-047    | 1   | F     | Nut                                           |
| 28    | 0624-302    | 2   |       | Screw, Cap                                    |
| 29    | 1673-383    | 1   | /P/F  | Stud, Latch - Seat                            |
| 30    | 0624-126    | 2   | F     | Washer, Rubber                                |
| 31    | 0623-698    | 2   |       | Spacer, Seat Latch                            |
| 32    | 0773-302    | 1   | F     | Vent, Seat - Assembly (inc. 18, 19, 24, & 33) |
| 33    | 1673-203    | 1   | F     | Vent, Seat Base                               |

1998 TS-R 770 (98DTA-1998)  
SENSOR ASSEMBLY

Page 60 of 71




1998 TS-R 770 (98DTA-1998)  
SENSOR ASSEMBLY

Page 61 of 71

| Ref # | Part Number | Qty | S/P/F | Description               |
|-------|-------------|-----|-------|---------------------------|
| 1     | 3008-297    | 1   | /P    | Relay Assembly            |
| 2     | 3008-348    | 1   | S     | Protector, Circuit Charge |
| 3     | 3008-351    | 1   |       | Cap, Circuit Protector    |
| 4     | 3008-350    | 1   | /P    | Protector, Circuit Load   |
| 5     | 3008-294    | 1   | /P    | Holder, Circuit Protector |
| 6     | 3008-313    | 2   |       | Screw, Cap                |

1998 TS-R 770 (98DTA-1998)  
STARTER MOTOR ASSEMBLY

Page 62 of 71




1998 TS-R 770 (98DTA-1998)  
STARTER MOTOR ASSEMBLY

Page 63 of 71

| Ref # | Part Number | Qty | S/P/F | Description                        |
|-------|-------------|-----|-------|------------------------------------|
| 1     | 3008-462    | 1   |       | Starter Motor Assembly (inc. 2-11) |
| 2     | 3008-094    | 1   | /P    | Terminal Set, Brush (inc. 3)       |
| 3     | 3008-164    | 1   |       | O-Ring                             |
| 4     | 3008-095    | 1   | /P    | Holder Set, Brush (inc. 5)         |
| 5     | 3008-096    | 4   |       | Spring, Brush                      |
| 6     | 3008-328    | 1   | /P    | Front Bracket Assembly (inc. 7)    |
| 7     | 3008-363    | 1   | /P    | O-Ring                             |
| 8     | 3008-099    | 2   |       | Washer Set                         |
| 9     | 3008-563    | 2   | S     | O-Ring                             |
| 10    | 3008-103    | 1   |       | Armature                           |
| 11    | 3008-102    | 2   |       | Cap, Screw                         |
| 12    | 3008-387    | 1   | /P    | Pinion Assembly                    |
| 13    | 3008-463    | 2   |       | Screw, Cap                         |
| 14    | 3008-014    | 1   |       | Nut                                |
| 15    | 3008-020    | 1   |       | Washer                             |
| 16    | 3008-165    | 1   | /P    | Relay                              |
| 17    | 3008-140    | 1   |       | Bracket                            |
| 18    | 3008-313    | 1   |       | Screw, Cap                         |
| 19    | 3008-135    | 1   | S     | Tube                               |
| 20    | 3008-480    | 2   | /P    | Washer, Pinion                     |
| 21    | 3008-537    | 1   |       | Washer, Thrust                     |

1998 TS-R 770 (98DTA-1998)  
STEERING POST ASSEMBLY

Page 64 of 71




1998 TS-R 770 (98DTA-1998)  
STEERING POST ASSEMBLY

Page 65 of 71

| Ref # | Part Number | Qty | S/P/F | Description                        |
|-------|-------------|-----|-------|------------------------------------|
| 1     | 0624-186    | 6   |       | Screw, Machine                     |
| 2     | 1673-405    | 2   |       | Bearing, Half-Steering Post        |
| 3     | 1673-315    | 1   |       | Plate, Backing                     |
| 4     | 0624-019    | 2   |       | Clamp                              |
| 5     | 0673-056    | 1   |       | Seal, Bearing                      |
| 6     | 0773-603    | 1   |       | Post, Steering                     |
| 7     | 0717-052    | 0   | /P    | Foam, Neoprene Tape                |
| 8     | 0605-149    | 2   |       | Bearing, Steering Post             |
| 9     | 0605-171    | 1   |       | Housing, Bearing                   |
| 10    | 1673-026    | 1   |       | Bracket, Support                   |
| 11    | 0773-602    | 1   |       | Bracket, Steering Cable            |
| 12    | 0624-125    | 1   | /P    | Washer                             |
| 13    | 0624-229    | 1   |       | Screw, Cap                         |
| 14    | 0624-090    | 1   |       | Nut, Lock                          |
| 15    | 0624-192    | 2   |       | Screw, Cap                         |
| 16    | 0624-125    | 2   | /P    | Washer                             |
| 17    | 0673-932    | 1   |       | End, Steering Cable                |
| 18    | 0624-107    | 1   |       | Nut                                |
| 19    | 1673-355    | 1   |       | Cable, Steering                    |
| 20    | 0612-364    | 1   |       | Cover, Thread Cap - Steering Cable |
| 21    | 0612-363    | 1   |       | Seal, Rod                          |
| 22    | 0624-411    | 2   |       | Washer                             |
| 23    | 0624-105    | 2   |       | Nut                                |
| 24    | 0605-147    | 1   | S     | Housing, Bearing                   |
| 25    | 0673-366    | 1   |       | Spacer, Bearing Housing            |
| 26    | 0624-089    | 1   |       | Nut, Lock                          |
| 27    | 0673-931    | 1   |       | End, Steering Cable                |
| 28    | 0623-669    | 1   |       | Nut                                |
| 29    | 0624-279    | 1   |       | Nut                                |
| 30    | 0624-381    | 1   |       | Spacer                             |
| 31    | 0624-290    | 1   |       | Screw, Cap                         |
| 32    | 1673-193    | 1   |       | Gasket, Cable - Foam               |
| 33    | 0624-476    | 1   |       | Screw, Cap                         |
| 34    | 0624-250    | 6   |       | Nut, Lock                          |
| 35    | 0624-233    | 1   |       | Nut, Lock                          |

1998 TS-R 770 (98DTA-1998)  
TRIM ASSEMBLY

Page 66 of 71




1998 TS-R 770 (98DTA-1998)  
TRIM ASSEMBLY

Page 67 of 71

| Ref # | Part Number | Qty | S/P/F | Description                    |
|-------|-------------|-----|-------|--------------------------------|
| 1     | 1673-376    | 1   |       | Bracket, Mounting - Trim Motor |
| 2     | 0624-019    | 1   |       | Clamp                          |
| 3     | 1673-291    | 1   |       | Actuator, Trim                 |
| 4     | 0624-279    | 1   |       | Nut                            |
| 5     | 0624-231    | 2   |       | Screw, Cap                     |
| 6     | 1673-371    | 1   |       | Boot, Trim Rod                 |
| 7     | 0773-864    | 1   |       | Rod, Trim                      |
| 8     | 0624-022    | 1   |       | Washer, Lock                   |
| 9     | 0624-250    | 1   |       | Nut, Lock                      |
| 10    | 1673-049    | 1   |       | Spacer                         |
| 11    | 0624-089    | 2   |       | Nut, Lock                      |
| 12    | 0623-648    | 1   |       | Nut                            |
| 13    | 0673-932    | 1   |       | Rod End                        |
| 14    | 0624-056    | 1   |       | Screw, Cap                     |

1998 TS-R 770 (98DTA-1998)  
WATER FILTER ASSEMBLY

Page 68 of 71




1998 TS-R 770 (98DTA-1998)  
WATER FILTER ASSEMBLY

Page 69 of 71

| Ref # | Part Number | Qty | S/P/F | Description                             |
|-------|-------------|-----|-------|-----------------------------------------|
| 1     | 0675-042    | 1   |       | Screen                                  |
| 2     | 0710-190    | 0   |       | Hose, Water - 25 ft (770)               |
| 3     | 1673-158    | 1   |       | Fitting, Elbow (770)                    |
| 4     | 0624-016    | 4   |       | Clamp, Hose                             |
| 5     | 1673-450    | 1   | /P    | Fitting (770)                           |
| 6     | 1673-161    | 1   |       | Filter, Water Assembly (inc. 7-9) (770) |
| 7     | 0673-669    | 1   |       | Cover                                   |
| 8     | 0673-670    | 1   |       | O-Ring                                  |
| 9     | 0673-671    | 1   |       | Screen                                  |
| 10    | 1673-193    | 1   |       | Gasket, Foam (770)                      |
| 11    | 8060-428    | 2   |       | Rivet                                   |
| 12    | 0710-206    | 1   |       | Hose, Water (770)                       |
| 13    | 0623-648    | 1   |       | Nut (770)                               |
| 14    | 0624-016    | 2   |       | Clamp, Hose (770)                       |

1998 TS-R 770 (98DTA-1998)  
WIRING HARNESS

Page 70 of 71



1998 TS-R 770 (98DTA-1998)  
WIRING HARNESS

Page 71 of 71

| Ref # | Part Number | Qty | S/P/F | Description         |
|-------|-------------|-----|-------|---------------------|
| 1     | 3008-044    | 1   |       | Tie, Cable          |
| 2     | 3002-964    | 2   | /P    | Clamp               |
| 3     | 3008-466    | 1   |       | Cable               |
| 4     | 3008-345    | 1   | /P    | Cable (inc. 5)      |
| 5     | 3008-334    | 1   | /P    | Grommet             |
| 6     | 3008-467    | 1   |       | Cable, Ground (770) |
| 7     | 3008-547    | 1   | /P    | Harness, Wiring     |
| 8     | 3008-362    | 1   | /P    | Grommet             |
| 9     | 0686-430    | 1   |       | Harness, Gauge      |
| 10    | 0630-056    | 1   |       | Fuse, 3 AMP         |