

Illustrated Parts List

Model Series

111400 to 111499

TYPE NUMBERS
0035, 0036, 0049,
0101, 0102, 0112,
0119, 0120, 0131,
0135, 0136, 0141.

TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW

- A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- B. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- C. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. **THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."**
- D. If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- E. If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- F. For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.

PRINTED IN U.S.A.




COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

1058 OWNER'S MANUAL

1019 LABEL KIT

★ REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	690045	Kit-Cylinder Assembly	20	★692550	Seal-Oil (PTO Side)	523	693618	Dipstick
2	399269	Bushing/Seal (Magneto Side)	21	281658	Cap-Oil Fill	552	692346	Bushing-Governor Crank
3	★299819	Seal-Oil (Magneto Side)	22	692551	Screw (Crankcase Cover)	668	693604	Spacer (Oil Sensor)
12	★692549	Gasket-Crankcase	306	693610	Shield-Cylinder	714	693649	Nut (Stop Wire)
15	94916	Plug-Oil Drain	307	690345	Screw (Cylinder Shield)	718	230192	Pin-Locating
17	692517	Bearing-Ball	318	693609	Screw (Mounting Bracket)	799	693609	Screw (Oil Sensor)
18	693605	Cover-Crankcase Used on Type No(s). 0035, 0036, 0101, 0102, 0119, 0120, 0131, 0135, 0136.	356	693650	Wire-Stop	842	280393	Seal-Dipstick Tube
18A	693204	Cover-Crankcase Used on Type No(s). 0049, 0112.	364	693607	Terminal-Oil Plug	847	693617	Dipstick/Tube Assembly
			415	693463	Plug	1019	694851	Label Kit
			441	694262	Bracket-Oil Fill	1052	693805	Sensor-Oil
			449	94929	Screw	1058	273700	Owner's Manual (Oil Fill Bracket)
			493	693599	Bracket-Mounting (Oil Sensor)			

★ Included in Gasket Set-Ref. No. 358.
 ∅ Included in Valve Gasket Set-Ref. No. 1095.

● Included in Carburetor Overhaul Kit-Ref. No. 121.
 ◆ Included in Carburetor Gasket Set-Ref. No. 977.


111400 to 111499



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
5	693643	Head-Cylinder	122	●693749	Spacer-Carburetor	798	692559	Screw (Rocker Arm)
7	★∅695166	Gasket-Cylinder Head (Used After Code Date 99113000).	155	695168	Plate-Cylinder Head (Used After Code Date 99113000).	830	694544	Stud (Rocker Arm)
		Note	155A	692556	Plate-Cylinder Head (Used Before Code Date 99120100).	868	★∅498592	Seal-Valve
		273489 Gasket-Cylinder Head (Used Before Code Date 99120100).	189	694543	Ball-Rocker Arm	914	94786	Screw (Rocker Cover 7/16" Long)
13	691137	Screw (Cylinder Head)	238	691300	Cap-Valve	914A	692557	Screw (Rocker Cover 3/8" Long)
33	499642	Valve-Exhaust	337	491055	Sparkplug	993	★∅691892	Gasket-Cylinder Head Plate
34	499641	Valve-Intake			Note	1022	★∅691890	Gasket-Rocker Cover
35	691304	Spring-Valve (Intake)			691043 Sparkplug Used on Type No(s). 0102, 0141.	1023	499924	Cover-Rocker Arm
36	691304	Spring-Valve (Exhaust)	383	19374	Wrench-Sparkplug	1026	693517	Rod-Push
40	93312	Retainer-Valve	619	691108	Screw (Cylinder Head Plate)	1029	691230	Arm-Rocker
45	262679	Tappet-Valve	635	805529	Boot-Sparkplug	1034	691343	Guide-Push Rod
51	◆◆∅692555	Gasket-Intake	635A	280897	Boot-Sparkplug (Handle Type)			

★ Included in Gasket Set-Ref. No. 358.
 ∅ Included in Valve Gasket Set-Ref. No. 1095.

● Included in Carburetor Overhaul Kit-Ref. No. 121.
 ◆ Included in Carburetor Gasket Set-Ref. No. 977.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
16	693802	Crankshaft _____ Note _____ 693803 Crankshaft Used on Type No(s). 0049. 693797 Crankshaft Used on Type No(s). 0112. 694463 Crankshaft Used on Type No(s). 0131.	25	499627	Piston Assembly (Standard) _____ Note _____ 692788 Piston Assembly (.010 O.S.) 692789 Piston Assembly (.020 O.S.) 692790 Piston Assembly (.030 O.S.)	27	263190	Lock-Piston Pin
17	692517	Bearing-Ball	26	499631	Ring Set (Standard) _____ Note _____ 692785 Ring Set (.010 O.S.) 692786 Ring Set (.020 O.S.) 692787 Ring Set (.030 O.S.)	28	499423	Pin-Piston
24	222698	Key-Flywheel				29	499424	Rod-Connecting
						30	692562	Dipper-Connecting Rod
						32	94699	Screw (Connecting Rod)
						46	693404	Camshaft
						146	94388	Key-Timing
						219	693578	Gear-Governor
						220	221551	Washer (Governor Gear)
						357	91539	Key-Drive Pulley
						741	692565	Gear-Timing
						742	692564	Retainer-E-Ring
						746	692566	Gear-Idler

★ Included in Gasket Set-Ref. No. 358.
 ∅ Included in Valve Gasket Set-Ref. No. 1095.

● Included in Carburetor Overhaul Kit-Ref. No. 121.
 ◆ Included in Carburetor Gasket Set-Ref. No. 977.





111400 to 111499



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
51	◆◆692555	Gasket-Intake	117	498976	Jet-Main	276	◆◆271716	Washer-Sealing (Main Jet)
95	94098	Screw (Throttle Valve)	122	◆693749	Spacer-Carburetor	365	692568	Screw (Carburetor)
97	690024	Shaft-Throttle	125	693865	Carburetor	692	690572	Spring-Detent
98	398185	Kit-Idle Speed (Carburetor)	127	◆223472	Plug-Welch	708	◆◆691321	Washer (Throttle Shaft)
104	◆691242	Pin-Float Hinge	130	691181	Valve-Throttle	975	493640	Bowl-Float
108	692567	Valve-Choke	133	398187	Float-Carburetor			
109	690023	Shaft-Choke	134	◆398188	Needle/Seat Kit			
110	◆◆693867	Washer (Choke Shaft)	137	◆◆693981	Gasket-Float Bowl			
			163	◆◆272948	Gasket-Air Cleaner			
			186	493496	Connector-Hose			

★ Included in Gasket Set-Ref. No. 358.
 ◊ Included in Valve Gasket Set-Ref. No. 1095.


◆ Included in Carburetor Overhaul Kit-Ref. No. 121.
 ◆◆ Included in Carburetor Gasket Set-Ref. No. 977.



1119




347



286



729




333


851




334



356A



356B



356C




1054

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
209	692571	Spring-Governor	356B	692602	Wire-Stop	632	693408	Spring/Link-Mechanical Governor
209A	261306	Spring-Governor	356C	695630	Wire-Stop	729	694371	Clip-Wire
227	692573	Control Lever-Governor	474	694457	Alternator	851	493880	Terminal-Sparkplug
286	694523	Module-Oil Sensor	505	231082	Nut (Governor Control Lever)	1054	280275	Tie-Cable
333	692605	Armature-Magneto	562	94852	Bolt (Governor Control Lever)	1119	93621	Screw (Alternator)
334	94731	Screw (Magneto Armature)						
347	693623	Switch-Rocker						
356A	692390	Wire-Stop						

★ Included in Gasket Set-Ref. No. 358.
 ◊ Included in Valve Gasket Set-Ref. No. 1095.

● Included in Carburetor Overhaul Kit-Ref. No. 121.
 ◆ Included in Carburetor Gasket Set-Ref. No. 977.

111400 to 111499




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
98A	493280	Kit-Idle Speed (Control Bracket)	281A	693407	Panel-Control (Used Before Code Date 99070500).	615	692576	Shaft-Governor
188	94644	Screw (Control Bracket)	427	694255	Nut (Control Bracket) (Used After Code Date 99070400).	616	692547	Crank-Governor
222	694253	Bracket-Control (Used After Code Date 99070400).	427A	692575	Nut (Control Bracket) (Used Before Code Date 99070500).	621	396847	Switch-Stop
222A	693405	Bracket-Control (Used Before Code Date 99070500).	478	693709	Panel	663	694593	Screw (Control Panel, Used Without Casing Clamp)
265	221535	Clamp-Casing	504	694254	Washer Set-Friction (Used After Code Date 99070400).	668A	694257	Spacer (Control Bracket)
267	692577	Screw (Casing Clamp)	504A	495659	Washer Set-Friction (Used Before Code Date 99070500).	773	694258	Retainer
271	694256	Lever-Control				792	694259	Bracket-Fixed Speed (Used After Code Date 99070400).
281	694252	Panel-Control (Used After Code Date 99070400).				843	694061	Sleeve-Lever
						1113	692577	Screw (Panel)
						1172	94831	Screw (Fixed Speed Bracket)

★ Included in Gasket Set-Ref. No. 358.
 ⌀ Included in Valve Gasket Set-Ref. No. 1095.

● Included in Carburetor Overhaul Kit-Ref. No. 121.
 ◆ Included in Carburetor Gasket Set-Ref. No. 977.

111400 to 111499




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
11	692600	Tube-Breather	613	94706	Screw (Muffler)	836B	94930	Screw (Muffler Guard, 7/16" Long)
161	692579	Base-Air Cleaner	613A	694460	Screw (Muffler)	836C	94706	Screw (Muffler Guard, 5/8" Long)
163	272948	Gasket-Air Cleaner	613B	691108	Screw (Muffler)	863	692596	Bracket-Muffler
184	94914	Screw (Muffler Strap)	676	393757	Deflector-Muffler	864	694430	Adapter-Muffler
187	298049	Line-Fuel (Cut to Required Length)	677	94896	Screw (Muffler Deflector)	883	272309	Gasket-Exhaust
187A	692601	Line-Fuel (Molded)	736	693560	Nut-Clip	957	694261	Cap-Fuel Tank
190	692127	Screw (Fuel Tank)	819	692598	Screw (Muffler Bracket)	957A	493988	Cap-Fuel Tank
190A	94644	Screw (Fuel Tank)	823	94706	Screw (Muffler Adapter)	958	692586	Valve-Fuel Shut Off
285	692595	Strap-Muffler	832	693583	Guard-Muffler	967	493537	Filter-Pre-Cleaner
300	693593	Muffler (Lo Tone)	832A	694459	Guard-Muffler	968	692584	Cover-Air Cleaner
300A	694429	Muffler	836	94896	Screw (Muffler Guard, 3/8" Long)	971	690370	Screw (Air Cleaner Base)
425	692583	Screw (Air Cleaner Cover)	836A	693624	Screw (Muffler Guard, 9/16" Long)	972	694260	Tank-Fuel (Used After Code Date 99070400).
445	491588	Filter-Air Cleaner Cartridge				972A	692587	Tank-Fuel (Used Before Code Date 99070500).
601	95162	Clamp-Hose						

★ Included in Gasket Set-Ref. No. 358.
 ◊ Included in Valve Gasket Set-Ref. No. 1095.

● Included in Carburetor Overhaul Kit-Ref. No. 121.
 ◆ Included in Carburetor Gasket Set-Ref. No. 977.


111400 to 111499



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
23	692987	Flywheel (Rewind Start Only)	305	692608	Screw (Blower Housing)	1005	692592	Fan-Flywheel
23A	694902	Flywheel (Electric Start)	305A	690960	Screw (Blower Housing)	1036	694304	Label-Emissions
304	693621	Housing-Blower	332	94877	Nut (Flywheel)	1162	692590	Screw (Flywheel)
		Note	363	19069	Puller-Flywheel			
		694378 Housing-Blower Used on Type No(s). 0136.	455	692591	Cup-Flywheel			
			727	694467	Cover-Starter Drive			

★ Included in Gasket Set-Ref. No. 358.
 ∅ Included in Valve Gasket Set-Ref. No. 1095.

● Included in Carburetor Overhaul Kit-Ref. No. 121.
 ◆ Included in Carburetor Gasket Set-Ref. No. 977.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
55	691422	Housing-Rewind Starter	456	281503	Plate-Pawl Friction	689	263073	Spring-Friction
58	693389	Rope-Starter (Cut to Length)	459	281505	Pawl-Ratchet	1210	498144	Pulley/Spring Assembly (Pulley)
59	805957	Insert-Grip	592	94908	Nut (Rewind Starter)	1211	498144	Pulley/Spring Assembly (Spring)
60	715257	Grip-Starter Rope (Two Piece Handle)	597	94943	Screw (Pawl Friction Plate)			
65	94904	Screw (Rewind Starter)	608	693394	Starter-Rewind			

★ Included in Gasket Set-Ref. No. 358.
 ∅ Included in Valve Gasket Set-Ref. No. 1095.

● Included in Carburetor Overhaul Kit-Ref. No. 121.
 ◆ Included in Carburetor Gasket Set-Ref. No. 977.


111400 to 111499



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
3	*299819	Seal-Oil (Gear Reduction Case)	82A	691122	Screw (Gear Reduction Case, 1 1/2" Long)	86	690608	Cover-Gear
15A	94886	Plug-Oil Drain	83	690374	Auxiliary Drive Shaft-	87	19011	Seal-Oil (Gear Cover)
79	694511	Case-Gear Reduction	84	691121	Breather Plug-	88	27313	Gasket-Gear Reduction Cover
82	690369	Screw (Gear Reduction Case, 7/8" Long)	85	691117	Screw (Gear Cover to Gear Reduction)	127A	22831	Plug-Welch

★ Included in Gasket Set-Ref. No. 358.
 ∅ Included in Valve Gasket Set-Ref. No. 1095.

● Included in Carburetor Overhaul Kit-Ref. No. 121.
 ◆ Included in Carburetor Gasket Set-Ref. No. 977.







REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
309	694504	Motor-Starter	544	692966	Armature-Starter	801	694482	Cap-Drive
310	690372	Screw (Starter Motor)	675	225137	Washer (Brush Retainer)	802	497607	Cap-End
311	497608	Brush Set	783	692353	Gear-Pinion	803	691427	Housing-Starter
317	695494	Cover-Starter	797	92278	Nut (Brush Retainer)	1051	263080	Ring-Retaining
510	497705	Drive-Starter				1090	497605	Retainer-Brush
513	398003	Drive-Clutch						

★ Included in Gasket Set-Ref. No. 358.
 ∅ Included in Valve Gasket Set-Ref. No. 1095.

● Included in Carburetor Overhaul Kit-Ref. No. 121.
 ◆ Included in Carburetor Gasket Set-Ref. No. 977.

111400 to 111499



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
3	★299819	Seal—Oil (Magneto Side)	51	◆◆692555	Gasket—Intake	358	695155	Gasket Set—Engine
7	★∅695166	Gasket—Cylinder Head (Used After Code Date 99113000).	104	●691242	Pin—Float Hinge	708	●◆691321	Washer (Throttle Shaft)
	Note		110	●◆693867	Washer (Choke Shaft)	868	★∅498592	Seal—Valve
		273489 Gasket—Cylinder Head (Used Before Code Date 99120100).	121	695157	Overhaul Kit—Carburetor	883	★272309	Gasket—Exhaust
12	★692549	Gasket—Crankcase	122	●693749	Spacer—Carburetor	977	690033	Gasket Set—Carburetor
20	★692550	Seal—Oil (PTO Side)	127	●223472	Plug—Welch	993	★∅691892	Gasket—Cylinder Head Plate
			134	●398188	Needle/Seat Kit	1022	★∅691890	Gasket—Rocker Cover
			137	●◆693981	Gasket—Float Bowl	1095	690034	Gasket Set—Valve
			163	★◆272948	Gasket—Air Cleaner			
			276	●◆271716	Washer—Sealing (Main Jet)			

★ Included in Gasket Set—Ref. No. 358.
 ∅ Included in Valve Gasket Set—Ref. No. 1095.

● Included in Carburetor Overhaul Kit—Ref. No. 121.
 ◆ Included in Carburetor Gasket Set—Ref. No. 977.