

Illustrated Parts List

Model Series

127700 to 127799

TYPE NUMBERS

0100, 0115, 0117,
0119, 0120, 0123,
0124, 0130, 0131,
0144,

TYPE NUMBERS

0600, 0608, 0617,
0618 through 0627,
0629 through 0639,
0640 through 0648,
0651 through 0677,
1700, 1708, 1710,
1711, 1713, 1730,
1734, 1745, 1746,
1752, 1762, 1770,
1783, 1791, 4711,
4715.

TO FIND

**THE CORRECT NUMBER OF THE PART YOU NEED:
FOLLOW THE INSTRUCTIONS BELOW**


- A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- B. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- C. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. **THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."**
- D. If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- E. If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- F. For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.

PRINTED IN U.S.A.



COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.




127700 to 127799



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	493260	Cylinder Assembly	13	94547	Screw (Cylinder Head)	684	690345	Screw (Breather Passage Cover)
2	399269	Kit-Bushing/Seal (Magneto Side)	50	497465	Manifold-Intake	842	★280393	O-Ring Seal
3	★299819	Seal-Oil (Magneto Side)	51	★272199	Gasket-Intake	847	495263	O-Ring Seal (Dipstick/Tube)
5	691160	Head-Cylinder (Used After Code Date 98062100). ----- Note ----- 214626 Head-Cylinder (Used After Code Date 96060200 and Before Code Date 98062200). 691717 Head-Cylinder (Used Before Code Date 96060300).	54	94526	Screw (Intake Manifold)	869	691155	Seat-Valve (Intake)
7★	272916	Gasket-Cylinder Head	287	94511	Screw (Dipstick Tube)	870	690380	Seat-Valve (Exhaust)
8	695250	Breather Assembly	306	690450	Shield-Cylinder	871	262001	Bushing-Valve Guide (Exhaust Valve) ----- Note ----- 63709 Bushing-Valve Guide (Intake Valve)
9★	272481	Gasket-Breather	307	690345	Screw (Cylinder Shield)	1019	494256	Kit-Label
10	691125	Screw (Breather Assembly)	337	802592	Sparkplug (Resistor) ----- Note ----- 492167 Sparkplug	1058	274783	Owner's Manual (Emission Engines) ----- Note ----- 272262 Owner's Manual (Non Emission Engines)
11	231933	Tube-Breather	383	89838	Wrench-Sparkplug			
			523	495264	Dipstick			
			524	★280966	Seal-Dipstick Tube			
			525	495265	Tube-Dipstick			
			584	692342	Cover-Breather Passage			
			585	★272238	Gasket-Breather Passage			
			635	66538	Boot-Sparkplug			

★ Included in Engine Gasket Set-See Ref. 358.
● Included in Carburetor Overhaul Kit-See Ref. 121.

◆ Included in Carburetor Gasket Set-See Ref. 977.
Included in Valve Overhaul Gasket Set-See Ref. 1095.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
25	499429	Piston Assembly (Standard) (Used After Code Date 97011200). ----- Note ----- 493262 Piston Assembly (Standard) (Used Before Code Date 97011300).	26	499425	Ring Set (Standard) (Used After Code Date 97011200). ----- Note ----- 493261 Ring Set (Standard) (Used Before Code Date 97011300).	27	263190	Lock-Piston Pin (Used After Code Date 97011200). ----- Note ----- 26026 Lock-Piston Pin (Used Before Code Date 97011300).
	499430	Piston Assembly (.010" O.S.) (Used After Code Date 97011200).		499426	Ring Set (.010" O.S.) (Used After Code Date 97011200).	28	499423	Pin-Piston (Standard) (Used After Code Date 97011200). ----- Note ----- 298909 Pin-Piston (Standard) (Used Before Code Date 97011300).
	493385	Piston Assembly (.010" O.S.) (Used Before Code Date 97011300).		493388	Ring Set (.010" O.S.) (Used Before Code Date 97011300).	29	499424	Rod-Connecting (Standard) (Used After Code Date 97011200). ----- Note ----- 490566 Rod-Connecting (Standard) (Used Before Code Date 97011300).
	499431	Piston Assembly (.020" O.S.) (Used After Code Date 97011200).		499427	Ring Set (.020" O.S.) (Used After Code Date 97011200).	32	94699	Screw (Connecting Rod)
	493386	Piston Assembly (.020" O.S.) (Used Before Code Date 97011300).		493389	Ring Set (.020" O.S.) (Used Before Code Date 97011300).	32A	695759	Screw (Connecting Rod) (Used After Code Date 00042200)
	499432	Piston Assembly (.030" O.S.) (Used After Code Date 97011200).		499428	Ring Set (.030" O.S.) (Used After Code Date 97011200).			
	493387	Piston Assembly (.030" O.S.) (Used Before Code Date 97011300).		493390	Ring Set (.030" O.S.) (Used Before Code Date 97011300).			

★ Included in Engine Gasket Set-See Ref. 358.
● Included in Carburetor Overhaul Kit-See Ref. 121.

◆ Included in Carburetor Gasket Set-See Ref. 977.
Included in Valve Overhaul Gasket Set-See Ref. 1095.


127700 to 127799



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
16	691451	Crankshaft (Used After Code Date 97011200). ----- Note ----- 493362 Crankshaft (Used Before Code Date 97011300). 494546 Crankshaft Used on Type No(s). 0115, 0131, 0645, 1745. 691450 Crankshaft (Used After Code Date 97011200). Used on Type No(s). 0600, 0608, 0623, 0627, 0629, 0632, 0633, 0639, 0640, 0641, 1700, 1708, 1746. 493282 Crankshaft (Used Before Code Date 97011300). Used on Type No(s). 0100, 0120, 0123, 0600, 0608, 0623, 0627, 0632.			691452 Crankshaft (Used After Code Date 97011200). Used on Type No(s). 0617, 0618, 0624, 0647, 1711, 1791. 493363 Crankshaft (Used Before Code Date 97011300). Used on Type No(s). 0617, 0618, 0624.			691375 Crankshaft (Used Before Code Date 97011300). Used on Type No(s). 0660, 0672. 691482 Crankshaft Used on Type No(s). 1783.
				691454 Crankshaft (Used After Code Date 97011200). Used on Type No(s). 0646. 493946 Crankshaft (Used Before Code Date 97011300). Used on Type No(s). 0646.			24 222698 Key-Flywheel 33 262651 Valve-Exhaust 34 262652 Valve-Intake 35 691270 Spring-Valve (Intake) 36 691270 Spring-Valve (Exhaust) 40 93312 Retainer-Valve 45 690548 Tappet-Valve 146 94388 Key-Timing 741 262598 Gear-Timing	
				691455 Crankshaft (Used After Code Date 97011200). Used on Type No(s). 0660, 0672, 0674, 4711.				

★ Included in Engine Gasket Set-See Ref. 358.
● Included in Carburetor Overhaul Kit-See Ref. 121.

◆ Included in Carburetor Gasket Set-See Ref. 977.
Included in Valve Overhaul Gasket Set-See Ref. 1095.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
4	493279	Sump-Engine ----- Note ----- 498983 Sump-Engine Used on Type No(s). 1762.	46A	691460	Camshaft (Clockwise) (Used After Code Date 96060200). Used on Type No(s). 0627.	83	231671	Shaft-Auxiliary Drive ----- Note ----- 690521 Shaft-Auxiliary Drive Used on Type No(s). 0144, 0644.
4A	493365	Sump-Engine			----- Note ----- 493740 Camshaft (Clockwise) (Used Before Code Date 96060300). Used on Type No(s). 0627.			690522 Shaft-Auxiliary Drive Used on Type No(s). 1770.
12	★272198	Gasket-Crankcase			691459 Camshaft (Counterclockwise) (Used After Code Date 96060200). Used on Type No(s). 0629, 0633, 0644, 1746, 1752, 1770.	101	93474	Pin-Shaft
15	94880	Plug-Oil Drain (Square)			493738 Camshaft (Counterclockwise) (Used Before Code Date 96060300). Used on Type No(s). 0144, 0644.	374	691074	Washer (Camshaft)
15A	691093	Plug-Oil Drain (Hex)				715	94874	Screw (Shaft Stop)
20	★399781	Seal-Oil (PTO Side)				721	690449	Stop-Shaft
20A	391484	Seal-Oil (Auxiliary PTO Side)				743	690516	Gear-Drive (Clockwise) Used on Type No(s). 0627.
22	691092	Screw (Engine Sump)						----- Note ----- 231279 Gear-Drive (Counterclockwise) Used on Type No(s). 0144, 0629, 0633, 0644, 1752, 1770.
43	493737	Slinger -Governor/Oil ----- Note ----- 691486 Slinger- Governor/Oil Used on Type No(s). 1762.				1102	691255	Guide-Pilot
46	691449	Camshaft (Used After Code Date 96060200). ----- Note ----- 492830 Camshaft (Used Before Code Date 96060300).						

★ Included in Engine Gasket Set-See Ref. 358.
● Included in Carburetor Overhaul Kit-See Ref. 121.

◆ Included in Carburetor Gasket Set-See Ref. 977.
Included in Valve Overhaul Gasket Set-See Ref. 1095.


127700 to 127799



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
95	94098	Screw (Throttle Valve)		497315	Jet-Main (High Altitude) (Used After Code Date 96060200).	125	498170	Carburetor (Used After Code Date 96060200).
97	493267	Shaft-Throttle		496495	Jet-Main (High Altitude) (Used After Code Date 95102900 and Before Code Date 96060300).			----- Note ----- 498254 Carburetor (Used After Code Date 95102900 and Before Code Date 96060300).
104	●691242	Pin-Float Hinge		497348	Jet-Main (High Altitude) (Used Before Code Date 95103000).			496114 Carburetor Used on Type No(s). 0100, 0117, 0119, 0124, 0130, 0131, 0144.
117	494870	Jet-Main (Standard) (Used After Code Date 96060200).		496063	Jet-Main (High Altitude) Used on Type No(s). 0100, 0117, 0119, 0124, 0130, 0131, 0144.	127	●694468	Plug-Welch
		----- Note ----- 497466 Jet-Main (Standard) (Used After Code Date 95102900 and Before Code Date 96060300).				130	691203	Valve-Throttle
		497315 Jet-Main (Standard) (Used Before Code Date 95103000).				133	398187	Float-Carburetor
		493637 Jet-Main (Standard) Used on Type No(s). 0100, 0117, 0119, 0124, 0130, 0131, 0144.				134	●398188	Kit-Needle/Seat
						137	●●693981	Gasket-Float Bowl
						163	★●◆272653	Gasket-Air Cleaner
						276	●●271716	Washer-Sealing
						365	94840	Screw (Carburetor)
						617	●●270344	O-Ring Seal (Intake Manifold)
						633	●◆691321	Seal-Throttle Shaft (Throttle Shaft)
						975	493640	Bowl-Float

★ Included in Engine Gasket Set-See Ref. 358.
● Included in Carburetor Overhaul Kit-See Ref. 121.

◆ Included in Carburetor Gasket Set-See Ref. 977.
Included in Valve Overhaul Gasket Set-See Ref. 1095.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
94	●493765	Kit-Idle Mixture	125A	498965	Carburetor (Used After Code Date 96060200).	217	262749	Spring-Choke Return
95	94098	Screw (Throttle Valve)			----- Note -----	276	●●271716	Washer-Sealing
97	493267	Shaft-Throttle			494217 Carburetor (Used Before Code Date 96060300).	365	94840	Screw (Carburetor)
98	398185	Kit-Idle Speed			499059 Carburetor Used on Type No(s). 1762.	617	●●270344	O-Ring Seal (Intake Manifold)
104	●691242	Pin-Float Hinge	127	●223472	Plug-Welch	633	●◆691321	Seal-Throttle Shaft
108	691182	Valve-Choke	130A	691181	Valve-Throttle	975	493640	Bowl-Float
109	494218	Shaft-Choke	133	398187	Float-Carburetor			
117A	498977	Jet-Main (Standard) (Used After Code Date 96060200).	134	●398188	Kit-Needle/Seat			
		----- Note -----	137	●◆693981	Gasket-Float Bowl			
		493637 Jet-Main (Standard) (Used Before Code Date 96060300).	163★	◆272653	Gasket-Air Cleaner			
		498981 Jet-Main (High Altitude) (Used After Code Date 96060200).						
		496063 Jet-Main (High Altitude) (Used Before Code Date 96060300).						

★ Included in Engine Gasket Set-See Ref. 358.
● Included in Carburetor Overhaul Kit-See Ref. 121.

◆ Included in Carburetor Gasket Set-See Ref. 977.
Included in Valve Overhaul Gasket Set-See Ref. 1095.

127700 to 127799







REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
98A	493280	Kit-Idle Speed	267	94882	Screw (Casing Clamp)	590	93758	Screw (Brake Bracket)
188	94644	Screw (Control Bracket)	268	65616	Casing-Control Wire (72" Long; Cut to Required Length)	621	396847	Switch-Stop
188A	94882	Screw (Control Bracket)	269	26633	Wire-Control (78" Long; Cut to Required Length)	624	691419	Bracket-Control
222	497203	Bracket-Control (Remote Manual Friction Primer)	270	63426	Nut (Control Wire Casing)	627	692872	Bracket-Stop Switch
222A	495975	Bracket-Control (Remote Choke A Matic)	271	290568	Lever-Control	668	★493823	Spacer (Includes 2)
		----- Note ----- 690839 Bracket- Control (Manual Friction Choke A Matic) Used on Type No(s). 0648, 0651, 0653, 0654, 0672, 0676, 0677.	347	691396	Switch-Rocker	745	94512	Screw (Brake)
222B	692982	Bracket-Control (Fixed Speed Five Position Manual Choke)	359	691077	Washer (Ground Terminal)	843	272616	Sleeve-Lever (Speed Control)
222C	692467	Bracket-Control (Fixed Speed)	373	90576	Nut (Ground Terminal)	843A	280149	Sleeve-Lever (Choke)
236	262461	Link-Lockout	410	690575	Link-Control	922	262640	Spring-Brake
259	691223	Bracket-Casing Clamp	497	94874	Screw (Stop Switch Bracket)	923	493442	Brake
265	213146	Clamp-Casing	507	398525	Insulator	935	499421	Switch-Interlock (Used After Code Date 92100600). ----- Note ----- 398758 Switch- Interlock (Used Before Code Date 92100700).
265A	221535	Clamp-Casing	520	691084	Terminal-Ground	940	94882	Screw (Casing Clamp Bracket)
						942	690455	Bracket-Brake
						1160	93758	Screw (Interlock Switch)

★ Included in Engine Gasket Set-See Ref. 358.

● Included in Carburetor Overhaul Kit-See Ref. 121.

◆ Included in Carburetor Gasket Set-See Ref. 977.

● Included in Valve Overhaul Gasket Set-See Ref. 1095.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION		
333	802574	Armature-Magneto	578	398153	Wire Assembly			(Used Before Code Date 00040700)		
334	94731	Screw (Magneto Armature)	789	695552	Harness-Wiring (Used After Code Date 00040600)	851	493880	Terminal-Sparkplugs		
356	692390	Wire-Stop	----- Note -----			910	691094	Stud (Alternator)		
356A	496381	Wire-Stop			691372		Harness-Wiring	1119	94512	Screw (Alternator)
356B	690650	Wire-Stop								
356C	693010	Wire-Stop								
474	492841	Alternator								

★ Included in Engine Gasket Set-See Ref. 358.
● Included in Carburetor Overhaul Kit-See Ref. 121.

◆ Included in Carburetor Gasket Set-See Ref. 977.
Included in Valve Overhaul Gasket Set-See Ref. 1095.

127700 to 127799










REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
202	262579	Link-Mechanical Governor	209A	691276	Spring-Governor			262665 Spring-Governor
209	263044	Spring-Governor			----- Note -----			Used on Type No(s). 0629, 0633, 0641, 0648, 0651, 0653, 0654.
		----- Note -----			690567 Spring-Governor			262666 Spring-Governor
		691290 Spring-Governor			Used on Type No(s). 0660.			Used on Type No(s). 0646, 0647.
		Used on Type No(s). 0674.			690568 Spring-Governor			690569 Spring-Governor
		691291 Spring-Governor			Used on Type No(s). 0672.			Used on Type No(s). 0627, 0632.
		Used on Type No(s). 4715.			691275 Spring-Governor	227	690783	Lever-Governor Control
		263042 Spring-Governor			Used on Type No(s). 0120, 0124.	404	690272	Washer (Governor Crank)
		Used on Type No(s). 0618, 0624, 0639, 1734.			262659 Spring-Governor	505	231082	Nut (Governor Lever)
		691292 Spring-Governor			Used on Type No(s). 0130.	562	92613	Bolt (Governor Lever)
		Used on Type No(s). 0600, 0608, 0645, 1700, 1708, 1710, 1711, 1713, 1745, 1746, 1791.			691834 Spring-Governor	615	690340	Retainer-Governor Shaft
		690241 Spring-Governor			Used on Type No(s). 0117, 0119, 0123, 0144.	616	691306	Crank-Governor
		Used on Type No(s). 1762.			262661 Spring-Governor			----- Note -----
					Used on Type No(s). 0100, 0115, 0131.			691308 Crank-Governor
					262664 Spring-Governor			Used on Type No(s). 1762.
					Used on Type No(s). 0626.	892	690646	Switch-Key
						990	392832	Key Set

★ Included in Engine Gasket Set-See Ref. 358.

● Included in Carburetor Overhaul Kit-See Ref. 121.

◆ Included in Carburetor Gasket Set-See Ref. 977.

Included in Valve Overhaul Gasket Set-See Ref. 1095.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
187	691050	Line-Fuel (15" Long Cut to Required Length)	930A	690598	Guard-Rewind (Trim Ring)	972A	497226	Tank-Fuel (1.5 Quart)
187A	691371	Line-Fuel (Molded)	957	397974	Cap-Fuel Tank	972B	497343	Tank-Fuel (1 Quart)
187B	498171	Line-Fuel	972	695106	Tank-Fuel (1 Quart)	1040	281252	Plate-Trim
190	94511	Screw (Fuel Tank)			(Used After Code Date 99101800).	1059	398540	Kit-Screw/Washer
240	298090	Filter-Fuel			----- Note -----			
601	95162	Clamp-Hose (Green)			497227 Tank-Fuel (1.5 Quart)			
670	280512	Spacer-Fuel Tank			(Used Before Code Date 99101900).			
930	281136	Guard-Rewind (Round)						

★ Included in Engine Gasket Set-See Ref. 358.
● Included in Carburetor Overhaul Kit-See Ref. 121.

◆ Included in Carburetor Gasket Set-See Ref. 977.
● Included in Valve Overhaul Gasket Set-See Ref. 1095.


127700 to 127799



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
81	223664	Lock-Muffler Screw	613A	94615	Screw (Exhaust Muffler)	967	493537	Filter-Pre Cleaner
159	224815	Bracket-Air Cleaner Primer	676	493871	Deflector-Muffler (Side Out Extended Horseshoe)	968	281340	Cover-Air Cleaner
163★◆	272653	Gasket-Air Cleaner	676A	393760	Deflector-Muffler (Side Out Deep)	970	94749	Screw (Air Cleaner Primer Bracket)
300	496106	Muffler (Tuned)	676B	396548	Deflector-Muffler (Louvered)	971	94873	Screw (Air Cleaner Primer Base)
300A	494343	Muffler (Square Lo-Tone)	676C	393756	Deflector-Muffler (Side Out Shallow)	976	694395	Primer-Carburetor (Used After Code Date 99103100).
346	94896	Screw (Spark Arrestor)	677	94896	Screw (Muffler Deflector)	----- Note -----		
425	94872	Screw (Air Cleaner Cover)	832	499034	Guard-Muffler	994	398067	Arrestor-Spark
445	491588	Filter-Air Cleaner Cartridge	836	94874	Screw (Muffler Guard)	994A	494486	Arrestor-Spark
529	281299	Grommet	883 ★	272253	Exhaust-Gasket	496115 Primer-Carburetor (Used Before Code Date 99110100).		
613	94231	Screw (Exhaust Muffler)	966	496116	Base-Air Cleaner Primer			

★ Included in Engine Gasket Set-See Ref. 358.
 ◆ Included in Carburetor Overhaul Kit-See Ref. 121.

◆ Included in Carburetor Gasket Set-See Ref. 977.
 Included in Valve Overhaul Gasket Set-See Ref. 1095.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
14	690368	Stud (Cylinder Head) Used on Type No(s). 0618, 0624.	304	493293	Housing-Blower ----- Note ----- 493294 Housing-Blower Used on Type No(s). 0115, 0626, 0639, 0646, 0660, 0672, 0674, 1734, 1762, 1770, 1783, 4711, 4715.	1036	695111	Label-Emissions (Used After Code Date 9909300). ----- Note ----- 694458 Label-Emissions (Used After Code Date 98123100 and Before Code Date 99100100). 499341 Label-Emissions (Used After Code Date 97052500 and Before Code Date 99010100). 690104 Label-Emissions (Used Before Code Date 97052600).
23	492177	Flywheel (Rewind Start)	305	691108	Screw (Blower Housing)			
23A	492175	Flywheel (Electric Start) ----- Note ----- 492893 Flywheel (Electric Start) Used on Type No(s). 0660, 0672, 0674, 1770, 1783, 4711, 4715.	332	94877	Nut (Flywheel)			
37	694086	Guard-Flywheel	353A	90832	Washer (Cylinder Head) Used on Type No(s). 0618, 0624.			
78	691108	Screw (Flywheel Guard)	363	19069	Flywheel Puller			
			986	693514	Filter-Debris			

★ Included in Engine Gasket Set-See Ref. 358.
● Included in Carburetor Overhaul Kit-See Ref. 121.

◆ Included in Carburetor Gasket Set-See Ref. 977.
Included in Valve Overhaul Gasket Set-See Ref. 1095.


127700 to 127799



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
55	691421	Housing-Rewind Starter	455	691219	Cup-Flywheel	689	263073	Spring-Friction
58	281464	Rope-Starter (Cut To Length)	456	281503	Plate-Pawl Friction	1210	498144	Pulley/Spring Assembly (Pulley)
60	281434	Grip-Starter Rope	459	281505	Pawl-Ratchet (Rewind Starter)	1211	498144	Pulley/Spring Assembly (Spring)
65	94904	Screw (Rewind Starter)	592	94908	Nut (Rewind Starter)			
73	691221	Screen-Rotating	597	94943	Screw (Pawl Friction Plate)			
			608	497680	Starter-Rewind			

★ Included in Engine Gasket Set-See Ref. 358.
 ● Included in Carburetor Overhaul Kit-See Ref. 121.

◆ Included in Carburetor Gasket Set-See Ref. 977.
 Included in Valve Overhaul Gasket Set-See Ref. 1095.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
55A	492831	Housing-Rewind Starter	65A	94686	Screw (Rewind Starter)	459A	492833	Pawl-Ratchet
57	491889	Spring-Rewind Starter	73	691221	Screen-Rotating	592	94908	Nut (Rewind Starter)
58	280399	Rope-Starter (Cut To Length)	101	262626	Pin-Shaft	608A	497598	Starter-Rewind
59	396892	Insert-Grip	144	493824	Pulley/Spring Assembly	678	224278	Spacer-Rewind
60A	393152	Grip-Starter Rope	276A	280973	Washer-Sealing	689A	262625	Spring-Friction
			455	691219	Cup-Flywheel	1134	224322	Washer (Pawl Friction Plate)
			456A	224321	Plate-Pawl Friction			

★ Included in Engine Gasket Set-See Ref. 358.
 ● Included in Carburetor Overhaul Kit-See Ref. 121.

◆ Included in Carburetor Gasket Set-See Ref. 977.
 Included in Valve Overhaul Gasket Set-See Ref. 1095.





127700 to 127799



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
309	695550	Motor-Starter (Used After Code Date 00040600). ----- Note ----- 691376 Motor-Starter (Used Before Code Date 00040700).	545	492919	Washer Set (Starter Motor)	802	695267	Cap-End (Used After Code Date 00040600). ----- Note ----- 690787 Cap-End (Used Before Code Date 00040700).
310	692327	Bolt (Starter Motor)	651	93490	Screw (Starter Gear Cover)	803	695266	Housing-Starter (Used After Code Date 00040600). ----- Note ----- 690785 Housing-Starter (Used Before Code Date 00040700).
510	494147	Drive-Starter	697	691127	Screw (Drive Cap)	853	695268	Adapter-Wire
513	692358	Clutch-Drive	742	93941	Retainer-E Ring	937	691325	Spline-Starter
544	690786	Armature-Starter	783	281127	Gear-Pinion			
			783A	691269	Gear-Pinion			
			784	692341	Cover-Starter Gear			
			785	692352	Gasket-Starter Cover			
			801	690782	Cap-Drive			

★ Included in Engine Gasket Set-See Ref. 358.
● Included in Carburetor Overhaul Kit-See Ref. 121.

◆ Included in Carburetor Gasket Set-See Ref. 977.
● Included in Valve Overhaul Gasket Set-See Ref. 1095.



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
3	★299819	Seal-Oil (Magneto Side)	121	498260	Kit-Carburetor Overhaul	585	★272238	Gasket-Breather Passage
7	★ 272916	Gasket-Cylinder Head	127	●223472	Plug-Welch	617	●◆270344	O-Ring Seal (Intake Manifold)
9	★ 272481	Gasket-Breather	134	●398188	Kit-Needle/Seat	633	●◆691321	Seal-Throttle Shaft
12	★272198	Gasket-Crankcase	137	●693981	Gasket-Float Bowl	668	★493823	Spacer (Includes 2)
20	★399781	Seal-Oil (PTO Side)	163	●◆272257	Gasket-Air Cleaner	842	★280393	O-Ring Seal
51	★272199	Gasket-Intake	276	●◆271716	Washer-Sealing	883	★ 272253	Gasket-Exhaust
94	●493765	Kit-Idle Mixture	358	497316	Gasket Set-Engine	977	498261	Gasket Set-Carburetor
104	●691242	Pin-Float Hinge	524	★280966	Seal-Dipstick Tube	1095	498528	Gasket Set-Valve

★ Included in Engine Gasket Set-See Ref. 358.
● Included in Carburetor Overhaul Kit-See Ref. 121.

◆ Included in Carburetor Gasket Set-See Ref. 977.
Included in Valve Overhaul Gasket Set-See Ref. 1095.