

TYPE NUMBERS 0100.

TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW


- A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- B. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- C. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."
- D. If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- E. If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- F. For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.



COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

PRINTED IN U.S.A.

K&T Saw Shop 606-678-9623 or 606-561-4983




★ REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL.

1058 OWNER'S MANUAL

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1		Cylinder Assembly	307	690345		552	692346	Bushing-Governor
2	399269	U U			(Cylinder Shield)	-10		Crank
		(Magneto Side)	307A	691003		718		Pin–Locating
3	*299819		441	604262	(Cylinder Shield) Bracket–Oil Fill	842	280393	Seal–O Ring
15	0/016	(Magneto Side) Plug–Oil Drain	441		Screw	847	693617	(Dipstick) Dipstick/Tube
306		Shield-Cylinder		34323	(Oil Fill Bracket)	047	033017	Assembly
			523	693618	Dipstick	1019	695751	, ,
					F	1058	274690	Manual-Owner's


 \star Included in Engine Gasket Set–Ref. No. 358. Δ Included in Valve Gasket Set–Ref. No. 1095.



REF. PART NO. NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
24 222698	Crankshaft Key–Flywheel Piston Assembly (Standard) —— Note —— 692788 Piston Assembly (.010" O.S.) 692789 Piston Assembly	26 27	263190	Ring Set (Standard) 	32 32A 46 146 219 220 741	94388 693578 221551 692565	(Connecting Rod) Screw (Connecting Rod) Camshaft Key–Timing Gear–Governor Washer (Governor Gear) Gear–Timing
	(.020" O.S.) 692790 Piston Assembly (.030" O.S.)	28 29 30	690124	Pin–Piston Rod–Connecting Dipper–Connecting Rod	742 746		Retainer–E–Ring Gear–Idler


 Δ Included in Valve Gasket Set–Ref. No. 1095.

Included in Carburetor Gasket Set–Ref. No. 977.



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
13 33 34 35 36 40 45 51∗◆	Ø695166 691137 499642 499641 691304 691304 93312 262679 ∞692555	Head–Cylinder Gasket–Cylinder Head Screw (Cylinder Head) Valve–Exhaust Valve–Intake Spring–Valve (Intake) Spring–Valve (Exhaust) Retainer–Valve Gasket–Intake (2 Required)	122 155 189 238 337 383 619 635 798 830	695168 694543 691300 491055	(Cylinder Head Plate) Boot–Spark Plug Screw (Rocker Arm) Stud (Rocker Arm)	914 914A 993 * 1022 * 1023 1026 1029 1034	94786 692557 ©691892 ©691890 499924 693517 691230 691343	(Rocker Cover) (7/16" Long) Screw (Rocker Cover) (3/8" Long)


 \star Included in Engine Gasket Set–Ref. No. 358. Δ Included in Valve Gasket Set–Ref. No. 1095.



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
12 18		Gasket–Crankcase Cover–Crankcase	20 21	★692550 281658	Seal–Oil (PTO Side) Cap–Oil Fill	22	692551	Screw (Crankcase Cover)

 \star Included in Engine Gasket Set–Ref. No. 358. Δ Included in Valve Gasket Set–Ref. No. 1095. Included in Carburetor Overhaul Kit–Ref. No. 121.
 Included in Carburetor Gasket Set–Ref. No. 977.

6503-5




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
51∗♦	•ø692555	Gasket–Intake (2 Required)	122 125		Spacer–Carburetor Carburetor	365	692568	Screw (Carburetor)
95	94098		127 130		Plug–Welch Valve–Throttle	633	●◆693867	Seal–Choke/Throttle Shaft
97 98		Shaft–Throttle Kit–Idle Speed	133	398187	Float–Carburetor Kit–Needle/Seat	633A	●◆691321	Seal–Choke/Throttle Shaft
	•691242	Pin–Float Hinge Valve–Choke		●◆693981	Gasket–Float Bowl Connector–Hose	692	690572	Spring–Detent (Choke)
109 117		Shaft–Choke Jet–Main	276	● + 271716	Washer-Sealing	975	493640	Bowl-Float
		(Standard)						
	la dia Erra	ine Casket Set_Ref. No. 3				udad in Car	hurstor Oue	arbaul Kit_Ref. No. 121

 \star Included in Engine Gasket Set–Ref. No. 358. Δ Included in Valve Gasket Set–Ref. No. 1095.


• Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION		
188	94644	Screw	270	63426	Nut	562	94852	Bolt		
188A	695709	(Control Bracket) Screw (Control Bracket)	271 271A		(Control Wire Casing) Lever–Control Lever–Control	615	692576	(Governor Control Lever) Retainer–Governor		
209	692571	1 5	427	694255				Shaft		
209A		Spring–Governor	405		(Control Bracket)	616		Crank–Governor		
222		Bracket–Control Lever–Governor	485 504		Knob–Control Set–Friction Washer	621		Switch–Stop		
227	092073	Control	504 505	231082		632	092003	Spring/Link– Mechanical Governor		
268	691072	Casing–Control Wire			(Governor Control	668	694257			
		(Cut to Length)			Lever)	773		Retainer		
269	26099	Wire-Control								
		(Cut to Length)								
	t Included in Engine Gasket Set–Ref. No. 358 ● Included in Carburetor Overhaul Kit–Ref. No. 121.									

 \star Included in Engine Gasket Set–Ref. No. 358. Δ Included in Valve Gasket Set–Ref. No. 1095.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
REF. NO. 333 334	NO. 695711	DESCRIPTION Armature–Magneto Screw (Magneto Armature)	REF. NO. 356 851	NO. 695731	DESCRIPTION Wire–Stop Terminal–Spark Plug	REF. NO. 892 990	NO.	Switch–Key
		ing Gasket Set-Ref. No. 2						rhaul Kit-Ref. No. 121

 $\star\,$ Included in Engine Gasket Set–Ref. No. 358. $\Delta\,$ Included in Valve Gasket Set–Ref. No. 1095.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
187	298049	Line–Fuel (Cut to Required	190 601		Clamp-Hose	958 972		Valve–Fuel Shut–Off Tank–Fuel
187A	692601	Length) Line–Fuel (Molded)	957	695737	Cap–Fuel Tank			

 \star Included in Engine Gasket Set–Ref. No. 358. Δ Included in Valve Gasket Set–Ref. No. 1095.



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
300 613A	695735 694460		819 823	94914 94706	(Muffler Bracket)	883	272309	Gasket–Exhaust (Between Adapter and Muffler)
613B	691108		823 863 864	695734	(Muffler Adapter) Bracket–Muffler Adapter–Muffler	883A	274246	
		ing Gasket Set-Pof. No. 2						rbaul Kit-Ref. No. 121


 \star Included in Engine Gasket Set–Ref. No. 358. Δ Included in Valve Gasket Set–Ref. No. 1095. Included in Carburetor Overhaul Kit–Ref. No. 121.
 Included in Carburetor Gasket Set–Ref. No. 977.



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
23 332	NO.	Flywheel	363 455 1005	NO. 19069 692591	DESCRIPTION Puller–Flywheel Cup–Flywheel Fan–Flywheel	1162	692590	

 \star Included in Engine Gasket Set–Ref. No. 358. Δ Included in Valve Gasket Set–Ref. No. 1095.


Included in Carburetor Overhaul Kit–Ref. No. 121.
 Included in Carburetor Gasket Set–Ref. No. 977.



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	
11 37 65		Tube–Breather Guard–Flywheel	305 318	690960 690370		731 976 1036	695750	Hood–Snow Primer–Carburetor Label–Emissions	
78	695724	(Rewind Starter) Screw	472 493	695744	Knob–Choke Shaft Bracket–Mounting	1196	695733	Screw (Snow Hood)	
281	695732	((Flywheel Guard) (Blower Housing) Panel–Control	528 604 663		Hose–Primer Cover–Control Screw	1224	94581	Nut (Carburetor Primer)	
304	695753	Housing–Blower			(Control Panel)				
★ Includ	Included in Engine Gasket Set–Ref. No. 358. Included in Carburetor Overhaul Kit–Ref. No. 121. 								

 Δ Included in Valve Gasket Set–Ref. No. 1095.

◆ Included in Carburetor Gasket Set-Ref. No. 977.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
55	695739	Housing–Rewind Starter	65	692608	Screw (Rewind Starter)	689 1210		Spring–Friction Pulley/Spring
58	693389		456 459		Plate–Pawl Friction Pawl–Rachet			Assembly (Pulley)
60	695740	Length)	597	94943		1211	498144	Pulley/Spring Assembly
	093740	Ghp-Statter Rope	608	695738	Starter–Rewind			(Spring)
								rhaul Kit–Ref. No. 121.

 Δ Included in Engine Gasket Set–Ref. No. 358.

Included in Carburetor Overhau Ric-Ref. No. 121.
 Included in Carburetor Gasket Set–Ref. No. 977.

K&T Saw Shop 606-678-9623 or 606-561-4983



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
3	*299819		121	695157	Carburetor Overhaul	633A	● + 691321	
		(Magneto Side)			Kit			Shaft
7★	Ø 695166	Gasket–Cylinder Head	122		Spacer–Carburetor	868		Seal–Valve
12	* 692549	Gasket–Crankcase	127	●694468	Plug–Welch	977		Gasket Set–Carburetor
20	* 692550	Seal–Oil	134	● 39818 8	Kit–Needle/Seat	993	★ Ø691892	Gasket–Cylinder Head
		(PTO Side)	137	●◆693981	Gasket–Float Bowl			Plate
51∗∙	•ø692555	Gasket–Intake	276	●◆271716	Washer-Sealing	1022	★ ∅691890	Gasket–Rocker Cover
		(2 Required)	358	695155	Gasket Set-Engine	1095	695289	Gasket Set–Valve
104	●691242	Pin-Float Hinge	633	•+693867	Seal-Choke/Thottle			
		5			Shaft			
L		ne Gasket Set–Ref. No. 3			• Incluc			rhaul Kit–Ref. No. 121.

 \star Included in Engine Gasket Set–Ref. No. 358. Δ Included in Valve Gasket Set–Ref. No. 1095.

Included in Carburetor Overhaul Kit–Ref. No. 121.
 Included in Carburetor Gasket Set–Ref. No. 977.

K&T Saw Shop 606-678-9623 or 606-561-4983