Illustrated Parts List Model Series 12D400 to 12D499

TYPE NUMBERS 0007, 0009, 0100, 0017, 0018, 0019.


TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW

- A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- B. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- C. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."
- D. If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- E. If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- F. For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.

BRIGGS & STRATTON

PRINTED IN U.S.A.


COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted,
in any form or by any means, electronic or mechanical, including photocopying,
recording or by any information storage and retrieval system, without permission
in writing from Briggs & Stratton Corporation.



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1		Cylinder Assembly	307A	691003		718		Pin-Locating
2	399269	Kit-Bushing/Seal (Magneto Side)	441	694262	(Cylinder Shield) Bracket–Oil Fill	842 847		Dipstick/Tube Seal Dipstick/Tube
3	*299819	Seal-Oil	449	94929	Screw			Assembly
15	94916	(Magneto Side) Plug-Oil Drain	523	693618	(Oil Fill Bracket) Dipstick	1019 1058		Kit–Label Manual–Owner's
306		Shield-Cylinder	552		Bushing-Governor	1000	21 7030	Manda Owners
307	690345	Screw			Crank			
		(Cylinder Shield)						

 $[\]star$ Included in Engine Gasket Set–Ref. No. 358. Δ Included in Valve Gasket Set–Ref. No. 1095.

Included in Carburetor Overhaul Kit–Ref. No. 121.
 Included in Carburetor Gasket Set–Ref. No. 977.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
16	693887	Crankshaft Note 695763 Crankshaft	26	499631	(Standard) Note	46		Camshaft Used on Type No(s). 0100.
24 25		Used on Type No(s). 0009, 0019. Key–Flywheel Piston Assembly			692785 Ring Set (.010" O.S.) 692786 Ring Set (.020" O.S.)	46A 146	694831 94388	Camshaft Used on Type No(s). 0110. Key–Timing
25	499627	Piston Assembly (Standard)			692787 Ring Set	219	693578	Gear-Governor
		Note 692788 Piston Assembly (.010" O.S.) 692789 Piston Assembly (.020" O.S.) 692790 Piston Assembly (.030" O.S.)	27 28 29 30 32	499423 690124 692562	(.030" O.S.) Lock-Piston Pin Pin-Piston Rod-Connecting Dipper-Connecting Rod Screw (Connecting Rod) Screw	741 742 746	692565 692564	Washer (Governor Gear) Gear-Timing ————————————————————————————————————

 $[\]star$ Included in Engine Gasket Set–Ref. No. 358. Δ Included in Valve Gasket Set–Ref. No. 1095.

[•] Included in Carburetor Overhaul Kit-Ref. No. 121.

[◆] Included in Carburetor Gasket Set-Ref. No. 977.





REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
NO. 5 7 ** 13 33 34 35 36 40 45	NO. 693643 695166 691137 499642 499641 691304 691304 93312 262679	Head-Cylinder Gasket-Cylinder Head	NO. 122 155 189 238 337 383 619 635 798	NO. •693749 695168 694543 691300 491055 19374 691108 280897 692559	Spacer–Carburetor Plate–Cylinder Head Ball–Rocker Arm Cap–Valve Sparkplug Wrench–Sparkplug Screw (Cylinder Head Plate) Boot–Sparkplug Screw (Rocker Arm)	914 914A 993 *	NO. 94786 692557 Ø691892 Ø691890 499924 693517 691230	Screw (Rocker Cover) (7/16" Long) Screw (Rocker Cover) (3/8" Long)

 $[\]star$ Included in Engine Gasket Set–Ref. No. 358. Δ Included in Valve Gasket Set–Ref. No. 1095.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

[•] Included in Carburetor Overhaul Kit-Ref. No. 121.






REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
12 18 18A	*692549 693204	Gasket–Crankcase Cover–Crankcase Cover–Crankcase Used on Type No(s). 0018.		*692550 *391484	(PTO Side)	21 22	281658 692551	Cap-Oil Fill Screw (Crankcase Cover)

 [★] Included in Engine Gasket Set–Ref. No. 358.
 △ Included in Valve Gasket Set–Ref. No. 1095.

6505–5 Assemblies include all parts shown in frames.

Included in Carburetor Overhaul Kit–Ref. No. 121.
 Included in Carburetor Gasket Set–Ref. No. 977.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
51∗	•∞692555	Gasket-Intake (2 Required)	117	690048	Jet-Main (Standard)	186 276		Connector-Hose Washer-Sealing
95	94098	Screw (Throttle Valve)			Note 498977 Jet-Main	365	692568	Screw (Carburetor)
97 98		Shaft–Throttle Kit–Idle Speed	122	•693749	(High Altitude) Spacer–Carburetor	633	●◆ 693867	Seal–Choke/Throttle Shaft
104 108		Pin–Float Hinge Valve–Choke	125 127	695727	Carburetor Plug–Welch	633A	●◆ 691321	Seal–Choke/Throttle Shaft
109	695729	Shaft-Choke	130 133		Valve–Throttle Float–Carburetor	692		Spring-Detent (Choke)
			134 137		Kit-Needle/Seat Gasket-Float Bowl	975	493640	Bowl–Float

 $[\]star$ Included in Engine Gasket Set–Ref. No. 358. Δ Included in Valve Gasket Set–Ref. No. 1095.

[•] Included in Carburetor Overhaul Kit–Ref. No. 121.

[◆] Included in Carburetor Gasket Set-Ref. No. 977.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
188	94644	Screw (Control Bracket)	271 271A		Control Lever Lever–Control	615	692576	Retainer–Governor Shaft
188A	695709	,	427	694255		616 621		Crank–Governor Switch–Stop
209 209A 222 227	261306 695742	Spring-Governor Spring-Governor Bracket-Control Lever-Governor	485 504 505		Knob–Control Washer Set–Friction Nut	632 668	693408 694257	Spring/Link- Mechanical Governo Spacer
268 269		Control Control Wire Casing (Cut to Length) Control Wire	562	94852	(Governor Control Lever) Bolt (Governor Control	773	694258	Retainer
270	63426	(Cut to Length)			Lever)			
210	03420	(Control Wire Casing)						

 $[\]star$ Included in Engine Gasket Set–Ref. No. 358. Δ Included in Valve Gasket Set–Ref. No. 1095.

6505-7


Included in Carburetor Overhaul Kit–Ref. No. 121.
 Included in Carburetor Gasket Set–Ref. No. 977.



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
318	690370		334	94731		851 892		Terminal–Sparkplug Switch–Key
333	695711	(Mounting Bracket) Armature–Magneto	356 493		(Magneto Armature) Wire–Stop Bracket–Mounting	892 990	695747 695756	Switch–Key Key

 $[\]star$ Included in Engine Gasket Set–Ref. No. 358. Δ Included in Valve Gasket Set–Ref. No. 1095.

Included in Carburetor Overhaul Kit–Ref. No. 121.
 Included in Carburetor Gasket Set–Ref. No. 977.



187 298049 Line–Fuel (Cut to Required Length) 190 692127 Screw (Fuel Tank) 958 692586 Valve–Fuel Shut–Guel (Fuel Tank) 187A 692601 Line–Fuel (Molded) 957 695737 Cap–Fuel Tank	REF. NO.		DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
	187	(Cı	cut to Required			(Fuel Tank)			
	187A	A 692601 Lin	ne-Fuel						


 $[\]star$ Included in Engine Gasket Set–Ref. No. 358. Δ Included in Valve Gasket Set–Ref. No. 1095.

6505-9

Assemblies include all parts shown in frames.

2Q-7/2000


Included in Carburetor Overhaul Kit–Ref. No. 121.
 Included in Carburetor Gasket Set–Ref. No. 977.



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
300 613	695735 694460		819 823		Screw (Muffler Bracket) Screw	863 864 883	694430	Bracket–Muffler Adapter–Muffler Gasket–Exhaust
613A	691108				(Muffler Adapter)	883A		Gasket–Exhaust

 $[\]star$ Included in Engine Gasket Set–Ref. No. 358. Δ Included in Valve Gasket Set–Ref. No. 1095.

Included in Carburetor Overhaul Kit–Ref. No. 121.
 Included in Carburetor Gasket Set–Ref. No. 977.



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
23	695741	Flywheel Note 695769 Flywheel	309		Motor-Starter	363 455 1005	692591 692592	Puller–Flywheel Cup–Flywheel Fan–Flywheel
		Used on Type No(s). 0100	332	94877	Nut (Flywheel)	1162	692590	Screw (Flywheel Fan)


 [★] Included in Engine Gasket Set–Ref. No. 358.
 △ Included in Valve Gasket Set–Ref. No. 1095.

6505-11

Assemblies include all parts shown in frames.

2Q-7/2000


Included in Carburetor Overhaul Kit–Ref. No. 121.
 Included in Carburetor Gasket Set–Ref. No. 977.



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
11 37 65		Tube–Breather Guard–Flywheel Screw (Rewind Starter)	305 472 528		Screw (Blower Housing) Knob–Choke Shaft Hose–Primer	731 976 1036 1196	695750	Hood–Snow Primer–Carburetor Label–Emissions Screw
78	695724	Screw (Flywheel Guard)	604 663		Cover–Control Screw	1224	94581	(Snow Hood) Nut
281 304		Panel–Control Housing–Blower			(Control Panel)			(Carburetor Primer)

 $[\]star$ Included in Engine Gasket Set–Ref. No. 358. Δ Included in Valve Gasket Set–Ref. No. 1095.

Included in Carburetor Overhaul Kit–Ref. No. 121.
 Included in Carburetor Gasket Set–Ref. No. 977.





REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
55	695739	Housing–Rewind Starter	456 459		Plate–Pawl Friction Pawl–Rachet	1210	498144	Pulley/Spring Assembly
58	693389		597 608	94943	Screw (Pawl Friction Plate) Starter–Rewind	1211	498144	(Pulley) Pulley/Spring Assembly
60 65	695740 692608	Grip-Starter Rope	608 689		Starter–Rewind Spring–Friction			Assembly (Spring)


 $[\]star$ Included in Engine Gasket Set–Ref. No. 358. Δ Included in Valve Gasket Set–Ref. No. 1095.


6505-13

Included in Carburetor Overhaul Kit–Ref. No. 121.
 Included in Carburetor Gasket Set–Ref. No. 977.









REF. PART NO. NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
3 ★299819 7 ★∅695166	Seal-Oil (Magneto Side) Gasket-Cylinder Head (Used After Code Date 9911300). Note *Ø 273489 Gasket- Cylinder Head (Used Before Code Date 99120100). Gasket-Crankcase	20A 51* 104 121 122 127 134 137	*391484 ••∞692555 •691242 695157 •693749 •694468 •398188 •693981		358 633 633A 868 977 993	695155 ••693867 ••691321 *Ø498592 695156 *Ø691892 *Ø691890	Set-Engine Gasket Seal-Choke/Throttle Shaft Seal-Choke/Throttle Shaft Seal-Valve Set-Carburetor Gasket Gasket-Cylinder Head Plate

 $[\]star$ Included in Engine Gasket Set–Ref. No. 358. Δ Included in Valve Gasket Set–Ref. No. 1095.

Included in Carburetor Overhaul Kit–Ref. No. 121.

[◆] Included in Carburetor Gasket Set-Ref. No. 977.