



122400

Illustrated Parts List

Model Series

122400

TYPE NUMBERS
0110 through 0138.

TABLE OF CONTENTS

Air Cleaner	5
Blower Housing	6
Camshaft	2
Carburetor	4
Controls	5
Crankcase Cover	2
Crankshaft	2
Cylinder	2
Cylinder Head	3
Electric Starter	6
Exhaust System	5
Flywheel	6
Fuel Supply	4
Governor Spring	5
Gear Reduction	6
Ignition	5
Kits/Gaskets - Carburetor	4
Kits/Gaskets - Engine	2
Kits/Gaskets - Valve	3
Lubrication	2
Piston Group	2
Rewind Starter	6



PRINTED IN U.S.A.












COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

122400





1019 LABEL KIT

1058 OWNER'S MANUAL

1330 REPAIR MANUAL











Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 3379-3 Assemblies include all parts shown in frames.

11/07/2005

122400









Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

122400



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	699490	Cylinder Assembly	18A	790337	Cover-Crankcase Used on Type No(s). 0110, 0112, 0113, 0114, 0115, 0118, 0119, 0122, 0123, 0124, 0125, 0127, 0128, 0129, 0135, 0136, 0137, 0138.	26	791969	Ring Set (Standard) (Used After Code Date 05093000). ----- Note -----
2	399269	Kit-Bushing/Seal (Magneto Side)						499631 Ring Set (Standard) (Used Before Code Date 05100100).
3	★299819S	Seal-Oil (Magneto Side)	18D	790330	Cover-Crankcase Used on Type No(s). 0111, 0121, 0126, 0130.			791324 Ring Set (.020" Oversize) (Used After Code Date 05093000).
5	699486	Head-Cylinder	20	★692550	Seal-Oil (PTO Side)			692786 Ring Set (.020" Oversize) (Used Before Code Date 05100100).
7	★Ø698210	Gasket-Cylinder Head	21	281658S	Cap-Oil Fill			692786 Ring Set (.020" Oversize) (Used Before Code Date 05100100).
11	812208	Tube-Breather (Flat Panel Air Cleaner)	22	699478	Screw (Crankcase Cover/ Sump)	27	691866	Lock-Piston Pin
12	★699485	Gasket-Crankcase	23	699488	Flywheel ----- Note ----- 699514 Flywheel Used on Type No(s). 0121.	28	499423	Pin-Piston
13	699482	Screw (Cylinder Head)	24	222698S	Key-Flywheel	29	690124	Rod-Connecting ----- Note ----- 792247 Rod- Connecting (.020" Undersize)
15	691686	Plug-Oil Drain (Square Head)	25	792004	Piston Assembly (Standard) (Used After Code Date 05093000). ----- Note ----- 499627 Piston Assembly (Standard) (Used Before Code Date 05100100). 791325 Piston Assembly (.020" Oversize) (Used After Code Date 05093000). 692789 Piston Assembly (.020" Oversize) (Used Before Code Date 05100100).	30	791584	Dipper-Connecting Rod
15A	691682	Plug-Oil Drain (Flush)				32	691664	Screw (Connecting Rod)
16	699835	Crankshaft Used on Type No(s). 0112, 0115. ----- Note ----- 699443 Crankshaft Used on Type No(s). 0113, 0114, 0124, 0125, 0135, 0136, 0137, 0138. 790329 Crankshaft Used on Type No(s). 0111, 0121, 0126, 0130. 698879 Crankshaft Used on Type No(s). 0110, 0118, 0119, 0122, 0123, 0127, 0128, 0129, 0132. 699452 Crankshaft Used on Type No(s). 0120.				32A	695759	Screw (Connecting Rod)
17	692517	Bearing-Ball				33	499642	Valve-Exhaust
17A	690824	Bearing-Ball				34	499641	Valve-Intake
						35	691304	Spring-Valve (Intake)
						36	691304	Spring-Valve (Exhaust)
						37	699661	Guard-Flywheel
						38	698557	Screw (Shut Off Valve)
						40	692194	Retainer-Valve
						45	690977	Tappet-Valve

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

Ø Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

122400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
46A	696813	Camshaft	155	★698214	Plate-Cylinder Head	231	690718	Screw
51★	∅692555	Gasket-Intake	161	699207	Base-Air Cleaner			(Choke Valve)
55	798148	Housing-Rewind Starter			(Metal)	238	691300	Valve-Cap
58	66574	Rope-Starter			(Flat Panel Air Cleaner)	265	691024	Clamp-Casing
		(Cut to Required Length)	163B★	◆696024	Gasket-Air Cleaner	267	699492	Screw
59	490653	Grip-Insert			(Flat Panel Air Cleaner)			(Casing Clamp)
60	490652	Grip-Starter Rope	180	791598	Tank-Fuel	268	691025	Casing-Control Wire
65	699228	Screw			(Metal)			(Cut to Required Length)
		(Rewind Starter)	181	699840	Cap-Fuel Tank	269	691026	Wire-Control
78	699205	Screw			(Metal)			(Cut to Required Length)
		(Flywheel Guard)	187B	791874	Line-Fuel	270	691027	Nut
82	807421	Screw			(Molded)			(Control Wire Casing)
		(Gear Reduction Case)			(Used After Code Date 05063000).	271	691028	Lever-Control
86	790332	Cover-Gear			----- Note -----	271A	694256	Lever-Control
88	790333	Gasket-Gear			693401 Line-Fuel	276A	◆698540	Washer-Sealing
		Reduction Cover			(Molded)	281	790261	Panel-Control
95A	698544	Screw			(Used Before Code Date 05070100).			----- Note -----
		(Throttle Valve)						699639 Panel-Control
97A	698542	Shaft-Throttle						Used on Type No(s).
98B	698551	Kit-Idle Speed	188	699479	Screw			0121, 0136.
104A	◆698536	Pin-Float Hinge			(Control Bracket)	286	698611	Module-Oil Sensor
105	698537	Valve-Float Needle	190	699220	Screw	287	699629	Screw
108C	698546	Valve-Choke			(Fuel Tank)			(Dipstick Tube)
117A	698666	Jet-Main	190B	699839	Screw	300A	699231	Muffler
		(Standard)			(Fuel Tank)	300E	791595	Muffler
118A	698552	Jet-Main			(High Altitude)	304	699598	Housing-Blower
		(High Altitude)	192	694543	Adjuster-Rocker Arm	305	699480	Screw
121B	698567	Kit-Carburetor	209	692571	Spring-Governor			(Blower Housing)
		Overhaul			----- Note -----	306	693610	Shield-Cylinder
122	★◆693749	Spacer-Carburetor			693206 Spring-Governor	307	699483	Screw
125A	698558	Carburetor			Used on Type No(s).			(Cylinder Shield)
127C	◆690727	Plug-Welch			0119, 0122, 0128,	309	694504	Motor-Starter
130B	698543	Valve-Throttle			0129, 0132.	310	690323	Screw
133A	698539	Float-Carburetor						(Starter Motor)
137A	◆698538	Gasket-Float Bowl	209A	691278	Spring-Governor	311	497608	Brush Set
141	698545	Kit-Choke Shaft	219	693578	Gear-Governor	332	699359	Nut
146	690979	Key-Timing	220	691724	Washer			(Flywheel)
		----- Note -----			(Governor Gear)	333	695711	Armature-Magneto
		790943 Key-Timing	222	699589	Bracket-Control	334	699477	Screw
		Used on Type No(s).	222C	699493	Bracket-Control			(Magneto Armature)
		0111, 0121, 0126,	227	692573	Lever-Governor			
		0130.			Control			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
337	491055S	Plug-Spark (Resistor)	524	281370S	Seal-Dipstick Tube	675	691261	Washer (Brush Retainer)
		----- Note -----	535	696263	Filter-Air Cleaner Foam	676	393760	Deflector-Muffler
		691043 Plug-Spark (EMS)	544	692966	Armature-Starter	677	690661	Screw (Muffler Deflector)
347	698338	Switch-Rocker	552	692346	Bushing-Governor Crank	689	691855	Spring-Friction
		----- Note -----	562	691119	Bolt (Governor Control Lever)	692	690572	Spring-Detent
		697854 Switch-Rocker Used on Type No(s). 0110, 0112, 0114, 0118, 0119, 0122, 0123, 0125, 0135, 0136.	564	699491	Screw (Control Cover)	697	790537	Screw (Starter Motor)
356	692602	Wire-Stop	564A	699206	Screw (Control Cover)	718	690959	Pin-Locating
356A	695630	Wire-Stop	597	691696	Screw (Pawl Friction Plate)	727	698039	Cover-Starter Drive
356K	791678	Wire-Stop	601	95162S	Clamp-Hose	732	699200	Screw (Starter Drive Cover)
358	699638	Gasket Set-Engine	604	697326	Cover-Control	741	695087	Gear-Timing
363	19069	Puller-Flywheel	608	791670	Starter-Rewind	742	692564	Retainer-E Ring
364	695693	Terminal-Oil Plug	613	699209	Screw (Muffler)	746	692566	Gear-Idler
365	699484	Screw (Carburetor)	613A	699230	Screw (Muffler)	773	694258	Retainer
383	19374S	Wrench-Spark Plug	613B	697812	Screw (Muffler)	783	692353	Gear-Pinion
415	693463	Plug (Air Cleaner Cover)	615	692576	Retainer-Governor Shaft	797	691029	Nut (Brush Retainer)
425	699208	Screw	616	692547	Crank-Governor	799	699202	Screw (Oil Sensor)
427	694255	Nut (Control Bracket)	619	699230	Screw (Cylinder Head Plate)	801	694482	Cap-Drive
445	491588S	Filter-Air Cleaner Cartridge (Flat Panel)	621	692310	Switch-Stop	802	691286	Cap-End
455	692591	Cup-Flywheel	632	693408	Spring/Link- Mechanical Governor	803	693757	Housing-Starter
456	692299	Plate-Pawl Friction	633B	◆690998	Seal-Choke/Throttle Shaft	819	699233	Screw (Muffler Bracket)
459	281505S	Pawl-Ratchet	635	692927	Boot-Spark Plug	823	699209	Screw (Muffler Adapter)
464	◆698550	Seal-O Ring (Fuel Shut Off Valve)	643	696264	Retainer-Air Filter	830	694544	Stud-Rocker Arm
474	695730	Alternator	652	699755	Screw (Support Bracket)	832A	697818	Guard-Muffler
504	694254	Washer Set-Friction	652A	699230	Screw (Support Bracket)	832D	791600	Guard-Muffler
505	691251	Nut (Governor Control Lever)	663	699206	Screw (Control Panel)	836B	699209	Screw (Muffler Guard)
510	499308	Drive-Starter	668	694257	Spacer	836C	699234	Screw (Muffler Guard)
513	692024	Drive-Clutch				836E	699491	Screw (Muffler Guard)
522	697689	Plug-Dipstick/Fill				842	691031	Seal-O Ring (Dipstick Tube)
523	693618	Dipstick				843A	695588	Sleeve-Lever
						847	693617	Dipstick/Tube Assembly

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

122400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
851	493880S	Terminal-Spark Plug	971	690370	Screw	1090	691293	Retainer-Brush
863	699229	Bracket-Muffler			(Air Cleaner Base To	1095	698215	Gasket Set-Valve
864	699232	Adapter-Muffler			Carburetor)	1119	699772	Screw
868	★∅692044	Seal-Valve	972	694260	Tank-Fuel			(Alternator)
883	★691893	Gasket-Exhaust	975A	698541	Bowl-Float	1210	791849	Pulley/Spring
883A	★692237	Gasket-Exhaust	977B	698568	Gasket Set-Carburetor			Assembly
890	790203	Bracket-Control	987	698556	Seal-Throttle Shaft			(Pulley)
914	699481	Screw	993	∅694088	Gasket-Cylinder Head	1211	791849	Pulley/Spring
		(Rocker Cover)			Plate			Assembly
		(Bottom)	1005	692592	Fan-Flywheel			(Spring)
914A	692557	Screw	1019	694852	Kit-Label	1305	699691	Screw
		(Rocker Cover)	1022	★∅691890	Gasket-Rocker Cover			(Oil Sensor Module)
		(Top)	1023	791585	Cover-Rocker Arm	1330	272147	Repair Manual
914B	697551	Screw	1026	790287	Rod-Push	1345	699887	Filter-Filler Neck
		(Rocker Cover)	1029	691230	Arm-Rocker	1363	790334	Sprocket-Gear
		(Center)	1034	691343	Guide-Push Rod			Reduction
957	694261	Cap-Fuel Tank	1036		Label-Emission	1364	790335	Chain-Gear Reduction
958	698549	Valve-Fuel Shut Off			(Available From An	1365	790336	Shaft-Output Gear
		(Plastic)			Authorized Briggs &			Reduction
967	493537S	Filter-Pre Cleaner			Statton Sevice Dealer)	1367	690936	Screw
		(Flat Panel)	1051	691265	Ring-Retaining			(Gear Reduction
968	692584	Cover-Air Cleaner	1052	790141	Sensor-Oil			Sprocket)
		(Flat Panel)	1054	280275	Cable-Tie	1368	690301	Washer
		----- Note -----	1058	276355	Owner's Manual			(Gear Reduction
		698811 Cover-	1070	699201	Screw			Sprocket)
		Air Cleaner			(Flywheel Fan)			
		(Flat Panel)						
		Used on Type No(s).						
		0118, 0119, 0132.						

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.