



125H00

Illustrated Parts List

Model Series

125H00

TYPE NUMBERS
0005 through 0127.

TABLE OF CONTENTS


Alternator	6
Air Cleaner	4
Blower Housing/Shrouds	5
Camshaft	2
Carburetor	3
Controls	4
Crankshaft	2
Cylinder	2
Electric Starter	6
Electrical	6
Engine Sump	2
Exhaust System	4
Flywheel	5
Flywheel Brake	6
Fuel Supply	3
Governor Spring	4
Ignition	6
Kits/Gaskets	2 & 3
Lubrication	2
Piston Group	2
Rewind Starter	5
Valves	2








PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

125H00




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 6680-2 Assemblies include all parts shown in frames. 10/05/2005








6680-3 *Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.* Assemblies include all parts shown in frames. 10/05/2005

125H00





Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 6680-4 Assemblies include all parts shown in frames. 10/05/2005



1036 EMISSION LABEL

6680-5 *Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.* Assemblies include all parts shown in frames. 10/05/2005

125H00



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 6680-6 Assemblies include all parts shown in frames. 10/05/2005

125H00

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	697324	Cylinder Assembly	25	790358	Piston Assembly (Standard) (Used After Code Date 04031400).	27	691866	Lock-Piston Pin
2	399269	Kit-Bushing/Seal (Magneto Side)				28	499423	Pin-Piston (Standard)
3	*299819	Seal-Oil (Magneto Side)				29	499424	Rod-Connecting (Standard)
4	493279	Sump-Engine				32	691664	Screw (Connecting Rod)
4A	493365	Sump-Engine (Auxiliary PTO)				32A	695759	Screw (Connecting Rod)
5	691160	Head-Cylinder				33	262651	Valve-Exhaust
7	*Ø692249	Gasket-Cylinder Head				34	262652	Valve-Intake
8	695250	Breather Assembly				35	691270	Spring-Valve (Intake)
9	*Ø272481	Gasket-Breather				36	691270	Spring-Valve (Exhaust)
10	691125	Screw (Breather Assembly)				37	694086	Guard-Flywheel
11	691781	Tube-Breather				40	692194	Retainer-Valve
12	*692232	Gasket-Crankcase				43	691997	Slinger-Governor/Oil
13	690912	Screw (Cylinder Head)				45	690548	Tappet-Valve
15	691680	Plug-Oil Drain (Square Socket)				46	691449	Camshaft
15A	691093	Plug-Oil Drain (Hex Socket)				46A	691459	Camshaft (Counterclockwise)
16	691451	Crankshaft				50	497465	Manifold-Intake
		----- Note -----				51	*272199	Gasket-Intake
		692978 Crankshaft Used on Type No(s). 0110, 0115, 0116.				54	691650	Screw (Intake Manifold)
		691452 Crankshaft Used on Type No(s). 0113, 0114, 0121, 0122, 0123, 0124.	26	790360	Ring Set (Standard) (Used After Code Date 04031400).	55	691421	Housing-Rewind Starter
20	*399781	Seal-Oil (PTO Side)				58	697316	Rope-Starter (Cut To Required Length)
20A	*691952	Seal-Oil (PTO Side) (Auxiliary PTO)				60	281434	Grip-Starter Rope
22	691092	Screw (Crankcase Cover/Sump)				65	690837	Screw (Rewind Starter)
23	692315	Flywheel (Rewind Start)				73	691222	Screen-Rotating
23A	691992	Flywheel (Electric Start)					696565	Shaft-Throttle (Plastic)
24	222698	Key-Flywheel				78	691108	Screw (Flywheel Guard)
						81	691740	Lock-Muffler Screw
						83	690522	Shaft-Auxiliary
						95	691636	Screw (Throttle Valve)

* Included in Engine Gasket Set-Ref. No.358.
 ● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.
 Ø Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

125H00

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
97	493267	Shaft-Throttle (Metal) ----- Note ----- 696565 Shaft-Throttle (Plastic)	187	791766	Line-Fuel (Cut to Required Length) (Used After Code Date 05063000).	222	790143	Bracket-Control (Remote/Manual Friction)(Primer)
101	691623	Pin-Shaft			----- Note -----	227	690783	Lever-Governor Control
104	●691242	Pin-Float Hinge			691050 Line-Fuel (Cut to Required Length) (Used Before Code Date 05070100).	236	691826	Link-Lockout
117	494870	Jet-Main (Standard) (Used After Code Date 02092900). ----- Note ----- 498975 Jet-Main (Standard) (Used Before Code Date 02093000).	187A	791873	Line-Fuel (Molded) (Used After Code Date 05063000). ----- Note -----	265	690798	Clamp-Casing
118	497315	Jet-Main (High Altitude) (Used After Code Date 02092900). ----- Note ----- 496495 Jet-Main (High Altitude) (Used Before Code Date 02093000).			691371 Line-Fuel (Molded) (Used Before Code Date 05070100).	267	691044	Screw (Casing Clamp)
121	498260	Kit-Carburetor Overhaul	188	690877	Screw (Control Bracket)	268	691025	Casing-Control Wire (Cut to Required Length)
125	698444	Carburetor	190	690940	Screw (Fuel Tank)	269	691026	Wire-Control (Cut to Required Length)
127	●694468	Plug-Welch (3/8" Diameter)	202	691829	Link-Mechanical Governor	270	691027	Nut (Control Wire Casing)
130	691203	Valve-Throttle ----- Note ----- 696564 Valve-Throttle (Used With Plastic Throttle Shaft)	209B	691291	Spring-Governor ----- Note -----	271	691028	Lever-Control
133	398187	Float-Carburetor			691851 Spring-Governor Used on Type No(s). 0110, 0115, 0116, 0121, 0122.	276 ●◆271716	Washer-Sealing	
134	●398188	Kit-Needle/Seat			691292 Spring-Governor Used on Type No(s). 0015, 0118, 0120, 0123, 0127.	287	690940	Screw (Dipstick Tube)
137	●◆693981	Gasket-Float Bowl			699056 Spring-Governor Used on Type No(s). 0126.	300	692038	Muffler (Super Lo Tone Tuned)
146	690979	Key-Timing				304A	493294	Housing-Blower ----- Note ----- 493293 Housing-Blower Used on Type No(s). 0110, 0116, 0126. 696420 Housing-Blower Used on Type No(s). 0015, 0115, 0118, 0127.
159	691753	Bracket-Air Cleaner Primer				305	691108	Screw (Blower Housing)
163	★●◆272653	Gasket-Air Cleaner				306	690450	Shield-Cylinder
						307	690345	Screw (Cylinder Shield)
						309	695550	Motor-Starter
						310	692327	Bolt (Starter Motor)

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

⊘ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

125H00

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
332	690662	Nut (Flywheel)	562	92613	Bolt (Governor Control Lever)	689	691855	Spring-Friction
333	802574	Armature-Magneto				697	691127	Screw (Drive Cap)
334	691061	Screw (Magneto Armature)	563	691138	Screw (Debris Guard Screen)	703	696309	Clip
337	802592	Plug-Spark (Resistor)	564	690664	Screw (Control Cover)	715	691147	Screw (Stop Shaft)
		----- Note -----	578	398153	Wire Assembly	718	690959	Pin-Locating
		697451 Plug-Spark (EMS)	584	697734	Cover-Breather Passage	721	690449	Stop-Shaft
356	692390	Wire-Stop	585	★691879	Gasket-Breather Passage	741	790345	Gear-Timing (Use Without Woodruff Key)
358	497316	Gasket Set-Engine						----- Note -----
363	19069	Puller-Flywheel	592	690800	Nut (Rewind Starter)			691830 Gear-Timing (Uses Woodruff Key)
365	691688	Screw (Carburetor)	597	691696	Screw (Pawl Friction Plate)	742	93941	Retainer-E Ring
374	691074	Washer (Camshaft)	601	95162	Clamp-Hose (Green)	743	691772	Gear-Drive
383	89838	Wrench-Spark Plug	604	691757	Cover-Control	745	691648	Screw (Brake)
404	690272	Washer (Governor Crank)	608	497680	Starter-Rewind	783	691918	Gear-Pinion (Starter Drive) (19 Teeth)
425A	690670	Screw (Air Cleaner Cover)	613	691340	Screw (Muffler)	783A	691269	Gear-Pinion (12 Teeth)
443A	692523	Screw (Air Cleaner Primer Base)	615	690340	Retainer-Governor Shaft	784	692341	Cover-Starter Gear
445A	491588	Filter-Air Cleaner Cartridge	616	698801	Crank-Governor	785	692352	Gasket-Starter Cover
455	695161	Cup-Flywheel	617★◆270344	Seal-O Ring (Intake Manifold)	789	696546	Harness-Wiring	
456	692299	Plate-Pawl Friction	621	692310	Switch-Stop	801	690782	Cap-Drive
459	281505	Plate-Ratchet	633◆691321	Seal-Choke/Throttle Shaft	802	695267	Cap-End	
474	691991	Alternator	635	66538	Boot-Spark Plug	803	695266	Housing-Starter
505	691251	Nut (Governor Control Lever)	651	690345	Screw (Starter Gear Cover)	832	499034	Guard-Muffler
510	494147	Drive-Starter	668	★493823	Spacer	836	690664	Screw (Muffler Guard)
513	692358	Clutch-Drive	670	692294	Spacer-Fuel Tank	842	★691031	Seal-O Ring (Dipstick Tube)
523	495264	Dipstick	676	396548	Deflector-Muffler (Single Louver)	843	691884	Sleeve-Lever (Control Bracket)
524	★692296	Seal-Dipstick Tube	676E	393760	Deflector-Muffler (Side Out)	847	692017	Dipstick/Tube Assembly
525	495265	Tube-Dipstick	677	690661	Screw (Muffler Deflector)	871	262001	Bushing-Valve Guide (Exhaust)
529	691923	Grommet						----- Note -----
544	690786	Armature-Starter	684	690345	Screw (Breather Passage Cover)			63709 Bushing- Valve Guide (Intake)
545	492919	Washer Set (Starter Motor)						

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

⊘ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

125H00

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
883	691881	Gasket-Exhaust	949	696306	Guard-Debris Screen	1036		Label-Emission
910	691094	Stud (Alternator)	957	397974	Cap-Fuel Tank (Plastic)			(Available From An Authorized Briggs & Statton Sevice Dealer)
922	691831	Spring-Brake	966A	496116	Base-Air Cleaner Primer	1058	276171	Manual Owner's
		----- Note -----	967A	493537	Filter-Pre Cleaner	1059	692311	Kit-Screw/Washer
		692135 Spring-Brake	968B	692298	Cover-Air Cleaner	1095	498528	Gasket Set-Valve
		Used on Type No(s). 0015, 0115, 0118, 0127.	970	691681	Screw (Air Cleaner Primer Bracket)	1119	691648	Screw (Alternator)
923	691994	Brake	972B	699374	Tank-Fuel (Plastic)	1210	498144	Pulley/Spring Assembly (Pulley)
		----- Note -----	975	493640	Bowl-Float	1211	498144	Pulley/Spring Assembly (Spring)
		695891 Brake	976	694395	Primer-Carburetor	1229	696308	Extension-Blower Housing
		Used on Type No(s). 0015, 0115, 0118, 0127.	977	498261	Gasket Set-Carburetor	1330	270962	Manual-Repair
925	690595	Cover-Linkage	997	696310	Shield-Debris			
937	691325	Spline-Starter	1019	696438	Kit-Label			
			1005	691346	Fan-Flywheel			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

⊘ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

6680-10

Assemblies include all parts shown in frames.

10/05/2005