



**12D100**

# Illustrated Parts List

## Model Series

### 12D100

TYPE NUMBERS  
0110

#### TABLE OF CONTENTS

|                                 |   |
|---------------------------------|---|
| Blower Housing/Shrouds .....    | 6 |
| Camshaft .....                  | 2 |
| Carburetor .....                | 4 |
| Controls .....                  | 5 |
| Crankcase Cover .....           | 2 |
| Crankshaft .....                | 2 |
| Cylinder .....                  | 2 |
| Cylinder Head .....             | 3 |
| Electric Starter .....          | 5 |
| Exhaust System .....            | 6 |
| Flywheel .....                  | 6 |
| Fuel Supply .....               | 4 |
| Governor Spring .....           | 5 |
| Ignition .....                  | 5 |
| Kits/Gaskets – Carburetor ..... | 4 |
| Kits/Gaskets – Engine .....     | 2 |
| Kits/Gaskets – Valves .....     | 3 |
| Lubrication .....               | 2 |
| Piston Group .....              | 2 |
| Rewind Starter .....            | 5 |


**BRIGGS & STRATTON**



PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION  
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

# 12D100







Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

3399-2

Assemblies include all parts shown in frames.

11/10/2005











Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

3399-3

Assemblies include all parts shown in frames.

11/10/2005

# 12D100









Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

3399-4

Assemblies include all parts shown in frames.

11/10/2005



334

1119

347

356C


356L

892  
990

1054

65A

930



578A

578B


Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

3399-5

Assemblies include all parts shown in frames.

11/10/2005

# 12D100



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

3399-6

Assemblies include all parts shown in frames.

11/10/2005

**12D100**

| REF. NO.   | PART NO.        | DESCRIPTION                                                                                  | REF. NO.     | PART NO.      | DESCRIPTION                                                                        | REF. NO.    | PART NO.       | DESCRIPTION                                                                                    |
|------------|-----------------|----------------------------------------------------------------------------------------------|--------------|---------------|------------------------------------------------------------------------------------|-------------|----------------|------------------------------------------------------------------------------------------------|
| <b>1</b>   | <b>699510</b>   | Cylinder Assembly                                                                            | <b>26</b>    | <b>791969</b> | Ring Set<br>(Standard)<br>(Used After Code Date<br>05060600).                      | <b>78</b>   | <b>699205</b>  | Screw<br>(Flywheel Guard)                                                                      |
| <b>2</b>   | <b>399269</b>   | Kit-Bushing/Seal<br>(Magneto Side)                                                           |              |               |                                                                                    | <b>95</b>   | <b>691636</b>  | Screw<br>(Throttle Valve)                                                                      |
| <b>3</b>   | <b>★299819S</b> | Seal-Oil<br>(Magneto Side)                                                                   |              |               | ----- <b>Note</b> -----                                                            | <b>97</b>   | <b>690024</b>  | Shaft-Throttle                                                                                 |
| <b>5</b>   | <b>699486</b>   | Head-Cylinder                                                                                |              |               | <b>499631</b> Ring Set<br>(Standard)<br>(Used Before Code<br>Date 05060700).       | <b>98</b>   | <b>398185</b>  | Kit-Idle Speed                                                                                 |
| <b>7</b>   | <b>★Ø698210</b> | Gasket-Cylinder Head                                                                         |              |               | <b>791324</b> Ring Set<br>(.020" Oversize)<br>(Used After Code Date<br>05060600).  | <b>104</b>  | <b>●691242</b> | Pin-Float Hinge                                                                                |
| <b>11B</b> | <b>695745</b>   | Tube-Breather                                                                                |              |               | <b>692786</b> Ring Set<br>(.020" Oversize)<br>(Used Before Code<br>Date 05060700). | <b>108</b>  | <b>695807</b>  | Valve-Choke                                                                                    |
| <b>12</b>  | <b>★699485</b>  | Gasket-Crankcase                                                                             |              |               |                                                                                    | <b>109B</b> | <b>695729</b>  | Shaft-Choke                                                                                    |
| <b>13</b>  | <b>699482</b>   | Screw<br>(Cylinder Head)                                                                     |              |               |                                                                                    | <b>117</b>  | <b>690048</b>  | Jet-Main<br>(Standard)                                                                         |
| <b>15</b>  | <b>691686</b>   | Plug-Oil Drain                                                                               |              |               |                                                                                    | <b>118</b>  | <b>498977</b>  | Jet-Main<br>(High Altitude)                                                                    |
| <b>15B</b> | <b>695757</b>   | Plug-Oil Drain                                                                               |              |               |                                                                                    | <b>121</b>  | <b>696998</b>  | Kit-Carburetor<br>Overhaul                                                                     |
| <b>16</b>  | <b>699445</b>   | Crankshaft                                                                                   |              |               |                                                                                    | <b>122</b>  | <b>●693749</b> | Spacer-Carburetor                                                                              |
| <b>18B</b> | <b>699677</b>   | Cover-Crankcase                                                                              |              |               |                                                                                    | <b>125A</b> | <b>791292</b>  | Carburetor                                                                                     |
| <b>20</b>  | <b>★692550</b>  | Seal-Oil<br>(PTO Side)                                                                       | <b>27</b>    | <b>691866</b> | Lock-Piston Pin                                                                    | <b>127</b>  | <b>●694468</b> | Plug-Welch                                                                                     |
| <b>20A</b> | <b>★691952</b>  | Seal-Oil<br>(PTO Side)<br>(Auxiliary Drive)                                                  | <b>28</b>    | <b>499423</b> | Pin-Piston                                                                         | <b>127A</b> | <b>●691739</b> | Plug-Welch                                                                                     |
| <b>21</b>  | <b>281658S</b>  | Cap-Oil Fill                                                                                 | <b>29</b>    | <b>690124</b> | Rod-Connecting                                                                     | <b>130</b>  | <b>691181</b>  | Valve-Throttle                                                                                 |
| <b>22</b>  | <b>699478</b>   | Screw<br>(Crankcase Cover/<br>Sump)                                                          | <b>30</b>    | <b>692562</b> | Dipper-Connecting<br>Rod                                                           | <b>133</b>  | <b>398187</b>  | Float-Carburetor                                                                               |
| <b>23</b>  | <b>699516</b>   | Flywheel                                                                                     | <b>32</b>    | <b>691664</b> | Screw<br>(Connecting Rod)                                                          | <b>134</b>  | <b>●398188</b> | Kit-Needle/Seat                                                                                |
| <b>24</b>  | <b>222698S</b>  | Key-Flywheel                                                                                 | <b>32A</b>   | <b>695759</b> | Screw<br>(Connecting Rod)                                                          | <b>137</b>  | <b>●693981</b> | Gasket-Float Bowl                                                                              |
| <b>25</b>  | <b>791968</b>   | Piston Assembly<br>(Standard)<br>(Used After Code Date<br>05060600).                         | <b>33</b>    | <b>499642</b> | Valve-Exhaust                                                                      | <b>146</b>  | <b>690979</b>  | Key-Timing                                                                                     |
|            |                 | ----- <b>Note</b> -----                                                                      | <b>34</b>    | <b>499641</b> | Valve-Intake                                                                       | <b>155</b>  | <b>698214</b>  | Plate-Cylinder Head                                                                            |
|            |                 | <b>690021</b> Piston<br>Assembly<br>(Standard)<br>(Used Before Code<br>Date 05060700).       | <b>35</b>    | <b>691304</b> | Spring-Valve<br>(Intake)                                                           | <b>186</b>  | <b>692317</b>  | Connector-Hose                                                                                 |
|            |                 | <b>791326</b> Piston<br>Assembly<br>(.020" Oversize)<br>(Used After Code Date<br>05060600).  | <b>36</b>    | <b>691304</b> | Spring-Valve<br>(Exhaust)                                                          | <b>187</b>  | <b>791766</b>  | Line-Fuel<br>(Cut to Required<br>Length)<br>(Used After Code Date<br>05063000).                |
|            |                 | <b>694168</b> Piston<br>Assembly<br>(.020" Oversize)<br>(Used Before Code<br>Date 05060700). | <b>37</b>    | <b>699661</b> | Guard-Flywheel                                                                     |             |                | ----- <b>Note</b> -----                                                                        |
|            |                 |                                                                                              | <b>40</b>    | <b>692194</b> | Retainer-Valve                                                                     |             |                | <b>691050</b> Line-Fuel<br>(Cut to Required<br>Length)<br>(Used Before Code<br>Date 05070100). |
|            |                 |                                                                                              | <b>45</b>    | <b>690977</b> | Tappet-Valve                                                                       |             |                |                                                                                                |
|            |                 |                                                                                              | <b>46A</b>   | <b>695285</b> | Camshaft                                                                           |             |                |                                                                                                |
|            |                 |                                                                                              | <b>51★♦Ø</b> | <b>692555</b> | Gasket-Intake                                                                      | <b>187A</b> | <b>791867</b>  | Line-Fuel<br>(Molded)<br>(Used After Code Date<br>05063000).                                   |
|            |                 |                                                                                              | <b>55A</b>   | <b>696710</b> | Housing-Rewind<br>Starter                                                          |             |                | ----- <b>Note</b> -----                                                                        |
|            |                 |                                                                                              | <b>58</b>    | <b>693389</b> | Rope-Starter<br>(Cut To Required<br>Length)                                        |             |                | <b>692601</b> Line-Fuel<br>(Molded)<br>(Used Before Code<br>Date 05070100).                    |
|            |                 |                                                                                              | <b>60B</b>   | <b>699334</b> | Grip-Starter Rope                                                                  |             |                |                                                                                                |
|            |                 |                                                                                              | <b>65</b>    | <b>699228</b> | Screw<br>(Rewind Starter)                                                          |             |                |                                                                                                |
|            |                 |                                                                                              | <b>65A</b>   | <b>699851</b> | Screw<br>(Rewind Starter)                                                          |             |                |                                                                                                |

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

♦ Included in Carburetor Gasket Set-Ref. No. 977.

Ø Included in Valve Gasket Set-Ref. No 1095.

*Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.***3399-7**

Assemblies include all parts shown in frames.

**11/10/2005**

**12D100**

| REF. NO. | PART NO. | DESCRIPTION                                                                              | REF. NO. | PART NO. | DESCRIPTION                             | REF. NO.                                                                                    | PART NO. | DESCRIPTION                                       |
|----------|----------|------------------------------------------------------------------------------------------|----------|----------|-----------------------------------------|---------------------------------------------------------------------------------------------|----------|---------------------------------------------------|
| 188      | 699479   | Screw<br>(Control Bracket)                                                               | 332      | 699359   | Nut<br>(Flywheel)                       | 615                                                                                         | 692576   | Retainer-Governor<br>Shaft                        |
| 190      | 699220   | Screw<br>(Fuel Tank)                                                                     | 333      | 695711   | Armature-Magneto                        | 616                                                                                         | 692547   | Crank-Governor                                    |
| 192      | 694543   | Ball-Rocker Arm                                                                          | 334      | 699477   | Screw<br>(Magneto Armature)             | 619                                                                                         | 699230   | Screw<br>(Cylinder Head Plate)                    |
| 209      | 692571   | Spring-Governor                                                                          | 337      | 691043   | Spark-Plug                              | 632                                                                                         | 692653   | Spring/Link-<br>Mechanical Governor               |
| 219      | 693578   | Gear-Governor                                                                            | 347      | 698338   | Switch-Rocker                           | 633                                                                                         | ◆693867  | Seal-Choke/Throttle<br>Shaft                      |
| 220      | 691724   | Washer<br>(Governor Gear)                                                                | 356C     | 695630   | Wire-Stop                               | 633A                                                                                        | ◆◆691321 | Seal-Choke/Throttle<br>Shaft                      |
| 222D     | 790549   | Bracket-Control                                                                          | 356L     | 790552   | Wire-Stop                               | 635A                                                                                        | 692927   | Boot-Sparkplug                                    |
| 227      | 692573   | Lever-Governor<br>Control                                                                | 358      | 699638   | Set-Engine Gasket                       | 663                                                                                         | 699854   | Screw<br>(Control Panel)                          |
| 238      | 691300   | Cap-Valve                                                                                | 363      | 19069    | Puller-Flywheel                         | 689                                                                                         | 691855   | Spring-Friction                                   |
| 268      | 691072   | Control Wire Casing<br>(Cut to Required<br>Length)                                       | 365      | 699484   | Screw<br>(Carburetor)                   | 692                                                                                         | 690572   | Spring-Detent<br>(Choke)                          |
| 269      | 691026   | Control Wire<br>(Cut to Required<br>Length)                                              | 383      | 19374S   | Wrench-Spark Plug<br>(Oil Fill Bracket) | 718                                                                                         | 690959   | Pin-Locating                                      |
| 270      | 691027   | Nut<br>(Control Wire Casing)                                                             | 455      | 692591   | Cup-Flywheel                            | 731A                                                                                        | 790554   | Hood-Snow                                         |
| 271      | 691028   | Lever-Control                                                                            | 456      | 692299   | Plate-Pawl Friction                     | 731B                                                                                        | 791943   | Hood-Snow<br>(Used After Code Date<br>05101800).  |
| 276      | ◆271716  | Washer-Sealing                                                                           | 459      | 281505   | Pawl-Ratchet                            | ----- <b>Note</b> -----<br><b>790547</b> Hood-Snow<br>(Used Before Code<br>Date 05101900).  |          |                                                   |
| 281A     | 699639   | Panel-Control                                                                            | 472A     | 790553   | Knob-Choke Shaft                        |                                                                                             |          |                                                   |
| 287      | 699629   | Screw<br>(Dipstick Tube)                                                                 | 474      | 694457   | Alternator                              | 741                                                                                         | 695087   | Gear-Timing                                       |
| 300E     | 791940   | Muffler<br>(Used After Code Date<br>05101800).                                           | 493A     | 695744   | Bracket-Mounting                        | 742                                                                                         | 692564   | Retainer-E Ring                                   |
|          |          | ----- <b>Note</b> -----<br><b>790548</b> Muffler<br>(Used Before Code<br>Date 05101900). | 505      | 691251   | Nut<br>(Governor Control<br>Lever)      | 746                                                                                         | 692566   | Gear-Idler                                        |
| 304      | 699598   | Housing-Blower                                                                           | 523      | 693618   | Dipstick                                | 830                                                                                         | 694544   | Stud<br>(Rocker Arm)                              |
| 305      | 699480   | Screw<br>(Blower Housing)                                                                | 524      | 281370   | Seal-Dipstick Tube                      | 842                                                                                         | 691031   | Seal-O Ring<br>(Dipstick Tube)                    |
| 306A     | 695710   | Shield-Cylinder                                                                          | 528      | 695746   | Hose-Primer                             | 847                                                                                         | 693617   | Dipstick/Tube<br>Assembly                         |
| 307      | 699483   | Screw<br>(Cylinder Shield)                                                               | 552      | 692346   | Bushing-Governor<br>Crank               | 851                                                                                         | 493880   | Terminal-Spark Plug                               |
| 307A     | 699234   | Screw<br>(Cylinder Shield)                                                               | 562      | 691119   | Bolt<br>(Governor Control<br>Lever)     | 868                                                                                         | ★Ø692044 | Seal-Valve                                        |
| 307B     | 790557   | Screw<br>(Cylinder Shield)                                                               | 564      | 699854   | Screw<br>(Control Cover)                | 883A                                                                                        | ★691893  | Gasket-Exhaust                                    |
| 309A     | 696818   | Motor-Starter                                                                            | 578A     | 790481   | Wire Assembly                           | 892                                                                                         | 791944   | Switch-Key<br>(Used After Code Date<br>05101800). |
| 318      | 690370   | Screw<br>(Mounting Bracket)                                                              | 578B     | 791956   | Wire Assembly                           | ----- <b>Note</b> -----<br><b>696749</b> Switch-Key<br>(Used Before Code<br>Date 05101900). |          |                                                   |
|          |          |                                                                                          | 597      | 691696   | Screw<br>(Pawl Friction Plate)          |                                                                                             |          |                                                   |
|          |          |                                                                                          | 598      | 220624   | Shim-End Play                           |                                                                                             |          |                                                   |
|          |          |                                                                                          | 601      | 95162S   | Clamp-Hose                              |                                                                                             |          |                                                   |
|          |          |                                                                                          | 604A     | 695749   | Cover-Control                           |                                                                                             |          |                                                   |
|          |          |                                                                                          | 604B     | 790473   | Cover-Control                           |                                                                                             |          |                                                   |
|          |          |                                                                                          | 608A     | 699335   | Starter-Rewind                          |                                                                                             |          |                                                   |
|          |          |                                                                                          | 613D     | 699209   | Screw<br>(Muffler)                      |                                                                                             |          |                                                   |

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

Ø Included in Valve Gasket Set-Ref. No 1095.

*Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.*

3399-8

Assemblies include all parts shown in frames.

11/10/2005

**12D100**

| REF. NO.    | PART NO.      | DESCRIPTION                         | REF. NO.     | PART NO.      | DESCRIPTION                                                                            | REF. NO.     | PART NO.      | DESCRIPTION                           |
|-------------|---------------|-------------------------------------|--------------|---------------|----------------------------------------------------------------------------------------|--------------|---------------|---------------------------------------|
| <b>914</b>  | <b>699481</b> | Screw<br>(Rocker Cover)<br>(Bottom) | <b>1019</b>  | <b>695751</b> | Kit-Label                                                                              | <b>1210</b>  | <b>498144</b> | Pulley/Spring<br>Assembly<br>(Pulley) |
| <b>914A</b> | <b>692557</b> | Screw<br>(Rocker Cover)<br>(Top)    | <b>1022</b>  | <b>691890</b> | Gasket-Rocker Cover                                                                    | <b>1211</b>  | <b>498144</b> | Pulley/Spring<br>Assembly<br>(Spring) |
| <b>914B</b> | <b>697551</b> | Screw<br>(Rocker Cover)<br>(Center) | <b>1023</b>  | <b>499924</b> | Cover-Rocker Arm                                                                       | <b>1224</b>  | <b>696824</b> | Nut<br>(Carburetor Primer)            |
| <b>930</b>  | <b>696709</b> | Guard-Rewind                        | <b>1026</b>  | <b>790287</b> | Rod-Push                                                                               | <b>1230</b>  | <b>699847</b> | Screw<br>(Control Bracket)            |
| <b>957</b>  | <b>694261</b> | Cap-Fuel Tank                       | <b>1029</b>  | <b>691230</b> | Arm-Rocker                                                                             | <b>1251</b>  | <b>696699</b> | Shield-Snow                           |
| <b>958</b>  | <b>698180</b> | Valve-Fuel Shut Off                 | <b>1034</b>  | <b>691343</b> | Guide-Push Rod                                                                         | <b>1251A</b> | <b>790555</b> | Shield-Snow                           |
| <b>972</b>  | <b>694260</b> | Tank-Fuel                           | <b>1036</b>  |               | Label-Emission<br>(Available From An<br>Authorized Briggs &<br>Statton Service Dealer) | <b>1251B</b> | <b>790556</b> | Shield-Snow                           |
| <b>975</b>  | <b>493640</b> | Bowl-Float                          | <b>1054</b>  | <b>280275</b> | Tie-Cable                                                                              | <b>1252</b>  | <b>699234</b> | Screw<br>(Snow Shield)                |
| <b>976</b>  | <b>790221</b> | Primer-Carburetor                   | <b>1058</b>  | <b>275697</b> | Owner's Manual                                                                         | <b>1252A</b> | <b>699632</b> | Screw<br>(Snow Shield)                |
| <b>977</b>  | <b>697001</b> | Gasket Set-Carburetor               | <b>1070</b>  | <b>699201</b> | Screw<br>(Flywheel Fan)                                                                | <b>1330</b>  | <b>272147</b> | Repair Manual                         |
| <b>990</b>  | <b>695756</b> | Key-Set                             | <b>1095</b>  | <b>698215</b> | Gasket Set-Valve                                                                       |              |               |                                       |
| <b>993</b>  | <b>694088</b> | Gasket-Cylinder Head<br>Plate       | <b>1119</b>  | <b>699772</b> | Screw<br>(Alternator)                                                                  |              |               |                                       |
| <b>998</b>  | <b>696683</b> | Pipe-Oil                            | <b>1196</b>  | <b>696692</b> | Screw<br>(Snow Hood)                                                                   |              |               |                                       |
| <b>1005</b> | <b>692592</b> | Fan-Flywheel                        | <b>1196A</b> | <b>699854</b> | Screw<br>(Snow Hood)                                                                   |              |               |                                       |

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

⌀ Included in Valve Gasket Set-Ref. No 1095.

*Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.***3399-9**

Assemblies include all parts shown in frames.

**11/10/2005**