



12J600

Illustrated Parts List

Model Series

12J600

TYPE NUMBERS
0100 through 0149.

TABLE OF CONTENTS


Air Cleaner	6
Blower Housing/Shrouds	7
Camshaft	2
Carburetor	4
Controls	5
Crankshaft	2
Cylinder	2
Cylinder Head	3
Engine Sump	2
Exhaust System	6
Flywheel	7
Flywheel Brake	5
Fuel Supply	6
Governor Spring	5
Ignition	5
Lubrication	2
Piston Group	2
Rewind Starter	7






PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

12J600







Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5835-2 Assemblies include all parts shown in frames. 08/03/2005




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5835-3 Assemblies include all parts shown in frames. 08/03/2005

12J600














Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5835-4 Assemblies include all parts shown in frames. 08/03/2005




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5835-5 Assemblies include all parts shown in frames. 08/03/2005

12J600



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5835-6 Assemblies include all parts shown in frames. 08/03/2005



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5835-7 Assemblies include all parts shown in frames. 08/03/2005

12J600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	692670	Cylinder Assembly	25	791968	Piston Assembly (Standard) (Used After Code Date 04040400).	27	691866	Lock-Piston Pin
2	399269	Kit-Bushing/Seal (Magneto Side)				28	499423	Pin-Piston
3	*299819	Seal-Oil (Magneto Side)				29	499424	Rod-Connecting
4	493279	Sump-Engine				32	691664	Screw (Connecting Rod)
		----- Note -----				32A	695759	Screw (Connecting Rod)
		498983 Sump-Engine Used on Type No(s). 0119, 0149.				33	499642	Valve-Exhaust
5	695276	Head-Cylinder				34	499641	Valve-Intake
7	*Δ695166	Gasket-Cylinder Head				35	691304	Spring-Valve (Intake)
8	495786	Breather Assembly				36	691304	Spring-Valve (Exhaust)
9	*272481	Gasket-Breather				37	694086	Guard-Flywheel
10	691125	Screw (Breather Assembly)				40	692194	Retainer-Valve
11A	499675	Tube-Breather				43	691997	Slinger-Governor/Oil
12	*692232	Gasket-Crankcase						----- Note -----
13	691137	Screw (Cylinder Head)						691486 Slinger-Governor/Oil Used on Type No(s). 0149.
15	691680	Plug-Oil Drain (Square Socket)				45	690977	Tappet-Valve
16	693291	Crankshaft Used on Type No(s). 0121.				46	694039	Camshaft
		----- Note -----				51*♦Δ	692668	Gasket-Intake
		692803 Crankshaft Used on Type No(s). 0149.				55	691421	Housing-Rewind Starter
		691457 Crankshaft Used on Type No(s). 0100, 0119, 0120, 0122, 0123.	26	791969	Ring Set (Standard) (Used After Code Date 04040400).	58	697316	Rope-Starter (Cut To Required Length)
20	*399781	Seal-Oil (PTO Side)						----- Note -----
22	691092	Screw (Crankcase Cover/Sump)				60	281434	Grip-Starter Rope
23	696569	Flywheel				65	690837	Screw (Rewind Starter)
		----- Note -----				78	691108	Screw (Flywheel Guard)
		699488 Flywheel Used on Type No(s). 0119, 0149.				95	691636	Screw (Throttle Valve)
24	222698	Key-Flywheel				97	499682	Shaft-Throttle (Metal)
								----- Note -----
								790121 Shaft-Throttle (Plastic)
						98	398185	Kit-Idle Speed
						104	●691242	Pin-Float Hinge

* Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

♦ Included in Carburetor Gasket Set-Ref. No. 977.

Δ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
108	691182	Valve-Choke	121	692703	Kit-Carburetor Overhaul	209	692906	Spring-Governor Used on Type No(s). 0122.
109A	499779	Shaft-Choke	122	◆◆692799	Spacer-Carburetor			----- Note -----
109B	693866	Shaft-Choke	125	790120	Carburetor Used on Type No(s). 0100, 0120, 0121, 0123.			691292 Spring-Governor Used on Type No(s). 0123, 0149.
117	692677	Jet-Main (Standard) Used on Type No(s). 0119, 0149.	125B	698056	Carburetor Used on Type No(s). 0122.			690319 Spring-Governor Used on Type No(s). 0120, 0121.
		----- Note -----	125C	694505	Carburetor Used on Type No(s). 0119, 0149.			691290 Spring-Governor Used on Type No(s). 0119.
		498981 Jet-Main (Standard) (Used After Code Date 03110600). Used on Type No(s). 0100, 0120, 0121, 0123.	127	◆694468	Plug-Welch	211	692434	Spring-Governed Idle
		498978 Jet-Main (Standard) (Used Before Code Date 03110700). Used on Type No(s). 0120, 0121.	127A	◆691739	Plug-Welch	217	690354	Spring-Choke Return
117A	694250	Jet-Main (Standard) Used on Type No(s). 0122.	130	691203	Valve-Throttle ----- Note -----	222B	693897	Bracket-Control Used on Type No(s). 0123, 0149.
118	497315	Jet-Main (High Altitude) Used on Type No(s). 0119, 0149.	130A	691181	Valve-Throttle			----- Note -----
		----- Note -----	133	398187	Float-Carburetor			692672 Bracket-Control Used on Type No(s). 0100, 120, 0121.
		497466 Jet-Main (High Altitude) (Used After Code Date 03110600). Used on Type No(s). 0100, 0120, 0121, 0123.	134	◆398188	Kit-Needle/Seat			693378 Bracket-Control Used on Type No(s). 0119.
		498975 Jet-Main (High Altitude) (Used Before Code Date 03110700). Used on Type No(s). 0120, 0121.	137	◆◆693981	Gasket-Float Bowl	222G	697923	Bracket-Control Used on Type No(s). 0122.
118A	497466	Jet-Main (High Altitude) Used on Type No(s). 0122.	146	690979	Key-Timing	227	691467	Lever-Governor Control
			163A	◆◆692667	Gasket-Air Cleaner	238	691300	Cap-Valve
			187	791766	Line-Fuel (Cut to Required Length) (Used After Code Date 05063000). ----- Note -----	265	690798	Clamp-Casing
					691050 Line-Fuel (Cut to Required Length) (Used Before Code Date 05070100).	267	691044	Screw (Casing Clamp)
			188	691147	Screw (Control Bracket)			
			190	690940	Screw (Fuel Tank)			
			192	694543	Adjuster-Rocker Arm			
			202	691303	Link-Mechanical Governor			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

12J600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
268	691072	Casing-Control Wire (Cut To Required Length)	363	19069	Puller-Flywheel	604A	693807	Cover-Control
269	691026	Wire-Control (Cut To Required Length)	365	691136	Screw (Carburetor)			Used on Type No(s). 0119, 0149.
270	691027	Nut (Control Wire Casing)	383	19374	Wrench-Spark Plug			----- Note -----
271	691028	Lever-Control	404	690272	Washer (Governor Crank)			692669 Cover-Control
276	◆271716	Washer-Sealing	425	690670	Screw (Air Cleaner Cover)			Used on Type No(s). 0100, 0120, 0121, 0123.
287	690940	Screw (Dipstick Tube)	443	691637	Screw (Air Cleaner Primer Base)	608	497680	Starter-Rewind
300	694248	Muffler-Exhaust	443A	692523	Screw (Air Cleaner Primer Base)	613	691108	Screw (Muffler)
300B	699769	Muffler-Exhaust	445	491588	Filter-Air Cleaner Cartridge	613A	691140	Screw (Muffler)
304	499677	Housing-Blower ----- Note ----- 499676 Housing- Blower Used on Type No(s). 0119, 0149. 695976 Housing- Blower Used on Type No(s). 0100.	455	695161	Cup-Flywheel	615	690340	Retainer-Governor Shaft
305	691108	Screw (Blower Housing)	456	692299	Plate-Pawl Friction	616	698801	Crank-Governor
306	691232	Shield-Cylinder	459	281505	Pawl-Ratchet	619	691108	Screw (Cylinder Head Plate)
307	690345	Screw (Cylinder Shield)	472	693809	Knob-Choke Shaft	621	692310	Switch-Stop
332	690662	Nut (Flywheel)	493	692877	Bracket-Mounting	633	◆693867	Seal-Choke/Throttle Shaft
333	802574	Armature-Magneto	505	691251	Nut (Governor Control Lever)	633A	◆691321	Seal-Choke/Throttle Shaft
334	691061	Screw (Magneto Armature)	523	499621	Dipstick	635	66538	Boot-Spark Plug
337	692051	Plug-Spark (Resistor) ----- Note ----- 692720 Plug-Spark (EMS)	524	★692296	Seal-Dipstick Tube	670	692294	Spacer-Fuel Tank
341	690368	Stud (Mounting Bracket)	525	495265	Tube-Dipstick	676C	497682	Deflector-Muffler
347	691396	Switch-Rocker	529	692937	Grommet	676D	692957	Deflector-Muffler
356	692390	Wire-Stop	529A	691923	Grommet	677	690661	Screw (Muffler Deflector)
356A	693010	Wire-Stop	532	692851	Nut (Mounting Bracket)	684	690345	Screw (Breather Passage Cover)
358	694090	Gasket Set-Engine	562	691119	Bolt (Governor-Control Lever)	689	691855	Spring-Friction
			564A	693808	Screw (Control Cover)	692	690572	Spring-Detent
			584	697734	Cover-Breather Passage	718	690959	Pin-Locating
			585	★691879	Gasket-Breather Passage	741	790345	Gear-Timing (Use Without Woodruff Key) ----- Note -----
			592	690800	Nut (Rewind Starter)			691830 Gear-Timing (Uses Woodruff Key)
			597	691696	Screw (Pawl Friction Plate)	745	691648	Screw (Brake)
			601	95162	Clamp-Hose	830	694544	Stud-Rocker Arm

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

12J600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
832	691466	Guard-Muffler	925	690595	Cover-Linkage	1005	691346	Fan-Flywheel
832C	695593	Guard-Muffler	930A	692675	Guard-Rewind	1019	693868	Kit-Label
836	691147	Screw (Muffler Guard)	957	692046	Cap-Fuel Tank (Plastic)	1022	★△691890	Gasket-Rocker Cover
836A	697551	Screw (Muffler Guard)	966	692673	Base-Air Cleaner Primer	1023	499624	Cover-Rocker Arm
842	★691031	Seal-O Ring (Dipstick Tube)			Used on Type No(s). 0100, 0120, 0121.	1026	692045	Rod-Push
843	691884	Sleeve-Lever	966A	693863	Base-Air Cleaner Primer	1029	691230	Arm-Rocker
847	692047	Dipstick/Tube Assembly			Used on Type No(s). 0119, 0122, 0123, 0149.	1034	691343	Guide-Push Rod
851	493880	Terminal-Spark Plug	969	691138	Screw (Blower Housing Cover)	1036		Label-Emission (Available From An Authorized Briggs & Statton Sevice Dealer)
868	★△692044	Seal-Valve	967	493537	Filter-Pre Cleaner	1058	276348	Manual-Owner's
883	★△691893	Gasket-Valve	968	692298	Cover-Air Cleaner	1059	692311	Kit-Screw/Washer
886	696268	Gasket Set-Cylinder Head Plate	969	691138	Screw (Blower Housing Cover)	1095	694091	Gasket Set-Valve
914	691108	Screw (Rocker Arm Cover)	969A	697922	Screw (Blower Housing Cover)	1102	691255	Pilot-Guide Used on Type No(s). 0149.
921B	697921	Cover-Blower Housing	972	699374	Tank-Fuel (Plastic)	1210	498144	Pulley/Spring Assembly (Pulley)
922	691831	Spring-Brake ----- Note ----- 692135 Spring-Brake Used on Type No(s). 0100.	975	493640	Bowl-Float	1211	498144	Pulley/Spring Assembly (Spring)
923	691994	Brake ----- Note ----- 695891 Brake Used on Type No(s). 0100.	976	694395	Primer-Carburetor	1330	272147	Manual-Repair
			977	692704	Gasket Set-Carburetor			
			993	★△694088	Gasket-Cylinder Head Plate			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.