



12K300

Illustrated Parts List

Model Series

12K300

TYPE NUMBERS
0153.

TABLE OF CONTENTS










Air Cleaner	4
Blower Housing	5
Camshaft	2
Carburetor	4
Controls	4
Crankcase Cover	2
Crankshaft	2
Cylinder	2
Cylinder Head	3
Flywheel	5
Governor Spring	4
Ignition	4
Kits/Gaskets - Carburetor	4
Kits/Gaskets - Engine	2
Kits/Gaskets - Valve	3
Lubrication	2
Piston Group	2
Rewind Starter	5






PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

12K300
















Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.






Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

12K300



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

12K300

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	699490	Cylinder Assembly	32	691664	Screw (Connecting Rod)	134	●398188	Kit-Needle/Seat
2	399269	Kit-Bushing/Seal (Magneto Side)	32A	695759	Screw (Connecting Rod)	137	●●693981	Gasket-Float Bowl
3	★299819S	Seal-Oil (Magneto Side)	33	499642	Valve-Exhaust	146	690979	Key-Timing
5	699486	Head-Cylinder	34	499641	Valve-Intake	155	★698214	Plate-Cylinder Head
7	★∅698210	Gasket-Cylinder Head	35	691304	Spring-Valve (Intake)	161	699207	Base-Air Cleaner (Metal) (Flat Panel Air Cleaner)
11	692600	Tube-Breather (Flat Panel Air Cleaner)	36	691304	Spring-Valve (Exhaust)	163B	★●●696024	Gasket-Air Cleaner (Flat Panel Air Cleaner)
12	★699485	Gasket-Crankcase	37	699661	Guard-Flywheel	186	692317	Connector-Hose
13	699482	Screw (Cylinder Head)	40	692194	Retainer-Valve	188	699479	Screw (Control Bracket)
15	691686	Plug-Oil Drain (Square Head)	45	690977	Tappet-Valve	192	694543	Adjuster-Rocker Arm
15A	691682	Plug-Oil Drain (Flush)	46A	696813	Camshaft	209	692571	Spring-Governor
16	790568	Crankshaft	51	★●●∅692555	Gasket-Intake (2 Required)	219	693578	Gear-Governor
17	692517	Bearing-Ball	55	691422	Housing-Rewind Starter	220	691724	Washer (Governor Gear)
17A	690824	Bearing-Ball	58	693389	Rope-Starter (Cut to Required Length)	222C	699493	Bracket-Control
18A	699672	Cover-Crankcase	59	490653	Grip-Insert	227	692573	Lever-Governor Control
20	★692550	Seal-Oil (PTO Side)	60	490652	Grip-Starter Rope (2 Piece)	238	691300	Valve-Cap
21	281658S	Cap-Oil Fill	65	699228	Screw (Rewind Starter)	265	691024	Clamp-Casing
22	699478	Screw (Crankcase Cover/ Sump)	78	699205	Screw (Flywheel Guard)	267	699492	Screw (Casing Clamp)
23	699488	Flywheel	95	691636	Screw (Throttle Valve)	268	691025	Casing-Control Wire (72" Long) (Cut to Required Length)
24	222698S	Key-Flywheel	97	690024	Shaft-Throttle	269	691026	Wire-Control (78" Long) (Cut to Required Length)
25	792004	Piston Assembly (Standard) ----- Note ----- 791325 Piston Assembly (.020" Oversize)	98	398185	Kit-Idle Speed (Carburetor)	270	691027	Nut (Control Wire Casing)
26	791969	Ring Set (Standard) ----- Note ----- 791234 Ring Set (.020" Oversize)	104	●691242	Pin-Float Hinge	271	691028	Lever-Control
27	691866	Lock-Piston Pin	108	692567	Valve-Choke	276	●271716	Washer-Sealing
28	499423	Pin-Piston	109	690023	Valve-Choke	286	698611	Module-Oil Sensor
29	690124	Rod-Connecting	117	790570	Jet-Main (Standard)	304	699598	Housing-Blower
30	692562	Dipper-Connecting Rod	121A	696998	Kit-Carburetor Overhaul	305	699480	Screw (Blower Housing)
			122	★●693749	Spacer-Carburetor	306	693610	Shield-Cylinder
			125	790569	Carburetor	307	699483	Screw (Cylinder Shield)
			127	●691739	Plug-Welch			
			130	691181	Valve-Throttle			
			133	398187	Float-Carburetor			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
332	699359	Nut (Flywheel)	615	692576	Retainer-Governor Shaft	968	692584	Cover-Air Cleaner (Flat Panel)
333	695711	Armature-Magneto	616	692547	Crank-Governor	971	690370	Screw (Air Cleaner Base To Carburetor)
334	699477	Screw (Magneto Armature)	619	699230	Screw (Cylinder Head Plate)	975	493640	Bowl-Float
337	491055S	Plug-Spark	632	693408	Spring/Link-Mechanical Governor	976A	692666	Primer-Carburetor
347	698338	Switch-Rocker	633	●693867	Seal-Choke/Throttle Shaft	977A	697001	Gasket Set-Carburetor
356	692602	Wire-Stop	633A	●691321	Seal-Choke/Throttle Shaft	993	∅694088	Gasket-Cylinder Head Plate
358	699638	Gasket Set-Engine	635	692927	Boot-Spark Plug	1005	692592	Fan-Flywheel
363	19069	Puller-Flywheel	643	696264	Retainer-Air Filter	1019	694852	Kit-Label
364	695693	Terminal-Oil Plug	689	691855	Spring-Friction	1022	★∅691890	Gasket-Rocker Cover
365	699484	Screw (Carburetor)	692	690572	Spring-Detent	1023	499924	Cover-Rocker Arm
383	19374S	Wrench-Spark Plug	718	690959	Pin-Locating	1026	693517	Rod-Push
415	693463	Plug	741	695087	Gear-Timing	1029	691230	Arm-Rocker
425	699208	Screw (Air Cleaner Cover)	742	692564	Retainer-E Ring	1034	691343	Guide-Push Rod
455	692591	Cup-Flywheel	746	692566	Gear-Idler	1052	790141	Sensor-Oil
456	692299	Plate-Pawl Friction	799	699202	Screw (Oil Sensor)	1058	276057	Owner's Manual
459	281505S	Pawl-Ratchet	830	694544	Stud-Rocker Arm (Muffler Guard)	1070	699201	Screw (Flywheel Fan)
505	691251	Nut (Governor Control Lever)	851	493880S	Terminal-Spark Plug	1095	698215	Gasket Set-Valve
535	696263	Filter-Air Cleaner Foam	868	★∅692044	Seal-Valve	1210	498144	Pulley/Spring Assembly (Pulley)
552	692346	Bushing-Governor Crank	914	699481	Screw (Rocker Cover) (Bottom)	1211	498144	Pulley/Spring Assembly (Spring)
562	691119	Bolt (Governor Control Lever)	914A	692557	Screw (Rocker Cover) (Top)	1305	699691	Screw (Oil Sensor Module)
597	691696	Screw (Pawl Friction Plate)	914B	697551	Screw (Rocker Cover) (Center)	1330	272147	Repair Manual
608	693394	Starter-Rewind						

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.