



Illustrated Parts List

Model Series

205400

TYPE NUMBERS
0035 through 0299.

TABLE OF CONTENTS


Air Cleaner	6
Alternator	10
Blower Housing/Shrouds	7
Camshaft	2
Carburetor (Walbro)	4
Carburetor (Nikki)	5
Controls	8
Crankcase Cover	2
Crankshaft	2
Cylinder	2
Cylinder Head	3
Electric Starter	9
Exhaust System	6
Flywheel	7
Fuel Supply	6
Gear Reducer	7
Governor Spring	8
Ignition	9
Kit/Gasket Sets-Carburetor (Walbro) ..	4
Kit/Gasket Sets-Carburetor (Nikki) ..	5
Kit/Gasket Sets-Engine	2
Kit/Gasket Sets-Valves	3
Lubrication	2
Piston, Rings, Connecting Rod	2
Rewind Starter	7
Valves	3

PRINTED IN U.S.A.





COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

205400




- 1330 REPAIR MANUAL
- 1019 LABEL KIT
- 1058 OPERATOR'S MANUAL

Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.
6359-2 Assemblies include all parts shown in frames. **10/25/2005**



Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.
 6359-3 Assemblies include all parts shown in frames. 10/25/2005



205400



Walbro		
121 CARBURETOR OVERHAUL KIT		
93	122 51A	163
98	51	176
104	127	276
105	137	633
106		633A


977 CARBURETOR GASKET SET		
93	137	276
122 51A	163	633
51	176	633A

Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.
 6359-4 Assemblies include all parts shown in frames. 10/25/2005










Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.
 6359-5 Assemblies include all parts shown in frames. 10/25/2005

205400




Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.
6359-6 Assemblies include all parts shown in frames. **10/25/2005**

1036 EMISSION LABEL











6359-7 **Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.** Assemblies include all parts shown in frames. 10/25/2005

205400






6359-8 *Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.* Assemblies include all parts shown in frames. 10/25/2005





Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.

205400



DC ONLY		10 - 16 AMP	
474A		474D	
<p>NOTE: All stators use a No. 1119 mounting screw. </p> <p>NOTE: The proper flywheel part number and/or the alternator magnet size will determine the alternator type or output. See repair instruction manual for additional information.</p>			<p>526 </p> <p>501 </p>



Illustrations cover a range of engines. Parts shown without corresponding text are not used on this engine.
 6359-10 Assemblies include all parts shown in frames. 10/25/2005

205400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	696772	Cylinder Assembly ----- Note ----- 694673 Cylinder Assembly Used on Type No(s). 0208.	16	695369	Crankshaft ----- Note ----- 695817 Crankshaft Used on Type No(s). 0049, 0050, 0112, 0195.	19	698340	Kit-Bushing/Seal (PTO Side)
2	698340	Kit-Bushing/Seal (Magneto Side)			694678 Crankshaft Used on Type No(s). 0038, 0116, 0118, 0130, 0140, 0153, 0154, 0159, 0163, 0174, 0175, 0177, 0178, 0179, 0184, 0186, 0187, 0188, 0190, 0191, 0194, 0205, 0208, 0232.	20	*391086	Seal-Oil (PTO Side)
3	*391086	Seal-Oil (Magneto Side)			695306 Crankshaft Used on Type No(s). 0126.	21	281658	Cap-Oil Fill
5	697233	Head-Cylinder (Used After Code Date 01102800) ----- Note ----- 698040 Head-Cylinder (Used Before Code Date 01102900)			695462 Crankshaft Used on Type No(s). 0141, 0168, 0171, 0172, 0173, 0183, 0197, 0198, 0203, 0299.	22	695174	Screw (Crankcase Cover/Sump)
7	*Δ694872	Gasket-Cylinder Head			695818 Crankshaft Used on Type No(s). 0035, 0165, 0166, 0196.	23	694954	Flywheel ----- Note ----- 695485 Flywheel Used on Type No(s). 0041, 0050, 0112, 0118, 0123, 0148, 0150, 0169, 0172, 0174, 0180, 0185, 0198, 0204, 0229.
11A	695305	Tube-Breather Used on Type No(s). 0113, 0126.			69512 Crankshaft Used on Type No(s). 0121.	24	222698	Key-Flywheel
11C	696796	Tube-Breather Used on Type No(s). 0100, 0130, 0140, 0172, 0177, 0178, 0179, 0184, 0187, 0194, 0198, 0202, 0203, 0205, 0229.	17	695434	Bearing-Ball	25	792117	Piston Assembly (Standard) ----- Note ----- 792144 Piston Assembly (.020" Oversize)
12	*694953	Gasket-Crankcase			695816 Cover-Crankcase (Gear Reduction)	26	792026	Ring Set (Standard) (Used After Code Date 05082100) ----- Note ----- 694004 Ring Set (Standard) (Used Before Code Date 05082200)
13	690360	Screw (Cylinder Head)	18	696914	Cover-Crankcase ----- Note ----- 695372 Cover-Crankcase Used on Type No(s). 0035, 0036, 0038, 0041, 0105, 0114, 0115, 0121, 0132, 0136, 0141, 0145, 0150, 0159, 0163, 0164, 0165, 0166, 0168, 0169, 0171, 0172, 0174, 0180, 0183, 0185, 0186, 0196, 0197, 0198, 0199, 0201, 0204, 0227, 0229, 0230, 0232.			792073 Ring Set (.020" Oversize) (Used After Code Date 05082100) 694008 Ring Set (.020" Oversize) (Used Before Code Date 05082200)
15	691686	Plug-Oil Drain				27	690975	Lock-Piston Pin
15A	691682	Plug-Oil Drain				28	696581	Pin-Piston
15B	695757	Plug-Oil Drain Used on Type No(s). 0278.				29	694691	Rod-Connecting
						30	694692	Dipper-Connecting Rod
						32	690976	Screw (Connecting Rod)
						33	499596	Valve-Exhaust
						34	697464	Valve-Intake

* Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No. 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

205400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
35	694865	Spring-Valve (Intake)	89	690283	Plug-Oil	117	●696134	Jet-Main (Standard)
36	694865	Spring-Valve (Exhaust)	93	●690602	Bushing-Throttle Shaft	118	696135	Jet-Main (High Altitude)
42	499586	Keeper-Valve	95	691636	Screw (Throttle Valve)	121	695441	Kit-Carburetor Overhaul (Use With Walbro Carburetor)
45	690977	Tappet-Valve	95A	690718	Screw (Throttle Valve)	121A	696146	Kit-Carburetor Overhaul (Nikki Carburetor)
46	790496	Camshaft	97	695325	Shaft-Throttle	122	●*Δ694876	Spacer- Carburetor
51	●*Δ694874	Gasket-Intake	97A	696387	Shaft-Throttle	125A	699966	Carburetor ----- Note -----
51A	●*Δ694875	Gasket-Intake	98	●495800	Kit-Idle Speed			695920 Carburetor Used on Type No(s). 0113, 0126.
53	694869	Stud (Carburetor)	98A	●695408	Kit-Idle Speed	127	●694524	Plug-Welch
53A	695433	Stud (Carburetor)	104	●690525	Pin-Float Hinge	127A	●690727	Plug-Welch
55	695288	Housing-Rewind Starter	104A	●694918	Pin-Float Hinge	130	690468	Valve-Throttle
58	693389	Rope-Starter (Cut To Required Length)	105	●691782	Valve-Float Needle	130A	696139	Valve-Throttle
59	805957	Insert-Grip	105A	●696136	Valve-Float Needle	133	494381	Float-Carburetor
60	490652	Grip-Starter Rope	106	●690577	Seat-Inlet	133A	694914	Float-Carburetor
65	690837	Screw (Rewind Starter)	108	693924	Valve-Choke (Used Before Code Date 00082700) Used on Type No(s). 0038, 0116, 0118, 0130, 0140, 0175, 0177, 0178, 0179.	135	696142	Tube-Fuel Transfer
		----- Note -----	108A	696143	Valve-Choke	137	●281165	Gasket-Float Bowl
		690759 Screw (Rewind Starter) Used on Type No(s). 0041, 0050, 0115, 0118, 0123, 0141, 0148, 0150, 0163, 0164, 0169, 0172, 0174, 0180, 0185, 0198, 0199, 0201.	108B	696209	Valve-Choke (Used After Code Date 00082800) Used on Type No(s). 0038, 0116, 0118, 0130, 0140, 0154, 0175, 0177, 0178, 0179, 0232.	137A	●695426	Gasket-Float Bowl
79	690614	Case-Gear Reduction	109	695331	Shaft-Choke	141	696144	Kit-Choke Shaft Used on Type No(s). 0113, 0126.
80	691603	Gasket-Gear Case	109A	695326	Shaft-Choke (Used Before Code Date 00082800) Used on Type No(s). 0130, 0140, 0177.	141A	696145	Kit-Choke Shaft Used on Type No(s). 0100, 0165, 0202, 0299.
81	695400	Lock-Muffler Screw	109B	695329	Shaft-Choke (Used After Code Date 00082900 and Before Code Date 00092900). Used on Type No(s). 0113, 0126, 0130.	141C	698457	Kit-Choke Shaft Used on Type No(s). 0038, 0116, 0118, 0130, 0140, 0154, 0175, 0177, 0178, 0179, 0232.
82	690287	Screw (Gear Reduction Case)	109C	696145	Shaft-Choke	142	695528	Nozzle-Carburetor (Standard)
83	690387	Shaft-Auxiliary Drive	109D	696144	Shaft-Choke (Used After Code Date 00092800) Used on Type No(s). 0113, 0126.	143	695529	Nozzle-Carburetor (High Altitude)
84	691121	Plug-Breather	109E	696735	Shaft-Choke	146	690979	Key-Timing
85	691076	Screw (Gear Cover to Gear Reduction Case)						
86	690613	Cover-Gear						
87	391086	Seal-Gear Reduction						
88	691601	Gasket-Gear Reduction Cover Used on Type No(s). 0049, 0050, 0112, 0195.						

* Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

Δ Included in Valve Gasket Set-Ref. No.1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

205400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
161	695384	Base-Air Cleaner (Metal)	187	791766	Line-Fuel (Cut To Required Length)	188	690877	Screw (Control Bracket)
161A	699960	Base-Air Cleaner (Metal) (Used After Code Date 04010400)			(Used After Code Date 05063000)	190	692127	Screw (Fuel Tank)
		Used on Type No(s). 0116, 0130, 0140, 0154, 0175, 0177, 0178, 0187, 0194, 0205, 0229.			----- Note -----	192	690083	Adjuster-Rocker Arm
		----- Note -----			691050 Line-Fuel (Cut To Required Length)	209	694867	Spring-Governor
		694870 Base-Air Cleaner (Metal) (Used Before Code Date 04010500)	187A	791869	Line-Fuel (Used After Code Date 05063000)			----- Note -----
		Used on Type No(s). 0038, 0116, 0118, 0130, 0140, 0154, 0175, 0177, 0178, 0179, 0187, 0194, 0232.			----- Note -----			695491 Spring-Governor
163★♦	692277	Gasket-Air Cleaner			695429 Line-Fuel (Used Before Code Date 05070100)	211	695307	Spring-Governed Idle
170	695296	Stud (Crankcase Cover/Sump)	187B	791834	Line-Fuel (Used After Code Date 05063000)	219	693578	Gear-Governor
176★♦	691917	Seal-O Ring (Air Cleaner Base)			----- Note -----	220	691724	Washer (Governor Gear)
		----- Note -----	187C	791871	Line-Fuel (Used After Code Date 05063000)	222	695380	Bracket-Control
		691876 Seal-O Ring (Air Cleaner Base) (Used on Type No(s). 0184.			695482 Line-Fuel (Used Before Code Date 05070100)	222A	694866	Bracket-Control (Used on Type No(s). 0038, 0116, 0118, 0120, 0126, 0130, 0140, 0153, 0154, 0159, 0163, 0165, 0174, 0175, 0177, 0178, 0179, 0184, 0186, 0187, 0188, 0190, 0191, 0194, 0205, 0208, 0227, 0228, 0232.
185	690958	Nut (Air Cleaner Base)	187D	791879	Line-Fuel (Used After Code Date 05063000)	222B	791753	Bracket-Control
186	692317	Connector-Hose			Used on Type No(s). 0278.	227	694864	Lever-Governor Control
					698080 Line-Fuel (Used Before Code Date 05070100)	231	691636	Screw (Choke Valve)
					Used on Type No(s). 0278.	240	394358	Filter-Fuel (Used on Type No(s). 0116.
						240A	694485	Filter-Fuel
						265	691024	Clamp-Casing
						267	692577	Screw (Casing Clamp)
						268	691025	Casing-Control Wire (Cut To Required Length)

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

♦ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No. 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

205400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
269	691026	Wire-Control (Cut To Required Length)	286C	699952	Module-Oil Sensor (Used After Code Date 03082800)	304A	791481	Housing-Blower Used on Type No(s). 0194.
270	691027	Nut (Control Wire Casing)			Used on Type No(s). 0118, 0168.	305	691108	Screw (Blower Housing) ----- Note -----
271	691028	Lever-Control			----- Note -----			691125 Screw (Blower Housing) Used on Type No(s). 0194.
271A	695381	Lever-Control			699951 Module-Oil Sensor			
272	691168	Lock-Screw Head			(Used After Code Date 03072300)	306	697240	Shield-Cylinder (Used After Code Date 01102800) ----- Note -----
276	692255	Washer-Sealing			Used on Type No(s). 0112, 0115, 0116, 0130, 0136, 0140, 0141, 0153, 0154, 0159, 0163, 0164, 0165, 0166, 0171, 0172, 0174, 0175, 0177, 0178, 0179, 0183, 0184, 0185, 0186, 0187, 0188, 0190, 0191, 0194, 0196, 0197, 0198, 0200, 0201, 0205, 0208, 0232.			694677 Shield-Cylinder (Used Before Code Date 01102900)
277	691075	Washer (Gear Case To Gear Reduction)				307	691660	Screw (Cylinder Shield)
278	792008	Washer (Governor Control Lever)				309	695479	Motor-Starter
281	697268	Panel-Control (Used After Code Date 01102800) ----- Note -----	287	691693	Screw (Dipstick Tube)	310	690323	Screw (Starter Motor)
		695294 Panel-Control (Used Before Code Date 01102900)	298	698838	Locknut-Muffler/Elbow	311	497608	Brush Set
286	695186	Module-Oil Sensor (Used Before Code Date 03072400) Used on Type No(s). 0116, 0130, 0136, 0140, 0141, 0153, 0154, 0159, 0163, 0165, 0166, 0171, 0175, 0177, 0178, 0179, 0183, 0184, 0187, 0188, 0190, 0191, 0205.	300	697252	Muffler (Used After Code Date 02012000) ----- Note -----	312	694685	Nut (Flywheel)
					695311 Muffler (Used Before Code Date 02012100)	333	715231	Armature-Magneto
286B	696058	Module-Oil Sensor (Used Before Code Date 03010600) Used on Type No(s). 0112, 0172, 0174, 0185, 0186.			698101 Muffler Used on Type No(s). 0191.	334	691061	Screw (Magneto Armature)
		----- Note -----	304	791479	Housing-Blower (Used After Code Date 01102800) ----- Note -----	337	491055	Plug-Spark ----- Note -----
		696058 Module-Oil Sensor (Used Before Code Date 03082900) Used on Type No(s). 0118, 0168.			791478 Housing-Blower (Used Before Code Date 01102900)			691043 Plug-Spark Used on Type No(s). 0105, 0115, 0116, 0118, 0123, 0141, 0159, 0163, 0164, 0166, 0183, 0190, 0195, 0196, 0199, 0200, 0201.

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

205400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
346	690661	Screw (Spark Arrestor) Used on Type No(s). 0113, 0116, 0120, 0123, 0125, 0128, 0129, 0148. ----- Note ----- 690367 Screw (Spark Arrestor) Used on Type No(s). 0190.	369	695422	Spring-Float Bowl	504	695383	Washer Set-Friction
			383	19374	Wrench-Spark Plug	505	691251	Nut (Governor Control Lever)
			410	695382	Link-Control	510	693699	Drive-Starter
			412	690958	Nut (Air Cleaner Cover) Used on Type No(s). 0172, 0177, 0179, 0188, 0198.	513	692024	Clutch-Drive
			415	691363	Plug	522	697689	Plug-Dipstick/Fill Used on Type No(s). 0178, 0184, 0187, 0188, 0194.
			425	694515	Screw (Air Cleaner Cover)	523	695344	Dipstick
347	698338	Switch-Rocker Used on Type No(s). 0038, 0115, 0120, 0123, 0126, 0141, 0148, 0227, 0228.	425A	790043	Screw (Air Cleaner Cover)	524	691876	Seal-Dipstick Tube
			445	491588	Filter-Air Cleaner Cartridge	525	695343	Tube-Dipstick
347A	697854	Switch-Rocker	445A	695302	Filter-Air Cleaner Cartridge Used on Type No(s). 0113, 0126.	526	690297	Screw (Regulator)
347B	790949	Switch-Rocker				529	791822	Grommet
356	692603	Wire-Stop				544	692034	Armature-Starter
356A	692390	Wire-Stop Used on Type No(s). 0035, 0036, 0049, 0100, 0105, 0113, 0132, 0133, 0134, 0145, 0161, 0167, 0173.	455	694683	Cup-Flywheel ----- Note ----- 697357 Cup-Flywheel Used on Type No(s). 0194.	552	694674	Bushing-Governor Crank
						562	691119	Bolt (Governor Control Lever)
356B	695815	Wire-Stop Used on Type No(s). 0036, 0114, 0121, 0125, 0128, 0129, 0150, 0168, 0180, 0203, 0204, 0229, 0230, 0278.	456	692299	Plate-Pawl Friction	564	691673	Screw (Control Cover)
			459	281505	Pawl-Ratchet	564A	692198	Screw (Control Cover) Used on Type No(s). 0154, 0177, 0179, 0184.
			467	691668	Knob-Air Cleaner Used on Type No(s). 0113. ----- Note ----- 691668 Knob-Air Cleaner Used on Type No(s). 0126.	575	692303	Switch-Starting Used on Type No(s). 0179.
356C	695295	Wire-Stop Used on Type No(s). 0112, 0115, 0115, 0126, 0141, 0164, 0171, 0172, 0185, 0194, 0197, 0198, 0199, 0200.	474A	695730	Alternator (3 Amps DC)	577	690630	Cable-Starter
			474D	695466	Alternator (10 Amp Regulator)	577A	690795	Cable-Starter
			493	694861	Bracket-Mounting (Oil Sensor)	578	692306	Wire Assembly Used on Type No(s). 0123, 0148, 0185, 0186, 0204, 0229.
356D	695366	Wire-Stop (Used Before Code Date 03072400) Used on Type No(s). 0118.	493A	691177	Bracket-Mounting	578A	790948	Wire Assembly
			493B	699973	Bracket-Mounting	579	691029	Nut (Starter Cable) ----- Note ----- 696198 Nut (Starter Cable) Used on Type No(s). 0118.
356E	696328	Wire-Stop	500	691086	Washer (Key Switch)			
356J	699994	Wire-Stop (Used After Code Date 03072300)	501	691185	Regulator			
			503	691532	Strap-Starter			
358	695438	Gasket Set-Engine						
361	691681	Screw (Starting Switch)						
361A	690297	Screw (Starting Switch)						
364A	699947	Terminal-Oil Plug Used on Type No(s). 0168, 0232.						

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

205400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
592	690800	Nut (Rewind Starter)	635	710901	Boot-Spark Plug	799	695446	Screw (Oil Sensor)
597	691696	Screw (Pawl Friction Plate)	636	696198	Nut (Starting Switch)			(Shoulder Screw)
601	95162	Clamp-Hose	641	690282	Washer (Starting Switch)			----- Note -----
604	697326	Cover-Control (Used After Code Date 01061000) Used on Type No(s). 0116, 0118, 0120, 0177, 0179. ----- Note ----- 696078 Cover-Control (Used Before Code Date 01061100) Used on Type No(s). 0116, 0118, 0120, 0177, 0179.	663	692577	Screw (Control Panel) ----- Note ----- 690372 Screw (Control Panel) Used on Type No(s). 0041, 0050, 0118, 0169.	801	694482	Cap-Drive
604A	791752	Cover-Control	664	691087	Nut (Key Switch)	802	691286	Cap-End
608	695287	Starter-Rewind ----- Note ----- 697356 Starter- Rewind Used on Type No(s). 0194.	668	694257	Spacer (Control Bracket)	803	693757	Housing-Starter
613	695312	Screw (Muffler)	676	393761	Deflector-Muffler	813	690635	Clamp
613A	695399	Screw (Muffler)	677	690661	Screw (Muffler Deflector)	832	695386	Guard-Muffler
615	694676	Retainer-Governor Shaft	689	691855	Spring-Friction	836	695312	Screw (Muffler Guard) (Used After Code Date 01061000) ----- Note ----- 690367 Screw (Muffler Guard) (Used Before Code Date 01061100)
616	694675	Crank-Governor	692	691301	Spring-Detent	842	691031	Seal-O Ring (Dipstick Tube)
621	692310	Switch-Stop	697	690372	Screw (Drive Cap)	843	695588	Sleeve-Lever
622	698839	Washer (Heat Shield)	718	690959	Pin-Locating	847	695342	Dipstick/Tube Assembly
627	696064	Bracket-Stopswitch	718A	695178	Pin-Locating (Head)	868	★△690968	Seal-Valve
627A	790952	Bracket-Stopswitch	725	698836	Shield-Heat Used on Type No(s). 0194, 0205. ----- Note ----- 698837 Shield-Heat Used on Type No(s). 0194, 0205.	875	695304	Base-Air Cleaner (Plastic) Used on Type No(s). 0113, 0126.
632	694868	Spring/Link- Mechanical Governor (Used With Walbro Carburetors) ----- Note ----- 695917 Spring/Link- Mechanical Governor (Use With Nikki Carburetor)	727	697465	Cover-Starter Drive	877A	399916	Wire/Connector- Alternator
633	◆690597	Seal-Choke/Throttle Shaft	728	696763	Screw (Heat Shield)	877C	393456	Wire/Connector- Alternator
633A	◆691326	Seal-Choke/Throttle Shaft	732	691097	Screw (Starter Drive Cover)	883	★△695398	Gasket-Exhaust (Used Before Code Date 02012000)
633B	◆690998	Seal-Choke/Throttle Shaft	741	691288	Gear-Timing	883A	697255	Gasket-Exhaust (Used After Code Date 02011900)
			742	692564	Retainer-E Ring	892	392833	Switch-Key
			746	694679	Gear-Idler	914	693732	Screw (Rocker Cover)
			773	694258	Retainer	920	691656	Solenoid-Starter
			774	695447	Screw (Stop Wire)	934	710550	Screw (Fan Retainer)
			783	693713	Gear-Pinion	950	691657	Screw-Float Bowl
			797	693167	Nut (Brush Retainer)			
			798	697890	Screw (Rocker Arm)			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

205400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
951	699961	Lever-Choke (Used After Code Date 04010500) Used on Type No(s). 0038, 0116, 0118, 0130, 0140, 0154, 0175, 0178, 0188, 0205, 0229, 0232.	971	695181	Screw (Air Cleaner Base to Carburetor)	1051	691265	Ring-Retaining
957	694261	Cap-Fuel Tank (Plastic)	972	694260	Tank-Fuel (Plastic)	1052A	790274	Sensor-Oil
958	698180	Valve-Fuel Shut Off (Plastic)	975	495933	Bowl-Float	1058	276355	Operator's Manual
967	491435	Filter-Pre Cleaner	975A	696138	Bowl-Float	1070	691058	Screw (Flywheel Fan)
967A	695303	Filter-Pre Cleaner Used on Type No(s). 0126.	977	◆695439	Gasket Set-Carburetor (Used With Walbro Carburetors)	1090	691293	Retainer-Brush
		----- Note ----- 695303 Filter-Pre Cleaner Used on Type No(s). 0113.	977A	◆696147	Gasket Set-Carburetor (Use With Nikki Carburetor)	1095	695440	Gasket Set-Valve
968	697061	Cover-Air Cleaner Used on Type No(s). 0100, 0121, 0125, 0128, 0129, 0133, 0134, 0161, 0165, 0167, 0172, 0173, 0190, 0198, 0202, 0203, 0230.	990	691959	Key Set	1100	690973	Pivot-Rocker Arm
968A	692321	Cover-Air Cleaner	994	392390	Arrestor-Spark Used on Type No(s). 0116, 0190.	1119	691183	Screw (Alternator)
968B	695301	Cover-Air Cleaner Used on Type No(s). 0113, 0126.	998	696683	Pipe-Oil Used on Type No(s). 0278.	1127A	695407	Screw (Float Bowl)
			1005	694684	Fan-Flywheel	1138	694255	Nut (Control Bracket)
			1006	690452	Retainer-Fan	1171	696754	Stud (Rocker Cover)
			1019	695442	Kit-Label	1194	691876	Seal-O Ring (Plug)
			1022	★△690971	Gasket-Rocker Cover	1210	498144	Pulley/Spring Assembly (Pulley)
			1023	697691	Cover-Rocker	1211	498144	Pulley/Spring Assembly (Spring)
			1026	695177	Rod-Push	1230	791754	Stud (Control Bracket)
			1029	690972	Arm-Rocker	1330	272147	Repair Manual
			1036		Label-Emissions (Available from an Authorized Briggs & Stratton Dealer)	1404	696757	Nut (Control Cover)

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.