FORM MS-1209-2/97 REPLACES FORM MS-1209-9/96 FILE IN SECT. 2 OF SERVICE MANUAL

28F700 to 28F799

Illustrated Parts List Model Series 28F700 to 28F799

TYPE NUMBERS 0298.


TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW

- A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- B. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- C. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."
- D. If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- E. If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- F. For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.

PRINTED IN U.S.A.



COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted,
in any form or by any means, electronic or mechanical, including photocopying,
recording or by any information storage and retrieval system, without permission
in writing from Briggs & Stratton Corporation.



★ REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL.

1019 LABEL KIT


1058 OWNER'S MANUAL

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1 2 3 5	496413 399265 ★391086 494240 Ø★271866 495735 Ø★27803 94719 280100 94622 ★491323	Cylinder Assembly Bushing	306 307 308 337 383 552 635 664 668 869	224545 94930 491490 802592 89838 491986 66538 94881 231109	Shield-Cylinder Screw-Hex. Cover-Cylinder Plug-Spark Wrench-Spark Plug Bushing-Gov. Crank Boot-Spark Plug Screw-Hex.	870 871 1019 1058	262924 261961 491255	Seat–Valve (Exhaust)

[★] Included in Gasket Set-Part Number 494241.

Included in Carburetor Kit–Part No. 499220.


 [◆] Included in Carburetor Gasket Set–Part No. 494385.
 Ø Included in Valve Overhaul Gasket Set–Part No. 498539.



[★] Included in Gasket Set-Part Number 494241.

Included in Carburetor Kit-Part No. 499220.

[◆] Included in Carburetor Gasket Set–Part No. 494385. Ø Included in Valve Overhaul Gasket Set–Part No. 498539.




THIS CARBURETOR SERVICES BOTH CHOKE-A-MATIC AND MANUAL CHOKE SYSTEMS

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
51 ••2 51A Ø*2 51A Ø*2 53 93 2 94 4 94A 4 95 •2 105 •2 106 •2 108A 2 111 2 123 125 4 127 •	272465 272554 94637 281346 498030 494383 •94098 495800 231789 231855 231854 224558 224540 262715 94616 498027	Manifold-Intake Gasket-Carb. Elbow Gasket-Intake Stud-Carb. Mtg. Bushing-Throttle Shaft Valve-Idle Adjustment Valve-Idle Adjustment Screw-Rounded Head Screw-Idle Speed Pin-Float Hinge Valve-Needle Seat-Inlet Valve-Choke Valve-Choke Spring-Friction Screw-Torx®Hex. Carburetor Plug-Welch (Sold in Kit Only) Valve-Throttle		494381 •+281165 •+281164 495097 495931	Shaft-Throttle Float-Carburetor Gasket-Float Bowl Washer Shaft-Choke (Manual Choke) Shaft-Choke (Choke-A-Matic) Nozzle-Carburetor (Standard) (LMT 157) 497567 Nozzle-Carb. (High Altitude) (LMT 157) •497736 Nozzle-Carb. (Standard) (LMT 96) 499040 Nozzle-Carb. (High Altitude) (LMT 96)	186 187 240 601 634 634A 955 965 975 1091	298090 93053 •494453 •494455 94642 94010 494378 •281166	Connector-Hose Line-Fuel (Cut to Required Length) Filter-Fuel Clamp-Hose Seal-Spring Assembly Seal-Spring Assembly Plug Nut-Hex. Bowl-Float Seal-Throttle Shaft Cap-Limiter

[★] Included in Gasket Set-Part Number 494241.

[•] Included in Carburetor Kit-Part No. 499220.

 [◆] Included in Carburetor Gasket Set–Part No. 494385.
 Ø Included in Valve Overhaul Gasket Set–Part No. 498539.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
116 209 216 216A 222 227 230 232 268	260871 262766 262767 495611 493935 94927 262785	Seal-O-Ring Spring-Governor Link-Choke Link-Choke Bracket-Control Lever-Governor Washer Spring-Link Casing-Wire (72" Long)	270 271 333 334 356 423 474 482 523	290568 492341 94731 494328 94903 393474 93621	Locknut-Casing Lever-Control Armature-Magneto Screw-Hex. Wire-Stop Screw-Shoulder Alternator (Dual Circuit) Screw-Hex. Dipstick	529 562 592 614 616 663 847 851	94852 231978 93306 495157 94929 496415	Seal–Fill Tube Bolt–Governor Lever Nut–Hex. Pin–Cotter Crank–Governor Screw–Hex. Dipstick–Tube Assembly Terminal–Cable Wire–Alternator
269	26633	(Cut to Required Length) Wire–Control (78" Long) (Cut to Required Length)	525		Tube–Oil Fill	878		Harness-Alternator

[★] Included in Gasket Set-Part Number 494241.

Included in Carburetor Kit–Part No. 499220.

[◆] Included in Carburetor Gasket Set–Part No. 494385. Ø Included in Valve Overhaul Gasket Set–Part No. 498539.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
	NO. 494237 281051 94704	Base-Air Cleaner	NO. 467 535	NO. 493903 272403	Knob Filter–Air Gasket–Air Cleaner		NO. 94929 94513	DESCRIPTION Screw-Hex. Screw-Hex. Cover-Air Cleaner

[★] Included in Gasket Set-Part Number 494241.

Included in Carburetor Kit–Part No. 499220.

[◆] Included in Carburetor Gasket Set–Part No. 494385. Ø Included in Valve Overhaul Gasket Set–Part No. 498539.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
23 37 73 75 78 188 284A 304	224502 224517 225136 94626 94627 94073	Flywheel Guard–Flywheel Screen–Rotating Washer–Flywheel Screw–Phillips Screw–Hex. Screw–Shoulder Housing–Blower (Red)	305 346 363 455 668 726	94896 19203 222561 280848	Screw-Torx®Hex. Screw-Hex. Flywheel Puller Cup-Flywheel Spacer Gear-Ring (Includes Mounting Hardware)	727 729 1005 1006	281159 280687	Cover–Starter Drive Clip–Wire Fan–Flywheel Retainer–Fan

[★] Included in Gasket Set-Part Number 494241.

[•] Included in Carburetor Kit-Part No. 499220.


[◆] Included in Carburetor Gasket Set–Part No. 494385. Ø Included in Valve Overhaul Gasket Set–Part No. 498539.





REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
110 309 310 311 503 510	497595 94003 497608 806000	Washer Motor-Starter Screw-Hex. Brush Set Strap-Starter Drive-Starter	544 592 615A 728 729A	92278 263080 94773	Armature–Starter Nut–Hex. Retainer Screw–Torx® Hex. Clip–Wire	783 801 802 803 1090	394856 497607 497604	Gear–Starter Cap–Drive Cap–End Housing–Starter Retainer–Brush


[★] Included in Gasket Set–Part Number 494241.
◆ Included in Carburetor Kit–Part No. 499220.

[◆] Included in Carburetor Gasket Set-Part No. 494385. Ø Included in Valve Overhaul Gasket Set-Part No. 498539.









REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
3 7 9 12 20 51	*391086 ∅*271866 ∅*27803 *271916 *291675 •4272465 ∅*272554	Seal-Oil Gasket-Cylinder Head Gasket-Breather Gasket-Crankcase (.015" Thick, Std.) *271997 Gasket- Crankcase (.005" Thick) *271996 Gasket- Crankcase (.009" Thick)	95 104 105 106 116 121	●94098 ●231789 ●231855 ●231854 ★270920 499220 ● ● ◆281165 ● ◆281164	Screw-Slotted Pin-Float Hinge Valve-Needle Seat-Inlet Seal-O-Ring Carburetor Kit (LMT 96) ————————————————————————————————————	358 529	494241 281370 281106 494453 494455 494385 494385	(Standard) (LMT 157) ●497736 Nozzle–Carb. (Standard) (LMT 96) Gasket Set Seal–Fill Tube Gasket–Air Cleaner Seal–Spring Assembly (Manual Choke) Seal–Spring Assembly (Choke–a–Matic) Gasket Set– Carburetor Seal–Throttle Shaft

[★] Included in Gasket Set-Part Number 494241.

Included in Carburetor Kit–Part No. 499220.

[◆] Included in Carburetor Gasket Set–Part No. 494385. Ø Included in Valve Overhaul Gasket Set–Part No. 498539.