



433400

Illustrated Parts List

Model Series

433400

700cc

GAS

TYPE NUMBERS

0115, 0116, 0215,
0216, 0217, 0317.

TO FIND

THE CORRECT NUMBER OF THE PART YOU NEED:


FOLLOW THE INSTRUCTIONS BELOW

- A. Refer to Model, Type and Code Number that is located on the engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01, 02, E1, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- B. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- C. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. **THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER NOTE.**
- D. If a *Note* appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under *Note*, order the part referred to at the *Note*.
- E. If your Engine Type Number does not appear after any part number listed under *Note*, use the Primary Part Number.
- F. For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.
- G. **REFER TO REPAIR MANUAL MS 0750 FOR ASSEMBLY AND/OR TORQUE REQUIREMENTS.**

PRINTED IN U.S.A.



COPYRIGHT by BRIGGS & STRATTON DAIHATSU LLC
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton DAIHATSU LLC.


433400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	825333	Cylinder Assembly (9 mm Head Bolts) (Used After Code Date 98123100). ----- Note ----- 825027 Cylinder Assembly (8 mm Head Bolts) (Used Before Code Date 99010100).	239	821135	Switch-Oil Pressure	591	821069	Plug-Camshaft
			287	820273	Screw (Dipstick Tube)	713	820129	Bushing-Camshaft
			292	820662	Collar-Dipstick Tube	718	820063	Pin-Locating
			415	820051	Plug (Cylinder)	718A	820062	Pin-Locating
			573	820283	Plate-Back	718B	820061	Pin-Locating
20	★821073	Seal-Oil (PTO Side)	573A	820170	Plate-Back	724	820146	Retainer-Seal
127	820004	Plug-Welch	508	820031	Screw (Seal Retainer)	890	820238	Bracket-Support (Dipstick Tube)
197	820176	Screw (Back Plate)	523	821158	Dipstick	1027	491056	Filter-Oil
			523A	820572	Dipstick	1028	820851	Adapter-Oil Filter
			523B	820646	Dipstick	1069	820102	Nozzle-Oil
			525	820144	Tube-Dipstick	1080	★820145	Gasket-Seal Retainer
			525A	820652	Tube-Dipstick	1300	820042	Screw (Crankshaft Bearing Cap)

★ Engine Gasket Set – Reference 358
 Δ Valve Gasket Set – Reference 1095

◆□♣ Carburetor Overhaul Kit – Reference 121, 121A or 121B


433400



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
5	825681	Head-Cylinder (Used After Code Date 04083100). ----- Note ----- 825545 Head-Cylinder (Used Before Code Date 04090100).	21	825024	Cap-Oil Fill	1011	821003	Tube-Vent Used on Type No(s). 0116, 0216.
7	★Δ820650	Gasket-Cylinder Head	127	820004	Plug-Welch	1022	★Δ820150	Gasket-Rocker Cover
11	820048	Tube-Breather Used on Type No(s). 0115, 0215. ----- Note ----- 820886 Tube-Breather Used on Type No(s). 0217, 0317.	127A	820005	Plug-Welch	1023	825277	Cover-Rocker (Order Reference 1019, Label Kit and Reference 1036, Emissions Label for your Model, Type, Trim)
13	820623	Screw (Cylinder Head) (9 mm) (Used After Code Date 98123100). ----- Note ----- 820074 Screw (Cylinder Head) (8 mm) (Used Before Code Date 99010100).	151	820014	Stud (Exhaust Manifold)	1077	820260	Bracket-Lifting
			151A	820466	Stud (Exhaust Manifold)	1130	820015	Stud (Intake Manifold)
			276	★Δ820064	Washer-Sealing (Rocker Cover)	1170	820012	Screw (Ignition Coil)
			318	820024	Screw (Mounting Bracket)	1171	820076	Stud (Rocker Cover)
			337	491055	Plug-Spark			
			350	820078	Stud (Water Pump)			
			383	89838	Wrench-Spark Plug			
			493	820083	Bracket-Mounting (Ignition Coil)			
			635	820084	Boot-Spark Plug			
			700	820037	Coil-Ignition			
			729	820672	Clip-Wire			
			773	820130	Retainer (Valve Guide Bushing)			
			806	820024	Screw (Lifting Bracket)			
			812	820071	Nut (Rocker Cover)			
			871	825030	Bushing-Valve Guide			

★ Engine Gasket Set – Reference 358
Δ Valve Gasket Set – Reference 1095

◆□♣ Carburetor Overhaul Kit – Reference 121, 121A or 121B


433400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
50	825261	Manifold-Intake Used on Type No(s). 0115, 0215, 0217, 0317. ----- Note ----- 825260 Manifold- Intake Used on Type No(s). 0116, 0216.	654	820011	Nut (Carburetor)	918	820393	Hose-Vacuum (Carburetor to Manifold) Used on Type No(s). 0116, 0216.
51	★◆820087	Gasket-Intake (Intake Manifold)	855	820446	Adaptor-Air Cleaner (Upward)	1011A	820184	Tube-Vent
53	820077	Stud (Carburetor)	855A	820284	Adaptor-Air Cleaner Used on Type No(s). 0115, 0215.	1061	820090	Cover-Outlet
54	820031	Screw (Intake Manifold)	855B	820578	Adapter-Air Cleaner (Parallel to Crankshaft)	1112	820543	Plug-Vent (Intake Manifold)
296	820553	Stud (Muffler)	883	△★820817	Gasket-Exhaust (Exhaust Manifold)	1112A	820576	Plug-Vent Used on Type No(s). 0116, 0216.
436	825055	Manifold-Exhaust	883A	★821001	Gasket-Exhaust (Muffler)	1174	820069	Nut (Intake Manifold)
601	820382	Clamp-Hose	909	820547	Valve-Vacuum Check Used on Type No(s). 0116, 0216.	1175	820034	Screw (Outlet Cover)
						1176	820010	Nut (Exhaust Manifold)

★ Engine Gasket Set – Reference 358
 △ Valve Gasket Set – Reference 1095

◆□♣ Carburetor Overhaul Kit – Reference 121, 121A or 121B


433400




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
51A	◆★820385	Gasket-Intake	125	825121	Carburetor Used on Type No(s). 0115, 0215.	187	825044	Line-Fuel
72	820487	Tube-Jet	131	825244	Kit-Throttle Shaft	231	◆820485	Screw (Choke Valve)
93	◆	Bushing-Throttle Shaft (Sold In Kit Only)	133	825240	Float-Carburetor	240	821026	Filter-Fuel
94	◆825241	Kit-Idle Mixture	137	◆820489	Gasket-Float Bowl	254	820491	Drain-Carburetor Bowl
95	◆820485	Screw (Throttle Valve)	141	825243	Kit-Choke Shaft	276A	◆692343	Washer-Sealing
98	825259	Kit-Idle Speed	142	821051	Nozzle-Carburetor (Used After Code Date 01073100).	387	825232	Pump-Fuel
104	◆690739	Pin-Float Hinge	----- Note ----- ◆820490 Nozzle-Carburetor (Used Before Code Date 01080100).			601A	820006	Clamp-Hose
105	◆820486	Valve-Float Needle				947	825377	Solenoid-Fuel
117	820540	Jet-Main (Standard)				975	825239	Bowl-Float
118	820488	Jet-Main (High Altitude) (2,400-6,600 Feet)				987	◆690734	Seal-Throttle Shaft
121	◆825238	Kit-Carburetor Overhaul				1091	◆691515	Cap-Limiter
122	◆820082	Spacer-Carburetor						

★ Engine Gasket Set - Reference 358
 △ Valve Gasket Set - Reference 1095

◆□♣ Carburetor Overhaul Kit - Reference 121, 121A or 121B




www.mymowerparts.com

433400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
51A	♣820385	Gasket-Intake	133A	825248	Float-Carburetor	947B	825677	Solenoid-Fuel
94A	♣825374	Kit-Idle Mixture	137A	♣820508	Gasket-Float Bowl			Used on Type No(s). 0217.
95A	♣820504	Screw	141B	825613	Kit-Choke Shaft			(Used After Code Date 01073100).
		(Throttle Valve)	168	♣820603	Jet-Idle Circuit			----- Note -----
98A	♣825250	Kit-Idle Speed			(Used After Code Date 98033100).			825255 Solenoid-Fuel
104A	♣693506	Pin-Float Hinge	187	825044	Line-Fuel			Used on Type No(s). 0116, 0216, 0217.
105A	♣820506	Valve-Float Needle	231A	♣820504	Screw			(Used Before Code Date 01080100).
117B	825615	Jet-Main			(Choke Valve)	955	♣820510	Plug-Carburetor
		(Standard)	240	821026	Filter-Fuel			(Slow Passage)
121B	♣825441	Kit-Carburetor	276B	♣820511	Washer-Sealing	955A	♣820520	Plug-Carburetor
		Overhaul	387	825232	Pump-Fuel			(Jet)
122	♣820082	Spacer-Carburetor	601A	820006	Clamp-Hose	975A	825247	Bowl-Float
125B	825585	Carburetor	630	825292	Lever/Plate-Throttle			
		Used on Type No(s). 0217, 0317.			(To Replace Throttle Shaft, Order Corresponding Carburetor)			
		(Used After Code Date 01073100).						

★ Engine Gasket Set – Reference 358
 △ Valve Gasket Set – Reference 1095


◆□♣ Carburetor Overhaul Kit – Reference 121, 121A or 121B

433400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
33	820114	Valve-Exhaust	192	825688	Adjuster-Rocker Arm (Used After Code Date 04083100). ----- Note ----- 825041 Adjuster-Rocker Arm (Used Before Code Date 04090100).	773	820130	Retainer (Valve Guide Bushing)
34	820115	Valve-Intake				773A	820003	Retainer (Rocker Arm Shaft)
35	820406	Spring-Valve (Intake) (Used After Code Date 04083100). ----- Note ----- 820043 Spring-Valve (Intake) (Used Before Code Date 04090100).	238	821214	Cap-Valve (Used After Code Date 04083100). ----- Note ----- 820113 Cap-Valve (Used Before Code Date 04090100).	1014	820105	Screw (Rocker Arm Support)
36	820406	Spring-Valve (Exhaust) (Used After Code Date 04083100). ----- Note ----- 820043 Spring-Valve (Exhaust) (Used Before Code Date 04090100).	371	820613	Gear-Cam (Right Helix) (Used After Code Date 98123100). ----- Note ----- 820119 Gear-Cam (Left Helix) (Used Before Code Date 99010100).	1026	821216	Rod-Push (Used After Code Date 04083100). ----- Note ----- 820109 Rod-Push (Used Before Code Date 04090100).
42	825042	Keeper-Valve	553	820111	Retainer-Valve Spring	1029	820387	Rocker Arm
42A	825082	Keeper-Valve	668	820065	Spacer (Rocker Arm Shaft)	1030	820106	Support-Rocker Arm
45	820110	Tappet-Valve				1031	825093	Shaft-Rocker Arm
46	820388	Camshaft				1060	820044	Spring-Rocker Shaft
146	691639	Key-Timing				1074	820118	Retainer-Camshaft
						1178	820032	Screw (Camshaft Retainer)
						1179	820177	Washer (Rocker Arm Support)
						1180	820070	Nut (Rocker Arm Support)
						1290	820075	Screw (Cam Gear)
						1358	820112	Seat-Valve Spring

★ Engine Gasket Set – Reference 358
 Δ Valve Gasket Set – Reference 1095


◆□♣ Carburetor Overhaul Kit – Reference 121, 121A or 121B

433400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
15	825278	Plug-Oil Drain (16 mm)	479	820034	Screw (Oil Pump Screen)	1017	825089	Screen-Oil Pump
		----- Note -----	848	820069	Nut (Oil Pump Screen)	1039	820034	Screw (Oil Pan)
		825043 Plug-Oil Drain (12 mm)	941	820017	Stud (Oil Pan)	1041	★820104	Gasket-Oil Strainer
276C	★820582	Washer-Sealing (Oil Drain Plug) (16 mm)	952	820068	Nut (Oil Pan)	1078	★820137	Gasket-Oil Pan
		----- Note -----				1088	825285	Pan-Oil (Dual Drain) (16 mm)
		★820049 Washer-Sealing (Oil Drain Plug) (12 mm)						

★ Engine Gasket Set – Reference 358
 Δ Valve Gasket Set – Reference 1095


◆□♣ Carburetor Overhaul Kit – Reference 121, 121A or 121B

433400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
3	★821071	Seal-Oil (Magneto Side)	86	825119	Cover-Gear Used on Type No(s). 0115, 0116, 0215, 0216, 0217, 0317. (Used After Code Date 98033100). ----- Note ----- 825046 Cover-Gear Used on Type No(s). 0116. (Used Before Code Date 98040100).	88	★820148	Gasket-Gear Reduction Cover
85	820026	Screw (Gear Cover to Gear Reduction Case)				691	820054	Seal-Governor Shaft Used on Type No(s). 0116. (Used Before Code Date 98040100).
85A	820029	Screw (Gear Cover to Gear Reduction Case)				1173	820069	Nut (Gear Cover)
85B	820027	Screw (Gear Cover to Gear Reduction Case)						

★ Engine Gasket Set – Reference 358
 △ Valve Gasket Set – Reference 1095


◆□♣ Carburetor Overhaul Kit – Reference 121, 121A or 121B

433400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
88	★820148	Gasket-Gear Reduction Cover	249	825032	Valve-Pressure Relief	1024		Pump-Oil (Sold in Gear Housing Only, Reference 115)
88A	★820155	Gasket-Gear Reduction Cover	743	820615	Gear-Drive (Used After Code Date 98123100).	1189	820156	Stud (Gear Housing)
115	825120	Housing-Gear Used on Type No(s). 0115, 0116, 0215, 0216, 0217, 0317. (Used After Code Date 98033100).	----- Note -----			1190	820180	Screw (Drive Gear)
		----- Note -----		820121	Gear-Drive (Used Before Code Date 99010100).	1191	820030	Screw (Gear Housing)
		825059 Housing-Gear Used on Type No(s). 0116. (Used Before Code Date 98040100).	818	820016	Stud (Oil Pump Screen)	1191A	820033	Screw (Gear Housing)

★ Engine Gasket Set – Reference 358
 Δ Valve Gasket Set – Reference 1095


◆□♣ Carburetor Overhaul Kit – Reference 121, 121A or 121B

433400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
77	820209	Motor-Servo	265	691024	Clamp-Casing	493B	820876	Bracket-Mounting
188	820174	Screw (Control Bracket)	267	820229	Screw (Casing Clamp)	813	820047	Clamp
212	820226	Link-Throttle	318A	820034	Screw (Mounting Bracket)	992	820228	Screw (Servo Motor)
222	825062	Bracket-Control Used on Type No(s). 0116. (Used Before Code Date 98030100).				1048	825284	Module-Electronic Governor (Diode and Instructions Included) Used on Type No(s). 0216, 0217, 0317.
232	820227	Spring-Governor Link				1085	821082	Module-Ignition
259	820224	Bracket-Casing Clamp Used on Type No(s). 0115, 0215, 0217, 0317.				1086	825009	Trigger-Ignition
						1181	820029	Screw (Ignition Trigger)
						1181A	820013	Screw (Ignition Trigger)

★ Engine Gasket Set – Reference 358
 Δ Valve Gasket Set – Reference 1095


◆□♣ Carburetor Overhaul Kit – Reference 121, 121A or 121B

433400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
49	820590	Sensor-Water Temperature Used on Type No(s). 0116, 0216, 0217, 0317.	415A	820052	Plug (Outlet Housing)	1065	★820098	Gasket-Inlet Housing
291	825064	Thermostat	415B	820182	Plug (Water Pump)	1066	825051	Housing-Inlet
323	820239	Belt-Vee (925 mm) Used on Type No(s). 0217, 0317.	519	820034	Screw (Radiator Fan)	1067	★820100	Gasket-Water Pump
		----- Note -----	839	825076	Fan-Radiator	1087	825275	Pump-Water
		820288 Belt-Vee (915 mm) Used on Type No(s). 0115, 0116, 0215, 0216.	1062	★820093	Gasket-Outlet Housing	1185	820031	Screw (Outlet Housing)
368	820208	Switch-Water Temperature	1063	820095	Pulley-Pump	1186	820022	Screw (Water Pump)
			1064	825074	Housing-Outlet Used on Type No(s). 0217, 0317.	1187	820181	Nut (Water Pump)
					----- Note -----	1188	820031	Screw (Inlet Housing)
					825267 Housing- Outlet Used on Type No(s). 0116, 0216.	1193	820185	Screw (Thermostat)

★ Engine Gasket Set – Reference 358
 Δ Valve Gasket Set – Reference 1095


◆□♣ Carburetor Overhaul Kit – Reference 121, 121A or 121B

433400**0.8 KW RED LABEL****697**

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
309	825095	Motor-Starter	697	820019	Screw (Drive Cap)	893	820805	Nut (Starter Solenoid) (Terminal)
310	820807	Screw (Starter Motor)	703	820803	Clip	893A	820067	Nut (Starter Solenoid) (Terminal)
311	825411	Brush Set	722	820801	Seal-Plunger	899	820811	Washer (Starter Solenoid) (Terminal)
388	820799	Lever-Pinion Drive	773B	825420	Retainer (Starter Drive)	920	825418	Solenoid-Starter
510	820789	Drive-Starter	801	820791	Cap-Drive	1090	825412	Retainer-Brush
544	825414	Armature-Starter	802	825416	Cap-End	1112B	820797	Plug-Vent (End Cap)
683	820813	Nut (Starter Solenoid) (Terminal)	803	820783	Housing-Starter			
683A	820809	Nut (Starter Solenoid) (Terminal)						

★ Engine Gasket Set – Reference 358
 Δ Valve Gasket Set – Reference 1095






◆□♣ Carburetor Overhaul Kit – Reference 121, 121A or 121B

433400**40 AMP**

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
312	820692	Housing-Brush End	699	825390	Rotor Assembly	1201	820715	Screw (Brush Cover)
314	820711	Pulley-Alternator	890B	820213	Bracket-Support	1202	820701	Screw (Brush Retainer)
379	820703	Cover-Brush	1010	825384	Retainer-Bearing	1202A	820702	Screw (Brush Retainer)
474	825084	Alternator (40 Amp)	1090A	825387	Retainer-Brush	1203	820702	Screw (Stator Wire)
475	825385	Rectifier	1119	820483	Screw (Alternator)	1204	820705	Nut (Alternator Pulley)
501	825388	Regulator	1119A	820270	Screw (Alternator)	1205	820707	Screw (Brush End Housing)
526	820702	Screw (Regulator)	1150	820023	Screw (Adjusting Strap)	1206	820709	Nut (Brush End Housing)
530	825383	Housing-Drive End	1151	820066	Washer (Adjusting Strap)	1306	820781	Nut (Rectifier)
606	820819	Strap-Adjusting				1307	820690	Stud (Drive End Housing)
636	820069	Nut (Starting Switch)						
652A	820275	Screw (Support Bracket)						
668A	820713	Spacer (Rotor Assembly)						

★ Engine Gasket Set – Reference 358
 △ Valve Gasket Set – Reference 1095


◆□♣ Carburetor Overhaul Kit – Reference 121, 121A or 121B

433400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
318B	820212	Screw (Mounting Bracket)	534	820273	Screw (Air Cleaner)	1315	820554	Hose-Air Cleaner
445	820263	Filter-Air Cleaner Cartridge	536	825117	Cleaner-Air (With Vacuum Adaptor)	1315A	820555	Hose-Air Cleaner
493C	820195	Bracket-Mounting (Air Cleaner)	536A	825118	Cleaner-Air (90 Degree Elbow With Vacuum Adaptor)	1315B	820556	Hose-Air Cleaner
532	820070	Nut (Mounting Bracket)	582	820230	Clamp-Air Cleaner			

★ Engine Gasket Set – Reference 358
 Δ Valve Gasket Set – Reference 1095







◆□♣ Carburetor Overhaul Kit – Reference 121, 121A or 121B

433400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
139	820190	Support-Radiator (Right Hand)	652B	820452	Screw (Support Bracket)	1101	820272	Screw (Radiator Support)
139A	820191	Support-Radiator (Left Hand)	652C	820273	Screw (Support Bracket)	1101A	820309	Screw (Radiator Support)
140	820255	Bracket-Radiator (Front)	668B	820307	Spacer (Radiator Mount)	1114	820070	Nut (Radiator Support)
140A	820192	Bracket-Radiator (Right Hand)	668C	820198	Spacer (Radiator Mount)	1115	820296	Washer (Radiator Support)
140B	820193	Bracket-Radiator (Left Hand)	890C	820194	Bracket-Support (Radiator)	1116	820023	Screw (Radiator Bracket) (Used With Engine Mounts And Radiator Brackets)
140C	820294	Bracket-Radiator				1116A	820174	Screw (Radiator Bracket)
260	820220	Shroud-Fan (320 mm) Used on Type No(s). 0217, 0317.				1221	820636	Screw (Fan Shroud)
						1228	825135	Mount-Radiator

★ Engine Gasket Set – Reference 358
 Δ Valve Gasket Set – Reference 1095




◆□♣ Carburetor Overhaul Kit – Reference 121, 121A or 121B

433400

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
194	825068	Radiator (Copper) Used on Type No(s). 0217, 0317.	493D	825106	Bracket-Mounting (Radiator)	1068	825134	Hose/Clamp Assembly (Outlet)
253	825462	Tank-Reserve	532A	820011	Nut (Mounting Bracket)	1068A	825133	Hose/Clamp Assembly (Inlet)
318A	820034	Screw (Mounting Bracket)	601B	820256	Clamp-Hose	1068B	825296	Hose/Clamp Assembly
415C	825075	Plug (Radiator)	601C	820201	Clamp-Hose	1097	820287	Cap-Surge Tank
			734	820258	Cap-Radiator	1237	825461	Cap/Hose Reserve

★ Engine Gasket Set – Reference 358
 Δ Valve Gasket Set – Reference 1095




◆□♣ Carburetor Overhaul Kit – Reference 121, 121A or 121B

433400**SAE****GENERAL MOUNTING****SAE MOUNTING**

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
318	820024	Screw (Mounting Bracket) (Used With Engine Mounts Only)	465	820449	Washer (Mounting Bracket)	494	825214	Mount-Engine (General Mounting)
318C	820023	Screw (Mounting Bracket) (Use Only When Front Engine Mounts And Radiator Brackets Are Installed)	493E	820835	Bracket-Mounting (Front Right) (General and SAE)	494A	825215	Mount-Engine (SAE Mounting)
318D	820306	Screw (Mounting Bracket)	493F	820832	Bracket-Mounting (Front Left) (General and SAE)			
			493G	820833	Bracket-Mounting (Rear General)			
			493H	820834	Bracket-Mounting (Rear SAE)			

★ Engine Gasket Set – Reference 358
 Δ Valve Gasket Set – Reference 1095











◆□♣ Carburetor Overhaul Kit – Reference 121, 121A or 121B



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
264	820178	Nut (Muffler Adapter)	622	820631	Washer (Heat Shield)	728	821011	Screw (Heat Shield)
300	825200	Muffler	725	820628	Shield-Heat	728A	820431	Screw (Heat Shield)
300A	825550	Muffler	725A	820629	Shield-Heat	837	820867	Spacer-Muffler
613	820023	Screw (Muffler)	725B	820630	Shield-Heat	864	825358	Adapter-Muffler
						883A	821001	Gasket-Exhaust (Muffler)

★ Engine Gasket Set – Reference 358
 △ Valve Gasket Set – Reference 1095




◆□♣ Carburetor Overhaul Kit – Reference 121, 121A or 121B

433400**358 ENGINE GASKET SET****1095 VALVE GASKET SET**

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
3	★8201071	Seal-Oil (Magneto Side)	358	825378	Gasket Set-Engine	1080	★820145	Gasket-Seal Retainer
7	★△820650	Gasket-Cylinder Head	691	★820054	Seal-Governor Shaft	1084	825154	Connector-Terminal
20	★821073	Seal-Oil (PTO Side)	868	★△820041	Seal-Valve	1084A	825155	Connector-Terminal
51	△★820087	Gasket-Intake (Intake Manifold)	883	★△820817	Gasket-Exhaust (Exhaust Manifold)	1084B	825156	Connector-Terminal
51A	★820385	Gasket-Intake	883A	★821001	Gasket-Exhaust (Muffler)	1084C	825157	Connector-Terminal
88	★820148	Gasket-Gear Reduction Cover	1022	★△820150	Gasket-Rocker Cover	1084D	825158	Connector-Terminal
88A	★820155	Gasket-Gear Reduction Cover	1041	★820104	Gasket-Oil Pump Screen	1084E	825160	Connector-Terminal
276	★△820064	Washer-Sealing (Rocker Cover)	1062	★820093	Gasket-Outlet Housing	1084F	825162	Connector-Terminal
276C	★820582	Washer-Sealing (Oil Drain Plug) (16 mm)	1065	★820098	Gasket-Inlet Housing	1084G	825163	Connector-Terminal
----- Note -----			1067	★820100	Gasket-Water Pump	1095	825379	Gasket Set-Valve
★820049 Washer-Sealing (Oil Drain Plug) (12 mm)			1078	★820137	Gasket-Oil Pan			

★ Engine Gasket Set – Reference 358
 △ Valve Gasket Set – Reference 1095

◆□♣ Carburetor Overhaul Kit – Reference 121, 121A or 121B

**1058 OPERATOR'S MANUAL****1330 REPAIR MANUAL****1019A****1036**

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1019	825617	Kit-Label (Used After Code Date 02033100).	1036	825620	Label-Emissions (Used After Code Date 01073100).	1040	820290	Plate-Trim
1019A	820289	Kit-Label (Used Before Code Date 02040100).			----- Note -----	1058	820883	Operator's Manual
					825623 Label-Emissions (Used Before Code Date 01080100 and After Code Date 99123100).	1319	821160	Label-Warning
					825281 Label Emissions (Used Before Code Date 00010100).	1330	MS0750	Repair Manual

★ Engine Gasket Set – Reference 358
 △ Valve Gasket Set – Reference 1095

◆□♣ Carburetor Overhaul Kit – Reference 121, 121A or 121B