

44Q700

Illustrated Parts List

Model Series

44Q700

TYPE NUMBERS
0025 through 0505.

TABLE OF CONTENTS

Air Cleaner 6

Alternators 8

Blower Housing/Shrouds 6

Camshaft 3

Carburetor 5

Controls 7

Crankcase Cover/Sump 2

Crankshaft 3

Cylinder 2

Cylinder Head 4

Electric Starter 7

Exhaust System 5

Flywheel 7

Ignition 8

Kit/Gasket Set – Carburetor 5

Gasket Set – Engine 2

Gasket Set – Valve 4

Lubrication 3

Piston, Rings, Connecting Rod 3





Valves 4





PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
 All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.






44Q700




1058 OPERATOR'S MANUAL
1330 REPAIR MANUAL



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.




24 ⌋










Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

44Q700




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

44Q700



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
3533-6 Assemblies include all parts shown in frames.


11/22/2005







Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

44Q700

10 - 16 AMP	
474B	1059
877B 	
578A 	
526B  501B 	

NOTE: All stators use a No. 1119 mounting screw. 

NOTE: The proper flywheel part number and/or the alternator magnet size will determine the alternator type or output. See repair instruction manual for additional information.



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

44Q700

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	699753	Cylinder Assembly	25	792023	Piston Assembly (Standard)	54	699816	Screw (Intake Manifold)
2	499585	Kit-Bushing/Seal (Magneto Side)			----- Note -----	73	494439	Screen-Rotating
3	★391086s	Seal-Oil (Magneto Side)			792072 Piston Assembly (.020" Oversize)	74	698425	Screw (Rotating Screen)
4	699747	Sump-Engine	26	792026	Ring Set (Standard)	75	691056	Washer (Flywheel)
5	792299	Head-Cylinder (Cylinder 1)			----- Note -----	95	690718	Screw (Throttle Valve)
5A	792300	Head-Cylinder (Cylinder 2)			792073 Ring Set (.020" Oversize)	98	699721	Kit-Idle Speed
7	★Δ693997	Gasket-Cylinder Head	27	690975	Lock-Piston Pin	104	●694918	Pin-Float Hinge
8	792185	Breather Assembly	28	690229	Pin-Piston (Standard)	105	●698537	Valve-Float Needle
9	★690937	Gasket-Breather	29	699699	Rod-Connecting (Standard)	108	699723	Valve-Choke
10	691108	Screw (Breather Assembly)	32	690976	Screw (Connecting Rod)	117	699733	Jet-Main (Standard)
11	792184	Tube-Breather	33	697576	Valve-Exhaust			(Left)(Nikki)
12	★697227	Gasket-Crankcase	34	792200	Valve-Intake	117A	792296	Jet-Main (Standard)
13	791130	Screw (Cylinder Head)	35	694865	Spring-Valve (Intake)			(Right)(Nikki)
15	690946	Plug-Oil Drain	36	694865	Spring-Valve (Exhaust)	121	792455	Kit-Carburetor Overhaul
16	790132	Crankshaft	42	499586	Keeper-Valve	125	792295	Carburetor
		----- Note -----	45	690977	Tappet-Valve			
		790136 Crankshaft Used on Type No(s). 0025.	46	791235	Camshaft			
		699700 Crankshaft Used on Type No(s). 0027.	50	695241	Manifold-Intake			
20	★791892	Seal-Oil (PTO Side)	51★●◆791677		Gasket-Intake			
22	694966	Screw (Crankcase Cover/Sump)	53	690951	Stud (Carburetor)			
23	691053	Flywheel						
24	222698s	Key-Flywheel						

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

Δ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

44Q700

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
130	690993	Valve-Throttle	265	691024	Clamp-Casing	383	19374s	Wrench-Spark Plug
131	499805	Kit-Throttle Shaft	267	691044	Screw (Casing Clamp)	385	691108	Screw (Fuel Pump)
133	◆699724	Float-Carburetor			Used on Type No(s). 0025, 0027.	387	808656	Pump-Fuel
135	◆699729	Tube-Fuel Transfer				404	690442	Washer (Governor Crank)
137	◆690994	Gasket-Float Bowl	267A	695134	Screw (Casing Clamp)	405A	697820	Screw-Backplate (Mounting)
141	699722	Kit-Choke Shaft			Used on Type No(s). 0026, 0471, 0505.	415	690283	Plug
142	◆699726	Nozzle-Carburetor (Standard)	268	691025	Casing-Control Wire (Cut To Required Length)	418	690999	Plate-Carburetor
146	690979	Key-Timing	269	691026	Wire-Control (Cut To Required Length)	431	792297	Elbow-Intake
150	◆690995	Gasket-Nozzle	270	691027	Nut (Control Wire Casing)	445	792105	Filter-Air Cleaner Cartridge
163	◆★△691001	Gasket-Air Cleaner	271	691028	Lever-Control	447	691003	Screw (Air Guide Cover)
165	693148	Nut (Ring Gear)	276	◆◆695410	Washer-Sealing	447A	691108	Screw (Air Guide Cover)
187	791881	Line-Fuel (Molded)	278	792651	Washer (Governor Control Lever)	467A	790697	Knob-Air Cleaner
187A	791801	Line-Fuel (Molded)	280	691526	Bracket-Rod	474B	696458	Alternator (10-16 Amp Circuit)
187B	791766	Line-Fuel (15" Long, Cut to Required Length)	287	691108	Screw (Dipstick Tube)	501B	691185	Regulator (16 Amp Circuit)
188	691108	Screw (Control Bracket)	304	792301	Housing-Blower (Black)	505	691029	Nut (Governor Control Lever)
192	690083	Adjuster-Rocker Arm	305	691005	Screw (Blower Housing)	510	696541	Drive-Starter
206	691244	Nut-Governor Adjusting	305B	790690	Screw (Blower Housing to Intake Elbow)	513	692024	Clutch-Drive
208	690566	Rod-Governor Control			(11/16" Long)	523	691036	Dipstick
209	697674	Spring-Governor (Brown)	309	499521	Motor-Starter	524	★691032	Seal-Dipstick Tube
		----- Note -----	310	691263	Screw (Starter Motor)	525	691037	Tube-Dipstick
		691018 Spring-Governor (No Color) Used on Type No(s). 0505.	311	497608	Brush Set	526B	691108	Screw (Regulator)
211	691019	Spring-Governed Idle	332	691059	Nut (Flywheel)	544		Armature-Starter (Served By 499521 Starter Motor Only)
212	695238	Link-Throttle	333	691060	Armature-Magneto	552	690552	Bushing-Governor Crank
213	691021	Bracket-Choke Control	334	691061	Screw (Magneto Armature)	552A	690553	Bushing-Governor Crank
216	691022	Link-Choke	337	491055s	Plug-Spark	562	690311	Bolt (Governor Control Lever)
219	698231	Gear-Governor			----- Note -----	573	790444	Plate-Back
220	690412	Washer (Governor Gear)			691043 Plug-Spark Used on Type No(s). 0505.	578A	691208	Wire Assembly
221	841026	Cup-Governor	358A	694012	Gasket Set-Engine			
222	698761	Bracket-Control	363	19203	Puller-Flywheel			
227	792492	Lever-Governor Control						
231	690718	Screw (Choke Valve)						
239	792028	Switch-Oil Pressure (Normally Closed)						
240	695666	Filter-Fuel						
250	690957	Retainer-Breather						
252	690956	Collector-Oil						

★ Included in Engine Gasket Set-Ref. No.358.

◆ Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

44Q700

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
579	691029	Nut (Starter Cable)	797	693167	Nut (Brush Retainer)	1023	499599	Cover-Rocker (Cylinder 1)
601	691038	Clamp-Hose (Green)	798	697890	Screw (Rocker Arm)	1023A	499600	Cover-Rocker (Cylinder 2)
613	690341	Screw (Muffler)	801	691283	Cap-Drive	1024	499054	Pump-Oil
615	698290	Retainer-Governor Shaft	802	691286	Cap-End	1026	690981	Rod-Push (Steel)
616	691045	Crank-Governor	803		Housing-Starter (Serviced By 499521 Starter Motor Only)	1026A	690982	Rod-Push (Aluminum)
617	697891	Seal-O Ring (Intake Manifold)	842	*691031	Seal-O Ring (Dipstick Tube)	1027	696854	Filter-Oil
628	691108	Screw (Fuel Pump Bracket)	847	499602	Dipstick/Tube Assembly	1029	690972	Arm-Rocker
633	◆690998	Seal-Choke/Throttle Shaft	851	493880s	Terminal-Spark Plug	1035	691042	Shaft-Pump
635	66538s	Boot-Spark Plug	865	691012	Cover-Air Guide (Cylinder 1)	1036		Label-Emissions (Available from an Authorized Briggs and Stratton Service Dealer)
654	690958	Nut (Carburetor)	865A	691014	Cover-Air Guide (Cylinder 2)	1040	791237	Plate-Trim
668	△691215	Spacer	865B	792286	Cover-Air Guide (Valley)	1051	691265	Ring-Retaining
672	◆690234	Gasket-Carburetor Plate	868	*690968	Seal-Valve	1054	280275	Tie-Cable
691	*790574	Seal-Governor Shaft	877B	399916	Wire/Connector- Alternator	1058	276352	Operator's Manual (Emission)
695	693149	Screw (Ring Gear)	883	*△690970	Gasket-Exhaust	1059	698516	Kit-Screw/Washer
697	690372	Screw (Drive Cap)	914	691127	Screw (Rocker Cover)	1070	691058	Screw (Flywheel Fan)
703	691010	Clip	918	694000	Hose-Vacuum	1090	691293	Retainer-Brush
718	690959	Pin-Locating	929	695239	Screw (Choke Control Bracket)	1095	694013	Gasket Set-Valve
726	499612	Gear-Ring	943	*690589	Seal-O Ring (Oil Pump Cover)	1100	791959	Pivot-Rocker Arm
729	694123	Clip-Wire	947	841546	Solenoid-Fuel	1119	691183	Screw (Alternator)
741	690980	Gear-Timing	965	499613	Cover-Oil Pump	1123	◆841653	Seal-O Ring (Solenoid Retainer)
742	690328	Retainer-E Ring	967	792303	Filter-Pre Cleaner	1124	◆690988	Seal-O Ring (Fuel Transfer Tube)
750	696999	Screw (Oil Pump Cover)	968	792289	Cover-Air Cleaner	1126	◆690991	Screw (Fuel Transfer Tube)
783	695708	Gear-Pinion	975	791232	Bowl-Float	1127	◆695407	Screw (Float Bowl)
788	691039	Bracket-Fuel Pump	977	792456	Gasket Set-Carburetor	1128	◆690990	Screw (Carburetor Nozzle)
789A	790544	Harness-Wiring	987	◆691000	Seal-Throttle Shaft	1169	690990	Screw (Carburetor Cover Plate)
789B	698330	Harness-Wiring	1005	791236	Fan-Flywheel	1330	273521	Repair Manual
789C	696576	Harness-Wiring	1013	690954	Nipple-Oil Filter			
789E	695050	Harness-Wiring	1017	690770	Screen-Oil Pump			
			1022	*△690971	Gasket-Rocker Cover			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.