



FORM MS-5131-08/31/2005
REPLACES FORM MS-5131-06/27/2005
FILE IN SECT. 2 OF SERVICE MANUAL

AA0101

Illustrated Parts List

Model Series


AA0101

TYPE NUMBER
0001, 0005, 0020, 0025.



TABLE OF CONTENTS

- Blower Housing/Cowl 5
- Cam 2
- Carburetor 4
- Carburetor Kit/Gasket Sets 6
- Controls 4
- Crankcase Cover/Sump 2
- Crankshaft 2
- Cylinder 2
- Cylinder Head 3
- Engine Gasket Set 6
- Flywheel 5
- Fuel Line/Filter/Pump 4
- Fuel Tank 7
- Gearcase 9
- Handles/Transom 7
- Ignition 5
- Midsection 8
- Muffler 2
- Oil 2
- Piston 2
- Rewind 5
- Valves 3
- Valve Gasket Set 6




PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted,
in any form or by any means, electronic or mechanical, including photocopying,
recording or by any information storage and retrieval system, without permission
in writing from Briggs & Stratton Corporation.

AA0101

1058 OPERATOR'S MANUAL



1330 REPAIR MANUAL



5131-2


Assemblies include all parts shown in frames.

08/31/2005






AA0101

WITHOUT REV LIMITER





WITH REV LIMITER





- 3051A
- 3077
- 703B




1019 LABEL KIT


1036 Emissions Label
EPA

1036A Emissions Label
California Two Star

1036B Emissions Label
California One Star



3051



305



332







3004B
CAMOUFLAGE




334



AA0101







5131-7

Assemblies include all parts shown in frames.

08/31/2005

AA0101





AA0101

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	697893	Cylinder Assembly	29	499424	Rod-Connecting	146	690979	Key-Timing (Used Before Code Date 04060900).
2	399269	Kit-Bushing/Seal (Magneto Side)	32	691664	Screw (Connecting Rod) (1" Long)	163	691894	Gasket-Air Cleaner
3	299819	Seal-Oil (Magneto Side)	32A	695759	Screw (Connecting Rod) (1 1/2" Long)	186	861190	Connector-Hose
4	696340	Sump-Engine	33	499642	Valve-Exhaust	187	691050	Line-Fuel (Cut To Required Length)
5	695276	Head-Cylinder	34	499641	Valve-Intake	187A	697895	Line-Fuel (Molded)
7	697230	Gasket-Cylinder Head	35	691304	Spring-Valve (Intake)	188	691147	Screw (Control Bracket)
8	495786	Breather Assembly	36	691304	Spring-Valve (Exhaust)	192	694543	Adjuster-Rocker Arm
9	699833	Gasket-Breather	37	694086	Guard-Flywheel	212	861184	Link-Throttle
10	691125	Screw (Breather Assembly)	40	692194	Retainer-Valve	222	861183	Bracket-Control
11	499675	Tube-Breather	45	690977	Tappet-Valve	238	691300	Cap-Valve
11A	692937	Tube-Breather	46	694039	Camshaft	240	394358	Filter-Fuel
12	692232	Gasket-Crankcase	47	697732	Slinger-Oil	259	691189	Bracket-Casing Clamp
13	691137	Screw (Cylinder Head)	51	697735	Gasket-Intake	265	691024	Clamp-Casing (Throttle Cable)
15	691680	Plug-Oil Drain	51A	699144	Gasket-Intake (Contains 2)	267	691044	Screw (Casing Clamp)
16	692824	Crankshaft	51B	692668	Gasket-Intake	276	271716	Washer-Sealing
20	399781	Seal-Oil (PTO Side)	55	691421	Housing-Rewind Starter	287	690940	Screw (Dipstick Tube)
22	691092	Screw (Crankcase Cover/Sump)	58	693389	Rope-Starter (Cut To Required Length)	300	699769	Muffler
23	699488	Flywheel	60	697742	Grip-Starter Rope	304	861188	Housing-Blower
24	222698	Key-Flywheel	65	690837	Screw (Rewind Starter)	305	691108	Screw (Blower Housing)
25	791968	Piston Assembly (Standard) (Used After Code Date 04040400).	78	691108	Screw (Flywheel Guard)	306	691232	Shield-Cylinder
		Note -----	94	697916	Kit-Idle Mixture	307	690345	Screw (Cylinder Shield)
		690021 Piston Assembly (Standard) (Used Before Code Date 04040500).	95	691636	Screw (Throttle Valve)	324	695161	Screen/Cup Assembly
		694168 Piston Assembly (.020" Oversize) (Used Before Code Date 04040500).	97	499682	Shaft-Throttle	332	690662	Nut (Flywheel)
			98	398185	Kit-Idle Speed	333	802574	Armature-Magneto
			104	691242	Pin-Float Hinge	334	691061	Screw (Magneto Armature)
			105	691782	Valve-Float Needle	337	692051	Plug-Spark
			108	691182	Valve-Choke	356	861294	Wire-Stop
			109	499681	Shaft-Choke	358	698156	Gasket Set-Engine
26	791969	Ring Set (Standard) (Used After Code Date 04040400).	111	861583	Pin-Retainer (Used After Code Date 03011900).	363	19069	Puller-Flywheel
		Note -----	117	697355	Jet-Main (Standard)	365	699143	Screw (Carburetor)
		499631 Ring Set (Standard) (Used Before Code Date 04040500).	118	694250	Jet-Main (High Altitude)	383	19374	Wrench-Spark Plug
		692786 Ring Set (.020" Oversize) (Used Before Code Date 04040500).	121	698155	Kit-Carburetor Overhaul	387	808656	Pump-Fuel
			125	697736	Carburetor	415	861217	Plug (Drive Shaft Housing)
			127	691739	Plug-Welch	456	692299	Plate-Pawl Friction
			130	691181	Valve-Throttle	459	281505	Ratchet-Pawl
27	691866	Lock-Piston Pin	133	398187	Float-Carburetor	480	691108	Screw (Tube Clamp)
28	499423	Pin-Piston	137	693981	Gasket-Float Bowl	493	861311	Bracket-Mounting (Valve Cover)
						523	698175	Dipstick (24 Ounces)

* Engine Gasket Set-Reference Number 358

● Carburetor Overhaul Kit-Reference Number 121

◆ Carburetor Gasket Set-Reference Number 977

△ Valve Gasket Set-Reference Number 1095

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
524	★692296	Seal-Dipstick Tube	684	690345	Screw (Breather Passage Cover)	842	★691031	Seal-O Ring (Dipstick Tube)
525	495265	Tube-Dipstick				847	698176	Dipstick/Tube Assembly
527	698467	Clamp-Tube	689	691855	Spring-Friction (Rewind Starter)	851	493880	Terminal-Spark Plug
529	861559	Grommet (Throttle Cable)	692	690572	Spring-Detent	868	★△692044	Seal-Valve
584	697734	Cover-Breather Passage	703	861202	Clip (Fuel Pump) (Used Before Code Date 03052300).	875	698003	Base-Air Cleaner
585	★691879	Gasket-Breather Passage				883	★△691893	Gasket-Exhaust
592	690800	Nut (Rewind Starter)	703A	861229	Clip (Fuel Fitting)	886	696268	Gasket Kit-Cylinder Head/Plate
597	691696	Screw (Pawl Friction Plate)	703B	861234	Clip (Cowl) (Used Before Code Date 03061600).	914	691108	Screw (Rocker Cover) (19/32" Long)
601	95162	Clamp-Hose				914A	691127	Screw (Rocker Cover) (13/16" Long)
608	697743	Starter-Rewind						
613	691108	Screw (Muffler)	718	690959	Pin-Locating	918	791766	Hose-Vacuum (Cylinder to Impulse Pump) (Cut to Required Length)
613A	691140	Screw (Muffler)	741	790345	Gear-Timing (Used After Code Date 04060800).			
614	861215	Pin-Cotter (Tilt Rod)						
614A	861305	Pin-Cotter (Transmission Shift Lever) (Used Before Code Date 03012000).			----- Note ----- 691830 Gear-Timing (Used Before Code Date 04060900).	953	861312	Screen-Air Cleaner
619	691108	Screw (Cylinder Head Plate)	776	861324	Guide-Rope	958	698180	Valve-Fuel Shut Off
621	861552	Switch-Stop (Used After Code Date 03061500).	788	861526	Bracket-Fuel Pump (Without Limiter)	971	690255	Screw (Air Cleaner Base to Carburetor)
633	◆691321	Seal-Choke/Throttle Shaft (Throttle Shaft)	789	861553	Harness-Wiring (Used After Code Date 03061500).	975	493640	Bowl-Float
633A	◆693867	Seal-Choke/Throttle Shaft (Choke Shaft)	789A	861293	Harness-Wiring (Used Before Code Date 03061600).	977	698157	Gasket Set-Carburetor
635	692927	Boot-Spark Plug	830	694544	Stud-Rocker Arm	993	★△694088	Gasket-Cylinder Head Plate
668	861231	Spacer (Standoff) (Used Before Code Date 03061600).	832	861201	Guard-Muffler	1005	691346	Fan-Flywheel
			836	694593	Screw (Muffler Guard)	1011	698094	Tube-Vent (Carburetor)
			836A	691108	Screw (Muffler Guard)	1019	861336	Kit-Label
			836B	691140	Screw (Muffler Guard)	1022	★△691890	Gasket-Rocker Cover
						1023	692694	Cover-Rocker
						1026	692045	Rod-Push
						1029	691230	Arm-Rocker
						1034	691343	Guide-Push Rod

★ Engine Gasket Set-Reference Number 358

● Carburetor Overhaul Kit-Reference Number 121

◆ Carburetor Gasket Set-Reference Number 977

△ Valve Gasket Set-Reference Number 1095

AA0101

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1036	861685	Label-Emissions (Used After Code Date 04063000). ----- Note ----- 861499 Label-Emissions (Used After Code Date 03062900 and Before Code Date 04070100). 861325 Label-Emissions (Used After Code Date 02063000 and Before Code Date 03063000). ----- Note ----- 861317 Label-Emissions (Used Before Code Date 02070100).	1054	861206	Tie-Cable (Black) ----- Note ----- 280275 Tie-Cable (White)	1210	498144	Pulley/Spring Assembly (Pulley)
1036A	861556	Label-Emissions (Black) (California Two Star) (Used After Code Date 03092100). Used on Type No(s). 0001, 0005. 861556 Label-Emissions (Camouflage) (California Two Star) (Used After Code Date 03081100). Used on Type No(s). 0020, 0025.	1058	MS5682	Operator's Manual	1211	498144	Pulley/Spring Assembly (Spring)
1036B	861326	Label-Emissions (Black) (California One Star) (Used Before Code Date 03092200). Used on Type No(s). 0001, 0005. ----- Note ----- 861326 Label-Emissions (Camouflage) (California One Star) (Used Before Code Date 03081100). Used on Type No(s). 0020, 0025.	1091	281425	Cap-Limiter	1330	275110	Repair Manual
			1095	698158	Gasket Set-Valve	1343	861531	Nut (Stop Switch)
			1112	861281	Plug-Vent			

★ Engine Gasket Set-Reference Number 358

● Carburetor Overhaul Kit-Reference Number 121

◆ Carburetor Gasket Set-Reference Number 977

△ Valve Gasket Set-Reference Number 1095

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
3000	861185	Adapter/Seal-Crankshaft	3022	861263	Screw-Set	3044	861304	Spring-Transmission Lever
3001	861528	Tiller (Black)	3023	861252	Plate-Retainer (Throttle Rod)	3045	861306	Pin-Clevis
3001A	861529	Tiller (Camouflage)	3023A	861252	Plate-Retainer (Transmission Shift Lever)	3046	861530	Limiters-Rev
3002	861216	Rod-Tilt	3025	861246	Bracket-Transom (Port or Starboard) (Black)	3047	861253	Screw (Retainer Plate) (Throttle Rod)
3003	861230	Fitting-Fuel			----- Note -----	3047A	861253	Screw (Retainer Plate) (Transmission Shift Lever)
3004	861535	Cowl (Black) (Used After Code Date 03061500).			861582 Bracket-Transom (Port or Starboard) (Camouflage)	3048	861212	Screw (Lower Unit to Engine)
3004A	861527	Cowl (Black) (Used Before Code Date 03061600).	3026	861251	Pad-Friction	3049	861213	Nut (Lower Unit to Engine)
3004B	861536	Cowl (Camouflage)	3027	861227	Standoff (Air Cleaner Base) (Used Before Code Date 03061600).	3050	861297	Seal-O Ring (Fuel Fitting)
3006	861673	Propeller (Black)	3027A	861228	Standoff (Blower Housing)	3051	690940	Screw (Cowl) (Used After Code Date 03061500).
		----- Note -----	3028	861274	Carrier-Output Shaft	3051A	861233	Screw (Cowl) (Used Before Code Date 03061600).
		861576 Propeller (Camouflage)	3029	861278	Gear-Reverse	3052	861232	Screw (Cowl Cover) (Used Before Code Date 03061600).
3007	861674	Coupling-Propeller	3030	861277	Gear-Forward	3053	861295	Fuel Line/Primer Assembly
3008	861225	Washer/Nut Set (Propeller)	3031	861288	Shaft-Output	3054	861214	Screw (Housing Pivot)
3009	861226	Cable-Choke	3032	861285	Clutch/Pin Kit	3055	861260	Screw (Front Handle)
3010	861220	Spring-Drive Shaft	3033	861284	Rod-Cam	3056	861260	Screw (Rear Handle)
3011	861219	Handle-Front (Black)	3034	861272	Case-Gear (Black)	3057	861250	Screw (Tilt Bracket)
		----- Note -----			----- Note -----	3058	861253	Screw (Neutral Switch)
		861562 Handle-Front (Camouflage)	3035	861290	Seal-Cam Rod	3059	861250	Screw (Friction Pad)
3012	861265	Isolator	3036	861291	Seal-Quad Ring	3060	861282	Stud (Gear Case)
3013	861222	Pivot-Housing (Black)	3037	861286	Follower-Cam Shift	3061	861240	Washer (Gear Case)
		----- Note -----	3038	861269	Lever-Transmission Shift	3062	861241	Screw (Gear Case)
		861563 Pivot-Housing (Camouflage)	3039	861186	Housing-Drive Shaft (Black)			
3014	861451	Clamp-Shift Rod			----- Note -----			
3015	861242	Carrier-Input Shaft			861570 Housing-Drive Shaft (Camouflage)			
3016	861636	Hook-Reverse	3040	861301	Handle-Throttle			
3017	861262	Handle-Rear (Black)	3041	861299	Rod-Throttle			
		----- Note -----	3042	861560	Cable-Throttle			
		861561 Handle-Rear (Camouflage)	3043	861303	Handle-Transmission Shift (Black)			
3018	861264	Hook-Actuator			----- Note -----			
3019	861244	Clamp/Handle Kit			861571 Handle-Transmission Shift (Camouflage)			
3020	861249	Ring-Isolator						

★ Engine Gasket Set-Reference Number 358

● Carburetor Overhaul Kit-Reference Number 121

◆ Carburetor Gasket Set-Reference Number 977

△ Valve Gasket Set-Reference Number 1095

AA0101

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
3063	861241	Screw (Input Shaft Carrier)	3078	861239	Nut (Rear Handle)	3092	861253	Screw (Clamp Washer/Screw Set)
3066	861239	Nut (Gear Case)	3079	861239	Nut (Front Handle)	3093	861580	Bracket–Starboard Tilt (Camouflage) ----- Note -----
3067	861267	Seal–O Ring (Input Shaft Carrier)	3080	861239	Nut (Friction Pad)			861568 Bracket– Starboard Tilt (Black)
3068	861248	Bolt (Transom Bracket)	3081	861240	Washer (Transmission Shift Lever)	3094	861580	Bracket–Port Tilt (Camouflage) ----- Note -----
3069	861247	Washer (Transom Bracket)	3082	861266	Seal–Shaft (Input Shaft Carrier)			861568 Bracket– Starboard Tilt (Black)
3070	861255	Nut (Transom Bracket)	3082A	861266	Seal–Shaft (Output Shaft Carrier)			
3071	861309	Shaft–Drive	3083	861319	Rivet (Transmission Shift Lever)	3095	861644	Shield–Intake
3072	861275	Seal–O Ring (Output Shaft Carrier)				3096	861253	Screw (Intake Shield)
3073	861280	Plug–Oil Drain/Fill	3084	861310	Clamp Washer/Screw Set			
3075	861268	Seal–Crankshaft Adapter	3085	861283	Switch–Neutral			
3076	861239	Nut (Housing Pivot)	3086	861240	Washer (Throttle Rod)			
3077	861316	Washer (Cowl) (Used Before Code Date 03061600).	3087	861209	Lanyard			
			3088	861323	Rod–Shift			
			3089	861334	Strap–Ground			
			3090	861320	Gear–Pinion Drive			
			3091	861449	Tank–Fuel			

★ Engine Gasket Set–Reference Number 358

● Carburetor Overhaul Kit–Reference Number 121

◆ Carburetor Gasket Set–Reference Number 977

△ Valve Gasket Set–Reference Number 1095