

100700 to 100799

SERVICE ENGINE



SALES MANUAL

**MODEL 100700 SERIES ENGINES REPLACED WITH
 STANDARD SERVICE ENGINES**

In most cases, the Original Type numbers shown may be replaced by a Service Type Number without making any changes. Necessary changes of engine parts such as crankshafts, reduction parts, blower housings, etc., are noted. Other differences, such as mufflers, elbows, deflectors, etc., are not listed but are very important for safety and engine performance. Be sure the exhaust system on the replacement engine duplicates the system originally selected by the equipment manufacturer. Parts that are suitable for additional use should be transferred. Before making any conversion, check the data shown in the column labeled "REMOVE, ADD and NOTE." See if the changes, which are shown, are actually necessary on the application in question. Often a standard service engine will be a WORKABLE replacement without converting to such things as a special fuel tank or starter position.

If the crankshaft number does not appear in the "Original Engine" column, consult the Illustrated Parts List for the correct service replacement crankshaft number.

Engine Replacement Notes:

NOTE 51: Replacement engine listed is not available in the State of California. Repair with individual parts.

Short Block Notes:

The SHORT BLOCK part number shown, is the assembly which can be used to rebuild the Original Type Number. If a letter appears after the short block number, it indicates the short block must be modified. The change denoted by each letter is as follows:

100700 to 100799

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0101	100708	262206	122K02	0525	1	690319	1	691851			All	3300		
0102	100708	262206	122K02	0525	1	690319	1	691851			All	3300		
0110	100708	262206	122K02	0525							All	3200		
0111	100708	262268	122K02	0515							All	3100	492380	
0112	100708	262260	12F802	2926	1	690319	1	691851	51		All	3300		
0113	100708	262260	12F802	2926					51		All	3200		
0114	100708	262268	122K02	0515							All	3100	492380	
0115	100708	262260	12F802	2926	1	690319	1	691851	51		All	3500		
0116	100708	262269	122K02	0516							All	3200	492381	
0117	100708	262206	122K02	0525							All	3200		
0118	100708	262268	122K02	0515							All	3200	492380	
0119	100708	262269	122K02	0516							All	3200	492381	
0120	100708	262269	122K02	0516							All	3100	492381	
0121	100708	262260	12F802	2926					51		All	3100		
0122	100708	262206	122K02	0525	1	690319	1	691851			All	3500		
0123	100708	262260	12F802	2926					51		All	3100		
0124	100708	262269	122K02	0516							All	3100	492381	
0125	100708	262260	12F802	2926					51		All	2800		
0126	100708	262260	12F802	2926					51		All	3100		
0127	100708	262206	122K02	0525							All	3100		
0128	100708	262268	122K02	0515	1	690319	1	691851			All	3500	492380	
0129	100708	262268	122K02	0515	1	690319	1	691851			All	3300	492380	
0130	100708	262269	122K02	0516							All	3000	492381	
0131	100708	262260	12F802	2926					51		All	3000		
0132	100708	262260	12F802	2926	1	690319	1	691851	51		All	3500		
0133	100708	262268	122K02	0515	1	690319	1	691290			All	3700	492380	
0134	100708	262268	122K02	0515	1	690319	1	691851			All	3300	492380	
0135	100708	262206	122K02	0525	1	690319	1	691851			All	3500		
0136	100708	262268	122K02	0515							All	3200	492380	
0137	100708	262268	122K02	0515	1	690319	1	691851			All	3300	492380	

100700 to 100799

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0138	100708	262268	122K02	0515						All	3100	492380		
0139	100708	262268	122K02	0515						All	3100	492380		
0140	100708	262268	122K02	0515						All	3100	492380		
0141	100708	262260	12F802	2926					51	All	3200			
0142	100708	262260	12F802	2926					51	All	3200			
0143	100708	262206	122K02	0025					51	All	3100			
0144	100708	262269	122K02	0516						All	3100	492381		
0145	100708	262260	12F802	2926					51	All	2900			
0146	100708	262268	122K02	0515	1	690319	1	691851		All	3400			
0147	100708	262206	122K02	0525						All	3200			
0148	100708	262268	122K02	0515						All	3200			
0149	100708	262268	122K02	0515						All	3000	492380		
0150	100708	262206	122K02	0525	1	690319	1	691851		All	3300			
0151	100708	262268	122K02	0515						All	3200			
0152	100708	262206	122K02	0525	1	690319	1	691851		All	3300			
0153	100708	262206	122K02	0525						All	2900			
0154	100708	262260	12F802	2926	1	690319	1	691851	51	All	3400			
0155	100708	262260	12F802	2926					51	All	3000			
0156	100708	262269	122K02	0516						All	3100	492381		
0157	100708	262269	122K02	0516						All	3100	492381		
0158	100708	262358	122K02	0518						All	3100			
0180	100708	262206	122K02	0525						All	3100			
0181	100708	262260	12F802	2926					51	All	3100			
3015	100708	262268	122K02	0515						All	3100	492380		
3016	100708	262269	122K02	0516						All	3100	492381		
3024	100708	262266	No Replacement Repair With Individual Parts.								All	3100		
3025	100708	262206	122K02	0525						All	3100			
3026	100708	262260	12F802	2926					51	All	3100			
3101	100708	262206	122K02	0525						All	3200			
3110	100708	262266	No Replacement Repair With Individual Parts.								All	3100		
3111	100708	262260	12J802	2926					51	All	3200			
3112	100708	262268	122K02	0515						All	3100	492380		
3113	100708	262268	122K02	0515	1	690319	1	691851		All	3300	492380		
3114	100708	262206	122K02	0525						All	2900			
3115	100708	262266	No Replacement Repair With Individual Parts.								All	3100		
3116	100708	262268	122K02	0515						All	3100	492380		
3117	100708	262358	122K02	0518						All	3100			
3118	100708	262268	122K02	0515						All	3200	492380		
3119	100708	262269	122K02	0516						All	3100	492381		
3120	100708	262266	No Replacement Repair With Individual Parts.								All	3200		
3121	100708	262358	122K02	0518						All	3100			
3122	100708	262269	122K02	0516						All	3100	492381		
3123	100708	262268	122K02	0515						All	2900	492380		
3124	100708	262269	122K02	0516						All	2900	492381		
3125	100708	262266	No Replacement Repair With Individual Parts.								All	3200		
3126	100708	262260	12F802	2926	1	690319	1	691851	51	All	3400			
3127	100708	262206	122K02	0525	1	690319	1	691851		All	3400			
3128	100708	262268	122K02	0515	1	690319	1	691851		All	3300	492380		
3129	100708	262358	122K02	0518						All	3100			
3130	100708	262268	122K02	0515						All	3100	492380		
3131	100708	262268	122K02	0515						All	2900	492380		
3132	100708	262260	12F802	2926	1	690319	1	691851	51	All	3400			
3133	100708	262206	122K02	0525	1	690319	1	691851		All	3300			
3134	100708	262269	122K02	0516	1	690319	1	691851		All	3500			

100700 to 100799

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
3135	100708	262269	122K02	0516							All	3100	492381		
3136	100708	262266	No Replacement Repair With Individual Parts.									All	3300		