

100900 to 100999**SERVICE ENGINE****SALES MANUAL****MODEL 100900 SERIES ENGINES REPLACED WITH
STANDARD SERVICE ENGINES**

In most cases, the Original Type numbers shown may be replaced by a Service Type Number without making any changes. Necessary changes of engine parts such as crankshafts, reduction parts, blower housings, etc., are noted. Other differences, such as mufflers, elbows, deflectors, etc., are not listed but are very important for safety and engine performance. Be sure the exhaust system on the replacement engine duplicates the system originally selected by the equipment manufacturer. Parts that are suitable for additional use should be transferred. Before making any conversion, check the data shown in the column labeled "REMOVE, ADD and NOTE." See if the changes, which are shown, are actually necessary on the application in question. Often a standard service engine will be a WORKABLE replacement without converting to such things as a special fuel tank or starter position.

If the crankshaft number does not appear in the "Original Engine" column, consult the Illustrated Parts List for the correct service replacement crankshaft number.

Engine Replacement Notes:**Short Block Notes:**

The SHORT BLOCK part number shown, is the assembly which can be used to rebuild the Original Type Number. If a letter appears after the short block number, it indicates the short block must be modified. The change denoted by each letter is as follows:

100900 to 100999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0015	100902	260650	No Replacement Repair With Individual Parts.								All	3500		
0016	100902	260646	No Replacement Repair With Individual Parts.								All	3500		
0017	100902	260908	No Replacement Repair With Individual Parts.								All	3500		
0040	100992	260646	No Replacement Repair With Individual Parts.								All	3500		
0110	100902	260646	No Replacement Repair With Individual Parts.								All	4000		
0111	100902	260650	No Replacement Repair With Individual Parts.								All	4000		
0112	100902	260908	No Replacement Repair With Individual Parts.								All	4000		
0115	100902	260646	No Replacement Repair With Individual Parts.								All	4000		
0116	100902	260650	No Replacement Repair With Individual Parts.								All	4100		
0117	100902	260908	No Replacement Repair With Individual Parts.								All	4000		
0120	100992	260646	No Replacement Repair With Individual Parts.								All	4000		
0121	100992	260650	No Replacement Repair With Individual Parts.								All	4100		
0122	100992	260908	No Replacement Repair With Individual Parts.								All	4100		
0123	100992	26646	No Replacement Repair With Individual Parts.								All	4100		
0124	100992	260650	No Replacement Repair With Individual Parts.								All	4100		
0125	100992	260908	No Replacement Repair With Individual Parts.								All	4100		
0130	100902	260650	No Replacement Repair With Individual Parts.								All	4000		
0131	100902	260650	No Replacement Repair With Individual Parts.								All	3300		
0132	100902	260908	No Replacement Repair With Individual Parts.								All	3300		
0133	100992	260646	No Replacement Repair With Individual Parts.								All	4100		
0134	100902	260650	No Replacement Repair With Individual Parts.								All	3500		
0135	100902	260646	No Replacement Repair With Individual Parts.								All	3300		
0136	100902	260646	No Replacement Repair With Individual Parts.								All	3300		
0137	100902	260826	No Replacement Repair With Individual Parts.								All	4000		
0138	100902	260646	No Replacement Repair With Individual Parts.								All	3300		
0139	100902	260650	No Replacement Repair With Individual Parts.								All	4000		
0140	100902	260650	No Replacement Repair With Individual Parts.								All	3500		
0141	100902	260646	No Replacement Repair With Individual Parts.								All	4000		
0142	100902	260646	No Replacement Repair With Individual Parts.								All	4000		
0143	100902	260908	No Replacement Repair With Individual Parts.								All	3600		
0144	100902	260650	No Replacement Repair With Individual Parts.								All	3200		

100900 to 100999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0145	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0146	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0147	100902	260650	No Replacement Repair With Individual Parts.									All	3800	
0148	100902	260908	No Replacement Repair With Individual Parts.									All	3300	
0149	100902	260650	No Replacement Repair With Individual Parts.									All	4000	
0150	100902	260908	No Replacement Repair With Individual Parts.									All	4000	
0151	100902	260908	No Replacement Repair With Individual Parts.									All	3300	
0152	100902	260908	No Replacement Repair With Individual Parts.									All	3300	
0153	100902	260908	No Replacement Repair With Individual Parts.									All	4000	
0154	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0156	100992	260650	No Replacement Repair With Individual Parts.									All	4000	
0157	100902	260908	No Replacement Repair With Individual Parts.									All	4000	
0158	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0159	100902	260908	No Replacement Repair With Individual Parts.									All	3300	
0160	100992	260646	No Replacement Repair With Individual Parts.									All	4000	
0161	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0163	100992	260646	No Replacement Repair With Individual Parts.									All	4000	
0164	100902	260908	No Replacement Repair With Individual Parts.									All	4100	
0165	100902	260646	No Replacement Repair With Individual Parts.									All	4000	
0166	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0167	100902	260908	No Replacement Repair With Individual Parts.									All	4000	
0168	100902	260908	No Replacement Repair With Individual Parts.									All	3300	
0169	100992	260646	No Replacement Repair With Individual Parts.									All	4000	
0170	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0171	100902	260908	No Replacement Repair With Individual Parts.									All	4100	
0172	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0173	100902	260908	No Replacement Repair With Individual Parts.									All	3300	
0174	100902	260646	No Replacement Repair With Individual Parts.									All	4100	
0175	100902	260908	No Replacement Repair With Individual Parts.									All	4100	
0176	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0177	100902	260908	No Replacement Repair With Individual Parts.									All	4100	
0178	100902	260646	No Replacement Repair With Individual Parts.									All	4100	
0179	100902	260908	No Replacement Repair With Individual Parts.									All	4100	
0180	100902	260908	No Replacement Repair With Individual Parts.									All	4100	
0181	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0182	100992	260646	No Replacement Repair With Individual Parts.									All	3300	
0183	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0184	100902	260646	No Replacement Repair With Individual Parts.									All	4100	
0185	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0186	100902	260908	No Replacement Repair With Individual Parts.									All	3300	
0187	100902	260908	No Replacement Repair With Individual Parts.									All	3300	
0188	100902	260646	No Replacement Repair With Individual Parts.									All	4000	
0189	100902	260646	No Replacement Repair With Individual Parts.									All	4000	
0190	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0191	100902	260908	No Replacement Repair With Individual Parts.									All	3300	
0192	100902	260646	No Replacement Repair With Individual Parts.									All	4000	
0193	100902	260646	No Replacement Repair With Individual Parts.									All	4000	
0194	100902	260908	No Replacement Repair With Individual Parts.									All	4100	
0195	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0196	100902	260646	No Replacement Repair With Individual Parts.									All	4100	
0197	100902	260826	No Replacement Repair With Individual Parts.									All	4100	
0198	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0199	100902	260646	No Replacement Repair With Individual Parts.									All	3100	
0200	100902	260650	No Replacement Repair With Individual Parts.									All	3800	
0201	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0202	100902	260908	No Replacement Repair With Individual Parts.									All	3300	

100900 to 100999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0203	100902	260650	No Replacement Repair With Individual Parts.									All	3500	
0204	100992	260646	No Replacement Repair With Individual Parts.									All	3300	
0205	100902	260646	No Replacement Repair With Individual Parts.									All	4100	
0206	100902	260646	No Replacement Repair With Individual Parts.									All	3500	
0207	100902	260646	No Replacement Repair With Individual Parts.									All	4100	
0208	100902	260646	No Replacement Repair With Individual Parts.									All	4100	
0209	100992	260646	No Replacement Repair With Individual Parts.									All	3300	
0210	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0211	100902	260908	No Replacement Repair With Individual Parts.									All	4100	
0212	100992	260646	No Replacement Repair With Individual Parts.									All	4100	
0213	100902	260646	No Replacement Repair With Individual Parts.									All	4100	
0214	100902	260908	No Replacement Repair With Individual Parts.									All	4100	
0215	100902	260908	No Replacement Repair With Individual Parts.									All	4100	
0216	100992	260646	No Replacement Repair With Individual Parts.									All	4100	
0217	100902	260650	No Replacement Repair With Individual Parts.									All	3500	
0218	100902	260646	No Replacement Repair With Individual Parts.									All	4100	
0219	100902	260908	No Replacement Repair With Individual Parts.									All	3300	
0220	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0221	100902	260908	No Replacement Repair With Individual Parts.									All	4100	
0222	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0223	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0224	100902	260650	No Replacement Repair With Individual Parts.									All	3500	
0225	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0226	100902	260908	No Replacement Repair With Individual Parts.									All	4100	
0227	100992	260908	No Replacement Repair With Individual Parts.									All	3500	
0228	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0229	100902	260650	No Replacement Repair With Individual Parts.									All	4000	
0230	100902	260650	No Replacement Repair With Individual Parts.									All	4000	
0232	100902	260646	No Replacement Repair With Individual Parts.									All	3500	
0233	100902	260908	No Replacement Repair With Individual Parts.									All	4100	
0234	100992	260646	No Replacement Repair With Individual Parts.									All	4100	
0235	100902	260908	No Replacement Repair With Individual Parts.									All	4100	
0236	100902	260908	No Replacement Repair With Individual Parts.									All	4100	
0237	100902	260646	No Replacement Repair With Individual Parts.									All	4100	
0238	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0239	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0240	100992	260646	No Replacement Repair With Individual Parts.									All	4100	
0241	100992	260646	No Replacement Repair With Individual Parts.									All	4100	
0242	100902	260650	No Replacement Repair With Individual Parts.									All	4100	
0243	100902	260908	No Replacement Repair With Individual Parts.									All	4100	
0244	100902	260908	No Replacement Repair With Individual Parts.									All	3500	
0245	100902	260646	No Replacement Repair With Individual Parts.									All	3500	
0246	100902	260908	No Replacement Repair With Individual Parts.									All	4100	
0247	100992	260908	No Replacement Repair With Individual Parts.									All	4100	
0248	100902	260650	No Replacement Repair With Individual Parts.									All	3500	
0249	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0250	100902	260646	No Replacement Repair With Individual Parts.									All	4000	
0251	100902	260908	No Replacement Repair With Individual Parts.									All	4000	
0252	100902	260908	No Replacement Repair With Individual Parts.									All	4000	
0253	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0254	100902	260646	No Replacement Repair With Individual Parts.									All	4000	
0256	100902	260646	No Replacement Repair With Individual Parts.									All	4000	
0257	100902	260908	No Replacement Repair With Individual Parts.									All	4000	
0258	100902	260650	No Replacement Repair With Individual Parts.									All	3600	
0259	100992	260646	No Replacement Repair With Individual Parts.									All	4000	
0260	100902	260908	No Replacement Repair With Individual Parts.									All	3500	

100900 to 100999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0261	100902	260646	No Replacement Repair With Individual Parts.									All	3500	
0262	100902	260908	No Replacement Repair With Individual Parts.									All	3300	
0263	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0264	100902	260646	No Replacement Repair With Individual Parts.									All	3500	
0265	100992	260646	No Replacement Repair With Individual Parts.									All	4000	
0266	100902	260908	No Replacement Repair With Individual Parts.									All	4000	
0267	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0268	100902	260650	No Replacement Repair With Individual Parts.									All	3500	
0269	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0270	100992	260646	No Replacement Repair With Individual Parts.									All	4000	
0271	100902	260908	No Replacement Repair With Individual Parts.									All	4000	
0272	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0273	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0274	100902	260908	No Replacement Repair With Individual Parts.									All	3300	
0275	100902	260690	No Replacement Repair With Individual Parts.									All	3300	
0276	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0277	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0278	100902	260646	No Replacement Repair With Individual Parts.									All	3600	
0279	100902	260908	No Replacement Repair With Individual Parts.									All	3500	
0280	100902	260646	No Replacement Repair With Individual Parts.									All	4000	
0281	100902	260650	No Replacement Repair With Individual Parts.									All	3800	
0282	100992	260646	No Replacement Repair With Individual Parts.									All	3300	
0283	100900	260908	No Replacement Repair With Individual Parts.									All	4000	
0284	100902	260646	No Replacement Repair With Individual Parts.									All	4000	
0285	100902	260908	No Replacement Repair With Individual Parts.									All	3500	
0286	100902	260650	No Replacement Repair With Individual Parts.									All	3700	
0287	100902	260996	No Replacement Repair With Individual Parts.									All	3300	
0288	100902	260908	No Replacement Repair With Individual Parts.									All	4000	
0289	100902	260908	No Replacement Repair With Individual Parts.									All	4000	
0290	100902	260908	No Replacement Repair With Individual Parts.									All	3300	
0291	100902	260996	No Replacement Repair With Individual Parts.									All	3300	
0292	100902	260646	No Replacement Repair With Individual Parts.									All	3500	
0293	100902	260908	No Replacement Repair With Individual Parts.									All	4000	
0294	100902	260908	No Replacement Repair With Individual Parts.									All	3500	
0295	100902	260908	No Replacement Repair With Individual Parts.									All	3500	
0296	100902	260650	No Replacement Repair With Individual Parts.									All	3500	
0297	100902	260908	No Replacement Repair With Individual Parts.									All	3500	
0298	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0299	100902	260650	No Replacement Repair With Individual Parts.									All	3500	
0300	100902	260650	No Replacement Repair With Individual Parts.									All	3500	
0301	100992	260646	No Replacement Repair With Individual Parts.									All	3300	
0302	100902	160646	No Replacement Repair With Individual Parts.									All	3300	
0303	100902	260908	No Replacement Repair With Individual Parts.									All	3000	
0304	100902	260908	No Replacement Repair With Individual Parts.									All	2800	
0305	100902	260996	No Replacement Repair With Individual Parts.									All	3000	
0306	100902	260996	No Replacement Repair With Individual Parts.									All	3000	
0307	100902	260908	No Replacement Repair With Individual Parts.									All	2900	
0308	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0309	100902	260650	No Replacement Repair With Individual Parts.									All	3500	
0310	100992	260908	No Replacement Repair With Individual Parts.									All	3500	
0311	100902	260646	No Replacement Repair With Individual Parts.									All	3800	
0312	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0313	100902	260605	No Replacement Repair With Individual Parts.									All	3300	
0314	100902	260646	No Replacement Repair With Individual Parts.									All	4000	
0315	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0316	100902	260646	No Replacement Repair With Individual Parts.									All	3000	

100900 to 100999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0317	100902	260908	No Replacement Repair With Individual Parts.									All	4000	
0318	100902	260650	No Replacement Repair With Individual Parts.									All	3000	
0319	100992	260826	No Replacement Repair With Individual Parts.									All	4000	
0320	100902	260650	No Replacement Repair With Individual Parts.									All	3800	
0321	100902	260650	No Replacement Repair With Individual Parts.									All	3500	
0322	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0323	100902	260646	No Replacement Repair With Individual Parts.									All	4000	
0324	100902	260908	No Replacement Repair With Individual Parts.									All	3300	
0325	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0326	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0327	100902	260650	No Replacement Repair With Individual Parts.									All	3500	
0328	100902	260908	No Replacement Repair With Individual Parts.									All	3600	
0329	100902	260908	No Replacement Repair With Individual Parts.									All	2600	
0330	100992	260650	No Replacement Repair With Individual Parts.									All	3800	
0331	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0332	100992	260650	No Replacement Repair With Individual Parts.									All	3800	
0333	100902	260908	No Replacement Repair With Individual Parts.									All	4000	
0334	100992	260908	No Replacement Repair With Individual Parts.									All	3500	
0335	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0336	100902	260650	No Replacement Repair With Individual Parts.									All	3700	
0337	100902	260908	No Replacement Repair With Individual Parts.									All	3000	
0338	100902	260908	No Replacement Repair With Individual Parts.									All	3000	
0339	100992	261045	No Replacement Repair With Individual Parts.									All	3500	
0340	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0341	100902	260908	No Replacement Repair With Individual Parts.									All	3500	
0342	100992	260908	No Replacement Repair With Individual Parts.									All	3500	
0343	100902	260646	No Replacement Repair With Individual Parts.									All	4000	
0344	100902	260908	No Replacement Repair With Individual Parts.									All	3500	
0345	100902	260908	No Replacement Repair With Individual Parts.									All	3000	
0346	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0347	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0348	100902	260646	No Replacement Repair With Individual Parts.									All	4000	
0349	100902	260646	No Replacement Repair With Individual Parts.									All	3600	
0350	100902	260646	No Replacement Repair With Individual Parts.									All	3100	
0351	100902	260650	No Replacement Repair With Individual Parts.									All	3200	
0352	100992	260908	No Replacement Repair With Individual Parts.									All	3100	
0353	100902	260646	No Replacement Repair With Individual Parts.									All	3600	
0354	100902	260908	No Replacement Repair With Individual Parts.									All	3000	
0355	100902	260646	No Replacement Repair With Individual Parts.									All	4000	
0356	100992	260646	No Replacement Repair With Individual Parts.									All	3300	
0357	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0358	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0359	100902	260650	No Replacement Repair With Individual Parts.									All	4000	
0360	100902	260908	No Replacement Repair With Individual Parts.									All	3100	
0361	100902	260650	No Replacement Repair With Individual Parts.									All	3300	
0362	100902	260908	No Replacement Repair With Individual Parts.									All	3300	
0363	100902	260650	No Replacement Repair With Individual Parts.									All	3800	
0364	100902	260646	No Replacement Repair With Individual Parts.									All	3300	
0365	100992	260908	No Replacement Repair With Individual Parts.									All	3100	
0366	100992	260908	No Replacement Repair With Individual Parts.									All	3500	
0367	100902	260908	No Replacement Repair With Individual Parts.									All	3000	
0368	100902	260908	No Replacement Repair With Individual Parts.									All	3000	
0369	100902	260646	No Replacement Repair With Individual Parts.									All	3500	
400015	100902	260646	No Replacement Repair With Individual Parts.									All	4000	
400016	100902	260650	No Replacement Repair With Individual Parts.									All	4000	
400017	100902	260908	No Replacement Repair With Individual Parts.									All	4000	



100900 to 100999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
400020	100902	260646	No Replacement Repair With Individual Parts.									All	3300		
400021	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400022	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400023	100902	260650	No Replacement Repair With Individual Parts.									All	4000		
400024	100902	260650	No Replacement Repair With Individual Parts.									All	3300		
400025	100902	260646	No Replacement Repair With Individual Parts.									All	3300		
400026	100902	260650	No Replacement Repair With Individual Parts.									All	3300		
400027	100902	260650	No Replacement Repair With Individual Parts.									All	3300		
400028	100902	260650	No Replacement Repair With Individual Parts.									All	4000		
400029	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400030	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400031	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400032	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400033	100902	260650	No Replacement Repair With Individual Parts.									All	3300		
400034	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400035	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400036	100902	260908	No Replacement Repair With Individual Parts.									All	4000		
400037	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400038	100902	260650	No Replacement Repair With Individual Parts.									All	3300		
400039	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400040	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400041	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400042	100902	260650	No Replacement Repair With Individual Parts.									All	4000		
400043	100902	260650	No Replacement Repair With Individual Parts.									All	4000		
400044	100902	260908	No Replacement Repair With Individual Parts.									All	3300		
400045	100902	260908	No Replacement Repair With Individual Parts.									All	3300		
400046	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400047	100902	260908	No Replacement Repair With Individual Parts.									All	4000		
400048	100902	260908	No Replacement Repair With Individual Parts.									All	4000		
400049	100902	260650	No Replacement Repair With Individual Parts.									All	4000		
400050	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400051	100902	260908	No Replacement Repair With Individual Parts.									All	4000		
400052	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400053	100902	260646	No Replacement Repair With Individual Parts.									All	3300		
400054	100902	260908	No Replacement Repair With Individual Parts.									All	4000		
400055	100902	260646	No Replacement Repair With Individual Parts.									All	3300		
400056	100902	260908	No Replacement Repair With Individual Parts.									All	4000		
400057	100902	260650	No Replacement Repair With Individual Parts.									All	4100		
400058	100902	260646	No Replacement Repair With Individual Parts.									All	3300		
400059	100902	260646	No Replacement Repair With Individual Parts.									All	3300		
400060	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400061	100902	260908	No Replacement Repair With Individual Parts.									All	4000		
400062	100902	260650	No Replacement Repair With Individual Parts.									All	3300		
400063	100902	260908	No Replacement Repair With Individual Parts.									All	4000		
400064	100902	260650	No Replacement Repair With Individual Parts.									All	4000		
400065	100902	260650	No Replacement Repair With Individual Parts.									All	3300		
400066	100902	260650	No Replacement Repair With Individual Parts.									All	3300		
400067	100902	260650	No Replacement Repair With Individual Parts.									All	3500		
400068	100902	260650	No Replacement Repair With Individual Parts.									All	3300		
400069	100902	260908	No Replacement Repair With Individual Parts.									All	4000		
400070	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400071	100902	260650	No Replacement Repair With Individual Parts.									All	3300		
400072	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400073	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400074	100902	260908	No Replacement Repair With Individual Parts.									All	3300		
400075	100902	260646	No Replacement Repair With Individual Parts.									All	3300		

100900 to 100999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
400076	100902	260646	No Replacement Repair With Individual Parts.									All	3300		
400077	100902	260650	No Replacement Repair With Individual Parts.									All	4000		
400078	100902	260908	No Replacement Repair With Individual Parts.									All	4100		
400079	100902	260908	No Replacement Repair With Individual Parts.									All	4000		
400080	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400081	100902	260908	No Replacement Repair With Individual Parts.									All	3300		
400082	100902	260650	No Replacement Repair With Individual Parts.									All	4000		
400083	100902	260908	No Replacement Repair With Individual Parts.									All	4000		
400084	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400085	100902	260650	No Replacement Repair With Individual Parts.									All	4100		
400086	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400087	100902	260908	No Replacement Repair With Individual Parts.									All	4100		
400088	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400089	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400090	100902	260646	No Replacement Repair With Individual Parts.									All	3300		
400091	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400092	100902	260650	No Replacement Repair With Individual Parts.									All	3300		
400093	100902	260650	No Replacement Repair With Individual Parts.									All	4000		
400094	100902	260908	No Replacement Repair With Individual Parts.									All	4000		
400095	100902	260650	No Replacement Repair With Individual Parts.									All	4000		
400096	100902	260650	No Replacement Repair With Individual Parts.									All	4000		
400097	100902	260908	No Replacement Repair With Individual Parts.									All	4000		
400098	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400099	100902	260908	No Replacement Repair With Individual Parts.									All	3300		
400100	100992	260646	No Replacement Repair With Individual Parts.									All	4000		
400101	100992	260650	No Replacement Repair With Individual Parts.									All	4000		
400102	100992	260908	No Replacement Repair With Individual Parts.									All	4000		
400103	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400104	100902	260908	No Replacement Repair With Individual Parts.									All	4000		
400105	100902	260650	No Replacement Repair With Individual Parts.									All	4000		
400106	100902	260908	No Replacement Repair With Individual Parts.									All	4000		
400107	100902	260646	No Replacement Repair With Individual Parts.									All	4000		
400108	100902	260908	No Replacement Repair With Individual Parts.									All	4000		

MODEL 100900



MODEL 135700

