

126700 to 126799

SERVICE ENGINE



SALES MANUAL

**MODEL 126700 SERIES ENGINES REPLACED WITH
 STANDARD SERVICE ENGINES**

In most cases, the Original Type numbers shown may be replaced by a Service Type Number without making any changes. Necessary changes of engine parts such as crankshafts, reduction parts, blower housings, etc., are noted. Other differences, such as mufflers, elbows, deflectors, etc., are not listed but are very important for safety and engine performance. Be sure the exhaust system on the replacement engine duplicates the system originally selected by the equipment manufacturer. Parts that are suitable for additional use should be transferred. Before making any conversion, check the data shown in the column labeled "REMOVE, ADD and NOTE." See if the changes, which are shown, are actually necessary on the application in question. Often a standard service engine will be a WORKABLE replacement without converting to such things as a special fuel tank or starter position.

If the crankshaft number does not appear in the "Original Engine" column, consult the Illustrated Parts List for the correct service replacement crankshaft number.

Engine Replacement Notes:

- NOTE 47:** Remove Fuel Tank from replacement engine. Transfer Rotating Screen and Flywheel Guard Group to replacement engine.
- NOTE 51:** Replacement engine listed is not available in the State of California. Repair with individual parts.
- NOTE 73:** Transfer Flywheel Assembly to the replacement engine.
- NOTE 88:** Transfer Muffler and/or Spark Arrester Assembly from the original engine if suitable for additional service or add new parts as required

Short Block Notes:

The SHORT BLOCK part number shown, is the assembly which can be used to rebuild the Original Type Number. If a letter appears after the short block number, it indicates the short block must be modified. The change denoted by each letter is as follows:

- NOTE L:** Change Drive Shaft in Short Block. Add 231759.
- NOTE UU:** Change Drive Shaft in Short Block. Add 231748.
- NOTE WV:** Change Drive Shaft in Short Block. Add 231711.

126700 to 126799

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
0106	126702	493362	129802	2915					51		All	3000	498826		
0114	126702	493282	129802	2925					51		All	3300	498829		
0116	126702	493363	129802	2916					51		All	3000	498827		
0117	126702	493947	12J802	2918					51		All	3300	498828		
0118	126782	493362	129882	2951	1	690522	1	691778	51		All	3000	498833		
0119	126702	493362	129802	2915	1	690319	1	691290	51		All	3700	498826		
0120	126782	493362	129882	2951	1	690319	1	691851	51		All	3300	498833	UU	
									73						
0121	126702	493362	129802	2915	1	690319	1	691290	51		All	3700	498826		
0122	126702	493362	129802	2915	1	690319	1	691291	51		All	3600	498826		
									73						
									88						
0123	126702	493363	12J802	2916					51		All	3100	498827		
0124	126702	493363	129802	2915	1	690319	1	691290	51		All	3700	498826		
0125	126787	493362	No Replacement Repair With Short Block and/or Individual Parts									All	3300	498833	UU
0126	126702	493363	12J802	2916					51		All	3000	498827		
0127	126702	493362	129802	2915	1	690319	1	691851	51		All	3500	498826		
									73						
0128	126702	493362	129802	2915					51		All	3100	498826		
0129	126782	493362	129882	2951	1	690319	1	691851	51		All	3300	498833	UU	
									73						
0130	126787	493362	No Replacement Repair With Short Block and/or Individual Parts									All	3300	498833	UU
0131	126702	493362	129802	2915					51		All	2900	498826		
0132	126707	493362	No Replacement Repair With Individual Parts.									All	2900	498826	
0133	126702	493362	129802	2915					51		All	3000	498826		
0134	126702	493282	129802	2925					51		All	3000	498829		

126700 to 126799

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
0135	126702	493282	129802	2925	1	690319	1	691851	51		All	3400	498829		
0136	126702	493362	129802	2915					51 73 88		All	3200	498826		
0137	126702	493363	12J802	2916					51 73		All	3300	498827		
0138	126702	493362	129882	2951	1	690319	1	691851	51 73		All	3300	498833	UU	
0139	126702	493282	129802	2925	1	690319	1	691851	51		All	3300	498829		
0140	126702	493362	129802	2915	1	690319	1	691851	51 73		All	3500	498826		
0141	126782	493362	129882	2950	1	690522	1	691778	51		All	3100	498834		
0142	126782	493362	129882	2951					51		All	3100	498833	UU	
0143	126702	493362	129802	2915	1	690319	1	691290	51		All	3700	498826		
0144	126702	493362	129802	2915					51 73 88		All	3200	498826		
0145	126702	493362	129882	2950	1	690319	1	691291	51		All	3600	498834		
0146	126702	493282	129802	2925					51		All	3000	498829		
0147	126702	493432	No Replacement Repair With Individual Parts.									All	3300		
0148	126782	493362	129882	2950	1	690319	1	690521	51 73		All	3600	498834	VV	
						1	690522	1	691291						
0149	126702	493363	12J802	2916					73		All	3600	498827		
0610	126782	493362	129882	2951	1	262665	1	690524	51		All	3300	498833	L	
						1	690522	1	691851						
0611	126702	493362	129802	2915	1	690319	1	691851	51		All	3300	498826		
0612	126702	493282	129802	2925	1	690319	1	691851	51		All	3300	498829		
0613	126702	493381	12J802	2926	1	690319	1	691851	51		All	3300	498830		
0614	126702	493282	129802	2925	1	690319	1	691851	51		All	3300	498829		
0615	126702	493362	129802	2915	1	690319	1	691851	51		All	3300	498826		
0616	126702	493362	129802	2915					51		All	2900	498826		
0617	126782	493282	129882	2951	1	690522	1	691450	51		All	3200			
						1	691451	1	691778						
0618	126702	493362	129802	2915					51		All	3100	498826		
0619	126702	493282	129802	2925					51		All	3200	498829		
0620	126702	493362	129802	2915					51 73		All	3100	498826		
0621	126702	493362	129802	2915					51 73 88		All	3200	498826		
0622	126707	493362	No Replacement Repair With Short Block and/or Individual Parts									All	2900	498826	
0623	126787	493362	No Replacement Repair With Individual Parts.									All	3300		
0647	126702	493432	No Replacement Repair With Individual Parts.									All	3300		
3106	126702	493282	129802	2925					51		All	3000	498829		
3108	126702	493362	129802	2915					51		All	3100	498826		
3111	126702	493362	129802	2915					51		All	3200	498826		
3112	126702	493282	129802	2925	1	690319	1	691851	51		All	3300	498829		
3113	126782	493282	129882	2950	1	690319	1	691450	51		All	3300			
						1	690522	1	691778						
						1	691451	1	691851						
3114	126702	493362	129802	2915	1	690319	1	691851	51		All	3300	498826		
3115	126782	493362	129882	2950	1	690319	1	691778	51		All	3300	498834		
						1	690522	1	691851						
3116	126702	493362	129802	2915	1	690319	1	691851	51		All	3300			
3117	126702	493362	129802	2915	1	690319	1	691851	51		All	3400	498826		

126700 to 126799

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
3118	126702	493362	129802	2915					51		All	3100	498826		
3119	126702	493362	129802	2915	1	690319	1	691851	51		All	3300	498826		
3120	126702	493433	No Replacement Repair With Individual Parts.									All	3200		
3121	126702	493362	129802	2915					51		All	3100	498826		
3122	126702	493947	12J802	2918					51		All	3300	498828		
3123	126702	493363	12J802	2916					51		All	3100	498827		
3125	126707	493433	No Replacement Repair With Individual Parts.									All	3200		
3126	126702	493362	129802	2915	1	690319	1	691291	51		All	3600	498826		
3130	126702	493362	129802	2915					51		All	3100	498826		
3140	126702	493362	129802	2915					51		All	3100	498826		
3149	126702	493363	12J802	2916					47		All	3100	498827		
									51						
3189	126702	493433	No Replacement Repair With Individual Parts.									All	3200		
3190	126702	493282	129802	2925					51		All	3000	498829		
3191	126702	493362	129802	2915					51		All	3150	498826		
3192	126702	493362	129802	2915					51		All	3150	498826		
3193	126702	493362	129802	2915					51		All	3150	498826		
3194	126782	493362	129882	2950	1	690522	1	691778	51		All	3100	498834		
4001	126702	493362	129802	2915	1	690319	1	691291	51		All	3600	498826		
									73						
4003	126702	493438	No Replacement Repair With Individual Parts.									All	3600		
5001	126702	493362	129802	2915					51		All	3100	498826		
									73						
5002	126702	493363	12J802	2916					51		All	3100	498827		
									73						
5003	126702	493282	129802	2925					51		All	3100	498829		
									73						
5005	126702	493282	129802	2925					51		All	3100	498829		
									73						
5006	126702	493362	129802	2915					51		All	3100	498826		
									73						
5007	126702	493362	129802	2915					51		All	3100	498826		
									73						
7001	126702	493362	129802	2915	1	690319	1	691851	51		All	3300	498826		
7002	126702	493362	129802	2915	1	690319	1	691851	51		All	3300	498826		
7015	126702	493362	129802	2915					51		All	3100	498826		
7016	126702	493363	12J802	2916					51		All	3100	498827		
7017	126702	493438	129802	2915	1	691451	1	691453	51		All	3100			
7025	126702	493282	129802	2925					51		All	3100	498829		
7026	126702	493381	12J802	2926					51		All	3100	498830		
7050	126782	493362	129882	2950					51		All	3100	498834	UU	
7051	126782	493362	129882	2951					51		All	3100	498833	UU	