

132900 to 132999

SERVICE ENGINE



SALES MANUAL

**MODEL 132900 SERIES ENGINES REPLACED WITH
 STANDARD SERVICE ENGINES**

In most cases, the Original Type numbers shown may be replaced by a Service Type Number without making any changes. Necessary changes of engine parts such as crankshafts, reduction parts, blower housings, etc., are noted. Other differences, such as mufflers, elbows, deflectors, etc., are not listed but are very important for safety and engine performance. Be sure the exhaust system on the replacement engine duplicates the system originally selected by the equipment manufacturer. Parts that are suitable for additional use should be transferred. Before making any conversion, check the data shown in the column labeled "REMOVE, ADD and NOTE." See if the changes, which are shown, are actually necessary on the application in question. Often a standard service engine will be a WORKABLE replacement without converting to such things as a special fuel tank or starter position.

If the crankshaft number does not appear in the "Original Engine" column, consult the Illustrated Parts List for the correct service replacement crankshaft number.

Engine Replacement Notes:

Short Block Notes:

The SHORT BLOCK part number shown, is the assembly which can be used to rebuild the Original Type Number. If a letter appears after the short block number, it indicates the short block must be modified. The change denoted by each letter is as follows:

132900 to 132999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0110	132922	492091	No Replacement Repair With Individual Parts.						All	3500				
0111	132922	493410	No Replacement Repair With Individual Parts.						All	3500				
0116	132982	493410	No Replacement Repair With Individual Parts.						All	3500				
0127	132927	397119	No Replacement Repair With Individual Parts.						All	3500				
0130	132922	492092	No Replacement Repair With Individual Parts.						All	4000				
0131	132922	493410	No Replacement Repair With Individual Parts.						All	3500				
0132	132922	493410	No Replacement Repair With Individual Parts.						All	3500				
0133	132922	492091	No Replacement Repair With Individual Parts.						All	3400				
0134	132922	492091	No Replacement Repair With Individual Parts.						All	3500				
0135	132922	493410	No Replacement Repair With Individual Parts.						All	3500				
0136	132922	492092	No Replacement Repair With Individual Parts.						All	4000				
0137	132922	493410	No Replacement Repair With Individual Parts.						All	3600				
0138	132927	397119	No Replacement Repair With Individual Parts.						All	3600				
0139	132922	397109	No Replacement Repair With Individual Parts.						All	3300				
0140	132922	493410	No Replacement Repair With Individual Parts.						All	4000				
0141	132922	493410	No Replacement Repair With Individual Parts.						All	3300				
0142	132922	493410	No Replacement Repair With Individual Parts.						All	3300				
0143	132922	492091	No Replacement Repair With Individual Parts.						All	3300				
0144	132922	493410	No Replacement Repair With Individual Parts.						All	3000				
0145	132925	397119	No Replacement Repair With Individual Parts.						All	3400				
0146	132927	397119	No Replacement Repair With Individual Parts.						All	3500				
0147	132922	493410	No Replacement Repair With Individual Parts.						All	3500				
0148	132922	492091	No Replacement Repair With Individual Parts.						All	3300				
0149	132922	493410	No Replacement Repair With Individual Parts.						All	3600				
0150	132982	493410	No Replacement Repair With Individual Parts.						All	3200				
0151	132922	493410	No Replacement Repair With Individual Parts.						All	3300				
0152	132922	397109	No Replacement Repair With Individual Parts.						All	3300				
0153	132922	397109	No Replacement Repair With Individual Parts.						All	3600				
0154	132922	493410	No Replacement Repair With Individual Parts.						All	4000				
0155	132922	493410	No Replacement Repair With Individual Parts.						All	3300				
0156	132982	397109	No Replacement Repair With Individual Parts.						All	3200				

132900 to 132999



Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
0157	132922	493410	No Replacement Repair With Individual Parts.									All	4000		
0158	132922	493410	No Replacement Repair With Individual Parts.									All	3300		
0159	132922	493410	No Replacement Repair With Individual Parts.									All	3000		
0160	132982	492091	No Replacement Repair With Individual Parts.									All	3500		
0161	132982	492091	No Replacement Repair With Individual Parts.									All	3500		
0162	132982	493410	No Replacement Repair With Individual Parts.									All	3300		
0163	132982	493410	No Replacement Repair With Individual Parts.									All	3500		
0164	132922	492091	No Replacement Repair With Individual Parts.									All	4000		
0165	132982	493410	No Replacement Repair With Individual Parts.									All	3500		
0166	132982	397109	No Replacement Repair With Individual Parts.									All	3500		
0167	132982	492091	No Replacement Repair With Individual Parts.									All	3500		
0168	132982	492091	No Replacement Repair With Individual Parts.									All	3500		
0169	132922	492091	No Replacement Repair With Individual Parts.									All	3100		
0170	132922	397109	No Replacement Repair With Individual Parts.									All	3100		
0171	132922	493410	No Replacement Repair With Individual Parts.									All	3000		
0172	132922	492091	No Replacement Repair With Individual Parts.									All	3500		
0173	132922	493410	No Replacement Repair With Individual Parts.									All	3500		
0174	132922	493410	No Replacement Repair With Individual Parts.									All	3000		
0175	132922	493410	No Replacement Repair With Individual Parts.									All	3500		
0176	132992	493410	No Replacement Repair With Individual Parts.									All	3500		
0177	132982	493410	No Replacement Repair With Individual Parts.									All	3500		
0178	132982	397109	No Replacement Repair With Individual Parts.									All	3600		
0179	132982	493410	No Replacement Repair With Individual Parts.									All	3500		
0180	132922	493410	No Replacement Repair With Individual Parts.									All	3200		
0181	132982	492091	No Replacement Repair With Individual Parts.									All	3500		
0183	132922	493410	No Replacement Repair With Individual Parts.									All	3500		
0184	132922	492091	No Replacement Repair With Individual Parts.									All	3300		
0185	132982	492091	No Replacement Repair With Individual Parts.									All	3100		
0186	132982	492091	No Replacement Repair With Individual Parts.									All	3500		
0187	132982	397109	No Replacement Repair With Individual Parts.									All	3000		
0188	132922	492091	No Replacement Repair With Individual Parts.									All	3000		
0189	132922	492091	No Replacement Repair With Individual Parts.									All	2900		
0190	132982	492091	No Replacement Repair With Individual Parts.									All	3000		
0191	132922	492091	No Replacement Repair With Individual Parts.									All	2900		
0192	132982	492091	No Replacement Repair With Individual Parts.									All	3500		
0193	132922	492091	No Replacement Repair With Individual Parts.									All	3500		
0194	132922	492091	No Replacement Repair With Individual Parts.									All	3000		
0195	132982	397109	No Replacement Repair With Individual Parts.									All	3000		
0196	132922	492091	No Replacement Repair With Individual Parts.									All	3500		
0197	132922	492091	No Replacement Repair With Individual Parts.									All	3000		
0198	132982	493410	No Replacement Repair With Individual Parts.									All	3600		
0199	132982	492091	No Replacement Repair With Individual Parts.									All	3500		
0200	132927	397119	No Replacement Repair With Individual Parts.									All	3400		
0201	132922	493410	No Replacement Repair With Individual Parts.									All	3500		
0202	132922	493410	No Replacement Repair With Individual Parts.									All	3400		
0203	132922	492091	No Replacement Repair With Individual Parts.									All	3500		
0204	132922	397109	No Replacement Repair With Individual Parts.									All	3600		
2015	132922	397109	No Replacement Repair With Individual Parts.									All	3500		
2016	132922	492091	No Replacement Repair With Individual Parts.									All	3500		
2017	132922	493410	No Replacement Repair With Individual Parts.									All	3500		
2052	132982	493410	No Replacement Repair With Individual Parts.									All	3500		
2055	132982	493410	No Replacement Repair With Individual Parts.									All	3500		
3015	132922	397109	No Replacement Repair With Individual Parts.									All	3200		
3016	132922	492091	No Replacement Repair With Individual Parts.									All	3200		
3017	132922	493410	No Replacement Repair With Individual Parts.									All	3200		
3018	132922	492091	No Replacement Repair With Individual Parts.									All	3500		

132900 to 132999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
3051	132982	493410	No Replacement Repair With Individual Parts.									All	3200		
3100	132922	492091	No Replacement Repair With Individual Parts.									All	3500		
3120	132982	493410	No Replacement Repair With Individual Parts.									All	3500		
3121	132922	493410	No Replacement Repair With Individual Parts.									All	3000		
3122	132922	397109	No Replacement Repair With Individual Parts.									All	3300		
3123	132982	397109	No Replacement Repair With Individual Parts.									All	3200		
3124	132982	397109	No Replacement Repair With Individual Parts.									All	3300		
3125	132982	492091	No Replacement Repair With Individual Parts.									All	3500		
3126	132922	493410	No Replacement Repair With Individual Parts.									All	3000		
3127	132922	492091	No Replacement Repair With Individual Parts.									All	3300		
3128	132922	492091	No Replacement Repair With Individual Parts.									All	3300		
3129	132992	493410	No Replacement Repair With Individual Parts.									All	3000		
3130	132922	492091	No Replacement Repair With Individual Parts.									All	3500		
3131	132922	493410	No Replacement Repair With Individual Parts.									All	3000		
3132	132922	493634	No Replacement Repair With Individual Parts.									All	3200		
3133	132922	397109	No Replacement Repair With Individual Parts.									All	3300		
3134	132922	493410	No Replacement Repair With Individual Parts.									All	3500		
3135	132922	493410	No Replacement Repair With Individual Parts.									All	3500		
3136	132922	493410	No Replacement Repair With Individual Parts.									All	3500		
4000	132922	493410	No Replacement Repair With Individual Parts.									All	3500		
4001	132922	492091	No Replacement Repair With Individual Parts.									All	3600		
4002	132922	493410	No Replacement Repair With Individual Parts.									All	3600		
4003	132922	493410	No Replacement Repair With Individual Parts.									All	3600		
4004	132922	493410	No Replacement Repair With Individual Parts.									All	3000		
4015	132922	397109	No Replacement Repair With Individual Parts.									All	3600		
4016	132922	492091	No Replacement Repair With Individual Parts.									All	3600		
4017	132922	493410	No Replacement Repair With Individual Parts.									All	3600		
4019	132922	397109	No Replacement Repair With Individual Parts.									All	3300		
4052	132982	493410	No Replacement Repair With Individual Parts.									All	3600		
4055	132982	493410	No Replacement Repair With Individual Parts.									All	3500		
7001	132922	493410	No Replacement Repair With Individual Parts.									All	3600		
7002	132922	493410	No Replacement Repair With Individual Parts.									All	3000		
7003	132922	492091	No Replacement Repair With Individual Parts.									All	3300		
7006	132922	492091	No Replacement Repair With Individual Parts.									All	3600		
7016	132922	492091	No Replacement Repair With Individual Parts.									All	3600		
7017	132922	493410	No Replacement Repair With Individual Parts.									All	3600		

132900 to 132999

MODEL 132900



MODEL 133700

