

60900 to 60999

SERVICE ENGINE  **SALES MANUAL**

**MODEL 60900 SERIES ENGINES REPLACED WITH
 STANDARD SERVICE ENGINES**

In most cases, the Original Type numbers shown may be replaced by a Service Type Number without making any changes. Necessary changes of engine parts such as crankshafts, reduction parts, blower housings, etc., are noted. Other differences, such as mufflers, elbows, deflectors, etc., are not listed but are very important for safety and engine performance. Be sure the exhaust system on the replacement engine duplicates the system originally selected by the equipment manufacturer. Parts that are suitable for additional use should be transferred. Before making any conversion, check the data shown in the column labeled "REMOVE, ADD and NOTE." See if the changes, which are shown, are actually necessary on the application in question. Often a standard service engine will be a WORKABLE replacement without converting to such things as a special fuel tank or starter position.

If the crankshaft number does not appear in the "Original Engine" column, consult the Illustrated Parts List for the correct service replacement crankshaft number.

Engine Replacement Notes:

Short Block Notes:

The SHORT BLOCK part number shown, is the assembly which can be used to rebuild the Original Type Number. If a letter appears after the short block number, it indicates the short block must be modified. The change denoted by each letter is as follows:

60900 to 60999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
950010	60901	26943	9M902	0015										
950011	60902	260274	9M902	0015										
950012	60903	26943	9M902	0015										
950013	60906	260274	9M902	0015										
950015	60901	26943	9M902	0015										
950016	60902	260274	9M902	0015										
950017	60903	26943	9M902	0015										
950018	60906	260274	9M902	0015										
950022	60902	260047	No Replacement Repair With Individual Parts.											
950023	60906	260047	No Replacement Repair With Individual Parts.											
950024	60902	260274	No Replacement Repair With Individual Parts.											
950025	60902	260005	9M902	0016										
950026	60902	260005	9M902	0016										
950027	60906	260005	122K02	0016										
950028	60902	260005	9M902	0016							All	3000		
950029	60901	26978	9M902	0018	1	692009	1	690843			All	3600		
950030	60902	260047	No Replacement Repair With Individual Parts.											
950510	61901	26943	9M902	0015										
950511	61902	260274	9M902	0015										
950512	61903	26943	9M902	0015										
950513	61906	260274	9M902	0015										
950515	61901	26943	9M902	0015										
950516	61902	260274	9M902	0015										
950517	61903	26943	9M902	0015										
950518	61906	260274	9M902	0015										
950522	61906	260003	No Replacement Repair With Individual Parts.											
950523	61902	260274	9M902	0015							All	3500		
950524	61902	260005	9M902	0016										
950525	61902	260274	9M902	0015										