


5252E Tractor S/N 1J015G & After
2WD Transmission Connections

Page 1 of 71




5252E Tractor S/N 1J015G & After
2WD Transmission Connections

Page 2 of 71

Ref #	Part Number	Qty	S/P/F	Description
	737-3120	1	/P	Transmission Oil, 1 Qt. 5 gal.
	737-3121	1	/P	Transmission Oil, 1 Gal.
	759-3958	AR		Sealant, Loctite Black, 5.3 oz.
1	603-0980	1	S	Arm, Hydro
2	603-04192	1		Bracket, Clutch Torque
3	603-04195	1		Bracket, Return
4	603-04298	1		Bracket, Filter Mounting
5	703-05041	1		Arm, Neutral - RH
6	703-05042	1		Arm, Neutral - LH
7	703-05742	1		Keeper, Belt
8	710-0189	2	/P	Screw, Hex Cap, 5/16-18 x 3.0 GR5
9	710-0299	1		Screw, Hex Cap, 1/4-28 x 1.0 GR5
10	710-0751	2	/P	Screw, Hex Cap, 1/4-20 x .62 GR5
11	710-0817	2		Screw, Hex Wash. Hd. Tapp, 5/16-18 x 1.25 GR5
12	710-1882	3		Screw, Hex Flange, 5/16-18 x 1.5 GR5
13	710-3218	4		Screw, Socket Hd. Cap 1/4-20 x .62 GR8
14	710-3226	2		Screw, Hex Cap Lock, 5/16-18 x 5.5 GR5
15	710-3242	1		Screw, Set - Lock 5/16 x .5 GR5
16	710-04040	1	/P	Screw, Shoulder, .497 x .750: 3/8-16
17	712-0262	1	/P	Nut, Hex Jam Lock, 3/8-24
18	712-0896	2		Nut, Hex Nylon Lock, 1/4-28
19	712-3004A	3	/P	Nut, Hex Flange Lock, 5/16-18 GR5
20	712-3005	1	S	Nut, Hex Flange Lock, 3/8-16
21	716-0111	1	/P	Ring, Retaining
22	718-04141	1	S	Pump, Hydrostatic Transmission
23	721-04002	1	S	O-Ring, 2.425 ID x .103
24	726-0205	1	/P	Clamp, Hose
25	727-3002	1	S	Fitting, Straight
26	727-3012	1	/P	Fitting, 90 Degree
27	727-04095	1	S	Tube, Hydro Inlet
28	731-05247	1	S	Fan, Transmission Cooling
29	732-3119	1	S	Spring, Extension, .50 x 1.975 x .072
30	736-0119	4	S	Washer, Lock, 5/16
31	736-0331	1	/P	Washer, Belleville
32	736-0864	1	S	Washer, Thrust, .375 x .812 x .06
33	737-0296	1	/P	Vent, 3/8 Dia
34	737-0299	1		Fitting, Elbow
35	737-0349	2		Fitting, Plug
36	737-04011	1	S	Adapter, Oil Filter
37	737-04026	1	S	Fitting, Run Tee
38	737-04032	1	S	Indicator, Oil Level Sight
39	737-04047	1	S	Fitting, Elbow
40	748-04086	1	S	Adapter. Cog Pump
41	751-10234	1		Tube, Rubber, .25 .375 x .38
42	751-3130	1		Hose, Vent 13 in.
43	GW-90064	2		Screw, Hex Wash Hd Tapp 3/8-16 x .62
44	BS-492932S	1	/P	Filter, Hydro Pump
45	718-04001	1	S	Valve, Check, 30 PSI
46	727-04111	1	S	Tube, Inlet Filter
47	737-04016	1	S	Fitting, Branch Tee
48	737-04020	1	S	Fitting, Adapter

5252E Tractor S/N 1J015G & After
Air Intake

Page 3 of 71




5252E Tractor S/N 1J015G & After
Air Intake

Page 4 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	KH-54-755-01-S	1	/P	Kit, Knob w/Seal (Incl. Ref #2,3)
2	KH-25-341-04-S	1	/P	Knob, Cover
3	KH-24-153-20-S	1		Seal, Air Cleaner Cover Knob
4	KH-24-096-69-S	1	/P	Cover, Air Cleaner
5	KH-12-100-01	1	/P	Wing Nut
6	KH-24-096-01	1	/P	Cover, Inner Air Cleaner
7	KH-230046	1	/P	Seal, Inner Air Cleaner
8	KH-24-083-05-S	1	S	Precleaner, Element, 71mm deep
9	KH-24-083-03-S	1	S	Element, Air Cleaner, 74mm deep
10	KH-24-086-53-S	3		Screw, Hex Flange, M6 x 1.0 x16
11	KH-24-126-88-S	1	/P	Bracket, Air Cleaner Base
12	KH-M-0545010	2	/P	Screw, Hex Flng, M5 x 0.8 x 10
13	KH-24-094-37-S	1		Base, Air Cleaner
14	KH-24-126-130-S	1		Bracket, Air Cleaner Base
15	KH-24-041-06	1	/P	Gasket, Air Cleaner Base
16	KH-M-651040-S	4		Screw, Hex Flange, M6 x 1.0 x 40
17	KH-24-164-54-S	1	S	Manifold, Intake (Includes Ref. Nos. 15 and 16)
18	KH-24-153-27-S	2	/P	O-Ring, Intake Manifold
19	KH-24-041-53-S	1		Gasket, Carburetor

5252E Tractor S/N 1J015G & After
Battery and Electrical


Page 5 of 71



5252E Tractor S/N 1J015G & After
Battery and Electrical

Page 6 of 71


Ref #	Part Number	Qty	S/P/F	Description
1	629-04128	1		Harness, Main Wire
2	703-4104-0637	1	/P	Strap, Battery Holddown
3	710-0206	2	/P	Screw, Hex Cap, 1/4-10 x .875 GR5
4	710-0224	3	S	Screw, Hex Wash Hd. Tapp #10-16 x .5
5	712-0324	2	/P	Nut, Hex Nylon Insert Lock, 1/4-20
6	712-0421	2		Nut, Wing w/Bell Washer, 5/16-18
7	725-0157	7	/P	Tie, Cable
8	725-3174	1	S	Battery, 500 cca Dry
9	747-3433	2		Rod, Battery Holddown



5252E Tractor S/N 1J015G & After
Blower Housing and Baffles

Page 8 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	KH-24-027-175-S	1	/P	Housing, Blower (Incl. Ref #2-4)
2	KH-24-100-02	2		Nut, Plastic
3	KH-25-139-16	1		Plug, Button, 9/16
4	KH-24-100-01	3		Nut, Plastic
5	KH-M-561016-S	1		Screw, Hex Flange, M5 x 0.8 x 16
6	KH-M-545016-S	3	/P	Screw, Hex Flange, M5 x 0.8 x 16
7	KH-M-545020-S	4		Screw, Hex Flange, M5 x 0.8 x 20
8	KH-24-146-50-S	1		Plate, Backing - #2 Side
9	KH-24-063-39-S	1	S	Baffle, Cylinder Barrel - #2 Side ..
10	KH-M-645016-S	6	/P	Screw, Hex Flange, M6 x 1.0 x 16
11	KH-24-063-70-S	1		Baffle, Valley - #2 Side
12	KH-M-0545010	2	/P	Screw, Hex Flange, M5 x 0.8 x 10
13	KH-24-063-59-S	1		Baffle, Valley - #1 Side
14	KH-24-063-58-S	1	S	Baffle, Cylinder Barrel - #1 Side




Ref #	Part Number	Qty	S/P/F	Description
1	603-04018	1		Link, Hi-Lo
2	603-0945	1		Shaft Assembly, Pedal
3	603-04273	1		Shaft Assembly, Brake
4	603-0947	1		Shaft Assembly, Reverse
5	703-05847	1		Link Assembly, Parking Brake ..
6	703-05039A	1		Link, Hi-Lo Pivot
7	703-05666	1		Handle, Hi-Lo Shift
8	703-05674A	1	S	Bracket, Switch
9	703-4105	1		Lever, Brake
10	703-3012	1		Link, Pedal Mounting
11	703-3152	1		Bracket, Reverse Switch
12	703-3156A	1		Link, Brake Pedal
13	703-3183	1		Bracket, Pedal Brace
14	710-0521	1	/P	Screw, Hex Cap 3/8-16 x 3.0 GR8
15	710-0599	6	/P	Screw, Hex Wash Hd Tapp 1/4-20 x .5
16	710-0623	3	/P	Screw, Hex Wash Hd Tapp 3/8-16 x .75
17	710-0642	2	/P	Screw, Hex Wash Hd Tapp 1/4-20 x .75
18	710-3005	2	/P	Screw, Hex Cap 3/8-16 x 1.25 GR5
19	710-3170	1		Stud, Cylinder, 5/16-18
20	711-04038	2	S	Ferrule, Brake
21	711-0701	1	S	Pin, Clevis, .25 x .5
22	711-3397	1		Ferrule, 3/8-24 x .37
23	711-0679A	1	/P	Pin, Clevis, 3/8 x 2.015
24	711-0723A	2	S	Ferrule, 3/8 - 24 x .375
25	711-1363	1		Pin, 3/8-16: 3/8 x 2.43
26	712-0431	4	S	Nut, Hex Flange Lock, 3/8-16 ...
27	712-3004A	2	/P	Nut, Hex Flange Lock, 5/16-18
28	712-3027	3	S	Nut, Hex Flange Lock, 1/4-20 ...
29	712-0375	3	/P	Nut, Hex Lock, 3/8-16
30	712-3058	2	S	Nut, Hex Insert Lock, 1/2-20
31	714-0104	10	S	Pin, Internal Cotter
32	714-0145	1	S	Pin, Internal Cotter
33	714-0507	1	S	Pin, Cotter, 3/32 x .750
34	714-0147	4	/P	Pin, Internal Cotter
35	716-0104	1	S	E-Ring, .5 Dia
36	725-04232	1		Switch, Plunger (Brake)
37	725-3164A	1	S	Switch, Plunger (Reverse)
38	727-04004	1		Cylinder, Damper
39	731-3247	1		Pedal, Forward
40	731-3248	1		Pedal, Reverse
41	731-3249A	1	/P	Pedal, Brake
42	731-3250	1		Pedal, Diff. Lock
43	731-3321	1		Grip, Handle
44	732-04009	2	S	Spring, Compression
45	725-3167	1	S	Switch, Plunger (Brake)
46	732-0384	1	S	Spring, Extension, .62 x 6.12
47	732-0859A	1	/P	Spring, Rev/No Cut
48	732-3118	1		Spring, Extension, 3/8 x 1.44
49	712-0711	2	/P	Nut, Hex Jam, 3/8-24
50	736-0173	3	/P	Washer, Flat, .28 x .74 x .063 ...
51	736-3019	4		Washer, Flat, .53 x .1.06 x .134
52	738-0140	1	S	Screw, Shoulder, .435 x 1.78
53	738-0255	1	S	Screw, Shoulder, ..375 x .181 ...

5252E Tractor S/N 1J015G & After
Controls

Page 11 of 71


Ref #	Part Number	Qty	S/P/F	Description
54	738-0533	1	S	Screw, Shoulder, .498 x 1.635
55	738-0982	1		Screw, Shoulder, .498 x 3.245: 3/8-16
56	741-0598	4	S	Bearing, Hex Flange, .752 ID
57	741-0491	4		Bearing, Nylon. .50 ID x .341
58	741-3073	2	S	Bearing, Flange, .375 x .58 x .25
59	746-04017	1		Cable, Diff Lock
60	747-04021	1		Rod, Brake, LH
61	747-04022	1		Rod, Brake, RH
62	747-3486	1		Rod, Hydro Control
63	747-3324	1		Rod, Rear Connecting
64	747-3353	1		Rod, Front Connecting
65	747-3366	1		Shaft, Diff. Lock
66	748-0190	2	/P	Spacer, .508 x .75 x .68
67	748-0227A	2	S	Bearing, Hex Flange, .629 ID
68	736-0160	1	S	Washer, Flat, .53 ID x .93 x .05..
69	750-0668	1		Spacer, .39 x .625 x 1.74
70	703-05665	1		Bracket, Hi-Lo Shifter
71	710-0703	1	/P	Screw.Carriage, 1/4-20 x .75 GR5
72	712-04064	1	/P	Nut, Hex Flange Nylon Lock 14-20 GRF
73	703-05901	1	S	Bracket, Switch Clamp



5252E Tractor S/N 1J015G & After
Crankcase and Crankshaft

Page 13 of 71


Ref #	Part Number	Qty	S/P/F	Description
1	KH-7300149	1		Engine, Complete
1	KH-24-782-32	1		Miniblock
1	KH-24-522-339	1		Short Block
2	KH-24-014-02-S	1	S	Crankshaft (Includes 3)
3	KH-52-139-09	2	S	Plug, Cup
4	KH-25-139-57-S	2	/P	Plug, Hex Head, 3/8 NPTF
5	KH-24-032-01	1	S	Seal, Oil
6	KH-24-380-16-S	6	/P	Pin, Dowel Locating
7	KH-24-067-13-S	2	S	Rod, Connecting, Std
7	KH-24-067-14-S	2	S	Rod, Connecting, .010
8	KH-24-874-08-S	2	S	Piston w/Ring Set, Std
8	KH-24-874-16-S	2	S	Piston w/Ring Set, .003
8	KH-24-874-20-S	2	S	Piston w/Ring Set, .010
8	KH-24-874-21-S	2		Piston w/Ring Set, .020
9	KH-24-108-05-S	2	/P	Ring Set, Std & .003
9	KH-24-108-06-S	2	S	Ring Set, Std & .010
9	KH-24-108-07-S	2		Ring Set, Std & .020
10	KH-24-018-01	4	S	Retainer, Piston Pin
11	KH-24-012-16-S	1		Camshaft
12	KH-24-018-09-S	1		Ring, Retainer
13	KH-12-422-09	AR	S	Shim, Camshaft, .0320 red
13	KH-12-422-13	AR	S	Shim, Camshaft, .0400 black
13	KH-12-422-07	AR	S	Shim, Camshaft, .0280 white
13	KH-12-422-08	AR	S	Shim, Camshaft, .0300 blue
13	KH-12-422-10	1	S	Shim, Camshaft, .0340 yellow ..
13	KH-12-422-11	AR	S	Shim, Camshaft, .0360 green ...
13	KH-12-422-12	AR	S	Shim, Camshaft, .0380 gray
14	KH-M-931010-S	1		Washer, Flat 8mm
15	KH-28-032-09-S	1		Seal, Governor Cross Shaft
16	KH-24-468-15-S	1		Washer, Plain
17	KH-24-144-38-S	1	/P	Shaft, Governor Cross
	KH-24-755-113-S	1	S	Gasket Set



5252E Tractor S/N 1J015G & After
Cylinder Head, Valves and Breathers

Page 15 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	KH-24-559-11-S	1		Kit, Valve Cover (Includes 2-5) ...
2	KH-M-0651030	4	/P	Screw, Hx. Flng, M6 x 1.0 x 30 ...
3	KH-25-294-13-S	1		Kit, 1/4" Fitting (45°)
4	KH-25-294-11-S	1		Kit, 1/4" Fitting (90°)
5	KH-24-153-28-S	1	S	O-Ring, Valve Cover
6	KH-24-445-01	1	S	Strap, Lifting
7	KH-12-755-03	4	/P	Kit, Retainer
8	KH-12-173-01	4	/P	Cap, Valve Spring
9	KH-24-089-02	4	/P	Spring, Valve
10	KH-235011-S	4	/P	Retainer, Spring
11	KH-66-032-05-S	2	/P	Seal, Valve Stem
12	KH-24-318-65-S	1	S	Head Assembly, #1 Cylinder
13	KH-24-017-01	2	/P	Valve, Intake (Std.)
13	KH-24-017-02	2		Valve, Intake (.25mm)
14	KH-24-016-01	2	/P	Valve, Exhaust (Std.)
14	KH-24-016-02	2		Valve, Exhaust (.25mm)
15	KH-24-755-66	1	/P	Kit, Valve Train (Includes 17,20,21)
16	KH-25-351-04-S	4	S	Lifter, Valve
17	KH-24-411-05	4	/P	Rod, Push
18	KH-24-841-03-S	2	/P	Kit, Gasket, Cylinder Head
19	KH-24-318-66-S	1	S	Head Assembly, #2 Cylinder
20	KH-25-186-01	4	/P	Arm, Rocker
21	KH-24-599-01	4	S	Pivot, Rocker Arm
22	KH-12-086-16	8	S	Screw, Hex Flange M10-1.5 x 90
23	KH-M-640034-S	2	/P	Screw, Hx. Flng, M6 x 1.0 x 34 ...
24	KH-24-755-140-S	1	/P	Cover, Valve - Oil Fill (Includes 22 and 24)
25	KH-24-755-46-S	1		Cap Assembly, Oil Fill (Includes 26)
26	KH-25-153-02-S	1		O-Ring
27	KH-24-402-03	1	/P	Reed, Breather
28	KH-66-018-04-S	1	/P	Retainer, Breather Reed
29	KH-M-0545010	1	/P	Screw, Hex Flange M5 x 0.8 x 10
30	KH-24-050-01	1	S	Filter, Breather
31	KH-24-033-01	1	/P	Kit, Breather (Includes 32, 33)
32	KH-24-041-51-S	1	S	Gasket, Breather
33	KH-24-096-86-S	1	S	Cover, Breather
34	KH-M0645020-S	4		Screw, Hex Flange M6 x 1.0 x 20
35	KH-25-237-14-S	1	/P	Clamp, Breather
36	KH-24-326-26-S	1	S	Hose, Breather
	KH-24-755-147-S	1		Kit, Cylinder Head Repair (Includes 7-11,13,14,20,21,23) not shown)




5252E Tractor S/N 1J015G & After
Dash Panel and Steering Wheel

Page 17 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	603-04305	1	/P	Bracket, Throttle Cable
2	629-04112	1		Wire Harness, Dash
3	631-0076	1		Boot, Steering Shaft
4	631-04007B	1	S	Dash
5	703-05132A	1	/P	Bracket, Throttle Mtg.
6	710-0604A	2	/P	Screw, Hex Wash. Hd. Tapp 5/16-18 x .625
7	710-0924	4	/P	Screw, Pan Hd., 1/4-20 x .75
8	710-3013	5	/P	Screw, Hex Cap, 1/4-20 x .5 GR5
9	712-0116	1	S	Nut, Hex Insert Jam Lock, 3/8-24 ..
10	712-0237	1	S	Nut, Hex Lock, 5/16-24
11	712-0292	2	/P	Nut, Speed, 1/4-20
12	723-3013	1	S	Washer, Friction, .515 x 1.5 x .12 ..
13	725-04022	1	S	Meter, Hour/Indicator
14	725-04076	1	S	Switch, PTO
15	725-04241	1		Gauge, Fuel
16	725-04259	1	S	Gauge, RPM
17	725-2017	1		Plug
18	725-3274	1		Switch, Headlight
19	725-3277	1	S	Switch, Ignition
20	725-3279B	1	/P	Switch, Hazard
21	731-05066	1		Panel, Meter
22	731-3209	1		Steering Wheel, Soft Grip
23	731-3210	1		Cover, Steering Wheel
24	731-3298	1		Handle, Throttle
25	731-3344	1		Panel, Dash Insert
26	731-3372	1	S	Extension, Dash
27	736-0255	2	S	Washer, Belleville, .51 x 1.14 x .04
28	736-0329	3	S	Washer, Lock, 1/4
29	736-04062	1	S	Washer, Flat, .344 x 1.5 x .1
30	736-0331	5	/P	Washer, Belleville, .39 x 1.13 x .062
31	736-3072	1	/P	Washer, Flat, .38 x .93 x .110 Hdn
32	732-04288	1		Spring, Torsion
33	738-04170	1		Screw, Shoulder, .374 x .56
34	759-3950	1	S	Key Set, Ingition
35	736-0514	1	S	Washer, Flat, .885 x 1.85 x .06
36	748-0176	1		Bearing, Flange, .63ID x .62Lg

5252E Tractor S/N 1J015G & After
Deck Assembly, 60 inch

Page 18 of 71



5252E Tractor S/N 1J015G & After
Deck Assembly, 60 inch

Page 19 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	603-04121-0716	1		Axle, Caster, LH
2	603-04119-0716	1		Axle, Caster, RH
3	603-0783-0716	2		Wheel Yoke, Rear
4	603-04129-0716	1		Bracket, Mounting
5	703-05192A-0716	1		Bracket, Gear Box
6	703-05180-0716	1		Bracket, Caster LH Outer
7	603-04118B-0716	2		Wheel Yoke, Front
8	703-3247-0716	1		Guard, Finger
9	703-3248-0716	1	S	Baffle, Rear Inner
10	703-3272-0716	1	/P	Cover, Belt (R.H.)
11	703-3273-0716	1		Cover, Belt (L.H.)
12	703-3274-0716	1		Bracket, Belt Cover Mtg.
13	703-3275-0716	1		Bracket, Belt Cover Mtg.
14	703-3276-0716	1		Bracket, Belt Cover Mtg. LH
15	703-05182-0716	1		Bracket, Caster RH Outer
16	703-3596-0716	1		Bracket, Front Roller
17	703-3889B-0716	1	S	Deck
17	777D07876	1		Label, 60" Not shown
17	777S30503	1	/P	Label, Safety Not shown
17	777S30015	1		Label, Danger L.H. Side Not shown
18	603-04078	1		Bracket, Caster LH Inner
19	710-04191	4	/P	Screw, Carriage, 1/2-13 x 2.0 GR5..
20	710-1638	4	/P	Screw, Carriage, 1/2-13 x 4.5 GR5..
21	710-1649	2	/P	Screw, Carriage, 3/8-16 x 4.25 GR5
22	710-3001	4	/P	Screw, Hx Cap Lck 3/8-16 x .88 GR5
23	710-3168	4	/P	Carriage, Bolt 3/8-16 x 1.0
24	710-3178	18	/P	Carriage, Bolt 3/8-16 x .75
25	710-0376	5	/P	Screw, Hex Cap, 5/16-18 x 1 GR5 .
26	711-0415	2	S	Pin, Clevis, 3/8 x 1.75
27	711-3314	1	S	Pin, Roller 1/2 x 7.31
28	712-0431	28	S	Nut, Flange Lock 3/8-16
29	712-3083	8	/P	Nut, Hex Nylon Lock 1/2-13 GR8
30	714-0115	1	S	Pin, Cotter 1/8 x 1.0
31	714-0145	2	S	Pin, Internal Cotter
32	726-0211	5	S	Nut, "U" 5/16-18
33	726-3045	2	/P	Plug, Button
34	731-05679	1		Roller, Front
35	731-3257	1	/P	Deflector, Chute
	777S30145	1	S	Label, Danger
36	732-0939	1	/P	Spring, Torsion
37	734-3195	4		Caster, Wheel w/Bearings
	741-3090	8	/P	Bearing, Flange
38	703-05181	1		Bracket, Caster RH Inner
39	736-0362	2	/P	Washer, Flat, .33 x 1.25 x .06 Hd ...
40	737-3000	2	S	Fitting, Lube
41	741-0339	4	S	Bearing, Flange, .754 ID
42	747-3384	1	/P	Rod, Deflector Chute
43	750-3222	4	/P	Axle, Caster Wheel
44	750-3235	2	/P	Spacer, .505 x .75 x 3.31Lg.
45	710-3008	2	/P	Screw, Hex Cap, 5/16-18 x .75 GR5
46	721-04041	1	S	Adapter, Water Nozzle
47	737-04003C	2	S	Nozzle, Deck Water
48	712-0641	2	S	Nut, Hex, M16-1.5


5252E Tractor S/N 1J015G & After
Deck Assembly, 60 inch

Page 20 of 71

Ref #	Part Number	Qty	S/P/F	Description
49	736-0760	2	S	Washer, Lock

5252E Tractor S/N 1J015G & After
Deck Drive, 60 inch

Page 21 of 71




5252E Tractor S/N 1J015G & After
Deck Drive, 60 inch

Page 22 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	603-0848A-0716	1	/P	Bracket, Idler
2	618-3129C	3	S	Assembly, Spindle (Includes Ref. Nos. 32 thru 35)
3	710-0347	1	/P	Screw, Hex Cap 3/8-16 x 1.75 GR5
4	710-0395	1	/P	Screw, Hex Cap 5/16-18 x 2.25 GR5
5	710-3005	2	/P	Screw, Hex Cap 3/8-16 x 1.25 GR5
6	710-1260A	12	/P	Screw, Hex Wash Hd Tapp 5/16-18 x .75
7	710-1336A	3	/P	Bolt, Spindle, 3/4-16 x 4.25
8	710-0521	1	/P	Screw, Hex Cap 3/8-16 x 3.0 GR8
9	703-05658	1	/P	Plate, Idler Support
10	712-0290	1	/P	Nut, Hex Lock, 7/16-14
11	712-0417A	1	/P	Nut, Hex Flanged 5/8-18
12	712-0429	1	S	Nut, Hex Nylon Lock 5/16 -18
13	712-0431	5	S	Nut, Flange Lock 3/8-16
14	712-3078	3	/P	Nut, Hex Flange, 3/4-16
15	714-0126	1	S	Key, Hi-Pro
16	717-04036	1	S	Drive, Right Angle
18	732-0850	1	S	Spring, Extension 6.14" Lg.
19	736-0258	2	/P	Washer, Flat .385 x 1.0 x .135
20	736-0354	1	/P	Washer, Flat, .39 x .75 x .105
21	736-0322	1	/P	Washer, Flat, .45 x 1.25 x .164
22	736-04167	1	/P	Washer, Flat 1.063 x 2.5 x .16
23	737-3000	4	S	Fitting, Lube
24	738-3005A	1	S	Bolt, Shoulder .68" Dia. x 1.59
25	759-04013	3	/P	Blade, High Lift 20.5" Lg.
26	748-3065A	6	/P	Spacer, Deck Spindle
27	748-3087	1	/P	Spacer, Idler
28	754-3103	1	S	Belt, "V" 133" Lg.
29	756-3062	2	/P	Pulley, Flat Idler
30	756-3096	3	/P	Pulley, "V"
31	756-3098	1		Pulley, Drive
32	721-3018A	6	S	Seal, Oil
33	741-04129	6	S	Bearing, Cone
34	741-04130	6	S	Cup, Bearing
35	750-04409	3	/P	Spacer, Bearing
36	712-3046	1	/P	Nut, Hex Jam, 5/16-18 Lock
37	738-3056	1	S	Screw, Shoulder, 1/2 x 2.5
38	750-0535	1	S	Spacer, .38 ID x .625 OD x .21
39	710-3251	1	/P	Screw, Socket Hd. 5/16-18 x 1.75 GR5
40	712-0429	1	S	Nut, Hx Insert Lck, 5/16-18 Gr5
41	716-0111	1	/P	Ring, Retaining, (.875 Shaft)
42	717-04029	1	S	Shaft, Deck Drive

5252E Tractor S/N 1J015G & After
Deck Lift Linkage


Page 23 of 71



5252E Tractor S/N 1J015G & After
Deck Lift Linkage

Page 24 of 71


Ref #	Part Number	Qty	S/P/F	Description
1	603-04049	1	S	Clevis, Adjustment, 1/2 -13 x 4.76
2	603-0953-0637	1	/P	Bracket, Front Hanger LH
3	603-0954-0637	1	/P	Bracket,, Front Hanger RH
4	603-0955-0637	1	/P	Bracket, Rear Hanger LH
5	603-0956-0637	1	/P	Bracket, Rear Hanger RH
6	603-0957-0637	2	/P	Link, Deck Lift
7	603-0958-0637	1	/P	Link, Fixed
8	603-0959	1	S	Shaft. Lift
9	603-0960-0637	1	/P	Arm, Lift
10	603-0979	1		Plate, Lift Crank
11	703-4112A-0637	2		Brace, Deck Side
12	710-1807	2	/P	Screw, Hex Cap, 1/2-13 x 4.5 GR5
13	710-3181	14	/P	Screw, Hex Cap, 1/2-13 x 1.5 GR5
14	711-04343	1		Pin, Clevis, .625 x 2.18
15	711-0310	2	S	Pin, Clevis, .5 x 1.18
16	711-04031	1	S	Turn Buckle, Hex Adjustment
17	711-1622	1		Clevis, Check Chain
18	711-1643	2	/P	Pin, Clevis, 3/4 x 2.5
19	711-1728	1	S	Clevis, Chain
20	711-1739	2	S	Pin, Hanger Rod Mounting
21	712-3016	2	/P	Nut, Hex Insert Lock, 5/8-11
22	712-3022	10	/P	Nut, Hex Center Lock, 1/2-13
23	712-3048	1	S	Nut, Hex Jam, 1/2-13 GR5
24	714-0117	2	/P	Pin, Internal Cotter
25	714-0143	2	S	Pin, Klik
26	714-0145	4	S	Pin, Internal Cotter
27	715-0118	2	S	Pin, Spirol, 5/16 x 1.75
28	738-0744A	2	S	Screw, Shoulder, .625 x.36: 1/2-13
29	741-0170	2	S	Bearing, Flange w/Flats
30	747-3483	1	S	Rod, Front Hanger
31	747-3484A	1	/P	Rod, Crank Lift
32	750-3007	2		Spacer, .52 x .87 x 1.57



5252E Tractor S/N 1J015G & After
Engine and Drive Shaft

Page 26 of 71


Ref #	Part Number	Qty	S/P/F	Description
	629-04114	1		Harness, Engine Not shown
1	603-04180	1	S	Shield, Heat
2	703-05123-0637	1	/P	Plate, Baffle LH
3	730-05124-0637	1		Plate, Baffle, RH
4	703-05211-0637	1	/P	Plate, Air Baffle
4	777S30631	1		Graphic, Battery Warning Not shown
5	703-05215-0637	1	/P	Plate, Enging Mounting
6	703-05456	1	S	Cover, Flywheel
7	710-0237	1	/P	Screw, Hex Cap, 5/16-24 x .625 GR5
8	710-0299	2		Screw, Hex Cap, 1/4-28 x 1.0 GR5
9	710-0357	2		Screw, Square Hd. Set, 3/8-16
10	710-0514	4	/P	Screw, Hex Cap, 3/8-16 x 1.0 GR5
11	710-0539	4	/P	Screw, Hex Cap, 3/8-24 x 1.75 GR5
12	710-0599	4	/P	Screw, Hex Wash Hd Tapp 1/4-20 x .5
13	710-0607	2	/P	Screw, Hex Wash Hd Tapp 5/16-18 x .5
14	710-1260A	6	/P	Screw, Hex Wash Hd Tapp 5/16-18 x .75
15	710-1376	2	/P	Screw, Hex Cap, M8-1.25 x 16 GR8
16	710-3038	4	/P	Screw, Hex Cap, 5/16-18 x .875 GR5
17	710-3218	4		Screw, Socket Hd Cap, 1/4-20 x .62 GR8
18	712-04063	4	/P	Nut, Hx. Insert Flange Lck, 5/16-18 GRF
19	712-04065	4	/P	Nut, Hx. Insert Flange Lck, 3/8-16 GRF
20	712-3054	4	/P	Nut, Hex Lock, 3/8-24 GRB
21	714-0118	1	/P	Key, Sqare, 1/4 x 1.5
22	717-04112	1	S	Shaft, Drive
23	718-04068	1	S	Bushing, D Type
24	718-04069	1	S	Flywheel
25	723-3061	1		Seal, Heat Baffle 90 in.
26	725-0157	3	/P	Tie, Cable
27	725-3281	1		Wire, Battery Pos.
28	725-3282	1		Wire, Battery Neg.
29	726-0205	7	/P	Clamp, Hose
30	726-0209	1	/P	Tie, Cable
31	735-0226	3		Grommet
32	746-04015	1		Cable, Choke Control
33	746-04061	1		Cable, Throttle Control
34	751-10002A	1	/P	Muffler
35	751-10054	1	/P	Sleeve, Fuel Line
36	751-10055	1	S	Fitting, Reducer, 5/16 - 1/4
37	751-3130	1		Fuel Line 5/16 ID 65 in.
38	751-10517	1	S	Drain, Engine Oil
39	KH-25-072-04	4	/P	Stud, M8 - 1.25 x 33MM
40	KH-24-041-02	2	S	Gasket, Exhaust
41	712-3086	4	/P	Nut, Hex, M8 x 1.25
42	KH-24-050-09	1		Filter, Fuel
	737-3030A	1	/P	Engine Oil, quart Not shown



5252E Tractor S/N 1J015G & After
Engine controls

Page 28 of 71


Ref #	Part Number	Qty	S/P/F	Description
1	KH-M-0547050	1	/P	Nut, Hex Lock M5 x 0.8
2	KH-24-089-03	1		Spring, Choke Return
3	KH-M-545016-S	3	/P	Screw, Hex Flange M5 x 0.8 x 16
4	KH-M-645016-S	4	/P	Screw, Hex Flange M6 x 1.0 x 16
5	KH-24-126-56	1	S	Bracket, Control
6	KH-X-20-1-S	1		Washer, Lock
7	KH-M-541050-S	1		Nut, Hex Flange
8	KH-24-468-01	3		Washer , Plain 5.5mm
9	KH-24-090-07	1	/P	Lever, Throttle Actuator
10	KH-12-237-01	2		Clamp, Cable
11	KH-24-090-13	1		Lever, Throttle Control
12	KH-M-446030-S	1	/P	Nut, Hex M4 x 0.7
13	KH-M-401030-S	1		Screw, Hex Cap M4 x 0.7 x30
14	KH-24-079-21-S	1	/P	Linkage, Choke
15	KH-24-090-05	1		Lever, Choke
16	KH-41-468-03	1		Washer, Spring 1/4"
17	KH-M-0545020	1	/P	Screw, Hex Flange M5 x 0,.8 x 20
18	KH-24-089-51-S	1	/P	Spring, Throttle Limiter
19	KH-24-089-46-S	1		Spring, Governor
20	KH-24-211-03-S	1		Screw, Round Hd. Square Neck
21	KH-24-090-33-S	1	S	Lever, Governor
22	KH-M-0641060	1	S	Nut, Hex Flange M6 x 1.0
23	KH-25-158-08	1	/P	Bushing, Linkage Retaining
24	KH-24-089-01	1		Spring, Linkage
25	KH-25-158-11	1	/P	Bushing, Linkage Retaining
26	KH-24-079-01	1		Linkage, Throttle



5252E Tractor S/N 1J015G & After
Fender and Running Board

Page 30 of 71


Ref #	Part Number	Qty	S/P/F	Description
1	631-04031	1	S	Cover, Fender, LH
2	631-04107	1		Cover, Fender, RH
3	703-05105-0637	1	/P	Bracket, Running Brd Mtg. RH
4	703-05113-0637	1	/P	Bracket, Running Brd Mtg. LH
5	703-05199-0716	1		Running Board
	777S32332	1		Graphic, Instruction
	777S32274	1		Graphic, Warning
6	703-05306A	1	S	Bracket, Lift Float Gate
7	703-05307A	1		Bracket, Shift Gate, Hi-Lo
8	710-0602	2	/P	Screw, Hex Wash. Hd. Tapp 5/16-18 x 1.0
9	710-0895	4		Screw, Hex Wash. Hd, Tapp 1/4-15 x .75
10	710-0971	2		Screw, Pan Hd. 5/16-18 x 1.0 ..
11	710-1242	8	/P	Screw, Truss Phillips Hd. 5/16-14 x .75
12	710-1260A	4	/P	Screw, Hex Wash. Hd. Tapp 5/16-18 x .75
13	710-3013	6	/P	Screw, Hx. Cap, 1/4-20 x .5 GR5
14	712-0324	6	/P	Nut, Hx. Insert Lck, 1/4-20 GR8
15	725-3273	1		Switch, PTO Reverse
16	726-0211	2	S	Nut, Speed, 5/16-18
17	731-05089	1	S	Fender
	777D07729	1	/P	Graphic, Power Shaft
	777S32286	1		Graphic, Warning
18	735-0275	1		Pad, Floor - LH
19	735-0276	1		Pad, Floor - RH
20	736-3090	6	/P	Washer, Flat, .26 x .72 x .06 ...



5252E Tractor S/N 1J015G & After
Frame

Page 32 of 71


Ref #	Part Number	Qty	S/P/F	Description
1	603-0961B-0637	1		Frame
2	703-05031-0637	1	/P	Bracket, Front Seat Mount
3	703-05714-0637	1		Bracket, Fitting Mtg.
4	703-05737-0637	1		Shield, Drive Shaft
5	703-05741	1		Keeper, Belt
6	703-05743-0637	1		Bracket, Aux. Pump Mtg.
7	703-05748-0637	1		Shield Lower Drive Shaft
8	703-05771A-0637	1	/P	Plate, Filter Mounting
9	703-4124A-0637	1		Bracket, Running Board Mtg.
10	703-4125A-0637	1		Bracket, Running Board Mtg.
11	710-0473	3	/P	Screw, Truss Hd. Mach. #10-24 x .5
12	710-0607	1	/P	Screw, Hex Wash. Hd Tapp 5/16-18 x .5
13	710-1194	3		Screw, Hex Mach. #10-24 x 1.0 GR5
14	710-1260A	25	/P	Screw, Hex Wash. Hd. Tapp, 5/16-18 x .75
15	710-3005	2	/P	Screw, Hex Cap, 3/8-16 x 1.25 GR5
16	710-3015	4	/P	Screw, Hex Cap, 1/4-20 x .75 GR5
17	712-04064	3	/P	Nut, Hex Nylon Flange Lock, 1/4-20 GRF
18	712-03000	2		Nut, Hex Lock, 3/8-20 GrB
19	718-04129	1	S	Bushing, Tapered
20	718-04130	1	S	Pump, Aux. Hydraulic
21	726-0211	4	S	Nut, U Speed, 5/16-18
22	726-0475	1		Clamp
23	736-0329	2	S	Washer, Lock, 1/4
24	736-0722	3	S	Washer, Lock, #10
25	738-0572	1	S	Screw, Shoulder, .374 x 1.16
26	754-04086	1	S	Belt, HTS, 5 x 25 x 500
27	756-04176	1	S	Pulley, 52T Cog
28	703-05782	1	/P	Bracket, Hood Latch Mtg.
29	710-3025	2	/P	Screw, Hex Cap, 5/16-18 x .625 GR5
30	712-04063	2	/P	Nut, Hex Flange Insert Lock, 5/16-16 GrF



5252E Tractor S/N 1J015G & After
Front Axle

Page 34 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	703-05204-0637	2		Bracket, Axle Mounting
2	603-0721	1		Pin, Pivot Axle
3	603-0908B-0637	1	/P	Spindle Assembly, Steering LH
4	603-0909A-0637	1	/P	Spindle Assembly, Steering RH
5	619-3078A	2	S	Hub Assembly
5	741-3116	4		Bearing, Ball
6	703-05188	1	S	Bracket, Cylinder Mounting
7	710-04208	4		Screw, Hex Cap, w/Patch M12-1.75 x 25 GR8
8	710-1808	8		Bolt, Lug, M12-1.75 x 14 GR8.8
9	710-3118	1	/P	Screw, Hex Cap Lock 3/8-16 x 1.0 GR5
10	710-3126	2	/P	Screw, Hex Cap Lock 1/2-13 x 1.0 GR5
11	710-3181	10	/P	Screw, Hex Cap 1/2-13 x 1.5 GR5
12	712-04065	1	/P	Nut, Hx Insert Flange Lk, 3/8-16 GrF (Replaces 712-3005)
13	712-3016	4	/P	Nut, Hex Insert Lock 5/8-11 GR5
14	712-3083	8	/P	Nut, Hex Insert Lock, 1/2-13 GR8
15	712-3103	2		Nut, Hex Flange Lock, M12 x1.75
16	712-3104	1		Nut, Hex, M12 x 1.75 RH Thrd ..
17	712-3105	1		Nut, Hex, M12 x 1.75 LH Thrd ...
18	717-3502	1	S	Cylinder, Steering
19	719-3163	1		Axle, Pivot
20	721-0526	2		O-Ring, 1.374 x .139
21	723-0462	1		Ball Joint, RH Thrd
22	723-0463	1		Ball Joint, LH Thrd
23	736-0746	2		Washer, Flat, .66 x 1.94 x .25
24	736-0748	4		Washer, Flat, 1.25 x 1.94 x .063
25	736-0869	2		Washer, Flat, 1.25 x 2.25 x .040
26	736-3027	2		Washer, Flat, .531 x 1.75 x .09
27	737-3000	5	S	Fitting, Lube, 3/6 Drive
28	738-04049	2	S	Screw, Shoulder, .75 x 1.03
29	741-3110	4		Bearing, Sleeve, 1.25x1.5x1.25
30	741-3115	2		Bearing, Thrust, 1.25 x 1.94 x .78
31	747-3421	1		Rod, Tie
32	750-04375	2		Spacer, .501 x .75 x .775
33	736-0272	8	S	Washer, Flat, .51 x 1.0 x .06




5252E Tractor S/N 1J015G & After
Fuel System

Page 36 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	KH-25-111-34-S	1		Line, Fuel 24 length"
2	KH-25-237-14-S	2	/P	Clamp, Hose
3	KH-24-853-91-S	1		Kit, Carburetor w/Gasket (Includes 4,6)
4	KH-24-041-06	1	/P	Gasket, Air Cleaner Base
5	KH-24-041-53-S	1		Gasket, Carburetor
6	KH-M-651025-S	2		Screw, Hex Flange, M6 x 1.0 x 25
7	KH-24-050-09-S	1	S	Filter, Fuel
	KH-24-757-03-S	1	/P	Kit, Carburetor Repair (Not Illustrated)
	KH-24-757-07	1		Kit, Choke Repair (Not Illustrated)
	KH-24-757-02-S	1	/P	Kit, Float Repair (Not Illustrated)
	KH-24-755-130-S	1		Kit, High Altitude (Not Illustrated)
	KH-24-757-09-S	1		Kit, Repair - Accel. pump seal & bushing (not illustrated)
	KH-24-757-08-S	1		Kit, Repair - Accelerator pump diaphragm (not illustrated)
	KH-24-757-01	1	/P	Kit, Solenoid (Not Illustrated)
	KH-24-518-24-S	1		Lead, Ground (Not Illustrated)

5252E Tractor S/N 1J015G & After
Fuel Tank


Page 37 of 71



5252E Tractor S/N 1J015G & After
Fuel Tank

Page 38 of 71


Ref #	Part Number	Qty	S/P/F	Description
1	710-3119	4	/P	Screw, Hex Cap, Lock 3/8-16 x .75 GR5
2	736-0262	7	/P	Washer, Flat, .385 x .87 x .092
3	751-3124B	1	S	Cap, Fuel
4	751-10099	1	S	Sensor, Fuel Level
5	751-3212	1		Tank, Fuel



5252E Tractor S/N 1J015G & After
Hood, Grill and Side Panels

Page 40 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	625-04004	1	S	Headlight Assembly
1	725-04084	2	S	Bulb Assembly, Headlight
2	703-05143-0637	1	/P	Shield, Running Board LH
3	703-05145-0637	1	/P	Shield, Running Board RH
4	703-05652-0637	1		Bracket, Hinge, RH
5	703-05653-0637	1		Bracket, Hinge, LH
6	703-05655-0637	1		Bracket, Hood Mounting
7	703-3394	1	S	Screen, Intake
8	703-3764	2		Bracket, Panel Mtg.
9	703-3765	1		Shield, Lower Heat
10	710-04164	1	/P	Screw, Hex Wash Hd, #8-18 x .375
11	710-0473	6	/P	Screw, Truss Hd, 10-24 x .5
12	710-0599	6	/P	Screw, Hex Wash Hd Tapp 1/4-20 x .5
13	710-0607	4	/P	Screw, Hex Wash Hd Tapp 5/16-18 x .5
14	710-0751	4	/P	Screw, Hex Cap 1/4-20 x .62 GR5
15	710-0895	6		Screw, Hex Wash. Hd. 1/4-20 x .75
16	710-1220	8	/P	Screw, Truss Phil. Hd. 12-16 x .75
17	710-3015	2	/P	Screw, Hex Cap, 1/4-20 x .75 GR5
18	710-3170	4		Stud, Cylinder, 5/16-18 Thrd
19	712-0272	6	/P	Nut, Hex Sems, 10-24
20	712-04063	4	/P	Nut, Hex Insert Flange Lock, 5/16-18
21	712-04064	2	/P	Nut, Hex Insert Flange Lock, 1/4-20
22	712-04065	2	/P	Nut, Hex Insert Flange Lock, 3/8-16
23	714-0104	1	S	Pin, Internal Cotter
24	726-0233	4	/P	Nut, Push, .25 ID
25	727-04142	2		Cylinder, Gas Spring
26	731-04211	1	S	Bezel, Headlight
27	731-05161	1	S	Cover, Hood
28	759-04210	1	/P	Hood Service Kit (contains 931-06889, 726-0233, 710-1242, 721-04162 and installation instructions)
28	931-06889	1		Hood Replaces 731-05301
28	726-0233	4	/P	Push Nut .25 x .50 not shown
28	710-1242	4	/P	Screw, Hi Low 5/16-14 x .75 not shown
28	721-04162	2		Foam Strip not shown
28	777D09638	1		Graphic, Hood RH not shown
28	777D09639	1		Graphic, Hood LH not shown
28	777D07727	1	/P	Graphic, Model 5252 LH not shown
28	777D07728	1	/P	Graphic, Model 5252 RH not shown
29	732-04281A	1	/P	Spring, Torsion
30	736-0272	2	S	Washer, Flat, .51 x 1.0 x .060
31	736-3090	2	/P	Washer, Flat, .26 x .72 x .060
32	738-0380	2	S	Screw, Shoulder, .5 x .27 Lg 3/8-16
33	747-1323A	1		Rod, .25 x 4.55
34	783-04714	1	S	Plate, Latch
35	783-4717A	1		Bracket, Latch Pivot




5252E Tractor S/N 1J015G & After
Hydraulics

Page 42 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	710-0607	1	/P	Screw, Hex Wash Hd Tapp, 5/16-18 x .5
2	712-3035	2	/P	Nut, Hex Jam, 9/16-18 GR5
3	725-0157	7	/P	Tie, Cable
4	726-04004	1		Clamp, Hose
5	726-0132	1	/P	Clamp, Adjustable Hose
6	727-04014	1		Hose, Lift Cylinder
7	727-04015	1		Tube, Cylinder Return
8	727-04079	1		Tube, U Return
9	727-04082	1		Tube, Return Tank
10	727-04083	1		Tube, Return
11	727-04096	1	S	Hose, Steering Pressure
12	727-04127	1		Hose, Aux. Pump-Filter
13	727-04129	2		Hose, Steering
14	727-04146	1		Hose, Steering - Tank
15	727-04150	1		Hose, Lift Inlet
16	727-3012	2	/P	Fitting, 90 Degree
17	737-04033	3	S	Fitting, 90 Degree Swivel
18	737-3111	1		Fitting, 90 Degree
19	737-04087	2		Fitting, Bulkhead
20	737-04101	1		Fitting, 90 Degree
21	737-04114	1		Fitting, 10 Orb:5/8 tube
22	737-04139	1		Fitting, 90Degree
23	737-3127	1		Fitting, 90 Degree

5252E Tractor S/N 1J015G & After
Hydrostatic Transmission

Page 43 of 71




5252E Tractor S/N 1J015G & After
Hydrostatic Transmission

Page 44 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	HG-52224	1	/P	Shaft, Pump Input
2	HG-2000022	4	/P	Ring, Wire Retaining
3	HG-2000038	1	/P	Ring, Retaining
4	HG-2000023	1	/P	Spacer
5	HG-2000032	1	/P	Bearing, Ball
6	HG-51092	1	/P	Seal, Lip
7	HG-2000037	1	/P	Seal, Lip
8	HG-2000014	1	/P	Arm, Trunnion
9	HG-2000015	1	/P	Guide, Slot
10	HG-2510096	1	/P	Housing Assembly
11	HG-50552	2	/P	Bearing Assembly, Thrust Ball
12	HG-2000024	2	/P	Washer, Block Thrust
13	HG-2000025	2	/P	Spring, Block
14	HG-2510014	1	/P	Kit, Pump Cylinder Block
15	HG-2000007	1	/P	Shaft, Motor
16	HG-70973	1		Kit, Center Section
17	HG-50641	2		Pin
18	HG-2000061	1	/P	Gasket, Center Section
19	HG-50203	1		Swashplate, Variable
20	HG-2510013	1	/P	Kit, Motor Cylinder Block
21	HG-70743	2	/P	Shock Valve
22	HG-9007314-0808	8	/P	Screw, Socket Head Cap
	HG-2510010	1	/P	Kit, Overhaul Seal

5252E Tractor S/N 1J015G & After
Ignition Electrical

Page 45 of 71




5252E Tractor S/N 1J015G & After
Ignition Electrical

Page 46 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	KH-54-755-09-S	1	S	Kit, 15 Amp Stator (Includes Ref. 2)
2	KH-M-548025-S	2	/P	Screw, Hex Cap M5 x 0.8 x 25 .
3	KH-24-584-01	2	S	Module, Ignition
4	KH-M-545020-S	4		Screw, Hex Flange M5 x 0.8 x 20
5	KH-24-025-48-S	1		Flywheel
6	KH-X-42-15	1	/P	Key
7	KH-12-468-03	1	/P	Washer, Plain 3/8"
8	KH-12-086-14	1		Screw, Hex Flange M10 x 1.5 x 46
9	KH-24-157-11-S	1		Fan
10	KH-25-086-47	4	/P	Bolt, Shoulder, M6 x 1.0 x 16 ...
11	KH-54-755-15	1	/P	Kit, Grass Screen (Includes Ref. Nos. 13-15)
12	KH-25-086-117-S	4		Screw, Hex Cap M4 x 0.7 x 25 .
13	KH-X-25-92	3		Washer, Plain 3/16"
14	KH-24-086-18	2		Screw, Phillips Hd. 11-16 x 7/8"
15	KH-25-403-05-S	1	S	Rectifier-regulator 15 Amp
16	KH-236602-S	1	S	Connector (3 Contact)
17	KH-235173	1		Clip, Cable
18	KH-X-25-63	1	/P	Washer, Plain 1/4"
19	759-3336	2	/P	Spark Plug
	KH-24-176-08	1	S	Harness, Wire (not illustrated)
	KH-24-126-137-S	1		Bracket, Ground Strap (not illustrated)
	KH-25-086-91-S	2	/P	Screw, Tapping, #10-16 x .5 (not illustrated)
	KH-25-454-03-S	1		Tie, Wire (not illustrated)

5252E Tractor S/N 1J015G & After
Lift Valve


Page 47 of 71



5252E Tractor S/N 1J015G & After
Lift Valve

Page 48 of 71


Ref #	Part Number	Qty	S/P/F	Description
1	603-04032	1	S	Handle, Lift
2	603-04033	1	S	Link, Valve
3	703-05090-0637	1		Bracket, Lift Valve Mounting
4	703-05038	1	S	Bracket, Handle Pivot
5	710-0514	2	/P	Screw, Hex Cap, 3/8-16 x 1.0 GR5
6	710-04370	2		Screw, Hex Cap 1/4-20 x 3.0 GR5
7	710-1260A	3	/P	Screw, Hex Wash, Hd Tapp 5/16-18 x .75
8	711-04214	1		Pin, Clevis, .25 x .9375
9	711-1614	1		Link, Valve
10	712-4065	2		Nut, Hex Flange Nylon Lock, 3/8-16 GRF
11	712-0298	1	S	Nut, Hex Jam, 1/4-20
12	712-0266	1	S	Nut, Hex Ctr Lock Jam, 3/8-16 ..
13	712-04064	3	/P	Nut, Hex Flange Nylon Lock 14-20 GRF
14	714-0127	1	/P	Pin, Cotter, 1/16 x .75
15	715-0120	1	S	Pin, Spirol, 3/16 x 1.0
16	718-3130	1		Valve, Hydraulic Lift
17	731-3321	1		Grip, Handle
18	736-0258	1	/P	Washer, Flat, .385 x 1.0 x .135
19	738-0137A	1	S	Screw, Shoulder, .34 x .285
20	738-0215A	1	/P	Screw, Shoulder, .498 x 2.99
21	741-0491	2		Bearing, Nylon Flange .5 ID
22	703-05545-0637	1		Link, Lift Valve Mounting
23	710-0564	1	/P	Screw, Hex Cap, 1/4-20 x 2.75 GR5



5252E Tractor S/N 1J015G & After
Oil Pan Lubrication

Page 50 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	KH-24-009-153-S	1		Plate, Closure Assembly (Includes 2-15)
2	KH-24-755-121-S	1	/P	Tube, Dipstick (Includes 2)
3	KH-24-038-10-S	1	/P	Dipstick
4	KH-24-043-12	1	/P	Kit, Governor Gear (Includes 5) ..
5	KH-12-380-01	1	/P	Pin, Governor Regulating
6	KH-24-448-02-S	1		Tab, Locking
7	KH-12-144-02	1		Shaft, Governor Gear
8	KH-52-032-08	1	S	Seal, Oil (PTO End)
9	KH-25-139-60-S	2	/P	Plug, Pipe 1/8"
10	KH-24-153-08	1		O-Ring
11	KH-24-393-51-S	1	/P	Oil Pump Assembly (Includes 12,13)
12	KH-24-153-01	1	/P	O-Ring, Oil Pick-Up
13	KH-24-381-04	1		Pick-Up, Oil
14	KH-M-0631005	2	S	Washer, Plain
15	KH-M-0645025	2	S	Screw, Hex Flange M6 x 1 x 25 ..
16	KH-12-050-08	1	S	Filter, Oil
17	KH-24-136-01-S	1		Nipple, Oil Filter
18	KH-25-099-24	1	S	Switch, Pressure
19	KH-24-086-16	9	S	Screw, Hex Flange M8 x 1.25 x 45
20	KH-24-086-17	1	S	Screw, Hex Flange M8 x 1.25 x 45




5252E Tractor S/N 1J015G & After
Pedestal

Page 52 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	603-04320	1	S	Tube Assy. Steering Column
2	603-04321	1	S	Shaft, Steering
3	603-04330	1		Rod, Parking Brake
4	703-05818	1		Bracket, Steering Mounting
5	703-05828-0637	1		Pedestal
6	703-3717	1		Bracket, Dash Mtg
7	703-3721	1		Bracket, Dash Mtg
8	710-0623	4	/P	Screw, Hex Wash, Hd Tapp 3/8-16 x .75
9	710-0642	4	/P	Screw, Hex Wash, Hd Tapp 1/4-20 x .75
10	710-0653	5	/P	Screw, Hex Wash, Hd Tapp 1/4-20 x .375
11	710-1690	4		Screw, Hex, M6-1 x 16 Hardened
12	710-3008	2	/P	Screw, Hex Cap 5/16-18 x .75 GR5
13	712-0292	2	/P	Nut, Speed, 1/4-20
14	710-04063	2	/P	Nut, Hex Insert Flange Lock, 5/16-18 GrF
15	714-0104	1	S	Pin, Internal Cotter
16	716-0101	1	S	Ring, Snap, .75 Dia
17	718-3155	1	S	Pump, Hydraulic Steering
18	731-3359	1		Lever, Parking Brake
19	732-0320	1	S	Spring, Extension
20	736-0343	2	/P	Washer, Flat, .33 x 1.25 x .12
21	741-0312	1	S	Bearing, Flg, .75 ID x 1.25 OD

5252E Tractor S/N 1J015G & After
PTO Drive

Page 53 of 71



5252E Tractor S/N 1J015G & After
PTO Drive

Page 54 of 71


Ref #	Part Number	Qty	S/P/F	Description
1	710-0650	2	/P	Screw, Hex Wash. Hd. Tapp. 5/16-18 x .875
2	710-1177	3	/P	Screw, Socket Hd. 5/16-18 x .75
3	710-04116	1	/P	Screw, 12 Pt. Wash. Hd. w/Patch 3/8-16 x 1.25
4	711-1325A	1	S	Shaft, 540 PTO
5	711-1683A	1	S	Shaft, Clutch Back
6	711-1684	1	S	Shaft, 2000 PTO
7	711-04420	1	S	Shaft, Input PTO
8	714-0128	1	/P	Key, Square, 1/4 x 1. 0
9	716-0180	2		Ring, Retaining
10	716-0181	1	/P	Ring, Retaining
11	716-0384	1		Ring, Retaining
12	716-0387	1		Ring, Retaining
13	716-0393	2		Ring, Retaining
14	716-04000	2	S	Ring, Retaining
15	717-3469	1		Gear, 540 PTO, 81T
16	717-3487	1		Gear, 2000 PTO , 61T
17	717-3492	1		Gear, Pinion, 540 PTO:14T
18	717-3494C	1	/P	Gear, Pinion, 2000 PTO:54T
19	717-3551	1	S	Gear, Pinion, 2000 PTO:34T
21	718-0681	1		Cover, 2000 PTO
22	718-04000	1	S	Adapter, PTO Output
23	718-04009	1	S	Clutch Assy. PTO
24	721-0504	1		Plug, Oil, 1.875 x .375
25	721-04094	1		Seal, Oil
26	721-0509	1		Seal, Oil
27	721-04002	1	S	O-Ring, 2.425 ID x .103
28	721-04124	1	S	Seal, Oil
29	721-04005	1	S	Seal, Oil
30	736-0570	1	S	Washer, Flat, .865 x 1.145 x .030 ..
31	736-04001	1	S	Washer, Thrust
32	738-04003	1	S	Spacer, Shoulder
33	741-1100	1		Bearing, Ball
34	741-3033A	3	S	Bearing, Ball
35	741-3037	2	S	Bearing, Ball
36	741-3057	2	S	Bearing, Ball
37	741-04034	2	S	Bearing, Ball
38	750-3365	1	S	Spacer, 15mm x 20mm x 14mm
39	750-04013	1	S	Spacer, .6 x 1.0 x 1.345
40	750-04020	1	S	Spacer, 1.004 x 1.375 x .25
41	716-04049	1	S	Ring, Retaining
42	736-0454	2	S	Washer, Flat, .915 x 1.37 x .010



5252E Tractor S/N 1J015G & After
Quick Reference

Page 56 of 71


Ref #	Part Number	Qty	S/P/F	Description
	759-3336	1	/P	Spark Plug
	KH-24-883-03-S1	1	/P	Air Filter & Pre Cleaner
	N/A	1		Pre Filter
	N/A	1		Air Filter
	KH-12-050-01-S	1	/P	Oil Filter
	KH-24-050-09-S	1	S	Fuel Filter
	KH-24-584-45-S	1	/P	Ignition Module
	KH-25-403-05-S	1	S	Voltage Regulator
	KH-24-559-11-S	1		Fuel Pump
	KH-24-757-03-S	1	/P	Carb Kit
	KH-24-757-01	1	/P	Carburetor Solenoid
	723-3014	1	S	Hydraulic Filter
	BS-492932S	1	/P	Hydro Filter
	754-04086	1	S	Aux. Pump Belt
	N/A	1		Fan Belt
	751-3124B	1	S	Fuel Cap
	759-3950	1	S	Ignition Keys
	725-3277	1	S	Ignition Switch Module
	725-04076	1	S	P.T.O. Switch
	725-3273	1		P.T.O. Reverse Switch
	725-3274	1		Headlight Switch
	725-04232	1		Brake Switch
	725-3167	1	S	Brake Switch
	725-3164A	1	S	Reverse Switch
	725-3167	1	S	Seat Switch
	725-3279B	1	/P	Hazard Switch
	725-1648	1	S	Starter Relay
	725-1648	1	S	P.T.O. Relay
	721-0342	1	S	Gasket use with 725-1648
	718-04009	1	S	P.T.O. Clutch
	KH-25-357-05-S	1	S	Engine Oil
	737-3121	1	/P	Transmission Fluid
	N/A	1		Front Axle Fluid



5252E Tractor S/N 1J015G & After
ROPS

Page 58 of 71


Ref #	Part Number	Qty	S/P/F	Description
1	603-04011	1		Rops. Upper
	777X41480	2		Decal, Reflective
2	603-04012	1		Rops, Lower
3	703-05032-0637	1	/P	Bracket, Rear Seat Mounting
4	703-05770-0637	2		Plate, Spacer
5	710-0514	8	/P	Screw, Hex Cap, 3/8-16 x 1.0 GR5
6	710-1260A	3	/P	Screw, Hex Wash. Hd. Tapp 5/16-18 x .75
7	710-04186	8	/P	Screw, Hex Cap Lock, 1/2-13 x 1.25 GR5
8	710-3038	4	/P	Screw, Hex Cap, 5/16-18 x .875 GR5
9	712-04065	8	/P	Nut, Hex Insert Flange Lock, 3/8-16 GRF
10	712-3066	2	S	Nut, Hex, 1/2-20 GR5
11	725-04266	2	S	Light, Hazard
12	726-0211	2	S	Nut, Speed, 5/16-18
13	731-0757	1		Conduit 12in.
14	736-0148	1	/P	Washer, Ext. Tooth Lock, 3/8
15	736-0185	8	S	Washer, Flat, .375 x .74x.063
16	736-0272	8	S	Washer, Flat, .51 x 1.0 x .060
17	736-0921	2	S	Washer, Lock, 1/2
18	736-3089	4	/P	Washer, Flat, .345 x 1.0 x .1



5252E Tractor S/N 1J015G & After
Seat

Page 60 of 71


Ref #	Part Number	Qty	S/P/F	Description
1	703-1812A -0716	1		Bracket, Seat Pivot
2	703-3208	1		Track, Seat - w/o Latch
3	703-3431	1	/P	Track, Seat - w/Latch
4	703-4149-0716	1	/P	Bracket, Seat Support
5	703-4151-0637	2	/P	Bracket, Seat Belt
6	710-1669	4		Screw, Pan Hd. Mach. 5/16-18 x 1.0
7	710-3005	4	/P	Screw, Hex Cap, 3/8-16 x 1.25 GR5
8	710-0376	6	/P	Screw, Hex Cap, 5/16-18 x 1.0 GR5
9	712-04063	10	/P	Nut, Hx Insert Flange Lk,
10	725-3167	1	S	Switch, Seat, N/O
11	732-0735	2	/P	Spring, Compression
12	735-04039	2		Cap, Spring
13	736-0343	2	/P	Washer, Flat, .33 x 1.25 x .12 .
14	738-0140	4	S	Screw, Shoulder, .435 x .178:5/16-18
15	750-0258	2	/P	Spacer, .315 x .75 x .375
16	750-04247	4		Spacer, .505 x .88 x .44
17	757-04005	1	S	Seat, High Back
	777D09646	1		Graphic, CubCadet, USA
18	757-3013	1		Belt Assembly, Seat
19	725-0154	1		Tie, Push Mnt. Cable



5252E Tractor S/N 1J015G & After
Starting System

Page 62 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	KH-M-0841080	1	S	Nut, Hex Flange M8 x 1.25"
2	KH-M-839080	2	S	Screw, Hex Flange M8 x 1.25 x 80
3	KH-25-098-09-S	1	S	Starter, Solenoid Shift Assembly (Includes 4-8)
4	KH-25-086-113-S	3		Screw, External Torx Hd.
5	KH-25-435-06-S	1	/P	Kit, Solenoid (Includes 4)
6	KH-25-755-33-S	1		Kit, Pinion Drive (Includes 7)
7	KH-25-141-05-S	1		Ring, Retainer
8	KH-25-221-01-S	1		Kit, Brush



5252E Tractor S/N 1J015G & After
Three Point Hitch

Page 64 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	603-04062-0637	1	/P	Plate, Cylinder Mounting
2	603-0964	1	S	Link Assembly, Upper
3	603-0965	2	S	Link, Lower
4	603-0970	1	S	Link, Fixed Lift
5	603-04333-0637	1		Bracket Ass'y., Lower Hitch
6	603-0972-0637	1	/P	Plate, Cylinder Mounting
7	603-0973	1	S	Link, Adjustable Lift
		1		603-0968 Link Rod RH Thrd.
		1		603-0969 Link Rod LH Thrd.
		1		711-1744 Turnbuckle
		1		712-04051 Jam Nut, M20 x 2.5 RH
8	603-0977	1		Chain Assembly, Check
		1		603-0974 Chain Link RH Thrd. ...
		1		603-0975 Chain Link Lh Thrd.
		1		603- 0976 Chain Rod, Adjust.
9	619-3095	1	S	Arm, Hitch Lift - LH
10	619-3096	1	S	Arm, Hitch Lift - RH
11	703-4137-0637	1	/P	Shield, PTO Shaft
12	703-4143-0637	1	/P	Bracket, Chain Mounting
13	710-04186	4	/P	Screw, Hex Cap Lock, 1/2-13 x 1.25 GR5
14	710-0514	11	/P	Screw, Hex Cap, 3/8-16 x 1.0 GR5
15	710-0599	5	/P	Screw, Hex Wash. Hd. Tapp 1/4-20 x .5
16	710-3168	4	/P	Screw, Carriage, 3/8-16 x 1.0
	777S30634	1		Graphic, Warning
17	710-3296	1		Screw, Hex Cap, 1/4-20 x .75 GR5
18	731-04114	1		Cover, PTO Shaft
19	711-0599	4	S	Pin, Clevis, .372 x 1.79
20	711-1105	4	/P	Pin, Klik
21	711-1733	1		Pin, Clevis, 19mm x 84mm
22	711-1743	2	S	Pin, Hitch, .75 OD
23	711-1750	1	S	Shaft, Hitch Rock
24	711-1753	2	S	Clevis, Chain
25	711-1761	2	S	Pin, Clevis, .75 x 1.938
26	712-0301	2	/P	Nut, Hex Jam, 3/4-10 GR5
27	712-0431	13	S	Nut, Hex Flange Lock, 3/8-16 GRF
28	714-0117	1	/P	Pin, Internal Cotter
29	714-0142	2	/P	Pin, Cotter, 3/16 x 1.5
30	714-0149B	4	S	Pin, Internal Cotter
31	715-0121	2	/P	Pin, Spirol, 1/4 x 2.0
32	716-04004	2	S	Ring, Retaining
33	717-3532A	1	S	Cylinder, Lift
34	736-0255	1	S	Washer, Belleville, .51 x 1.14 x .04
35	736-0315	2	/P	Washer, Flat, .76 x 1.5 x .12
36	736-0364	2	S	Washer, Lock, 3/4
37	737-3000	1	S	Fitting, Lube, 3/16 Drive
38	738-0143	1	/P	Screw, Shoulder, 3/8-16
39	741-04084	2	S	Bearing, Sleeve, 1.25 x 1.50 x 1.25
40	747-04122	1	S	Rod, Top Link Hanger
41	736-0185	8	S	Washer, Flat, .375 x .738 x .063
42	736-0272	4	S	Washer, Flat, .51 x 1.0 x .06
43	736-04177	4		Washer, Flat, .938 x 1.75 x .235
44	603-04332-0637	1		Bracket, Ass'y., Upper Hitch

5252E Tractor S/N 1J015G & After
Transmission Drive


Page 66 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	611-3033	1	S	Shaft, Axle RH
2	611-3034	1	S	Shaft, Axle LH
3	718-3116	1		Collar, Shift
4	618-3183	1	S	Collar Assembly, Diff Lock
5	703-05045	1	S	Bracket, Diff. Lock
6	710-0176	4	/P	Screw, Hex Cap, 5/16-18 x 2.75 GR5
7	710-0378	6	/P	Screw, Hex Cap, 5/16-18 x 2.5 GR5
8	710-0602	21	/P	Screw, Hex Wash. Hd. Tapp, 5/16-18 x 1.0
9	710-0817	12		Screw, Hex Wash. Hd. Tapp, 5/16-18 x 1.25
10	710-1880	8	/P	Screw, Hex Cap, w/Patch 5/16-18 x .75GR5
11	710-1633	1		Screw, Plug, M14 x 1.5 x .827
12	710-3006	1	/P	Screw, Set, 5/16-18 x .375
13	710-04035	4	/P	Screw, Shoulder .309 x .375: 1/4-20
14	711-1675	1	S	Shaft, Output, 11T
15	711-1676	1	S	Shaft, Cross, .625 x 3.95
16	711-04302	1	S	Shaft, Diff. Lock Actuator
17	711-04300	1	S	Shaft, Hi-Lo Actuator
18	711-04522	1	S	Shaft, Drive
19	712-0273	2	S	Nut, Hex Insert Lock, 5/16-24
20	714-0135	1	S	Key, Woodruff, 1/4 x 3/4
21	715-3010	4	/P	Pin, Dowel, .25 x .75
22	716-0114	1	S	Ring, Retaining
23	716-0127	1	/P	Ring, Snap
24	716-0180	4		Ring, Retaining
25	716-0194	4	/P	Clip, Rotor
26	718-04186	1		Gear, Hi-Lo Spline Coupling
27	716-04030	2	S	Ring, Retaining
28	717-0678	6	S	Pad, Brake
29	717-0682	2	S	Plate, Brake Puck
30	717-04271	1	S	Gear, Spur, 12T : Low
31	717-3535	1	S	Gear, Spur, 34T
32	717-04270	1	S	Gear, Spur, 19T
33	717-3537	1	S	Gear, Spur, 27T
34	717-3538	1	S	Gear, Spur, 56T
35	717-3541	1	S	Gear, Bevel, 16T
36	717-3542	1	S	Gear, Bevel, 16T Lock
37	717-3545A	2	S	Gear, Bevel, 10T Diff.
38	717-04132	1	S	Gear, Spiral Bevel, 13T
39	717-04133	1	S	Gear, Spiral Bevel, 54T
40	718-3148A	1	S	Cover, Differential
41	718-3149A	1	S	Cover, Differential Lock
42	718-3150	2	S	Block, Thrust
43	718-04080	1	S	Yoke, Diff. Lock Actuator
44	718-04185	1	S	Yoke, Shift, Hi-Lo
45	719-04001	1	S	Cover, Trans. Large
46	719-04002	1	S	Cover, Trans. Small
47	719-04153	1		Housing, Trans.
48	719-04004	1	S	Housing, Axle Inner - RH
49	719-04005	1	S	Housing, Axle Inner - LH
50	721-0381	2	S	Seal, Oil
51	721-0496	2		Seal, Oil
52	721-0519	1		Seal, Gland
53	721-3020A	2	S	Seal, Oil

5252E Tractor S/N 1J015G & After
Transmission Drive

Page 67 of 71


Ref #	Part Number	Qty	S/P/F	Description
54	721-04019	1	S	Plug, Oil
55	721-04020	1	S	Plug, Oil
56	732-04003	2	S	Spring, Torsion
57	732-04010	1	S	Spring, Compression, .845 x 1.0
58	732-04101	1	S	Spring, Compression, .24 x .563
59	736-0119	6	S	Washer, Lock, 5/16
60	736-04126	2		Washer, Flat, .597 x 1.0 x .04 ..
61	736-0371	2	/P	Washer, Flat, .343 x .88 x .062
62	736-0615	2		Washer, Thrust
63	736-0266	AR	S	Washer, Flat, 1.52 x 2.0 x .030
63	736-04095	AR	S	Washer, Flat, 1.52 x 2.0 x .005
63	736-04096	AR	S	Washer, Flat, 1.52 x 2.0 x .015
64	741-0343	4	S	Pin, Brake Actuating
65	741-0363	1	S	Bearing, Needle
66	741-0862	1	/P	Ball, Detent
67	741-1104	2	/P	Bearing, Ball
68	741-3033A	2	S	Bearing, Ball
69	741-3057	1	S	Bearing, Ball
70	741-3083	1		Bearing, Needle Thrust
71	741-04014	2	S	Bearing, Ball
72	741-04066	1	S	Bearing, Ball
73	750-3364	1	S	Spacer, 1.51 x 1.75 x 2.41
74	750-04024	1	S	Spacer, 1.515 x 2.039 x .335
75	750-04088	1	S	Spacer, 1.26 x 1.625 x .853
76	761-0215	4		Disc, Brake
77	761-04000	2	S	Yoke, Brake
78	761-04001	2	S	Bracket, Brake Anti Rotation
79	761-04002	2	S	Plate, Puck Retainer
80	761-04003	1	S	Arm, Brake Actuator - LH
81	761-04004A	1	S	Arm, Brake Actuator - RH
82	750-04413	1		Spacer, .573 x .938 x .832
83	750-04416	1		Plug, .437 x .16
84	736-0423	AR		Washer, Flat, 1.0 x 1.56 x .010
84	736-0424	AR	S	Washer, Flat, 1.0 x 1.56 x .020
84	736-0431	AR	S	Washer, Flat, 1.0 x 1.56 x .015



5252E Tractor S/N 1J015G & After
Transmission Mounting

Page 69 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	N/A	1		Transmission Assembly
2	603-04193	1		Link, Diff Lock Actuator
3	710-3071	4		Screw, Hex Cap 1/2-13 x 2.0 GR8
4	711-0701	1	S	Pin, Clevis, .25 x .50
5	712-3061	1	S	Nut, Hex Insert Lock, 3/8-24
6	712-3083	4	/P	Nut, Hex Insert Lock, 1/2-13
7	714-0104	1	S	Pin, Internal Cotter
8	731-05247	1	S	Fan, Transmission Cooling
9	736-3019	8		Washer, Flat, .531 x .1062 x .134 .
10	738-0689	1	S	Screw, Shoulder, 1/2 Dia. x .180 ..
11	725-0157	1	/P	Tie, Cable
12	723-3014	1	S	Filter, Oil
13	727-04128	1		Hose, Filter
14	618-04295	1	/P	Adapter, Oil Filter
15	737-04131	1		Fitting, 45° Elbow
16	737-04102	1		Fitting, 90° Elbow
17	726-0132	1	/P	Clamp, Adjustable Hose



5252E Tractor S/N 1J015G & After
Wheels

Page 71 of 71

Ref #	Part Number	Qty	S/P/F	Description
1	634-04004	2		Rim Assembly
1	734-0255	2	S	Valve Stem
2	634-04093	2		Rim Assembly
2	734-0255	2	S	Valve Stem
3	712-3050	10	/P	Nut, Lug, 7/16-14
4	734-04002	2	S	Tire, Tuft, 18 x 8.5 x 8
5	734-04080	2		Tire, Turf, 26 x 12.0 x 12