


7264 Tractor
4WD Axle Assembly

Page 1 of 79



7264 Tractor
4WD Axle Assembly

Page 2 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	IM-326021860	1		Housing Assembly, Axle Includes Ref. No. 2
2	IM-030500820	4		Pin, Dowel
3	IM-326345040	1		Housing, Axle LH
4	IM-398400440	1		Gauge, Oil Level
5	IM-322013110	2		Housing Assembly, Pinion Gear Includes Ref. No. 2
6	IM-052300400	2		O-Ring
7	IM-040136204	2		Bearing, Ball
8	IM-040106303	2		Bearing, Ball
9	IM-036500047	2		Ring, Snap
10	IM-326240290	4		Gear, Final Pinion Idler
11	IM-322511091	2		Shaft, Idler Drive
12	IM-052300650	2		O-Ring
13	IM-322117840	1	S	Housing, Final Drive LH
14	IM-322117850	1	S	Housing, Final Drive RH
15	IM-326240280	2		Gear, Final Drive Pinion
16	IM-042532006	2		Bearing, Tapered
17	IM-040106006	2		Bearing, Ball
18	IM-050600038	2		Seal, Oil
19	IM-064600016	2		Plug
20	IM-025100016	2		Washer, Seal
21	IM-025100012	3		Washer, Seal
22	IM-322212311	2	S	Housing, Final Drive
23	IM-326312330	2	S	Wheel Hub/Shaft
24	IM-326370450	2		Gear, Final Drive
25	IM-050609043	2		Seal, Oil, 35mm x 55mm x 15mm
26	IM-040106205	2		Bearing, Ball
27	IM-040106206	2		Bearing, Ball
28	IM-036100030	2		Ring, Snap
29	IM-330310712	2		Kingpin
30	IM-334525190	1		Arm, Steering LH
31	IM-334525200	1		Arm, Steering RH
32	IM-011511025	12		Bolt, M10 x 25
33	IM-011511030	4		Bolt, M10 x 30
34	IM-011510820	12		Bolt, M8 x 20
35	IM-11510825	8		Bolt, M8 x 25
36	IM-010311035	2		Bolt, M10 x 35
37	IM-010301212	3		Bolt, M12 x 12
38	IM-020900008	2		Nut, M8
39	IM-399234470	2		Collar
40	IM-010310825	2		Bolt, M8 x 25
41	IM-334712010	1		Rod, Tie
42	IM-334801170	1		Tie Rod End, LH Includes Ref. Nos. 43 thru 46
43		2		Spring, Dust Cover (With Cover, Dust)
44	IM-334810207	2		Cover, Dust
45	IM-334810209	2		Nut, Castle, M12 x 1.25
46	IM-030103025	2	S	Pin, Cotter
47	IM-334801150	1		Tie Rod End, RH Includes Ref. Nos. 43 thru 46
48	IM-020109029	1		Nut, Jam, LH Thrd
49	IM-020800014	1		Nut, Jam, M14 RH Thrd
50	IM-025100020	1		Washer, Seal


7264 Tractor
4WD Axle Assembly

Page 3 of 79

Ref #	Part Number	Qty	S/P/F	Description
51	IM-040106304	2		Bearing, Ball
52	IM-199280540	AR		Shim, 0.2T
53	IM-199280550	AR		Shim, 0.5T

7264 Tractor
4WD Axle Assembly W/Mounting

Page 4 of 79




7264 Tractor
4WD Axle Assembly W/Mounting

Page 5 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	IM-322017890	1		Mtg. Bracket, Axle Front Includes Ref. No. 2
2	IM-398510090	1		Bushing
3	IM-322017900	1		Mtg. Bracket, Axle Rear Includes Ref. No. 4
4	IM-398510450	1		Bushing
5	IM-050301140	1		Seal, Oil
6	IM-399261550	1		Washer, Thrust
7	IM-050309056	1		Seal, Oil
8	IM-399261580	1		Washer, Thrust
9	IM-060620000	2		Fitting, Grease
10	IM-395910030	1		Shim Kit, Service Only
11	IM-399234160	1		Collar
12	IM-052100210	1		O-Ring
13	IM-020109079	1		Nut
14	IM-326211011	1		Shaft, Differential LH
15	IM-326211021	1		Shaft, Differential RH
16	IM-199280630	AR		Shim, 0.1T
17	IM-199280640	AR		Shim, 0.2T
18	IM-199280650	AR		Shim, 0.5T
19	IM-040106305	1		Bearing, Ball
20	IM-399211140	1		Spacer
21	IM-040156305	1		Bearing, Ball
22	IM-326110490	1		Housing, Differential
23	IM-399310150	3		Plate, Locking
24	IM-010110816	6		Bolt, M8 x 16
25	IM-326130160	1		Shaft, Pinion
26	IM-030300540	1		Pin, Spring
27	IM-322050621	1		Gear Set, Ring and Pinion
28	IM-326160060	2		Gear, Pinion
29	IM-399261070	2		Washer, Thrust
30	IM-326140200	2		Gear, Differential
31	IM-040106304	2		Bearing, Ball
32	IM-399211130	1		Spacer
33	IM-199281030	AR		Shim, 0.1T
34	IM-199281040	AR		Shim, 0.2T
35	IM-199281050	AR		Shim, 0.5T
36	IM-399260530	1		Washer, Thrust
37	IM-199281240	AR		Shim, 0.1T
38	IM-199281250	AR		Shim, 0.2T
39	IM-199280430	AR		Shim, 0.5T
40	IM-042530205	2		Bearing, Tapered Roller
41	IM-050209004	1		Seal, Oil

7264 Tractor
4WD Traction Drive

Page 6 of 79




7264 Tractor
4WD Traction Drive

Page 7 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	603-0906	1		Pin Assembly, 2 Speed
2	710-0573	4		Screw, Hex Cap Lock, 5/16-18 x 1.25 GR5
3	710-3006	1	/P	Screw, Cup Set, 5/16-18 x 3/8
4	711-1339	1		Shaft, Motor
5	711-1344	1	S	Shaft, Pinion, 16T
6	711-1372	1		Shaft, 4WD
7	711-1397	1		Shaft, 2 Speed Actuator
8	715-0159	1		Pin, Spirol, 3/16 x .875
9	716-0185	1		Ring, Retaining
10	716-0384	1		Ring, Retaining
11	716-0387	1		Ring, Retaining
12	716-0393	1		Ring, Retaining
13	716-0396	1		Clip, Rotor
14	717-3472	1		Gear, Drive Pinion, LO 24T:17T
15	717-3473	1		Gear, Drive Pinion, HI 33T: 17T
16	717-3480	1		Gear, Drive, LO:59T; HI 50T
17	717-3484	1		Clutch, Overrunning
18	718-0674	1		Cover, Front
19	718-0678	1		Spacer, Drive
20	718-3116	1		Collar, 2 Speed
21	721-0496	1		Seal, Oil
22	721-0501	1		O-Ring
23	721-0507	1		Seal, Oil
24	732-0863	1	S	Spring, Detent
25	736-0715	1		Washer, Thrust
26	741-0862	1	/P	Ball, Detent
27	741-1106	1		Bearing, Ball
28	741-1107	1		Bearing, Ball
29	741-1109	1		Bearing, Angular Contact Ball
30	741-1112	1		Bearing, Thrust
31	741-3037	1	S	Bearing, Ball
32	741-3057	1	S	Bearing, Ball
33	741-3118	2		Bearing, Sleeve
34	748-3096	1		Yoke, 2 Speed

7264 Tractor
4WD Transmission

Page 8 of 79



7264 Tractor
4WD Transmission

Page 9 of 79

Ref #	Part Number	Qty	S/P/F	Description
	737-3025	1	/P	Transmission Oil, 1 Qt 6 gal.
	737-3062	1	/P	Transmission Oil, 1 Gal
	737-3035	1	/P	Transmission Oil, 5 Gal
	759-3958	1		Sealant, Loctite(R) Black, 5.3 oz as required
1	603-0688A	1	/P	Arm, Hydro Control
2	603-0712A	1		Bracket, Transmission Mtg. RH
3	603-0713A	1	S	Bracket, Transmission Mtg. RH
4	619-3059	1	S	Cover, Transmission Housing
5	703-3577	1		Plate, Feedback
6	703-3715	1	S	Baffle, Oil
7	703-05041	1		Arm, Neutral RH
8	703-05042	1		Arm, Neutral LH
9	710-0294	4		Screw, Hex Cap, 1/4-20 x .375 GR5
10	710-0591	1	/P	Screw, Hex Cap Lock, 3.8-24 x 1.0 GR5
11	710-0833	4	/P	Screw, Hex Cap, 5/16-18 x 5.25 GR5
12	710-1633	1		Screw, Plug, M14 x 1.5 x .827
13	710-1853	1		Screw, Hex Special Set, 5/16-18 x .625
14	710-3005	4	/P	Screw, Hex Cap, 3/8-16 x 1.25 GR5
15	710-3013	2	/P	Screw, Hex Cap, 1/4-20 x .5 GR5
16	710-3032	6	/P	Screw, Hex Cap, 1/2-13 x 1.25 GR5
17	710-3120	9		Screw, Hex Cap Lock, 3/8-16 x 1.5 GR5
18	710-3262	2		Screw, Low Hd. Cap, 3/8-16 x .75
19	711-1355	1		Shaft, Rock
20	712-0431	2	S	Nut, Hex Flange Lock, 3/8-16
21	716-0111	1	/P	Ring, Retaining
22	716-0195	1		Ring, Retaining
23	717-3507	1	S	Pump, Hydrostatic Transmission
24	718-3131	1		Pump, Auxiliary Hydraulic
25	719-3166	1		Arm, Upper Hitch RH
26	719-3167	1		Arm, Upper Hitch LH
27	721-0501	1		O-Ring, 2.987 ID x .103 Dia
28	721-0510	2		Seal, Oil, 1.5 x 2.0 x .25
29	723-3071	1		Filter, Oil, Hydraulic System use with 737-3105 Fitting, Nipple
29	723-04032A	1		Filter, Oil, Reverse Flow style Not shown, use with 619-04163, Refer to Service Advisory CC-566
29	619-04163	1	S	Housing, Reverse Flow Not shown, use with 723-04032A, Refer to Service Advisory CC-566
30	723-3014	1	S	Filter, Oil
31	723-3021	1	/P	Breather, Transmission
32	725-3272	1		Sensor, RPM
33	727-3012	2	/P	Fitting, 90 degree
34	727-3176	1		Tube, Auxiliary Pump Suction
35	727-3181	1		Tube, Hydro Suction
36	731-04018	1		Grommet
37	732-1162	1		Spring, Extension
38	736-3052	2	/P	Washer, Flat, .406 x 1.0 x .105
39	737-0146	1	S	Fitting, Grease
40	737-0349	2		Plug, Fitting
41	737-3105	1		Drain, Filter Nipple


7264 Tractor
4WD Transmission

Page 10 of 79

Ref #	Part Number	Qty	S/P/F	Description
42	737-3108	1		Fitting, 90 degree
43	737-3111	1		Fitting, 90 degree
44	737-3112	1		Fitting, Straight
45	737-3113	2		Fitting, Straight
46	738-0108	1	S	Screw, Shoulder, .498 Dia x 1.45
47	738-0430	1		Screw, Shoulder, .50 Dia x .685
48	738-04001	4		Screw, Shoulder, .625 x .18: 1/2-13
49	741-1110	2		Bearing, Sleeve, 1.52 x 1.75 x 1.0
50	750-1208	4		Spacer, .40 x 1.0 x 3.9
51	750-1239	2		Spacer, 1.52 x 2.25 x .188
52	737-04018	1		Dipstick

7264 Tractor
Alternator

Page 11 of 79




7264 Tractor
Alternator

Page 12 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	BS-820692	1		Housing, Brush End
2	BS-820711	1		Pulley, Alternator
3	BS-820703	1		Cover, Brush
4	BS-825084	1		Alternator
5	BS-825385	1		Rectifier
6	BS-825388	1		Regulator
7	BS-820702	1		Screw, Rectifier
8	BS-825383	1		Housing, Drive End
9	BS-820819	1		Strap, Adjusting
10	BS-820275	1		Screw, Support Bracket
11	BS-820713	1		Spacer, Support Bracket
12	BS-825390	1		Rotor
13	BS-820213	1		Bracket, Support
14	BS-820690	1		Stud, Alternator
15	BS-825384	1		Retainer, Bearing
16	BS-825157	1		Connector, Terminal
17	BS-825387	1		Retainer, Brush
18	BS-820343	1	S	Screw, Alternator
19	BS-820270	1		Screw, Alternator
20	BS-820023	1		Screw, Adjusting Strap
21	BS-820069	1		Nut, Alternator
22	BS-820715	1		Screw, Brush Cover
23	BS-820701	1		Screw, Brush Retainer
24	BS-820702	1		Screw, Brush Retainer
25	BS-820702	1		Screw, Ground Terminal
26	BS-820705	1		Nut, Alternator Pulley
27	BS-820707	1		Screw, Brush End Housing
28	BS-820709	1		Nut, Brush End Housing

7264 Tractor
Auxiliary Hydraulic Loader Valve (IF Equipped)


Page 13 of 79



7264 Tractor
Auxiliary Hydraulic Loader Valve (IF Equipped)

Page 14 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	603-0813	1	S	Pivot Bracket Assembly
2	603-0862	1		Valve Handle Assembly
3	703-3598-0637	1	/P	Loader Valve Mount Bracket
4	703-3972-0637	1	/P	Fitting Mount Plate
5	703-3973-0637	1	/P	Rear Fitting Mount Plate
6	710-0501	2	/P	Hex Screw, 1/4-20, 2.00, Gr5
7	710-0599	2	/P	Hex Wash. Hd. Tapp Screw 1/4-20 x .50
8	710-0604A	2	/P	Hex Wash. Hd. Tapp Screw 5/16-18 x .625
9	710-1260A	4	/P	Hex Wash. Hd. Tapp Screw 5/16-18 x .75
10	711-1611	1		Valve Pivot Shaft
11	711-1624	1		Valve Spool Link
12	711-1637	1		Ball Joint Pivot Stud
13	711-1642	1		Clevis Pin, .199 x .8125
14	712-0256	2	/P	Jam Nut, 5/16-24, Gr2
15	712-0324	2	/P	Hex Lock Nut, 1/4-20, Gr8, Nylon
16	713-3000	1	S	Chain Link
17	714-0104	1	S	Internal Cotter Pin
18	716-0865	2	/P	Snap Ring, .5
19	718-3138	1	S	Auxiliary Hydraulic Pump
	759-3964	2		Pin, Dowel
	759-3965	4	S	Bolt, Mounting
	759-3966	1		Coupler, Splined
20	718-3140	1		Loader Control Valve
21	723-0488	1	S	Ball Joint, .3125 Id x 5/16-24
22	727-3012	2	/P	Fitting, 90° 6-6 Orb
23	727-3206	1		Tube, Tandem Pump Suction
24	727-3210	1		Tube, Hydraulic - Bucket Rollback
25	727-3211	1		Tube, Hydraulic - Bucket Dump ..
26	727-3212	1		Tube, Hydraulic - Boom Lift
27	727-3213	1		Tube, Hydraulic - Boom Lower ...
28	727-3224	2		Coupling, Male Hydraulic, 3/8-18
29	727-3225	2		Coupling, Female Hydr. 3/8-18 ...
30	727-3226	1		Tube, Auxiliary Pump Pressure ..
31	727-3227	1		Tube, Valve Pressure
32	727-3228	1		Tube, Valve Return
33	727-3229	1		Tube, Valve Return
34	727-3261	2		Plug, Hydraulic Coupler - Male ...
35	727-3262	2	/P	Plug, Hydraulic Coupler - Female
36	731-3353	1		Knob, 1.625 Dia x 3/8-16 Thd
37	731-3374	1	/P	Washer, Indicator - Red
38	731-3375	1	/P	Washer, Indicator - Yellow
39	731-3376	1	/P	Washer, Indicator - Green
40	731-3377	1	/P	Washer, Indicator - Blue
41	735-0696	1		Joystick Boot
42	737-3111	1		Fitting, 90° -8 Orb
43	737-3112	2		Fitting, Straight -8 Orb
44	737-3113	2		Fitting, Straight
45	737-3125	2		Fitting, Straight - 6 Orb
46	737-3129	4		Fitting, Bulkhead 3/4-16 x 3/8-18
47	737-3130	2		Fitting, Bulkhead 3/4-16 x 3/4-16
48	750-0845	1	S	Spacer, .34 ID x .5 OD x .31




7264 Tractor
Battery And Electrical

Page 16 of 79

Ref #	Part Number	Qty	S/P/F	Description
	629-3060	1		Harness, Main Wire Not Shown
2	703-4104-0637	1	/P	Strap, Battery Holddown
3	703-4131	1	S	Bracket, Fuse Center
4	710-0206	2	/P	Screw, Hex Cap, 1/4-10 x .875 GR5
5	710-0599	2	/P	Screw, Hex Wash Hd. Tapp 1/4-20 x .5
6	712-0324	2	/P	Nut, Hex Nylon Insert Lock, 1/4-20
7	712-0421	2		Nut, Wing w/Bell Washer, 5/16-18
8	725-3174	1	S	Battery, 500 cca Dry
9	725-3273	1		Switch, PTO Reverse Override
10	747-3433	2		Rod, Battery Holddown
	BS-820373	1		Module, Timer Glow Plugs Not Shown
	BS-820455	1		Relay, Timer Not Shown

7264 Tractor
Camshaft And Valves


Page 17 of 79



7264 Tractor
Camshaft And Valves

Page 18 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	BS-820032	3		Washer, Flat
2	BS-820404	3		Valve, Exhaust
3	BS-820403	3		Valve, Intake
4	BS-820406	6		Spring, Valve
5	BS-820032	3		Screw, Hex, 6mm
6	BS-820111	6		Retainer, Valve
7	BS-825042	6		Keeper, Valve, Set of 2
8	BS-820075	1		Screw, Metric
9	BS-820110	6		Tappet, Valve
10	BS-820388	1		Camshaft
11	BS-820070	3		Nut, Hex Metric
12	BS-825041	6		Adjuster, Rocker Arm
13	BS-820065	3		Washer, Spacer
14	BS-820113	6		Cap, Valve
15	BS-820105	1		Screw, Metric
16	BS-691639	1		Key, Timing
17	BS-820112	6		Seat, Valve Spring
18	BS-820003	2		Retainer
19	BS-820613	1		Gear, Cam
20	BS-820405	6		Seal, Valve
21	BS-820422	6		Rod, Push
22	BS-820387	6		Arm, Rocker
23	BS-825093	1		Shaft, Rocker Arm
24	BS-820106	3		Support, Rocker Arm
25	BS-820044	2		Spring, Rocker Shaft
26	BS-820118	1		Retainer, Camshaft



7264 Tractor
Controls

Page 20 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	603-0671	1		Shaft Assembly, Brake
2	603-0672	1	S	Shaft Assembly, Forward
3	603-0673A	1		Link Assembly, Pedal
4	603-0674A	1		Plate, Bearing
5	603-0678	1		Link Assembly, Brake LH
6	603-0679A	1		Link Assembly, Parking Brake
7	603-0680	1		Link Assembly, Brake RH
8	603-0749	1		Shaft Assembly, Differential
9	603-0770	1		Link, PTO Select
10	703-3152	1		Bracket, Reverse Switch
11	703-3541	1		Bracket, Differential Pivot
12	703-3571	1		Handle, PTO
13	703-3575	1		Link, Differential Pivot
14	703-3582	1		Bracket, Diff. Actuator Mtg.
15	703-4099	1	S	Bracket, Reverse Switch
16	710-0599	2	/P	Screw, Hex Wash Hd Tapp 1/4-20 x .5
17	710-0642	4	/P	Screw, Hex Wash Hd Tapp 1/4-20 x .75
18	710-1260A	12	/P	Screw, Hex Wash Hd Tapp 5/16-18 x .75
19	710-0654A	2	/P	Screw, Hex Wash Hd Tapp 3/8-16 x 1.0
20	711-0415	1	S	Pin, Clevis, 3/8 x 1.75
21	711-0723A	3	S	Ferrule, 3/8-24 x .375 Dia. Hdn
22	711-1362	3		Ferrule, Brake
23	711-3397	1		Ferrule, 3/8-24 x .37
24	712-0239	3	S	Nut, Hex Lock, 1/2-20
25	712-0379	1	/P	Nut, Hex Flange Lock, 3/8-24
26	712-0431	1	S	Nut, Hex Flange Lock, 3/8-16
27	712-0711	1	/P	Nut, Hex Jam, 3/8-24
28	712-3027	3	S	Nut, Hex Flange Lock, 1/4-20
29	712-3077	2	/P	Nut, Hex, M8 x 1.25 GR8.8
30	713-3000	1	S	Link, Chain
31	714-0104	11	S	Pin, Internal Cotter
32	714-0147	2	/P	Pin, Internal Cotter
33	714-3020	1	/P	Pin, Internal Cotter
34	725-3164A	1	S	Switch, Plunger
35	725-3191A	1	S	Switch, Plunger
36	727-04033	1	S	Cylinder, Damper
37	731-3296	1		Pedal, Brake
38	731-3299A	1		Pedal, Forward/Reverse
39	731-3320	1		Pedal, Differential
40	731-3321	1		Grip, Handle
41	732-0324	2		Spring, Compression
42	732-0756A	1	S	Spring, Torsion
43	732-0859	1	S	Spring, Rev/No Cut
44	732-3065	1		Spring, Compression
45	732-3117	1		Spring, Switch Actuator
46	732-3118	1		Spring, Extension
47	736-0173	3	/P	Washer, Flat, .28 x .74 x .063
48	736-0185	2	S	Washer, Flat, .375 x .738 x .063
49	736-0232	1	S	Washer, Wave, .53 x .78 x .013
50	736-3019	3		Washer, Flat, .53 x .1.06 x .134
51	736-3069	1		Washer, Flat, .53 x .875 x .15
52	738-0509	1		Screw, Shoulder, .50 x 1.825
53	738-0533	1	S	Screw, Shoulder, .498 x 1.635


7264 Tractor
Controls

Page 21 of 79

Ref #	Part Number	Qty	S/P/F	Description
54	738-0689	1	S	Screw, Shoulder 1/2 x .180: 3/8-24
55	741-0491	2		Bearing, Nylon. .50 ID x .341
56	741-0598	2	S	Bearing, Hex Flange, .752 ID
57	741-3073	2	S	Bearing, Flange, .375 x .58 x .25
58	741-3074	2		Bearing, Flange .626 x .938 x .344
59	741-3084	2		Bearing, Flange .751 x 1.125 x .375
60	747-3396	1		Rod, Hydro Control
61	747-3399	1	S	Rod, Brake, LH
62	747-3400	1		Rod, Brake, RH
63	747-3414	1		Rod, PTO Control
64	747-3428	1		Rod, Diff. Lock Control

7264 Tractor Cooling

Page 22 of 79




7264 Tractor
Cooling

Page 23 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	BS-820031	4		Screw, Hex, 6mm
2	BS-820034	4		Screw, Hex,
3	BS-820022	2		Screw, Hex, 8mm
4	BS-820185	1		Screw, Metric
5	BS-820181	1		Nut, Hex Metric
6	BS-825064	1		Thermostat
7	BS-820271	1	S	Belt, V
8	BS-820208	1		Switch, Coolant Temperature
9	BS-820052	1		Plug
10	BS-820182	1		Plug
11	BS-825454	1		Fan, Radiator
12	BS-820093	1		Gasket, Outlet
13	BS-820095	1		Pulley, Pump
14	BS-825267	1		Housing, Outlet
15	BS-820098	1		Gasket, Inlet Housing
16	BS-825051	1		Housing, Inlet
17	BS-820100	1		Gasket, Water Pump
18	BS-825160	1		Connector, Coolant Temp. Switch
19	BS-825265	1		Pump, Water
20	BS-825462	1		Tank, Reserve
21	BS-825461	1		Cap, Reserve Tank
22	BS-820257	2		Clamp, Hose
23	BS-825314	1		Bracket, Reserve Tank Mtg.
24	BS-820034	1		Screw, Mtg. Bracket
25	BS-820011	1		Nut, Mtg. Bracket

7264 Tractor
Crankcase Cover

Page 24 of 79




7264 Tractor
Crankcase Cover

Page 25 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	BS-820055	1	S	Seal, Oil
2	BS-820425	2		Screw, Hex, 6mm
3	BS-820029	9		Screw, Hex, 6mm
4	BS-820027	3		Screw, Hex, 6mm
5	BS-825185	1		Cover Assembly, Gear
6	BS-820377	1		Gasket, Gear Cover
7	BS-820069	2		Nut, Hex Metric
8	BS-820061	2		Pin, Locating

7264 Tractor
Crankshaft, Pistons & Flywheel

Page 26 of 79




7264 Tractor
Crankshaft, Pistons & Flywheel

Page 27 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	BS-825552	1		Crankshaft
2	BS-825303	1		Flywheel
3	BS-825354	3		Piston Assembly, Standard
	BS-825355	3		Piston Assembly, .010 Oversize
4	BS-825187	3		Ring Set, Standard
	BS-825188	3		Ring Set, .010 Oversize
5	BS-820402	6		Lock Ring, Piston Pin
6	BS-825171	3		Rod, Connecting
7	BS-820128	6		Screw, Connecting Rod
8	BS-820080	6		Screw, Hex, 10mm
9	BS-820081	2		Screw, Hex, 8mm
10	BS-820079	1		Screw, Hex
11	BS-820073	6		Nut, Hex
12	BS-820140	1	S	Washer, Thrust, Standard
	BS-820139	1		Washer, Thrust, .005 Oversize
13	BS-820059	1		Pin, Locating
14	BS-820611	1		Gear, Drive
15	BS-820116	1		Shaft, Gear
16	BS-820117	1		Plate, Idler Gear
17	BS-820236	1		Pulley, Crankshaft
18	BS-820142	3	S	Bearing, Rod Standard
19	BS-825019	3	S	Bearing Set, Rod Standard
	BS-825060	3		Bearing Set, Rod, .010 Undersize
20	BS-825040	1	S	Bearing Set, Main Standard
	BS-825039	1		Bearing Set, Main, .010 Undersize

7264 Tractor
Cylinder Assembly

Page 28 of 79




7264 Tractor
Cylinder Assembly

Page 29 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	BS-825341	1		Cylinder Assembly (Includes 2, 6 & 8)
2	BS-820129	1	S	Bushing
3	BS-820056	1	S	Seal, Oil
4	BS-820031	6		Screw, Hex, 6mm
5	BS-820176	5		Screw, Hex, 10mm
6	BS-820042	8		Screw, Hex, 10mm
7	BS-820016	1		Stud, Metric
8	BS-820004	7		Plug, Welch
9	BS-820151	1		Plug, Welch Camshaft
10	BS-820375	1		Plug, Cylinder Block
11	BS-820147	1		Bracket, Mounting
12	BS-820063	4		Pin, Locating
13	BS-820062	3		Pin, Locating
14	BS-820061	2		Pin, Locating
15	BS-820314	1	/P	Filter, Oil
16	BS-820851	1		Adapter, Oil Filter
17	BS-820102	1		Nozzle, Oil
18	BS-820145	1		Gasket, Retainer
19	BS-820146	1		Seal, Retainer

7264 Tractor
Cylinder Head And Manifolds

Page 30 of 79




7264 Tractor
Cylinder Head And Manifolds

Page 31 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	BS-825347	1	S	Head, Cylinder
2	BS-820660	1		Gasket, Cylinder Head
3	BS-821003	1		Tube, Breather
4	BS-820623	14		Screw, Metric
5	BS-825024	1		Cap, Oil Fill
6	BS-820015	2		Stud, Metric
7	BS-820078	2		Stud, Metric
8	BS-820014	5		Stud, Metric
9	BS-820466	1		Stud, Metric
10	BS-820004	2		Plug, Welch
11	BS-820005	2		Plug, Welch
12	BS-820071	3		Nut, Hex Metric
13	BS-820064	3		Washer, Sealing
14	BS-820130	6		Ring, Retainer
15	BS-820076	3		Stud, Rocker Arm
16	BS-825030	6		Bushing, Guide
17	BS-820150	1		Gasket, Rocker Cover
18	BS-825088	1		Cover, Rocker
19	BS-820031	1		Screw, Hex, 6mm
20	BS-820408	3		Screw, Hex, 6mm
21	BS-825175	1		Manifold, Intake
22	BS-820407	1		Gasket, Intake Manifold
23	BS-820584	4		Stud, Exhaust Manifold
24	BS-820069	2		Nut, Hex Metric
25	BS-820010	6		Nut, Hex Metric
26	BS-820178	4		Nut, Hex Metric
27	BS-825055	1		Manifold, Exhaust
28	BS-820817	1		Gasket, Exhaust Manifold
29	BS-820670	1	S	Gasket, Muffler

7264 Tractor
Dash Panel And Steering Wheel

Page 32 of 79



7264 Tractor
Dash Panel And Steering Wheel

Page 33 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	603-0711	1	S	Tab Assembly, Throttle
2	629-3061	1		Wire Harness, Dash
3	631-0076	1		Boot, Steering Shaft
4	631-04007A	1	S	Dash
5	703-05132	1	S	Plate, Throttle Mtg.
6	710-0604A	2	/P	Screw, Hex Wash. Hd. Tapp 5/16-18 x .625
7	710-0924	4	/P	Screw, Pan Hd., 1/4-20 x .75
8	710-3013	6	/P	Screw, Hex Cap, 1/4-20 x .5 GR5
9	712-0237	1	S	Nut, Hex Lock, 5/16-24
10	712-0292	2	/P	Nut, Speed, 1/4-20
11	712-0116	1	S	Nut, Hex Insert Jam Lock, 3/8-24
12	723-3013	1	S	Washer, Friction, .515 x 1.5 x .12
13	725-2017	1		Plug
14		1		Panel, Instrument Refer to 759-04052 Service Kit
	725-3285	12		Bulb
	735-0688	12		Plug
15	725-3274	1		Switch, Headlight
16	725-3276	1		Switch, PTO
17	725-3277	1	S	Switch, Ignition
18	725-3279	1	S	Switch, Hazard
19	731-3209	1		Steering Wheel, Soft Grip
20	731-3210	1		Cover, Steering Wheel
21	731-3298	1		Handle, Throttle
22	731-3344	1		Panel, Dash Insert
23	736-0242	1	/P	Washer, Belleville, .34 x .872 x .06
24	736-0329	3	S	Washer, Lock, 1/4
25	736-0112	2	/P	Washer, Belleville, .531 x 1.62 x .045
26	736-3052	1	/P	Washer, Flat, .406 x 1.0 x .105
27	746-3086A	1		Cable, Throttle
28	759-3950	1	S	Key Set, Ingition

7264 Tractor
Differential And Final Drive

Page 34 of 79




7264 Tractor
Differential And Final Drive

Page 35 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	619-3060	2	S	Housing, Axle
2	661-3014	2		Brake Assembly, Drum
3	710-0538	10	/P	Screw, Hex Cap Lock, 5/16-18 x .625 GR5
4	710-1695	4		Screw, Socket Hd. Cap, 3/8-16 x 1.0
5	710-3119	4	/P	Screw, Hex Cap Lock, 3/8-16 x .75 GR5
6	710-3238	24		Screw, Hex Cap Lock, 7/16-14 x 1.75 GR5
7	711-1326	1		Shaft, Axle Stub RH
8	711-1327	2		Shaft, Axle
9	711-1358	1		Shaft, Axle Stub LH
10	711-1389A	1	/P	Shaft, Differential Lock Actuator
11	715-0226	8		Pin, Dowel, .3752 x .75
12	715-3010	4	/P	Pin, Dowel, .25 x .75
13	716-0180	2		Ring, Retaining
14	716-0195	2		Ring, Retaining
15	716-0196	2		Ring, Retaining
16	716-0390	2		Ring, Retaining
17	716-0391	4		Ring, Retaining
18	716-0396	1		Clip, Rotor
19	716-0397	1	/P	Ring, Retaining
20	717-1120	4		Gear, Differential, 10T
21	717-1173	1		Shaft, Cross
22	717-1178	2		Shaft, Cross
23	717-1180	1		Block, Differential Pinion
24	717-3316	1		Gear, Bevel, 65T
25	717-3317	2		Gear, Miter, 14T
26	717-3471	1		Gear, Drop Axle, 42T RH
27	717-3478	1		Gear, Drop Axle, 42T LH
28	718-0666	1		Carrier, Differential
29	718-3104	1		Collar, Differential Lock
30	718-3105	1		Yoke, Differential Lock
31	718-3112	1		Cover, Bearing
32	721-0495	2		Seal, Oil, 50mm x 75 mm x 10mm
33	721-0496	1		Seal, Oil
34	721-3020A	2	S	Seal, Oil, 1.181 x 2.453 x .276
35	732-0187	1		Spring, Compression
36	736-0355	1	/P	Washer, Flat, .56 x 1.0 x .04
37	736-0715	4		Washer, Thrust, 1.12 x 1.75 x .03
38	741-0721	2	/P	Bearing, Ball
39	741-1104	2	/P	Bearing, Ball
40	741-1107	2		Bearing, Ball
41	741-1112	2		Bearing, Thrust
42	741-3033A	2	S	Bearing, Ball
43	741-3080	1		Bearing, Needle
44	761-3071	2		Drum, Brake

7264 Tractor
Engine Connections

Page 36 of 79



7264 Tractor
Engine Connections

Page 37 of 79

Ref #	Part Number	Qty	S/P/F	Description
	629-3062	1	S	Harness, Engine Wire Not Shown
1	603-0744-0637	1	/P	Bracket, Engine LH
2	603-0745-0637	1	/P	Bracket, Engine RH
3	651-0007	1		Filter Assembly, Fuel
	759-04009	1		Filter Element
4	703-3483	1		Plate, Radiator Baffle
	777S30631	1		Graphic, Fan Warning
	777S30633	1		Graphic, Warning
5	703-3484	1		Bracket, Radiator Mtg. RH
	777S30632	1		Graphic, Warning
6	703-3485	1		Bracket, Radiator Mtg. LH
	777S30632	1		Graphic, Warning
7	703-3486	1		Bracket, Muffler Mtg
8	703-3603A	1	S	Bracket, Fuel Filter Mtg
9	703-3739	1		Plate, Baffle RH
10	703-3740	1		Plate, Baffle, LH
11	703-3741	1		Bracket, Radiator Mtg.
12	710-0224	1	S	Screw, Hex Wash Hd Tapp 10-16 x .5
13	710-0347	2	/P	Screw, Hex Cap 3/8-16 x 1.75 GR5
14	710-0597	2	/P	Screw, Hex Cap 1/4-20 x 1.0 GR5
15	710-0599	1	/P	Screw, Hex Wash Hd Tapp 1/4-20 x .5
16	710-0607	6	/P	Screw, Hex Wash Hd Tapp 5/16-18 x .5
17	710-0623	4	/P	Screw, Hex Wash Hd Tapp 3/8-16 x .75
18	710-1260A	10	/P	Screw, Hex Wash Hd Tapp 5/16-18 x .75
19	710-1376	3	/P	Screw, Hex Cap, M8-1.25 x 16
20	710-1681	5	/P	Screw, Hex Cap, M8-1.25 x 20
21	710-3005	2	/P	Screw, Hex Cap, 3/8-16 x 1/25 GR5
22	710-3008	10	/P	Screw, Hex Cap 5/16-18 x .75 GR5
23	710-3015	7	/P	Screw, Hex Cap 1/4-20 x .75 GR5
24	710-3138	17	/P	Screw, Hex Cap, I M8-1.25 x 16
25	710-3144	4	/P	Screw, Hex Cap 3/8-16 x 2/0 GR5
26	712-0324	4	/P	Nut, Hex Insert Lock, 1/4-20
27	712-0431	8	S	Nut, Hex Flange Lock, 3/8-16
28	712-3004A	10	/P	Nut, Hex Flange Lock, 5/16-18
29	717-3524	1		Shaft, Drive
30	720-0425	1		Plug, Cap
31	722-0262	4		Mount, Neoprene Engine
32	722-3022	1	S	Tape, Foam, .625 wide 42in.
33	723-3061	1		Seal, Heat Baffle 96in.
34	725-3281	1		Wire, Battery Pos.
35	725-3283	1		Wire, Ground
36	725-3287	1		Wire, Battery Neg
37	726-0205	7	/P	Clamp, Hose
38	726-0476	3		Clamp, Adjustable Hose
39	726-0480	4		Clamp, Hose
40	731-04018	2		Grommet, Hose Guard
41	731-3304	1		Hose, Radiator to Engine
42	731-3348	1		Hose, Air Filter
43	731-3349	1		Hose, Air Inlet
44	731-3350	1		Hose, Engine to Radiator
45	731-3363	1		Shroud, Fan
46	735-0226	1		Grommet, Rubber
47	736-0148	1	/P	Washer, External Lock, 3/8


7264 Tractor
Engine Connections

Page 38 of 79

Ref #	Part Number	Qty	S/P/F	Description
48	736-0173	7	/P	Washer, Flat, .28 x .74 x .063
49	736-0607	2	/P	Washer, External Lock, 5/16
50	751-0535	1		Hose, Fuel Line 92in.
51	751-0822	1		Fitting, 90 Degree Hose
52	751-0823	1		Fitting, Straight Hose
53	751-3001	2	/P	Plug, Drain
54	751-3130	1		Fuel Line, 5/16 ID 92in.
55	751-3163	1		Muffler, Engine
56	751-3165	1		Radiator
	722-0268	2		Grommet, Rubber Mtg.
57	751-3192	1	S	Cap, Radiator, 13psi
58	751-3193	1		Screen, Debris
59	718-3132	1	S	Cooler, Oil
60	751-3194	1	/P	Element, Air Cleaner
61	751-3195	1		Cap, Air Cleaner
62	751-3196	1		Cannister, Air Cleaner
63	751-3197	1		Nozzle, Air Cleaner
64	BS-825462	1		Bottle, Overflow
65	710-3206A	1	/P	Screw, Hx Cap, M8-1.25:25 GR8

7264 Tractor
Fender And Running Board

Page 39 of 79




7264 Tractor
Fender And Running Board

Page 40 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	625-0023B	1	S	Light Assembly, Rear RH
	725-3262	1	S	Bulb Only, Tail Light
	725-3263	1	S	Bulb Only, Reverse Indicator Light
	629-3059	1		Harness, Tail Light
2	625-0024B	1	S	Light Assembly, Rear LH
	725-3262	1	S	Bulb Only, Tail Light
	725-3263	1	S	Bulb Only, Reverse Indicator Light
	629-3059	1		Harness, Tail Light
3	703-3451	1		Bracket, Seat Mtg. LH
4	703-3572	1		Bracket, Seat Mtg. RH
5	703-3754	1		Bracket, Rear Seat Support
6	710-0604A	8	/P	Screw, Hex Wash Hd. Tapp 5/16-18 x .625
7	710-3038	4	/P	Screw, Hex Cap 5/16-18 x .875 GR5
8	710-0751	4	/P	Screw, Hex Cap 1/4-20 x .620 GR5
9	710-3021	3	/P	Screw, Hex Wash Hd. Tapp 5/16-18 x .625
10	710-3008	2	/P	Screw, Hex Cap 5/16-18 x .75 GR5
11	710-1242	8	/P	Screw, Truss Phillips Hd 5/16-14 x .75
12	710-1260A	3	/P	Screw, Hex Wash Hd. Tapp 5/16-18 x .75
13	710-0971	2		Screw, Pan Hd. 5/16-18 x 1.0
14	726-3057	4	S	Clip, Tail Light
15	726-3046	12	/P	Clip, Ratchet Fastener
16	726-0211	6	S	Speed Nut, "U" Type, 5/16-18
17	731-3324	1	S	Cover, Fender
	777S30630	1		Graphic, Warning
18	731-3289	1		Fender
	777S30635	1		Graphic, Warning
	777D06180	1		Graphic, Series 7000 Posi Trak
19	731-04005	1		Cover, Fender, RH
20	731-04006	1		Cover, Fender, LH
21	735-0669	1		Pad, Floor, RH
22	735-0670	1		Pad, Floor, LH
23	735-0690	4		Grommet, .4375 ID x .75
24	736-3089	4	/P	Washer, Flat, .345 x 1.0 x .100
25	736-0173	4	/P	Washer, Flat, .28 x .74 x .063
26	750-3310	4		Spacer, Flange, .3125 x .4375 x .625

7264 Tractor
Foldale Rops

Page 41 of 79



7264 Tractor
Foldale Rops

Page 42 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	603-0716	1	S	ROPS Assembly, Lower
2	603-0717	1		ROPS Assembly, Upper
3	603-0858	1		Mounting Assembly, ROPS RH
4	603-0861	1		Mounting Assembly, ROPS LH
5	710-0376	2	/P	Screw, Hex Cap, 5/16-18 x 1.0 GR5
6	710-0515	2		Screw, Hex Cap, 1/2-20 x 3.5 GR5
7	710-3032	8	/P	Screw, Hex Cap, 1/2-13 x 1.25 GR5
8	710-3131	8	/P	Screw, Hex Cap, 1/2-13 x 1.0 GR5
9	711-1610	2		Pin, Clevis, .5 x 3.5
10	712-3046	2	/P	Nut, Hex Jam, 5/16-18
11	712-3058	2	S	Nut, Hex Nylon Insert Lock, 1/2-20
12	712-3066	2	S	Nut, Hex, 1/2-20 GR5
13	714-3003	2	S	Pin, Internal Cotter
14	725-3280	2		Light Assembly, Hazard
	725-3286	2	S	Bulb, Light
15	736-0921	2	S	Washer, Lock, 1/2
16	731-0757-16	16in.		Conduit


7264 Tractor
Frame

Page 44 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	603-0666	1		Frame
2	703-3503	1	S	Lever, Hood Latch
3	703-3497A	1	/P	Bracket, Running Board Mtg. LH
4	703-3379A	1	/P	Bracket, Running Board Mtg. RH
5	703-3463	1		Bracket, Hood Latch Mtg.
6	710-3083	3	/P	Screw, Hex Cap, 5/16-18 x 1.375 GR5
7	710-0276	2	/P	Screw, Carriage, 5/16-18 x 1.0
8	710-1260A	6	/P	Screw, Hex Wash. Hd. 5/16-18 x .75
9	712-3004A	5	/P	Nut, Hex Flange Lock, 5/16-18
10	726-0455	1		Latch, Hood

7264 Tractor
Front Axle 4WD

Page 45 of 79




7264 Tractor
Front Axle 4WD

Page 46 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	603-0735-0637	1	/P	Plate, Steering Cylinder Mtg.
2	618-3207	1	S	Axle Assembly, Front 4WD
3	710-1843	4		Screw, Hex Cap, M12-1.75 x 25.GR8
4	710-3006	1	/P	Screw, Set, 5/16-18 x 3/8
5	710-3067	12	/P	Screw, Hex Cap, 1/2-13 x 1.75 GR5
6	711-1410	1		Stud, Cylinder Mtg.
7	712-3016	2	/P	Nut, Hex Nylon Insert Lock 5/8-11 GR5
8	712-3083	12	/P	Nut, Hex Nylon Insert Lock 1/2-13 GR8
9	712-3107	1	/P	Nut, Hex Lock, 3/4-10
10	717-3502	1	S	Cylinder, Steering
11	717-3513	1	S	Shaft, Drive 4WD
12	719-3158	2		Bracket, Axle Mtg.

7264 Tractor
Fuel Injection System


Page 47 of 79



7264 Tractor
Fuel Injection System

Page 48 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	BS-820031	2		Screw, Hex, 6mm
2	BS-820414	1		Seal, O-Ring
3	BS-820417	2		Nut, Hex Metric
4	BS-820419	1		Nut, Hex Metric
5	BS-820634	1		Bracket, Casing Clamp
6	BS-820225	1		Clamp, Casing
7	BS-820012	1		Screw, Casing Clamp
8	BS-820592	1		Screw, Support Bracket
9	BS-820272	4		Screw, Support Bracket
10	BS-820619	1		Gear, Drive
11	BS-825197	1		Clamp
12	BS-820415	1		Bracket, Support
13	BS-820479	1		Bracket, Support
14	BS-820640	1		Screw, Casing Clamp Bracket
15	BS-820467	1		Clamp, Swivel
16	BS-825179	1		Hose/Clamp Ass'y., Fuel Return
17	BS-825266	1		Connector, Injection Pump
18	BS-825176	3	S	Plug, Glow
19	BS-820409	1		Strap, Glow Plug
20	BS-825178	3		Nozzle, Injector
21	BS-820411	3		Seat, Injector
22	BS-825194	1		Pipe, Injector #1
23	BS-825195	1		Pipe, Injector #2
24	BS-825196	1		Pipe, Injector #3
25	BS-825300	1		Pump, Injection
26	BS-820412	1		Pipe, Fuel Return
27	BS-820829	3		Nut, Hex Injector Nozzle
28	BS-820831	3		Washer, Injector Nozzle





7264 Tractor
Fuel Tank

Page 50 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	703-3563	1		Bracket, Front Tank Mtg.
2	710-0817	4		Screw, Hex Wash Hd Tapp 5/16-18 x 1.25
3	710-1260A	3	/P	Screw, Hex Wash Hd Tapp 5/16-18 x .75
4	736-0231	4	S	Washer, Flat, .344 x 1.125 x .12
5	751-3188	1	/P	Cap, Fuel - Diesel
6	751-3175	1	S	Sensor, Fuel Level
7	751-3169A	1		Tank, Fuel
8	735-0149	1	S	Bushing, Rubber
9	751-3174	1		Fitting, Fuel Return

7264 Tractor
Gasket Sets

Page 51 of 79




7264 Tractor
Gasket Sets

Page 52 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	BS-820056	1	S	Seal, Oil
2	BS-820660	1		Gasket, Cylinder Head
3	BS-820055	1	S	Seal, Oil
4	BS-820407	1		Gasket, Intake
5	BS-820377	1		Gasket, Gear Cover
6	BS-820155	1		Gasket, Gear Cover
7	BS-820582	2		Washer, Sealing
8	BS-820064	3		Washer, Sealing
9	BS-825380	1		Gasket Set
10	BS-820405	1		Seal, Valve
11	BS-820817	1		Gasket, Exhaust
12	BS-820085	1		Gasket, Exhaust
13	BS-820150	1		Gasket, Rocker Cover
14	BS-825381	1		Kit, Valve Overhaul
15	BS-820104	1		Gasket, Oil Pump Screen
16	BS-820093	1		Gasket, Outlet
17	BS-820098	1		Gasket, Inlet Housing
18	BS-820100	1		Gasket, Water Pump
19	BS-820137	1		Gasket, Oil Pan
20	BS-820145	1		Gasket, Retainer

7264 Tractor
Gear Housing

Page 53 of 79




7264 Tractor
Gear Housing

Page 54 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	BS-820033	1		Screw, Hex, 6mm
2	BS-820030	4		Screw, Hex, 6mm
3	BS-820180	1		Screw, Hex, 8mm
4	BS-820377	1		Gasket, Gear Cover
5	BS-820155	1		Gasket, Gear Cover
6	BS-820016	1		Stud, Metric
7	BS-820156	2		Stud, Metric
8	BS-820426	2		Stud, Metric
9	BS-825186	1		Housing, Gear
10	BS-825032	1		Valve, Oil Relief
11	BS-820615	1		Gear, Oil Pump Drive
12	~N/A	1		Pump. Oil Sold ONLY in Gear Housing (Ref. 9)

7264 Tractor
Hood, Grill And Side Panels


Page 55 of 79



7264 Tractor
Hood, Grill And Side Panels

Page 56 of 79


Ref #	Part Number	Qty	S/P/F	Description
1	603-0719-0637	1	S	Hinge Assembly, Hood
2	603-0784-0637	1	/P	Bracket, Side Panel Mtg. RH
3	603-0785-0637	1	/P	Bracket, Side Panel Mtg. LH
4	603-0924-0637	1	/P	Bracket, Side Panel Mtg. RH Rear
5	603-0925-0637	1	/P	Bracket, Side Panel Mtg. LH Rear
6	625-0052	1	S	Headlight Assembly
6	725-3161A	4	S	Bulb, Headlight Not shown
7	703-3394	1	S	Screen, Intake
8	703-3712	1		Shield, Upper Heat
9	703-3764	1		Bracket, Panel Mtg.
10	703-3765	1		Shield, Lower Heat
11	710-0473	6	/P	Screw, Truss Hd, 10-24 x .5
12	710-0599	14	/P	Screw, Hex Wash Hd Tapp 1/4-20 x .5
13	710-0751	4	/P	Screw, Hex Cap, 1/4-20 x .62 GR5
14	710-3170	4		Stud, Cylinder, 5/16-18 Thrd
15	712-0272	6	/P	Nut, Hex Sems, 10-24
16	712-0324	4	/P	Nut, Hex Nylon Insert Lock, 1/4-20
17	712-0431	2	S	Nut, Hex Flange Lock, 3/8-16
18	712-3004A	4	/P	Nut, Hex Flange Lock, 5/16-18
19	726-3056	4		Latch, 1/4 Turn Panel
20	727-3194	2		Cylinder, Gas Spring
21	759-04113A	1	/P	Hood, Service Kit Replaces 731-3277, Refer to diagram Hood 759-04113A
21	731-06889	1	S	Hood Replaces 731-3277
21	777D05419	1		Graphic, Hood RH Not shown
21	777D05420	1		Graphic, Hood LH Not shown
21	777D06176	1		Graphic, Model 7264 Posi Trak LH Not shown
21	777D06177	1		Graphic, Model 7264 Posi Trak RH Not shown
22	731-3278	1		Panel, Side RH
23	731-3279	1		Panel, Side LH
24	732-0936	4		Clip, Spring
25	732-0937	4		Spring, Compression
26	736-0272	2	S	Washer, Flat, .510 x .1.0 x .060
27	738-0380	2	S	Screw, Shoulder, .5 x .27 Lg 3/8-16
28	726-04010	1		Clip, Retaining



7264 Tractor
Hood, Service Kit 759-04113A

Page 58 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	703-05652	1		RH Hinge Bracket
2	703-05653	1		LH Hinge Bracket
3	703-05655A	1		Hood Mounting Bracket
4	703-05782	1	/P	Hood Latch Bracket
5	710-0224	1	S	#10-16 x .500 Hex Screw
6	710-0607	4	/P	5/16-18 x .50 Screw
7	710-1242	4	/P	5/16-14 x .75 HiLow Screw
8	710-0895	2		1/4-20 x .750 Screw
9	710-3025	2	/P	5/16-18 x .625 Bolt
10	712-04063	2	/P	5/16-18 Nylon Flange Lock Nut
11	714-0104	1	S	Cotter Pin
12	726-0233	4	/P	Push Nut
13	731-05161	1	S	Hood Cover
14	731-06889	1	S	Hood
15	732-04281A	1	/P	Latch Spring
16	747-1323A	1		Pivot Rod
17	783-04714	1	S	Latch Plate
18	783-04717A	1	/P	Pivot Latch Bracket
	721-04162	2		Foam Strip Not shown
	736-0400	2	S	Flat washer Not shown
	726-0272	1	/P	Clamp Not shown
	759-04113A	1	/P	Service Kit Includes all parts shown




7264 Tractor
Hydraulics

Page 60 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	710-0607	9	/P	Screw, Hex Wash Hd. Tapp 5/16-18 x .5
2	712-3004A	2	/P	Nut, Hex Flange Lock, 5/161-18 GR5
3	726-0132	2	/P	Clamp, Adjustable Hose
4	726-04004	5		Clamp, Hose
5	726-0475	5		Clamp, Hose
6	727-3012	3	/P	Fitting, 90 Degree
7	727-3168	2		Hose, Steering
8	727-3177	1		Tube, Oil Cooler Return
9	727-3178	1		Hose, Oil Return
10	727-3182	1		Tube, Lift Return Line
11	727-3184	1		Hose, Lift Cylinder
12	727-3185A	1	/P	Hose, Lift Inlet
13	727-3187A	1	/P	Hose, Steering Pressure
14	727-3188A	1	/P	Hose, Steering Tank
15	727-3199	1		Manifold, Return
16	727-3209	1		Tube, Cylinder Return
17	737-3127	1		Fitting, 90 Degree

7264 Tractor
Lift Valve And Position Control


Page 61 of 79



7264 Tractor
Lift Valve And Position Control

Page 62 of 79


Ref #	Part Number	Qty	S/P/F	Description
1	603-0663	1		Link Assembly, Feedback
2	603-04091	1		Link Assembly, Input
3	603-04085	1		Link, HI-LO Shifter
4	703-3360	1	S	Link, Feedback
5	703-3610	1		Bracket, Lift Brace
6	703-04084	1		Bracket, Valve Mtg.
7	703-3698A	1		Handle, HI-LO Shifter
8	703-3762	1		Bracket, Lift Mtg.
9	703-3763A	1	/P	Handle, Lift
10	710-0564	3	/P	Screw, Hex Cap, 1/4-20 x 2.75 GR5
11	710-0607	7	/P	Screw, Hex Wash Hd. Tapp 5/16-18 x .5
12	710-3008	2	/P	Screw, Hex Cap, 5/16-18 x .75 GR5
13	711-1316	2		Ferrule, Feedback Adjustment ..
14	711-1612	1		Pin, .25 x 1.0
15	711-1614	1		Link, Valve
16	712-0324	7	/P	Nut, Hex Nylon Insert Lock 14-20 GR8
17	712-3004A	2	/P	Nut, Hex Flange Lock, 5/16-18 GR5
18	712-3029	2	/P	Nut, Hex Jam, 1/2-20 GR5
19	715-0120	1	S	Pin, Spirol, 3/16 x 1.0
20	718-3130	1		Valve, Hydraulic Lift
21	723-3013	1	S	Washer, Friction, .515 x 1.5 x .12
22	731-3321	2		Grip, Handle
23	732-0330	1	S	Spring, Compression
24	732-0499	1		Spring, Compression
25	736-3019	1		Washer, Flat, .531 x 1.062 x .134
26	736-3022	2	S	Washer, Belleville, .53 x 1.375 x .06
27	719-3013	1	/P	Clevis, Adjustment
28	741-3084	2		Bearing, Nylon Flange .75 ID
29	747-3394	1		Rod, Feedback
30	747-04131	1		Rod, Hi-LO Connecting
31	603-04086	1		Shaft, Hi-Lo Shifter
32	712-3058	1	S	Nut, Hex Nylon Lock, 1/2-20
33	714-0104	2	S	Pin, Internal Cotter



7264 Tractor
Lubrication

Page 64 of 79


Ref #	Part Number	Qty	S/P/F	Description
1	BS-825278	2		Plug, Oil Drain 16mm
2	BS-825000	1		Switch, Oil Pressure
3	BS-820582	2		Washer, Sealing
4	BS-820034	1		Screw, Oil Pump Screen
5	BS-820144	1		Tube, Dipstick
6	BS-820069	2		Nut, Oil Pump Screen
7	BS-820017	2		Stud, Oil Pan
8	BS-820068	2		Nut, Oil Pan
9	BS-825089	1		Oil Pump Screen
10	BS-820034	17		Screw, Oil Pan
11	BS-820104	1		Gasket, Oil Pump Screen
12	BS-820137	1		Gasket, Oil Pan
13	BS-820572	1		Dipstick
14	BS-825154	1		Connector, Oil Pressure Switch
15	BS-825285	1		Pan, Oil
16	BS-820238	1		Bracket, Support
17	BS-820662	1		Collar, Dipstick Tube



7264 Tractor
Pedestal

Page 66 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	703-3383A	1	S	Pedestal
2	703-3717	1		Bracket, Dash Mtg. RH
3	703-3721	1		Bracket, Dash Mtg. LH
4	703-3725	1		Bracket, Steering Column
5	703-3895	1		Bracket, Brake Lever
6	703-4064	1		Bracket, Pump Mtg
7	710-0623	4	/P	Screw, Hex Wash, Hd Tapp 3/8-16 x .75
8	710-0642	4	/P	Screw, Hex Wash, Hd Tapp 1/4-20 x .75
9	710-0653	4	/P	Screw, Hex Wash, Hd Tapp 1/4-20 x .375
10	710-1260A	3	/P	Screw, Hex Wash, Hd Tapp 5/16-18 x .75
11	710-3008	2	/P	Screw, Hex Cap 5/16-18 x .75 GR5
12	711-1361	1		Shaft, Steering
13	712-0292	2	/P	Nut, Speed, 1/4-20
14	712-0411	4	S	Nut, Hex Nylon Insert Lock, 5/16-24 GR8
15	712-3004A	2	/P	Nut, Hex Flange Lock, 5/16-18
16	714-0104	4	S	Pin, Internal Cotter
17	716-0101	1	S	Ring, Snap, .75 ID
18	718-3129	1		Pump, Hydraulic Steering
19	731-3359	1		Lever, Parking Brake
20	736-0343	2	/P	Washer, Flat, .33 x 1.25 x .12
21	741-0245	1	S	Bearing, Hex Flange, .75 ID
22	747-3543A	1		Rod, Parking Brake
23	747-3454	1		Pin, Parking Brake Pivot



7264 Tractor
PTO Drive

Page 68 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	618-3189	1		Clutch Assembly, PTO
2	619-3076A	1	S	Housing, Rear
3	710-0751	6	/P	Screw, Hex Cap Lock, 1/4-20 x .62
4	710-1238	2	/P	Screw, Hex Wash Hd, 5/16-18 x .875 GR5
5	710-3006	1	/P	Screw, Cup Set, 5/16-18 x 3/8 ..
6	710-3013	1	/P	Screw, Hex Cap, 1/4-20 x .5 GR5
7	710-3118	9	/P	Screw, Hex Cap Lock, 3/8-16 x 1.0 GR5
8	710-04003	6	S	Screw, Round Hd, 6mm x 40mm
9	711-1325	1		Shaft, 540 PTO
10	711-1337	1	S	Shaft, Input
11	711-1345	1		Shaft, 2000 PTO
12	711-1371	1		Shaft, PTO Back
13	711-1373	1		Shaft, PTO Actuator
14	716-0180	4		Ring, Retaining
15	716-0200	1		Ring, Retaining
16	716-0201	1		Ring, Retaining
17	716-0384	1		Ring, Retaining
18	716-0393	1		Ring, Retaining
19	716-0397	1	/P	Ring, Retaining
20	716-3001	1	S	Ring, Retaining
21	717-3469	1		Gear, 540 PTO: 81T
22	717-3479	1	S	Gear, Auxiliary Drive Idler: 28T
23	717-3487	1		Gear, 2000 PTO: 61T
24	717-3490	1	S	Gear, Auxiliary Drive Pinion: 28T
25	717-3491	1	S	Gear, Auxiliary Drive: 32T
26	717-3492	1		Gear, 540 PTO Pinion: 14T
27	717-3494B	1		Gear, 2000 PTO Pinion: 54T
28	717-3500	1		Gear, 2000 PTO Pinion: 34T
29	718-0668	1		Gear, Spline Coupling
30	718-0681	1		Cover, 2000 PTO
31	718-3116	1		Collar, 2 Speed
32	718-3134	1		Coupling, PTO
33	719-0551A	1	S	Actuator, PTO
34	721-0496	1		Seal, Oil
35	721-0497	1		Seal, Oil
36	721-0500	1		O-Ring
37	721-0504	1		Plug, Oil
38	721-0509	1		Seal, Oil
39	721-3020A	1	S	Seal, Oil
40	732-0187	1		Spring, Compression
41	732-0863	1	S	Spring, Detent
42	732-0980	1		Spring, Compression
43	736-0355	1	/P	Washer, Flat, .56 x 1.0 x .040 ...
44	736-0463	1	S	Washer, Flat, .25 x .630 x .0515
45	736-0615	2		Washer, Thrust, 1.007 x 1.542 x .03
46	741-0724	1		Bearing, Sleeve, 20mm x 23mm x 20mm
47	741-0862	1	/P	Ball, Detent
48	741-0991	2		Bearing, Sleeve, 13mm x 15mm x 10mm
49	741-1100	1		Bearing, Ball
50	741-1118	1		Bearing, Needle
51	741-3033A	5	S	Bearing, Ball
52	741-3037	2	S	Bearing, Ball
53	741-3057	3	S	Bearing, Ball


7264 Tractor
PTO Drive

Page 69 of 79

Ref #	Part Number	Qty	S/P/F	Description
54	741-3083	1		Bearing, Needle Thrust
55	748-3094	1		Arm, PTO Select
56	750-1223	1		Spacer, 13mm x 20mm x 14mm
57	750-1228	1		Spacer, .80 x 1.85 x .855
58	736-0570	1	S	Washer, Flat, .865 x 1.145 x .03
59	750-0532	1	S	Spacer, .980 x 1.25 x .420

7264 Tractor
Seat Assembly

Page 70 of 79




7264 Tractor
Seat Assembly

Page 71 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	603-0860-0637	1		Support, Seat - Upper
2	603-0866	1		Track Ass'y., Seat w/Latch
3	703-3208	1		Track Ass'y., Seat w/o Latch
4	703-3681A	1	/P	Tray, Lower Seat
5	703-3711	2		Bracket, Seat Belt
6	710-0376	2	/P	Screw, Hex Cap, 5/16-18 x 1.0 GR5
7	710-0451	4	/P	Screw, Carriage, 5/16-18 x .75
8	710-0528	2	/P	Screw, Hex Cap, 5/16-18 x 1.25 GR5
9	710-0759	4		Screw, Hex Flange, 5/16-18 x .625 GR5
10	710-3250	4	/P	Screw, Socket Hd Cap, 5/16-18 x 1.5
11	712-3004A	12	/P	Nut, Hex Flange Lock, 5/16-18
12	725-3167	1	S	Switch, Snap Mount (N.O.)
13	732-3080A	2	/P	Spring, Compression, 1.28 x 3.5
14	738-0140	4	S	Screw, Shoulder, .435 x .178-5/16-18
15	750-0258	4	/P	Spacer, .315 x .750 x .375
16	757-3012	1	S	Seat, High Back
	777D04541	1		Graphic, Cub Cadet
	777D01782	1	/P	Graphic, USA
17	757-3013	1		Belt Assembly, Seat

7264 Tractor
Starter

Page 72 of 79




7264 Tractor
Starter

Page 73 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	BS-820767	1		Gear, Starter Drive
2	BS-825222	1	S	Motor, Starter
3	BS-820773	2		Screw, Starter Motor
4	BS-825437	1		Terminal Kit, Solenoid
5	BS-820067	1		Nut, Starter Motor Terminal
6	BS-820719	1		Gasket, Solenoid Cover
7	BS-820725	1		Boot, Terminal
8	BS-820763	1		Screw, Solenoid Cover
9	BS-825406	1		Drive, Starter
10	BS-825404	1		Armature
11	BS-820769	2		Seal, O-Ring
12	BS-820723	1		Nut, Solenoid Terminal
13	BS-820721	1		Nut, Solenoid Terminal
14	BS-825421	1		Cover, Solenoid
15	BS-825402	1		Spring, Detent
16	BS-820777	1		Screw, Drive Cap
17	BS-825401	1		Clutch Roller
18	BS-825408	1		Cap, Drive
19	BS-820771	1		Cap, End
20	BS-825423	1		Housing, Starter (Includes 2 Brushes)
21	BS-825410	1		Solenoid, Starter
22	BS-820019	1		Screw, Starter Motor
23	BS-820779	1		Plug, Vent
24	BS-820775	1		Screw, End Cap

7264 Tractor
Three Point Hitch

Page 74 of 79




7264 Tractor
Three Point Hitch

Page 75 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	603-0750	2	S	Link, Lower Hitch
2	603-0756	1		Link, Lift - Fixed
3	603-0757	1		Link, Lift - Adjustable
4	603-0765	1		Link, Upper Center
5	603-0933	2		Chain Assembly, Check
6	711-0174	2	/P	Pin, Clevis, .624 Dia
7	711-1105	2	/P	Pin, Klik, 1.75 Lg.
8	711-1432	2		Pin, Upper Lift Arm
9	711-1622	2		"U" Clevis, Check Chain
10	711-1648	2		Pin, Clevis, .75 x 2.75
11	712-3018	2	S	Nut, Hex, 3/4-16 GR8
12	712-3058	2	S	Nut, Hex Insert Lock, 1/2-20
13	714-0117	2	/P	Pin, Internal Cotter, .148 x 3.0
14	714-0147	2	/P	Pin, Internal Cotter, .125 x 1.75
15	714-0149B	4	S	Pin, Internal Cotter
16	736-0156	2	/P	Washer, Flat, .635 x 1.12 x .09
17	736-0262	2	/P	Washer, Flat, .385 x .87 x .09
18	747-04014	2		Pin, Double Clevis
	703-3553	1	/P	Bar, Draw (Not Shown)

7264 Tractor
Transmission Connections

Page 76 of 79




7264 Tractor
Transmission Connections

Page 77 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	603-0748-0637	1	/P	Bracket, Lower Hitch RH
2	603-0751-0637	1	/P	Bracket, Lower Hitch LH
3	603-0753-0637	1	/P	Bracket, Top Link
4	603-0754A-0637	1	/P	Bracket, Cylinder
5	603-0758-0637	1	/P	Bracket, Drawbar
6	703-3542A	1	/P	Shield, PTO
	777S30634	1		Graphic, Warning
7	703-3548A	1	/P	Bracket, Chain LH
8	703-3549A	1	/P	Bracket, Chain RH
9	710-0505	4	/P	Screw, Hex Cap 7/16-14 x 1/0 GR5
10	710-0964A	8		Screw, Hex Cap 5/8-18 x 1.31 GR5
11	710-1515	1		Screw, Hex Cap 5/8-11 x 1.5 GR5
12	710-3039	4	/P	Screw, Hex Cap 5/16-18 x .5 GR5
13	710-3067	2	/P	Screw, Hex Cap 1/2-13 x 1.75 GR5
14	710-3119	6	/P	Screw, Hex Cap 3/8-16 x .75 GR5
15	710-3131	10	/P	Screw, Hex Cap 1/2-13 x 1.0 GR5
16	711-1503	1		Pin, Lift, .75 x 2.125
17	712-3063	8		Nut, Hex Lock, 5/8-18
18	716-0101	1	S	Ring, Snap, 75 Dia
19	717-3504	1	S	Cylinder, Lift
20	736-0192	2	S	Washer, Flat, .531 x .93 x .09
21	703-05133	1		Bracket, Hitch Clip
22	747-04109	1		Rod, Top Link Retainer

7264 Tractor
Wheels

Page 78 of 79



7264 Tractor
Wheels

Page 79 of 79

Ref #	Part Number	Qty	S/P/F	Description
1	634-3045	2		Rim, TURF Tire - Front
	634-04018	2		Rim, INDUSTRIAL Tire - Front
	734-0255	2	S	Valve Stem
2	734-3122	2	S	Tire, Turf
	734-04020	2		Tire, Industrial
3	634-3046	2		Rim, TURF Tire - Rear
	634-04017	2		Rim, INDUSTRIAL Tire - Rear
	734-0255	2	S	Valve Stem
4	734-3124	2		Tire, Turf
	734-04013	2		Tire, Industrial
5	710-1808	10		Screw, Lug, M12
6	710-3294	12		Bolt, Lug, M14 x 1.5 x 20