


7284 Tractor
Auxiliary Hydraulic Loader Valve

Page 1 of 54




7284 Tractor
Auxiliary Hydraulic Loader Valve

Page 2 of 54

Ref #	Part Number	Qty	S/P/F	Description
1	603-0813	1	S	Pivot Bracket Assembly
2	603-0862	1		Valve Handle Assembly
3	703-3598-0637	1	/P	Loader Valve Mount Bracket
4	703-3972-0637	1	/P	Fitting Mount Plate
5	703-3973-0637	1	/P	Rear Fitting Mount Plate
6	710-0501	2	/P	Hex Screw, 1/4-20, 2.00, Gr5
7	710-0599	2	/P	Hex Wash. Hd. Tapp Screw 1/4-20 x .50
8	710-0604A	2	/P	Hex Wash. Hd. Tapp Screw 5/16-18 x .625
9	710-1260A	4	/P	Hex Wash. Hd. Tapp Screw 5/16-18 x .75
10	711-1611	1		Valve Pivot Shaft
11	711-1624	1		Valve Spool Link
12	711-1637	1		Ball Joint Pivot Stud
13	711-1642	1		Clevis Pin, .199 x .8125
14	712-0256	2	/P	Jam Nut, 5/16-24, Gr2
15	712-0324	2	/P	Hex Lock Nut, 1/4-20, Gr8, Nylon
16	713-3000	1	S	Chain Link
17	714-0104	1	S	Internal Cotter Pin
18	716-0865	2	/P	Snap Ring, .5
19	718-3138	1	S	Auxiliary Hydraulic Pump
	759-3964	2		Pin, Dowel
	759-3965	4	S	Bolt, Mounting
	759-3966	1		Coupler, Splined
20	718-3140	1		Loader Control Valve
21	723-0488	1	S	Ball Joint, .3125 Id x 5/16-24
22	727-3012	2	/P	Fitting, 90° 6-6 Orb
23	727-3206	1		Tube, Tandem Pump Suction
24	727-3210	1		Tube, Hydraulic - Bucket Rollback
25	727-3211	1		Tube, Hydraulic - Bucket Dump
26	727-3212	1		Tube, Hydraulic - Boom Lift
27	727-3213	1		Tube, Hydraulic - Boom Lower
28	727-3224	2		Coupling, Male Hydraulic, 3/8-18
29	727-3225	2		Coupling, Female Hydr. 3/8-18
30	727-3226	1		Tube, Auxiliary Pump Pressure
31	727-3227	1		Tube, Valve Pressure
32	727-3228	1		Tube, Valve Return
33	727-3229	1		Tube, Valve Return
34	727-3261	2		Plug, Hydraulic Coupler - Male
35	727-3262	2	/P	Plug, Hydraulic Coupler - Female
36	731-3353	1		Knob, 1.625 Dia x 3/8-16 Thd
37	731-3374	1	/P	Washer, Indicator - Red
38	731-3375	1	/P	Washer, Indicator - Yellow
39	731-3376	1	/P	Washer, Indicator - Green
40	731-3377	1	/P	Washer, Indicator - Blue
41	735-0696	1		Joystick Boot
42	737-3111	1		Fitting, 90° -8 Orb
43	737-3112	2		Fitting, Straight -8 Orb
44	737-3113	2		Fitting, Straight
45	737-3125	2		Fitting, Straight - 6 Orb
46	737-3129	4		Fitting, Bulkhead 3/4-16 x 3/8-18
47	737-3130	2		Fitting, Bulkhead 3/4-16 x 3/4-16
48	750-0845	1	S	Spacer, .34 ID x .5 OD x .31

7284 Tractor Axle Assembly 4WD (Part 1)

Page 3 of 54




7284 Tractor
Axle Assembly 4WD (Part 1)

Page 4 of 54

Ref #	Part Number	Qty	S/P/F	Description
1	619-04017	2	S	Housing, Kingpin
	759-3958	AR		Sealant, Loctite(R) Black, 5.3 oz.
2	619-04020	1	S	Housing, Axle Drop, RH
3	619-04021	1	S	Housing, Axle Drop, LH
4	619-04024	2	S	Cover, Axle
5	619-04027A	1	S	Arm, Steering, LH
6	619-04028	1	S	Arm, Steering, RH
7	710-1313	8	/P	Screw, Hex Cap, M10-1.5 x 35 GR8.8
8	710-1323	2		Plug, Hex, 3/8-16 x .5
9	710-1681	12	/P	Screw, Hex Cap, M8-1.25 x 20 GR8.8
10	710-1633	2		Plug, Screw, M14-1.5 x .827
11	710-1683	2	/P	Screw, Hex Cap, M8-1.25 x 30
12	710-3208	8		Screw, Hex Cap, M10-1.5 x 25
13	711-04141	2	S	Axle, Flange
14	711-04104	2	S	Shaft, Stub
15	711-04106	2	S	Shaft, Kingpin
16	712-0690	2	/P	Nut, Hex, M8-1.25
17	712-3103	2		Nut, Hex Flange Lock, M12-1.75
18	712-3104	1		Nut, Hex, M12-1.75 RH Thrd.
19	712-3105	1		Nut, Hex, M12-1.75 LH Thrd.
20	715-04014	2	S	Pin, Dowel, 8mm x 20mm
21	716-0201	2		Ring, Retaining
22	716-0393	2		Ring, Retaining
23	717-04040	2	S	Gear, Bevel, 13T
24	717-04041	2	S	Gear, Bevel, 34T
25	717-04045	4	S	Gear, Bevel, 14T
26	721-04087	2		Seal, Oil, 38mm x 55mm x 7mm
27	721-04066	2	S	O-Ring, 40mm x 3mm
28	721-0497	2		Seal, Oil, 35mm x 55mm x 8mm
29	723-0462	1		Ball Joint, 12-1.75 RH
30	723-0463	1		Ball Joint, 12-1.75 LH
31	736-0567	2	/P	Washer, Flat, .39 x .75 x .062
32	741-0301	2	S	Bearing, Ball
33	741-04034	2	S	Bearing, Ball
34	741-04043	2	S	Bearing, Tapered Roller w/ Race
35	741-04044	2	S	Bearing, Ball
36	741-04068	2	S	Bearing, Ball
37	741-0919	2	S	Bearing, Ball
38	741-3033A	2	S	Bearing, Ball
39	747-04134	1	S	Rod, Tie, M12-1.75

7284 Tractor
Axle Assembly 4WD (Part 2)


Page 5 of 54



7284 Tractor
Axle Assembly 4WD (Part 2)

Page 6 of 54

Ref #	Part Number	Qty	S/P/F	Description
1	603-04059	1	S	Bracket, Front Axle Mtg. - Rear
	741-04036	1	S	Bearing, Sleeve
2	603-04058	1	S	Bracket, Front Axle Mtg. - Front
	741-04037	1	S	Bearing, Sleeve
3	619-04009	1	S	Housing, Main Axle RH
4	619-04014	1	S	Housing, Differential
5	619-04019	1	S	Housing, Axle LH
6	710-1313	2	/P	Screw, Hex Cap, M10-1.5 x 35 GR8.8
7	710-1682	8		Screw, Hex Cap, M8-1.25 x 25 GR8.8
8	710-3175	6	/P	Screw, Hex Cap, M8-1.25 x 14 GR8.8
9	710-1633	1		Plug, Screw, M14-1.5 x .827
10	710-3208	8		Screw, Hex Cap, M10-1.5 x 25
11	711-04140	1	S	Shaft, Input, 6T
12	711-04105	1	S	Shaft, Cross
13	711-04107	2	S	Shaft, Axle
14	712-04043	1	/P	Nut, Special, 24mm
15	715-04011	1		Pin, Roll, 5mm x 26mm
16	715-04014	4	S	Pin, Dowel, 8mm x 20mm
17	717-04064	1	S	Gear, Bevel, 34T
18	717-04046	2	S	Gear, Miter, 10T
19	717-04047	2	S	Gear, Miter, 16T
20	721-04056	1	S	Seal, Oil, 52mm x 35mm x 10mm
21	721-04067	1	S	O-Ring, 19mm x 3mm
22	731-04336	1	S	Dipstick, Front Axle
23	736-0264	6	S	Washer, Flat, .33 x .63 x .0635
24	736-0287	1	S	Washer, Flat, .793 x 1.24 x .06 Hdn.
25	736-04098	2	S	Washer, Special Spherical
26	736-0562	AR	S	Washer, Flat, .793 x 1.37 x .005
	736-0563	AR		Washer, Flat, .793 x 1.37 x .010
	736-0564	AR		Washer, Flat, .793 x 1.37 x .015
	736-0565	AR		Washer, Flat, .793 x 1.37 x .020
	736-0566	AR		Washer, Flat, .793 x 1.37 x .025
	736-0287	AR	S	Washer, Flat, .793 x 1.24 x .06 Hdn.
27	741-04038	1	S	Washer, Thrust, 1.66 x 2.59 x .059
28	741-04039	1	S	Washer, Thrust, 1.03 x 1.73 x .059
29	741-04042	2	S	Bearing, Tapered Roller w/ Race
30	741-04044	2	S	Bearing, Ball
31	741-04045	1	S	Bearing, Ball
32	741-04046	1	S	Bearing, Ball
33	750-04133	2	S	Spacer, 20 x 25 x 16mm
34	750-04164	1	S	Spacer, 25 x 35 x 12mm
35	750-0750	2	S	Spacer, .5 x .75 x .86
	737-3065	2.5 qt.	/P	Oil, 85W-140



7284 Tractor
Battery And Electrical

Page 8 of 54

Ref #	Part Number	Qty	S/P/F	Description
	629-04071	1		Harness, Main Wire Not Shown
2	703-4104-0637	1	/P	Strap, Battery Holddown
3	703-4131	1	S	Bracket, Fuse Center
4	710-0206	2	/P	Screw, Hex Cap, 1/4-10 x .875 GR5
5	710-0599	2	/P	Screw, Hex Wash Hd. Tapp 1/4-20 x .5
6	712-0324	2	/P	Nut, Hex Nylon Insert Lock, 1/4-20
7	712-0421	2		Nut, Wing w/Bell Washer, 5/16-18
8	725-3174	1	S	Battery, 500 cca Dry
9	725-04070	1	S	Switch, PTO Reverse Override
10	747-3433	2		Rod, Battery Holddown



7284 Tractor
Controls

Page 10 of 54

Ref #	Part Number	Qty	S/P/F	Description
1	603-0671	1		Shaft Assembly, Brake
2	603-0672	1	S	Shaft Assembly, Forward
3	603-0673A	1		Link Assembly, Pedal
4	603-0674A	1		Plate, Bearing
5	603-0678	1		Link Assembly, Brake LH
6	603-0679A	1		Link Assembly, Parking Brake
7	603-0680	1		Link Assembly, Brake RH
8	603-0749	1		Shaft Assembly, Differential
9	603-0770	1		Link, PTO Select
10	703-05183	1	S	Bracket, Brake Switch
11	703-3541	1		Bracket, Differential Pivot
12	703-3571A	1	S	Handle, PTO
13	703-3575	1		Link, Differential Pivot
14	703-3582	1		Bracket, Diff. Actuator Mtg.
15	703-4099	1	S	Bracket, Reverse Switch
16	710-0599	2	/P	Screw, Hex Wash Hd Tapp 1/4-20 x .5
17	710-0642	4	/P	Screw, Hex Wash Hd Tapp 1/4-20 x .75
18	710-1260A	12	/P	Screw, Hex Wash Hd Tapp 5/16-18 x .75
19	710-0654A	2	/P	Screw, Hex Wash Hd Tapp 3/8-16 x 1.0
20	711-0415	1	S	Pin, Clevis, 3/8 x 1.75
21	711-0723A	3	S	Ferrule, 3/8-24 x .375 Dia. Hdn
22	711-1362	3		Ferrule, Brake
23	711-3397	1		Ferrule, 3/8-24 x .37
24	712-0239	3	S	Nut, Hex Lock, 1/2-20
25	712-0379	1	/P	Nut, Hex Flange Lock, 3/8-24
26	712-0431	1	S	Nut, Hex Flange Lock, 3/8-16
27	712-0711	1	/P	Nut, Hex Jam, 3/8-24
28	712-3027	3	S	Nut, Hex Flange Lock, 1/4-20
29	712-3077	2	/P	Nut, Hex, M8 x 1.25 GR8.8
30	713-3000	1	S	Link, Chain
31	714-0104	11	S	Pin, Internal Cotter
32	714-0147	2	/P	Pin, Internal Cotter
33	714-3020	1	/P	Pin, Internal Cotter
34	725-3164A	1	S	Switch, Plunger
35	725-04064	1	S	Switch, 3-Pole Plunger - Brake
36	727-04033	1	S	Cylinder, Damper
37	731-3296	1		Pedal, Brake
38	731-3299A	1		Pedal, Forward/Reverse
39	731-3320	1		Pedal, Differential
40	731-3321	1		Grip, Handle
41	732-0324	2		Spring, Compression
42	732-0756A	1	S	Spring, Torsion
43	732-0859	1	S	Spring, Rev/No Cut
44	732-3065	1		Spring, Compression
45	732-3117	1		Spring, Switch Actuator
46	732-3118	1		Spring, Extension
47	736-0173	3	/P	Washer, Flat, .28 x .74 x .063
48	736-0185	2	S	Washer, Flat, .375 x .738 x .063
49	736-0232	1	S	Washer, Wave, .53 x .78 x .013
50	736-3019	3		Washer, Flat, .53 x .1.06 x .134
51	736-3069	1		Washer, Flat, .53 x .875 x .15
52	738-0509	1		Screw, Shoulder, .50 x 1.825
53	738-0533	1	S	Screw, Shoulder, .498 x 1.635

7284 Tractor
Controls

Page 11 of 54

Ref #	Part Number	Qty	S/P/F	Description
54	738-0689	1	S	Screw, Shoulder 1/2 x .180: 3/8-24
55	741-0491	2		Bearing, Nylon. .50 ID x .341
56	741-0598	2	S	Bearing, Hex Flange, .752 ID
57	741-3073	2	S	Bearing, Flange, .375 x .58 x .25
58	741-3074	2		Bearing, Flange .626 x .938 x .344
59	741-3084	2		Bearing, Flange .751 x 1.125 x .375
60	747-3396	1		Rod, Hydro Control
61	747-3399	1	S	Rod, Brake, LH
62	747-3400	1		Rod, Brake, RH
63	747-3414	1		Rod, PTO Control
64	747-3428	1		Rod, Diff. Lock Control
65	736-3072	2	/P	Washer, Flat, .38 x .93 x .11 HT


7284 Tractor
Dash Panel And Steering Wheel

Page 13 of 54

Ref #	Part Number	Qty	S/P/F	Description
1	603-0711A	1	S	Tab Assembly, Throttle
2	629-04058	1	S	Wire Harness, Dash
3	631-0076	1		Boot, Steering Shaft
4	631-04007B	1	S	Dash
5	703-05132	1	S	Plate, Throttle Mtg.
6	710-0604A	2	/P	Screw, Hex Wash. Hd. Tapp 5/16-18 x .625
7	710-0924	4	/P	Screw, Pan Hd., 1/4-20 x .75
8	710-3013	6	/P	Screw, Hex Cap, 1/4-20 x .5 GR5
9	712-0237	1	S	Nut, Hex Lock, 5/16-24
10	712-0292	2	/P	Nut, Speed, 1/4-20
11	712-0116	1	S	Nut, Hex Insert Jam Lock, 3/8-24
12	723-3013	1	S	Washer, Friction, .515 x 1.5 x .12
13	725-2017	1		Plug
14	725-3288	1	S	Panel, Instrument
15	725-3274	1		Switch, Headlight
16	725-04076	1	S	Switch, PTO
17	725-3277	1	S	Switch, Ignition
18	725-3279	1	S	Switch, Hazard
19	731-3209	1		Steering Wheel, Soft Grip
20	731-3210	1		Cover, Steering Wheel
21	731-3298	1		Handle, Throttle
22	731-3344	1		Panel, Dash Insert
23	736-0242	1	/P	Washer, Belleville, .34 x .872 x .06
24	736-0329	3	S	Washer, Lock, 1/4
25	736-0112	2	/P	Washer, Belleville, .531 x 1.62 x .045
26	736-3052	1	/P	Washer, Flat, .406 x 1.0 x .105
27	746-04126	1		Cable, Throttle
28	759-3950	1	S	Key Set, Ingition
	725-04218	1	S	Glow Timer Relay (Not Shown)

7284 Tractor
Differential And Final Drive

Page 14 of 54




7284 Tractor
Differential And Final Drive

Page 15 of 54

Ref #	Part Number	Qty	S/P/F	Description
1	619-3060	2	S	Housing, Axle
2	661-3014	2		Brake Assembly, Drum
3	710-0538	10	/P	Screw, Hex Cap Lock, 5/16-18 x .625 GR5
4	710-1695	4		Screw, Socket Hd. Cap, 3/8-16 x 1.0
5	710-3119	4	/P	Screw, Hex Cap Lock, 3/8-16 x .75 GR5
6	710-3238	24		Screw, Hex Cap Lock, 7/16-14 x 1.75 GR5
7	711-1326	1		Shaft, Axle Stub RH
8	711-1327	2		Shaft, Axle
9	711-1358	1		Shaft, Axle Stub LH
10	711-1389A	1	/P	Shaft, Differential Lock Actuator
11	715-0226	8		Pin, Dowel, .3752 x .75
12	715-3010	4	/P	Pin, Dowel, .25 x .75
13	716-0180	2		Ring, Retaining
14	716-0195	2		Ring, Retaining
15	716-0196	2		Ring, Retaining
16	716-0390	2		Ring, Retaining
17	716-0391	4		Ring, Retaining
18	716-0396	1		Clip, Rotor
19	716-0397	1	/P	Ring, Retaining
20	717-1120	4		Gear, Differential, 10T
21	717-1173	1		Shaft, Cross
22	717-1178	2		Shaft, Cross
23	717-1180	1		Block, Differential Pinion
24	717-3316	1		Gear, Bevel, 65T
25	717-3317	2		Gear, Miter, 14T
26	717-3471	1		Gear, Drop Axle, 42T RH
27	717-3478	1		Gear, Drop Axle, 42T LH
28	718-0666	1		Carrier, Differential
29	718-3104	1		Collar, Differential Lock
30	718-3105	1		Yoke, Differential Lock
31	718-3112	1		Cover, Bearing
32	721-0495	2		Seal, Oil, 50mm x 75 mm x 10mm
33	721-0496	1		Seal, Oil
34	721-3020A	2	S	Seal, Oil, 1.181 x 2.453 x .276
35	732-0187	1		Spring, Compression
36	736-0355	1	/P	Washer, Flat, .56 x 1.0 x .04
37	736-0715	4		Washer, Thrust, 1.12 x 1.75 x .03
38	741-0721	2	/P	Bearing, Ball
39	741-1104	2	/P	Bearing, Ball
40	741-1107	2		Bearing, Ball
41	741-1112	2		Bearing, Thrust
42	741-3033A	2	S	Bearing, Ball
43	741-3080	1		Bearing, Needle
44	761-3071	2		Drum, Brake

7284 Tractor
Engine And Drive Shaft

Page 16 of 54



7284 Tractor
Engine And Drive Shaft

Page 17 of 54

Ref #	Part Number	Qty	S/P/F	Description
	629-04084	1		Harness, Engine Wire Not Shown
1	703-05444-0637	1	S	Bracket, Air Filter Mtg.
2	731-04695	1		Hose, Air Inlet
3	731-04696	1		Hose, Air Filter
4	731-04704	1		Hose, Radiator to Engine
5	731-04706	1		Hose, Engine to Radiator
6	603-04130-0637	1		Bracket, Engine RH
7	603-04164-0637	1	S	Bracket, Engine LH
8	651-04044	1	S	Filter Assembly, Fuel
8	759-04027	1		Filter Element
9	703-05140A-0637	1	/P	Plate, Baffle RH
10	703-05141A-0637	1	/P	Plate, Baffle, LH
11	703-05282A	1		Plate, Engine RPM
12	703-05392-0637	1		Bracket, Cable Mtg.
13	703-05454-0637	1	/P	Bracket, Filter Mtg.
14	703-05361-0637	1	/P	Bracket, Over Flow Bottle
15	703-05511-0637	1	/P	Bracket, Sensor Mtg.
16	703-3483-0637	1		Plate, Radiator Baffle
16	777S30631	1		Graphic, Fan Warning
16	777S30633	1		Graphic, Warning
17	703-3484-0637	1		Bracket, Radiator Mtg. RH
17	777S30632	1		Graphic, Warning
18	703-3485-0637	1		Bracket, Radiator Mtg. LH
18	777S30632	1		Graphic, Warning
19	703-3741-0637	1		Bracket, Radiator Mtg.
20	710-0190	2	/P	Screw, Hex Cap, 5/16-18 x 4.0 GR5
21	710-0224	1	S	Screw, Hex Wash Hd Tapp 10-16 x .5
22	710-0347	2	/P	Screw, Hex Cap 3/8-16 x 1.75 GR5
23	710-04177	16	S	Screw, Hex Cap, M12-1.25 x 25 GR8.8
24	710-0425	1	/P	Screw, Truss Mach. #10-24 x .625
25	710-04315	3		Screw, Countersink Torx Hd M8-1.25 x 20
26	710-0597	2	/P	Screw, Hex Cap 1/4-20 x 1.0 GR5
27	710-0607	6	/P	Screw, Hex Wash Hd Tapp 5/16-18 x .5
28	710-0623	4	/P	Screw, Hex Wash Hd Tapp 3/8-16 x .75
29	710-1260A	10	/P	Screw, Hex Wash Hd Tapp 5/16-18 x .75
30	710-3008	8	/P	Screw, Hex Cap 5/16-18 x .75 GR5
31	710-3015	7	/P	Screw, Hex Cap 1/4-20 x .75 GR5
32	710-3138	5	/P	Screw, Hex Cap, M8-1.25 x 16
33	710-3144	4	/P	Screw, Hex Cap
34	710-3206A	4	/P	Screw, Hex Cap, M8-1.25 x 25 GR8.8
35	710-3208	3		Screw, Hex Cap, M10-1.5 x 25 GR5
36	710-3209	1		Screw, Hex Cap, M6-1.0 x 10 GR8.8
37	711-0653	1	/P	Pin, Clevis, .312 x 1.0
38	712-0324	9	/P	Nut, Hex Insert Lock, 1/4-20
39	712-0431	6	S	Nut, Hex Flange Lock, 3/8-16
40	712-3004A	10	/P	Nut, Hex Flange Lock, 5/16-18
41	712-3056	1	/P	Nut, Jam, 5/8-18 GR5
42	714-0104	1	S	Pin, Internal Cotter
43	717-04128	1	S	Shaft, Drive
43	759-04059	1		Flex Drive Shaft Coupler Kit Not Shown
44	722-3022	1	S	Tape, Foam, .625 wide 42in.
45	723-3061	1		Seal, Heat Baffle 104in
46	725-0157	1	/P	Tie, Cable


7284 Tractor
Engine And Drive Shaft

Page 18 of 54

Ref #	Part Number	Qty	S/P/F	Description
47	725-04212	1		Sensor, RPM
48	725-3281	1		Wire, Battery Pos.
49	725-3283	1		Wire, Ground
50	725-3287	1		Wire, Battery Neg.
51	726-0205	7	/P	Clamp, Hose
52	726-04026	4		Clamp, Hose
53	726-04041	1		Clamp, Hose
54	726-0476	3		Clamp, Adjustable Hose
55	731-04018	2		Grommet, Hose Guard
56	731-04617	1		Shroud, Fan
57	731-04667	4		Mount, Compression Engine
58	731-04731	1		Container, Over Flow
59	735-0226	1		Grommet, Rubber
60	736-0148	1	/P	Washer, External Lock, 3/8
61	736-0158	1	S	Washer, Lock, 5/8
62	736-0173	7	/P	Washer, Flat, .28 x .74 x .063
63	736-0275	2	S	Washer, Flat, .344 x .688 x .065
64	736-04018	4		Washer, Flat, .38 x 2.0 x .12
65	736-0607	1	/P	Washer, External Lock, 5/16
66	736-3008	3	S	Washer, Flat, .344 x .75 x .12
67	BS-691024	1	/P	Clamp, Casing
68	751-0535-68	.	S	Hose, Fuel Line 63in.
69	751-10048	1	S	Muffler, Engine
70	751-10151	1		Hose, Over Flow
71	751-3130	.		Fuel Line, 5/16 ID 83in.
72	751-3165	1		Radiator
72	722-0268	2		Grommet, Rubber Mtg.
73	751-3192	1	S	Cap, Radiator, 13psi
74	751-3193	1		Screen, Debris
75	718-3132	1	S	Cooler, Oil
76	751-3194	1	/P	Element, Air Cleaner
77	751-3195	1		Cap, Air Cleaner
78	751-3196	1		Canister, Air Cleaner
79	751-3197	1		Nozzle, Air Cleaner

7284 Tractor
Fender And Running Board


Page 19 of 54



7284 Tractor
Fender And Running Board

Page 20 of 54


Ref #	Part Number	Qty	S/P/F	Description
1	625-0023B	1	S	Light Assembly, Rear RH
	725-3262	1	S	Bulb Only, Tail Light
	725-3263	1	S	Bulb Only, Reverse Indicator Light
	629-3059	1		Harness, Tail Light
2	625-0024B	1	S	Light Assembly, Rear RH
	725-3262	1	S	Bulb Only, Tail Light
	725-3263	1	S	Bulb Only, Reverse Indicator Light
	629-3059	1		Harness, Tail Light
3	703-3451	1		Bracket, Seat Mtg. LH
4	703-3572	1		Bracket, Seat Mtg. RH
5	703-3754	1		Bracket, Rear Seat Support
6	710-0604A	8	/P	Screw, Hex Wash Hd. Tapp 5/16-18 x .625
7	710-3038	4	/P	Screw, Hex Cap 5/16-18 x .875 GR5
8	710-0206	4	/P	Screw, Hex Cap 1/4-20 x .875 GR5
9	710-3021	3	/P	Screw, Hex Wash Hd. Tapp 5/16-18 x .625
10	710-3008	2	/P	Screw, Hex Cap 5/16-18 x .75 GR5
11	710-1242	8	/P	Screw, Truss Phillips Hd. 5/16-14 x .75
12	710-1260A	3	/P	Screw, Hex Wash Hd. Tapp 5/16-18 x .75
13	710-0971	2		Screw, Pan Hd. 5/16-18 x 1.0
14	726-3057	4	S	Clip, Tail Light
15	726-3046	12	/P	Clip, Ratchet Fastener
16	726-0211	6	S	Speed Nut, 'U' Type, 5/16-18
17	731-3324	1	S	Cover, Fender
	777S30630	1		Graphic, Warning
18	731-3289	1		Fender
	777S30635	1		Graphic, Warning
	777D07976	1		Graphic, Series 7000
	777D07973	2		Graphic, Posi Trak
19	631-04005A	1	S	Cover, Fender, RH
20	631-04006A	1	S	Cover, Fender, LH
21	735-0669	1		Pad, Floor, RH
22	735-0670	1		Pad, Floor, LH
23	735-0690	4		Grommet, .4375 ID x .75
24	736-3089	4	/P	Washer, Flat, .345 x 1.0 x .100
25	750-3310	4		Spacer, Flange, .3125 x .4375 x .625
26	750-04143	4	S	Spacer, .258 x .5 x .5
27	710-0895	4		Screw, Hex Wash Hd Tapp, 1/4-15 x .75
28	703-05296	1	S	Bracket, Shift Gate (Hi-Lo)
29	703-05297	1	S	Bracket, Shift Gate (PTO)



7284 Tractor
Foldable ROPS

Page 22 of 54

Ref #	Part Number	Qty	S/P/F	Description
1	603-0716	1	S	ROPS Assembly, Lower
2	603-0717	1		ROPS Assembly, Upper
3	603-0858	1		Mounting Assembly, ROPS RH
4	603-0861	1		Mounting Assembly, ROPS LH
5	710-0376	2	/P	Screw, Hex Cap, 5/16-18 x 1.0 GR5
6	710-0515	2		Screw, Hex Cap, 1/2-20 x 3.5 GR5
7	710-3032	8	/P	Screw, Hex Cap, 1/2-13 x 1.25 GR5
8	710-3131	8	/P	Screw, Hex Cap, 1/2-13 x 1.0 GR5
9	711-1610	2		Pin, Clevis, .5 x 3.5
10	712-3046	2	/P	Nut, Hex Jam, 5/16-18
11	712-3058	2	S	Nut, Hex Nylon Insert Lock, 1/2-20
12	712-3066	2	S	Nut, Hex, 1/2-20 GR5
13	714-3003	2	S	Pin, Internal Cotter
14	725-3280	2		Light Assembly, Hazard
	725-3286	2	S	Bulb, Light
15	736-0921	2	S	Washer, Lock, 1/2
16	731-0757-16	16in.		Conduit




7284 Tractor
Frame

Page 24 of 54

Ref #	Part Number	Qty	S/P/F	Description
1	603-0666A	1	S	Frame
2	703-3503A	1	/P	Lever, Hood Latch
3	703-3497A	1	/P	Bracket, Running Board Mtg. LH
4	703-3379A	1	/P	Bracket, Running Board Mtg. RH
5	703-05137	1	S	Bracket, Hood Latch Mtg.
6	710-3083	3	/P	Screw, Hex Cap, 5/16-18 x 1.375 GR5
7	710-0451	2	/P	Screw, Carriage, 5/16-18 x .75
8	710-1260A	6	/P	Screw, Hex Wash. Hd. 5/16-18 x .75
9	712-3004A	5	/P	Nut, Hex Flange Lock, 5/16-18
10	726-0455	1		Latch, Hood

7284 Tractor
Front Axle 4WD


Page 25 of 54



7284 Tractor
Front Axle 4WD

Page 26 of 54

Ref #	Part Number	Qty	S/P/F	Description
1	618-04084	1	S	Axle, 4WD Front
2	703-05357	1	S	Bracket, Cylinder Mounting
3	710-04208	4		Screw, Hex Cap, w/Patch M12-1.75 x 25 GR8
4	710-04214	1		Screw, Sq. Hd Lock. 5/16-18
5	710-3181	8	/P	Screw, Hex Cap 1/2-13 x 1.5 GR5
6	711-1410	1		Stud, Cylinder Mounting
7	712-3016	2	/P	Nut, Hex Insert Lock 5/8-11 GR5
8	712-3083	8	/P	Nut, Hex Insert Lock, 1/2-13 GR8
9	712-3107	1	/P	Nut, Hex Lock, 3/4-10 GRC
10	717-3513A	1	/P	Shaft, 4WD Drive
11	717-04119	1	S	Cylinder, Steering
11	727-3012	1	/P	Fitting, 90 Deg Hyd 3/8 x 3/8 Not shown
11	927-3002	1	/P	Connector - Swivel Tube 37 Degree Fl Not shown
12	736-0921	2	S	Washer, Lock, 1/2
13	738-04049	1	S	Screw, Shoulder, .75 x 1.03




7284 Tractor
Fuel Tank

Page 28 of 54

Ref #	Part Number	Qty	S/P/F	Description
1	703-3563	1		Bracket, Front Tank Mtg.
2	710-0817	4		Screw, Hex Wash Hd Tapp 5/16-18 x 1.25
3	710-1260A	3	/P	Screw, Hex Wash Hd Tapp 5/16-18 x .75
4	735-0149	1	S	Bushing, Rubber
5	736-0231	4	S	Washer, Flat, .344 x 1.125 x .12
6	751-3169A	1		Tank, Fuel
7	751-3174	1		Fitting, Fuel Return
8	751-3175	1	S	Sensor, Fuel Level
9	751-3188	1	/P	Cap, Fuel - Diesel

7284 Tractor
Hood, Grill And Side Panels


Page 29 of 54



7284 Tractor
Hood, Grill And Side Panels

Page 30 of 54


Ref #	Part Number	Qty	S/P/F	Description
1	603-0719A-0637	1	/P	Hinge Assembly, Hood
2	625-0052	1	S	Headlight Assembly
2	725-3161A	4	S	Bulb, Headlight Not shown
3	703-05281-0637	1	/P	Bracket, Side Panel Mtg. RH
4	703-05284-0637	1	/P	Bracket, Side Panel Mtg. RH Rear
5	703-05293-0637	1	/P	Bracket, Side Panel Mtg. LH Rear
6	703-05295-0637	1	/P	Bracket, Side Panel Mtg. LH
7	703-3394	1	S	Screen, Intake
8	703-3712A	1	S	Shield, Upper Heat
9	703-3764-0637	1		Bracket, Panel Mtg.
10	703-3765-0637	1		Shield, Lower Heat
11	710-0473	6	/P	Screw, Truss Hd, 10-24 x .5
12	710-0599	14	/P	Screw, Hex Wash Hd Tapp 1/4-20 x .5
13	710-0751	4	/P	Screw, Hex Wash. Hd. 1/4-20 x .62 GR5
14	710-3170	4		Stud, Cylinder, 5/16-18 Thrd
15	712-0272	6	/P	Nut, Hex Sems, 10-24
16	712-0324	4	/P	Nut, Hex Nylon Insert Lock, 1/4-20
17	712-0431	2	S	Nut, Hex Flange Lock, 3/8-16
18	712-3004A	4	/P	Nut, Hex Flange Lock, 5/16-18
19	726-04010	1		Clip, Retaining
20	726-3056	4		Latch, 1/4 Turn Panel
21	727-3194	2		Cylinder, Gas Spring
22	731-04540	1	S	Panel, Side LH
23	731-04541	1	S	Panel, Side RH
24	759-04115A	1		Hood, Service Kit Replaces 731-3277 in this application, Refer to diagram Hood 759-04115A
24	731-06889	1	S	Hood Replaces 731-3277
24	777D07558	1		Graphic, Hood RH Not shown
24	777D07559	1		Graphic, Hood LH Not shown
24	777D07975	1		Graphic, Model 7284D LH Not shown
24	777D07974	1		Graphic, Model 7284D RH Not shown
24	751C129A	2		Graphic, Cat Not shown
25	732-0936	4		Clip, Spring
26	732-0937	4		Spring, Compression
27	736-0272	2	S	Washer, Flat, .51 x 1.0 x .060
28	738-0380	2	S	Screw, Shoulder, .5 x .27 Lg 3/8-16



7284 Tractor
Hood, Service Kit 759-04115A

Page 32 of 54

Ref #	Part Number	Qty	S/P/F	Description
1	603-04311	1		Air Filter Bracket Assy.
2	703-05652	1		RH Hinge Bracket
3	703-05653	1		LH Hinge Bracket
4	703-05655A	1		Hood Mounting Bracket
5	703-05782	1	/P	Hood Latch Bracket
6	710-0224	1	S	#10-16 x .500 Hex Screw
7	710-0607	4	/P	5/16-18 x .50 Screw
8	710-1242	4	/P	5/16 x .75 HiLow Screws
9	710-0895	2		1/4-20 x .750 Screw
10	710-3025	2	/P	5/16-18 x .625 Bolt
11	712-04063	2	/P	5/16-18 Nylon Flange Lock Nut
12	714-0104	1	S	Cotter Pin
13	726-0233	4	/P	Push Nut
14	731-05161	1	S	Hood Cover
15	731-06889	1	S	Hood
16	732-04281A	1	/P	Latch Spring
17	747-1323A	1		Pivot Rod
18	783-04714	1	S	Latch Plate
19	783-04717A	1	/P	Pivot Latch Bracket
	721-04162	2		Foam Strip Not Shown
	736-0400	2	S	Flat Washers Not Shown
	726-0272	1	/P	Clamp Not Shown
	759-04115A	1		Service Kit Includes all parts shown




7284 Tractor
Hydraulics

Page 34 of 54

Ref #	Part Number	Qty	S/P/F	Description
1	710-0607	9	/P	Screw, Hex Wash Hd. Tapp 5/16-18 x .5
2	712-3004A	2	/P	Nut, Hex Flange Lock, 5/16-18 GR5
3	726-0132	2	/P	Clamp, Adjustable Hose
4	726-04004	5		Clamp, Hose
5	726-0475	5		Clamp, Hose
6	727-04000	2		Hose, Steering
7	727-04003	1		Hose, Lift Inlet
8	727-04059	1		Hose, Steering Pressure
9	727-04060	1		Hose, Steering-Tank
10	727-3012	3	/P	Fitting, 90 Degree
11	727-3177	1		Tube, Oil Cooler Return
12	727-3178	1		Hose, Oil Return
13	727-3182	1		Tube, Lift Return Line
14	727-3184	1		Hose, Lift Cylinder
15	727-3199	1		Manifold, Return
16	727-3209	1		Tube, Cylinder Return
17	737-3127	1		Fitting, 90 Degree

7284 Tractor
Lift Valve And Position Control


Page 35 of 54



7284 Tractor
Lift Valve And Position Control

Page 36 of 54


Ref #	Part Number	Qty	S/P/F	Description
1	603-0663	1		Link Assembly, Feedback
2	603-04091	1		Link Assembly, Input
3	603-04085	1		Link, HI-LO Shifter
4	703-3360	1	S	Link, Feedback
5	703-3610	1		Bracket, Lift Brace
6	603-04084	1	S	Bracket, Valve Mtg.
7	703-3698B	1	S	Handle, HI-LO Shifter
8	703-3762	1		Bracket, Lift Mtg.
9	703-3763A	1	/P	Handle, Lift
10	710-0564	3	/P	Screw, Hex Cap, 1/4-20 x 2.75 GR5
11	710-0607	7	/P	Screw, Hex Wash Hd. Tapp 5/16-18 x .5
12	710-3008	2	/P	Screw, Hex Cap, 5/16-18 x .75 GR5
13	711-1316	2		Ferrule, Feedback Adjustment
14	711-04214	1		Pin, Clevis, .25 x .937
15	711-1614	1		Link, Valve
16	712-0324	7	/P	Nut, Hex Nylon Insert Lock 14-20 GR8
17	712-3004A	2	/P	Nut, Hex Flange Lock, 5/16-18 GR5
18	712-3029	2	/P	Nut, Hex Jam, 1/2-20 GR5
19	715-0120	1	S	Pin, Spirol, 3/16 x 1.0
20	718-3130	1		Valve, Hydraulic Lift
21	723-3013	1	S	Washer, Friction, .515 x 1.5 x .12
22	731-3321	2		Grip, Handle
23	732-0330	1	S	Spring, Compression
24	732-0499	1		Spring, Compression
25	736-3019	1		Washer, Flat, .531 x 1.062 x .134
26	736-3022	2	S	Washer, Belleville, .53 x 1.375 x .06
27	719-3013	1	/P	Clevis, Adjustment
28	741-3084	2		Bearing, Nylon Flange .75 ID
29	747-3394	1		Rod, Feedback
30	747-04131	1		Rod, Hi-LO Connecting
31	603-04086	1		Shaft, Hi-Lo Shifter
32	712-3058	1	S	Nut, Hex Nylon Lock, 1/2-20
33	714-0104	2	S	Pin, Internal Cotter
34	714-0127	1	/P	Pin, Cotter, 1/16 x .75



7284 Tractor
Pedestal

Page 38 of 54

Ref #	Part Number	Qty	S/P/F	Description
1	603-04001A	1	S	Shaft, Steering
2	703-3383B	1	S	Pedestal
3	703-3717	1		Bracket, Dash Mtg. RH
4	703-3721	1		Bracket, Dash Mtg. LH
5	703-05361	1	S	Bracket, Steering Column
6	703-3895	1		Bracket, Brake Lever
7	703-4154	1	S	Bracket, Pump Mtg.
8	710-0623	4	/P	Screw, Hex Wash, Hd Tapp 3/8-16 x .75
9	710-0642	4	/P	Screw, Hex Wash, Hd Tapp 1/4-20 x .75
10	710-0653	4	/P	Screw, Hex Wash, Hd Tapp 1/4-20 x .375
11	710-1260A	3	/P	Screw, Hex Wash, Hd Tapp 5/16-18 x .75
12	710-1690	4		Screw, Hex, M6-1 x 16 Hardened
13	710-3008	2	/P	Screw, Hex Cap 5/16-18 x .75 GR5
14	712-0292	2	/P	Nut, Speed, 1/4-20
15	712-3004A	2	/P	Nut, Hex Flange Lock, 5/16-18
16	714-0104	4	S	Pin, Internal Cotter
17	718-3155	1	S	Pump, Hydraulic Steering
18	731-3359	1		Lever, Parking Brake
19	732-3002	1	S	Spring, Extension
20	736-0343	2	/P	Washer, Flat, .33 x 1.25 x .12
21	741-0245	1	S	Bearing, Hex Flange, .75 ID
22	747-3543A	1		Rod, Parking Brake
23	747-3454	1		Pin, Parking Brake Pivot
24	703-05362	1	S	Plate, Bearing
25	710-3015	2	/P	Screw, Hex Cap, 1/4-20 x .75 GR5
26	712-0324	2	/P	Nut, Hex Insert Lock, 1/4-20
27	736-0173	2	/P	Washer, Flat, .28 x .74 x .063



7284 Tractor
PTO Drive


Page 40 of 54

Ref #	Part Number	Qty	S/P/F	Description
1	618-3189	1		Clutch Assembly, PTO
2	619-3076A	1	S	Housing, Rear
3	710-0751	6	/P	Screw, Hex Cap Lock, 1/4-20 x .62
4	710-1238	2	/P	Screw, Hex Wash Hd, 5/16-18 x .875 GR5
5	710-3006	1	/P	Screw, Cup Set, 5/16-18 x 3/8
6	710-3013	1	/P	Screw, Hex Cap, 1/4-20 x .5 GR5
7	710-3118	9	/P	Screw, Hex Cap Lock, 3/8-16 x 1.0 GR5
8	710-04003	6	S	Screw, Round Hd, 6mm x 40mm
9	711-1325	1		Shaft, 540 PTO
10	711-1337	1	S	Shaft, Input
11	711-1345	1		Shaft, 2000 PTO
12	711-1371	1		Shaft, PTO Back
13	711-1373	1		Shaft, PTO Actuator
14	716-0180	4		Ring, Retaining
15	716-0200	1		Ring, Retaining
16	716-0201	1		Ring, Retaining
17	716-0384	1		Ring, Retaining
18	736-0563	1		Washer, Flat, .793 x 1.368 x .01 As required
19	716-0397	1	/P	Ring, Retaining
20	716-3001	1	S	Ring, Retaining
21	717-3469	1		Gear, 540 PTO: 81T
22	717-3479A	1	S	Gear, Auxiliary Drive Idler: 28T
23	717-3487	1		Gear, 2000 PTO: 61T
24	717-3490A	1	S	Gear, Auxiliary Drive Pinion: 28T
25	717-3491A	1	S	Gear, Auxiliary Drive: 32T
26	717-3492	1		Gear, 540 PTO Pinion: 14T
27	717-3494C	1	/P	Gear, 2000 PTO Pinion: 54T
28	717-3500	1		Gear, 2000 PTO Pinion: 34T
29	718-0668	1		Gear, Spline Coupling
30	718-0681	1		Cover, 2000 PTO
31	718-3116	1		Collar, 2 Speed
32	718-3134	1		Coupling, PTO
33	719-0551A	1	S	Actuator, PTO
34	721-0496	1		Seal, Oil
35	721- 0497	1		Seal, Oil
36	721-0500	1		O-Ring
37	721-0504	1		Plug, Oil
38	721-0509	1		Seal, Oil
39	721-3020A	1	S	Seal, Oil
40	732-0187	1		Spring, Compression
41	732-04101	1	S	Spring, Detent
42	732-0980	1		Spring, Compression
43	736-0355	1	/P	Washer, Flat, .56 x 1.0 x .040
44	736-0463	1	S	Washer, Flat, .25 x .630 x .0515
45	736-0615	2		Washer, Thrust, 1.007 x 1.542 x .03
46	741-0724	1		Bearing, Sleeve, 20mm x 23mm x 20mm
47	741-0862	1	/P	Ball, Detent
48	741-0991	2		Bearing, Sleeve, 13mm x 15mm x 10mm
49	741-1100	1		Bearing, Ball
50	741-1118	1		Bearing, Needle
51	741-3033A	5	S	Bearing, Ball
52	741-3037	2	S	Bearing, Ball
53	741-3057	3	S	Bearing, Ball

7284 Tractor
PTO Drive

Page 41 of 54


Ref #	Part Number	Qty	S/P/F	Description
54	741-3083	1		Bearing, Needle Thrust
55	748-3094	1		Arm, PTO Select
56	750-1223	1		Spacer, 13mm x 20mm x 14mm
57	750-1228	1		Spacer, .80 x 1.85 x .855
58	736-0570	1	S	Washer, Flat, .865 x 1.145 x .03
59	750-0532	1	S	Spacer, .980 x 1.25 x .420
60	736-0566	1		Washer, Flat, .793 x 1.368 x .025 As required



7284 Tractor
Seat Assembly

Page 43 of 54


Ref #	Part Number	Qty	S/P/F	Description
1	603-0860-0637	1		Support, Seat - Upper
2	603-0866	1		Track Ass'y., Seat w/Latch
3	703-3208	1		Track Ass'y., Seat w/o Latch
4	703-3681A	1	/P	Tray, Lower Seat
5	703-3711	2		Bracket, Seat Belt
6	710-0376	2	/P	Screw, Hex Cap, 5/16-18 x 1.0 GR5
7	710-0451	4	/P	Screw, Carriage, 5/16-18 x .75
8	710-0528	2	/P	Screw, Hex Cap, 5/16-18 x 1.25 GR5
9	710-0759	4		Screw, Hex Flange, 5/16-18 x .625 GR5
10	710-3250	4	/P	Screw, Socket Hd Cap, 5/16-18 x 1.5
11	712-3004A	12	/P	Nut, Hex Flange Lock, 5/16-18
12	725-3167	1	S	Switch, Snap Mount (N.O.)
13	732-3080A	2	/P	Spring, Compression, 1.28 x 3.5
14	738-0140	4	S	Screw, Shoulder, .435 x .178-5/16-18
15	750-0258	4	/P	Spacer, .315 x .750 x .375
16	757-04006	1	S	Seat, High Back
	777D06883	1	/P	Graphic, Cub Cadet
	777D01782	1	/P	Graphic, USA
17	757-3013	1		Belt Assembly, Seat



7284 Tractor
Three Point Hitch

Page 45 of 54

Ref #	Part Number	Qty	S/P/F	Description
1	603-0750	2	S	Link, Lower Hitch
2	603-0756	1		Link, Lift - Fixed
3	603-0757	1		Link, Lift - Adjustable
4	603-0765	1		Link, Upper Center
5	603-0933	2		Chain Assembly, Check
6	711-0174	2	/P	Pin, Clevis, .624 Dia.
7	711-1105	2	/P	Pin, Klik, 1.75 Lg.
8	711-1432	2		Pin, Upper Lift Arm
9	711-1622	2		'U' Clevis, Check Chain
10	711-1648	2		Pin, Clevis, .75 x 2.75
11	712-0301	2	/P	Nut, Hex, 3/4-10 GR5
12	712-3058	2	S	Nut, Hex Insert Lock, 1/2-20
13	714-0117	2	/P	Pin, Internal Cotter, .148 x 3.0
14	714-0147	2	/P	Pin, Internal Cotter, .125 x 1.75
15	714-0149B	4	S	Pin, Internal Cotter
16	736-0156	2	/P	Washer, Flat, .635 x 1.12 x .09
17	736-0262	2	/P	Washer, Flat, .385 x .87 x .09
18	736-0364	2	S	Washer, Lock, 3/4
19	703-3553	1	/P	Bar, Draw
20	747-04014	2		Pin, Double Clevis




7284 Tractor
Traction Drive 4WD

Page 47 of 54

Ref #	Part Number	Qty	S/P/F	Description
1	603-04096	1	S	Pin Assembly, 2 Speed
2	710-0573	4		Screw, Hex Cap Lock, 5/16-18 x 1.25 GR5
3	710-3006	1	/P	Screw, Cup Set, 5/16-18 x 3/8
4	711-1339	1		Shaft, Motor
5	711-1344	1	S	Shaft, Pinion, 16T
6	711-1372	1		Shaft, 4WD
7	711-1397	1		Shaft, 2 Speed Actuator
8	715-0120	1	S	Pin, Spirol, 3/16 x 1.25
9	716-0185	1		Ring, Retaining
10	716-0384	1		Ring, Retaining
11	716-0387	1		Ring, Retaining
12	716-0393	1		Ring, Retaining
13	716-0396	1		Clip, Rotor
14	717-3472	1		Gear, Drive Pinion, LO 24T:17T
15	717-3473	1		Gear, Drive Pinion, HI 33T: 17T
16	717-3480	1		Gear, Drive, LO:59T; HI 50T
17	717-3484	1		Clutch, Overrunning
18	718-0674	1		Cover, Front
19	718-0678	1		Spacer, Drive
20	718-3116	1		Collar, 2 Speed
21	721-0496	1		Seal, Oil
22	721-0501	1		O-Ring
23	721-0507	1		Seal, Oil
24	732-04101	1	S	Spring, Detent
25	736-0715	1		Washer, Thrust
26	741-0862	1	/P	Ball, Detent
27	741-1106	1		Bearing, Ball
28	741-1107	1		Bearing, Ball
29	741-1109	1		Bearing, Angular Contact Ball
30	741-1112	1		Bearing, Thrust
31	741-3037	1	S	Bearing, Ball
32	741-3057	1	S	Bearing, Ball
33	741-3118	2		Bearing, Sleeve
34	748-3096	1		Yoke, 2 Speed

7284 Tractor
Transmission 4WD

Page 48 of 54



7284 Tractor
Transmission 4WD

Page 49 of 54

Ref #	Part Number	Qty	S/P/F	Description
	737-3025	1	/P	Transmission Oil, 1 Qt. 6.5 gal.
	737-3062	1	/P	Transmission Oil, 1 Gal.
	737-3035	1	/P	Transmission Oil, 5 Gal.
	759-3958	1		Sealant, Loctite(R) Black, 5.3 oz. as required
1	603-0688A	1	/P	Arm, Hydro Control
2	603-0712A	1		Bracket, Transmission Mtg. RH
3	603-0713B	1		Bracket, Transmission Mtg. RH
4	619-04075	1	S	Cover, Transmission Housing
5	703-3577	1		Plate, Feedback
6	703-3715	1	S	Baffle, Oil
7	703-05041	1		Arm, Neutral RH
8	703-05042	1		Arm, Neutral LH
9	710-0294	4		Screw, Hex Cap, 1/4-20 x .375 GR5
10	710-0591	1	/P	Screw, Hex Cap Lock, 3.8-24 x 1.0 GR5
11	710-0833	4	/P	Screw, Hex Cap, 5/16-18 x 5.25 GR5
12	710-1633	1		Screw, Plug, M14 x 1.5 x .827
13	710-1853	1		Screw, Hex Special Set, 5/16-18 x .625
14	710-3005	4	/P	Screw, Hex Cap, 3/8-16 x 1.25 GR5
15	710-3013	2	/P	Screw, Hex Cap, 1/4-20 x .5 GR5
16	710-3032	6	/P	Screw, Hex Cap, 1/2-13 x 1.25 GR5
17	710-3120	9		Screw, Hex Cap Lock, 3/8-16 x 1.5 GR5
18	710-3262	2		Screw, Low Hd. Cap, 3/8-16 x .75
19	711-1355	1		Shaft, Rock
20	712-0431	2	S	Nut, Hex Flange Lock, 3/8-16
21	716-0111	1	/P	Ring, Retaining
22	716-0195	1		Ring, Retaining
23	717-3507	1	S	Pump, Hydrostatic Transmission
24	718-3131	1		Pump, Auxiliary Hydraulic
25	719-3166	1		Arm, Upper Hitch RH
26	719-3167	1		Arm, Upper Hitch LH
27	721-0501	1		O-Ring, 2.987 ID x .103 Dia
28	721-0510	2		Seal, Oil, 1.5 x 2.0 x .25
29	723-3071	1		Filter, Oil, Hydraulic System use with 737-3105 Fitting, Nipple
29	723-04032A	1		Filter, Oil, Reverse Flow style Not shown, use with 619-04163, Refer to Service Advisory CC-566
29	619-04163	1	S	Housing, Reverse Flow Not shown, use with 723-04032A, Refer to Service Advisory CC-566
30	723-3014	1	S	Filter, Oil
31	723-3021	1	/P	Breather, Transmission
32	718-3138	1	S	Auxiliary Hydraulic Pump
32	759-3964	2		Pin, Dowel
32	759-3965	4	S	Bolt, Mounting
32	759-3966	1		Coupler, Splined
33	727-3012	2	/P	Fitting, 90 degree
34	727-3176	1		Tube, Auxiliary Pump Suction
35	727-3181	1		Tube, Hydro Suction
36	731-04018	1		Grommet
37	732-1162	1		Spring, Extension
38	736-3052	2	/P	Washer, Flat, 1/406 x 1.0 x .105


7284 Tractor
Transmission 4WD

Page 50 of 54

Ref #	Part Number	Qty	S/P/F	Description
39	737-0146	1	S	Fitting, Grease
40	737-0349	2		Plug, Fitting
41	737-3105	1		Fitting, Filter Nipple
42	737-3108	1		Fitting, 90 degree
43	737-3111	2		Fitting, 90 degree
44	737-3112	1		Fitting, Straight
45	737-3113	4		Fitting, Straight
46	738-0108	1	S	Screw, Shoulder, .498 Dia x 1.45
47	738-0430	1		Screw, Shoulder, .50 Dia x .685
48	738-04001	4		Screw, Shoulder, .625 x .18: 1/2-13
49	741-1110	2		Bearing, Sleeve, 1.52 x 1.75 x 1.0
50	750-1208	4		Spacer, .40 x 1.0 x 3.9
51	750-1239	2		Spacer, 1.52 x 2.25 x .188
52	737-04018	1		Dipstick
53	727-3206	1		Tube, Tandem Pump Suction

7284 Tractor
Transmission Connections

Page 51 of 54




7284 Tractor
Transmission Connections

Page 52 of 54

Ref #	Part Number	Qty	S/P/F	Description
1	603-0748-0637	1	/P	Bracket, Lower Hitch RH
2	603-0751-0637	1	/P	Bracket, Lower Hitch LH
3	603-0753-0637	1	/P	Bracket, Top Link
4	603-0754A-0637	1	/P	Bracket, Cylinder
5	603-0758-0637	1	/P	Bracket, Drawbar
6	703-3542A	1	/P	Shield, PTO
	777S30634	1		Graphic, Warning
7	703-3548A	1	/P	Bracket, Chain LH
8	703-3549A	1	/P	Bracket, Chain RH
9	710-0505	4	/P	Screw, Hex Cap 7/16-14 x 1/0 GR5
10	710-0964A	8		Screw, Hex Cap 5/8-18 x 1.31 GR5
11	710-1515	1		Screw, Hex Cap 5/8-11 x 1.5 GR5
12	710-3039	4	/P	Screw, Hex Cap 5/16-18 x .5 GR5
13	710-3067	2	/P	Screw, Hex Cap 1/2-13 x 1.75 GR5
14	710-3119	6	/P	Screw, Hex Cap 3/8-16 x .75 GR5
15	710-3131	10	/P	Screw, Hex Cap 1/2-13 x 1.0 GR5
16	711-1503	1		Pin, Lift, .75 x 2.125
17	712-3063	8		Nut, Hex Lock, 5/8-18
18	716-0101	1	S	Ring, Snap, 75 Dia
19	717-3504	1	S	Cylinder, Lift
20	736-0192	2	S	Washer, Flat, .531 x .93 x .09
21	703-05133	1		Bracket, Hitch Clip
22	747-04109	1		Rod, Top Link Retainer

7284 Tractor
Wheels

Page 53 of 54



7284 Tractor
Wheels

Page 54 of 54

Ref #	Part Number	Qty	S/P/F	Description
1	634-3045	2		Rim, TURF Tire - Front
	634-04018	2		Rim, INDUSTRIAL Tire - Front
	734-0255	2	S	Valve Stem
2	734-3122	2	S	Tire, Turf
	734-04020	2		Tire, Industrial
3	634-3046	2		Rim, TURF Tire - Rear
	634-04017	2		Rim, INDUSTRIAL Tire - Rear
	734-0255	2	S	Valve Stem
4	734-3124	2		Tire, Turf
	734-04013	2		Tire, Industrial
5	710-1808	10		Screw, Lug, M12
6	710-3294	12		Bolt, Lug, M14 x 1.5 x 20