


7530 Tractor
3 Point Linkage

Page 1 of 160




7530 Tractor
3 Point Linkage

Page 2 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-19573016AG0	2		Link,Lower
2	MA-10323018001	2	/P	Pin
3	MA-10323015000	2		Washer
4	MA-10323019000	2		Pin,Snap
5	MA-10323016000	2		Washer
6	MA-10323012000	8		Pin,Linch
	MA-19643011AG0	1	/P	Lift Rod RH Ass Includes 7-10
	MA-19643020000	1		Rod A Sub Assy Includes 7-9
7	MA-19643021000	1		Rod A
8	MA-19643022000	1	S	Lift Rod Middle
9	MA-19643024000	1	/P	Lock Nut
10	MA-19643014000	1	S	Rod B
11	MA-19643007AG0	1	/P	Lift Rod LH
	MA-19573020000	2	S	Stabilizer Assy Includes 12-19
12	MA-19573021000	2	S	Stabilizer,Rear
13	MA-19573022000	2	S	Stabilizer,Fron
14	MA-19693024000	2	S	Joint
15	MA-05621112090	2	S	Pin,Clevis
16	MA-05200130020	2		Pin,Split
17	MA-03500151226	2		Washer
18	MA-05621110050	2		Pin,Clevis
19	MA-05210110000	2		Pin,Snap
20	MA-05600112050	2		Pin,Wheel Tube
21	MA-05200130020	2		Pin,Split
	MA-19643036AG0	1		Top Link Assy Includes 22-25
22	MA-19643037000	1	S	Turn Buckle
23	MA-19643038000	1	S	Adjuster
24	MA-19643041000	1	S	Adjuster
25	MA-19643039000	1		Nut-Lock
26	MA-19633037000	1		Pin,Upper Link
27	MA-10323012000	1		Pin,Linch
28	MA-19633038000	1		Pin
29	MA-19633041000	1		Pin,Snap
30	MA-19633034AG0	1	S	Cover,PTO
31	MA-F1540112025	2		Bolt,w/Washer
32	MA-19633031000	1		Hook,Top Link

7530 Tractor
Accessory


Page 3 of 160



7530 Tractor
Accessory

Page 4 of 160


Ref #	Part Number	Qty	S/P/F	Description
1	MA-MF650102	1		Bolt, Eye
2	MA-MM100094	4		Bolt, eye
3	MA-05946-01001	2	S	Washer, Sealing
4	MA-30407-53900	1		Joint, Eye
5	MA-MM438183	1		Bracket, Oil
6	MA-05946-01601	8		Washer, Sealing
7	MA-30H36-10700	1		Tube Assy, Oil
8	MA-30H36-00600	1		Tube Assy, Oil
9	MA-MD162326	1		Filter Assy, Oil



7530 Tractor
Air Cleaner

Page 6 of 160

Ref #	Part Number	Qty	S/P/F	Description
	MA-19690531000	1		Air Cleaner Assembly Includes 1-5
1	MA-10400511100	1		Body Assy
2	MA-10400511200	1		Element Assy
3	MA-10400511300	1		Cover Assy
4	MA-35460501400	1		Valve,Unloader
5	MA-19690531100	1		Element,Inner
6	MA-19570512000	1		Hose,Air
7	MA-19560512000	1		Hose,Air
8	MA-00501100630	1		Clamp,hose
9	MA-00501100600	2		Clamp Hose
10	MA-00501100480	1		Clamp,hose
11	MA-19570515000	1	S	Bracket
12	MA-00511070070	2		Band,Wire
13	MA-H1540108020	1		Bolt,w/Washer
14	MA-F3010108000	4		Nut,Flange
15	MA-03500160826	4		Washer




7530 Tractor
Alternator

Page 8 of 160

Ref #	Part Number	Qty	S/P/F	Description
	MA-31A68-00402	1	/P	Alternator Ass'y
1	MA-A981X-20771	1		Nut Set
2	MA-A628T-62170	1		Pulley Ass'y
3	MA-A414X-19271	1		Bolt Set
4	MA-A640X-67070	1	S	Bracket Ass'y
5	MA-A414X-21271	1		Screw Set
6	MA-A930X-94570	1		Bearing,Front
7	MA-A880X-83770	1		Rotor Ass'y
8	MA-S930P-63670	1		Bearing,Rear
9	MA-A383X-56570	1	S	Starter Ass'y
10	MA-A642X-A9970	1	S	Bracket Ass'y
11	MA-A866X-44682	1		Regulator Set
12	MA-A647X-50170	2		Brush Set
13	MA-A860T-40670	1		Rectifier Ass'y
14	MA-A529X-07871	1		Nut Set
15	MA-MM409897	1		Service Kit

7530 Tractor
Bonnet (Part 1)

Page 9 of 160




7530 Tractor
Bonnet (Part 1)

Page 10 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-19572631000	1		Hood,Bonnet
2	MA-A3810108000	1		Nut
3	MA-19562621BC0	1		Cover,Side L.H
4	MA-19562622BC0	1		Cover,Side R.H
5	MA-F3000106001	12		Nut,Flange
6	MA-19562677000	1	S	Plate L.H
7	MA-19562678000	1	S	Plate R.H
8	MA-F3010108001	4		Nut,Flange
9	MA-03500140618	12		Washer
10	MA-10406313000	2		Clip
11	MA-H1540108016	3		Bolt,w/Washer
12	MA-19572624000	2		Cushion
13	MA-19572642000	1		Panel,Rear L.H
14	MA-19572643000	1		Panel,Rear R.H
15	MA-H1640406016	6		Bolt,w/Washer
16	MA-19562661000	1	S	Plate
17	MA-H1540108020	2		Bolt,w/Washer
18	MA-19562671BC0	1		Cover
19	MA-35180844000	2		Screw
20	MA-10442675000	2		Washer
21	MA-H1540108016	5		Bolt,w/Washer
22	MA-0553410000	1		Plug
23	MA-10442646000	1		Plate
24	MA-19562681000	1		Weather Strip
25	MA-19562651000	2	S	Plate
26	MA-35187458000	2		Rubber
27	MA-36205314000	A/R	S	Liner
28	MA-19560424000	2		Cushion
29	MA-19562656001	1		Cushion
30	MA-19562657000	1		Cushion LH
31	MA-19562658000	1		Cushion RH
32	MA-19572621000	2		Cushion
33	MA-19562686000	2		Rubber
34	MA-03500140818	1		Washer
35	MA-35593838600	1		Cushion

7530 Tractor
Bonnet (Part 2)

Page 11 of 160



7530 Tractor
Bonnet (Part 2)


Page 12 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-19562611000	1		Grill
2	MA-19562612AG0	1		Screen B
3	MA-04322105012	10		Screw,Tapping
4	MA-19572615000	1		Cover,Front
5	MA-19562616000	1		Reflector
6	MA-F3000106001	6		Nut,Flange
7	MA-19572637000	1	S	Bracket
8	MA-F3000106001	3		Nut,Flange
9	MA-H1540108016	2		Bolt,w/Washer
10	MA-19572636AG0	1		Stay,Bonnet
11	MA-F1540108020	4		Bolt,w/Washer
12	MA-19740722000	1		Spring
13	MA-10382636000	1	S	Bracket
14	MA-19572638000	1		Lever
15	MA-19562641BC0	1		Cover,Under
16	MA-H1440106016	3	/P	Bolt,w/Washer
17	MA-19562659000	1		Rod
18	MA-05200125016	1	S	Pin,Split
19	MA-03500160826	1		Washer
20	MA-H1540108016	3		Bolt,w/Washer
21	MA-04322106012	2		Screw,Tapping
22	MA-03500130613	2		Washer
23	MA-19562682000	1		Cushion
24	MA-27553236000	2		Rubber,Cushion
25	MA-19562687000	2		Cushion
26	MA-19562685001	2		Screw
27	MA-19572625000	1		Cushion
28	MA-19572626000	1		Cushion
29	MA-35323804200	4		Rubber
30	MA-10410441000	2		Cushion
31	MA-10402624001	2		Spring
32	MA-F0500106016	2		Bolt,Flange
33	MA-27935289000	1		Collar
34	MA-05200125016	1	S	Pin,Split
35	MA-19562684000	4		Cushion

7530 Tractor
Bonnet (Part 3)

Page 14 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-09810060225	1		Hose
2	MA-09810060225	1		Hose
3	MA-00504112005	4		Clamp,Hose
4	MA-35449448000	1		Rubber
5	MA-10253429000	2		Band,Rubber
6	MA-10440135000	1		Rubber
7	MA-60211728000	1		Rubber
8	MA-19560115AG0	1		Frame
9	MA-10250136000	1		Cushion
10	MA-F1540110016	4		Bolt,w/Washer
11	MA-19560121001	1		Bracket
12	MA-H1740108016	2		Bolt,w/Washer
13	MA-H1640106025	2		Bolt,w/Washer
14	MA-H1550110020	2		Bolt,w/Washer
15	MA-H1540110025	2		Bolt,w/Washer
16	MA-19560131001	1	S	Cover
17	MA-00401001600	1		Grommet
18	MA-00401002500	1		Grommet
19	MA-H1440106012	2		Bolt,w/Washer
20	MA-H1440106012	6		Bolt,w/Washer
21	MA-19560143AG0	1		Plate
22	MA-19560144AG0	1		Plate
23	MA-A0500108020	2		Bolt,Flange
24	MA-19560135000	1	S	Plate
25	MA-H1440106016	4	/P	Bolt,w/Washer
26	MA-F3000106000	1		Nut,Flange
27	MA-35011788000	1		Rubber



7530 Tractor
CB Controls

Page 16 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-11931812000	1		Cover,Pedal
2	MA-19571811AG0	1		Pedal,Clutch
3	MA-10391815001	1		Hook
4	MA-A6503100300	1	/P	Nipple,Grease
5	MA-A6513100300	1	S	Nipple,Grease
6	MA-10441813000	1		Rod,Clutch
7	MA-10441814000	1		Joint
8	MA-10391823000	1		Joint
9	MA-A3010110002	1		Nut
10	MA-05621108025	2		Pin,Clevis
11	MA-05200125016	2	S	Pin,Split
12	MA-10441841000	1		Spring
13	MA-19571813AG0	1		Pedal, LH Brake 7530
13	MA-19571815AG0	1		Pedal, LH Brake 7532
14	MA-19571817AG0	1		Pedal, RH Brake - Before S/N 10318 7530
14	MA-19571817AG1	1		Pedal, RH Brake - S/N 10318 & After (Replaces MA- 19571817AG0 by also ordering MA-19561829002) 7530
14	MA-19571819AG0	1		Pedal, RH Brake - Before S/N 15755 7532
14	MA-19571819AG1	1		Pedal, RH Brake - S/N 15755 & After (Replaces MA- 19571819AG0 by also ordering MA-19561829002) 7532
15	MA-11931812000	2		Cover,Pedal
16	MA-A6513100300	4	S	Nipple,Grease
17	MA-10441841000	2		Spring 7530
17	MA-67200-06300	1		Spring 7532
18	MA-19571823AG0	1		Shaft,Brake 7530
18	MA-19571825AG0	1		Shaft,Brake 7532
19	MA-07400102500	2	S	C-Ring
20	MA-05500008040	1		Pin,Spring
21	MA-07972025200	2		Bushing
22	MA-08400025355	2		Oil Seal
23	MA-19571826000	2		Rod,Brake
24	MA-05621108025	4		Pin,Clevis
25	MA-05200125016	4	S	Pin,Split
26	MA-10441814000	2		Joint
27	MA-10391823000	2		Joint
28	MA-A3010110002	2		Nut
29	MA-19571828AG0	1		Bracket LH
30	MA-19571829AG0	1		Bracket RH
31	MA-07400102500	2	S	C-Ring
32	MA-F1540110030	6		Bolt,w/Washer
33	MA-19571831AG0	1		Link LH
34	MA-19571832AG0	1		Link RH
35	MA-19571835000	2		Plate,Brake
36	MA-27613615000	4		Washer
37	MA-05200125016	4	S	Pin,Split
38	MA-14212284000	1		Grip
39	MA-19571837000	1		Lever,Parking
40	MA-19571838000	1		Wire
41	MA-07400102000	1		C-Ring 7530
42	MA-19561829001	1		Ratchet,Parking (Mod. 7530 before S/N10318)


7530 Tractor
CB Controls

Page 17 of 160

Ref #	Part Number	Qty	S/P/F	Description
42	MA-19561829002	1		Rachet, Parking (Mod. 7530 S/N10318 & after)
43	MA-03500130613	1		Washer
44	MA-05200125012	2		Pin, Split
45	MA-19740722000	1		Spring

7530 Tractor
Clutch Housing & Clutch


Page 18 of 160



7530 Tractor
Clutch Housing & Clutch

Page 19 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-19571001AG0	1		Housing,Clutch
2	MA-07961020250	2		Bushing
3	MA-27613733000	1		Cap
4	MA-05534-14000	12		Plug
5	MA-05534-10000	3		Plug
6	MA-19571011000	1		Hub,Release
7		0		Bushing Not used on this model.
8	MA-11761015000	1		Bearing
9	MA-11761014001	1		Lever,Clutch
10	MA-19571053000	1		Coupling
11	MA-19571051000	1		Bearing
12	MA-F2855-08040	1		Pin,Clevis
13	MA-05200120020	1		Pin,Split
14	MA-10381011AG0	1		Shaft,Release
15	MA-A0550112070	2		Bolt 7T
16	MA-A3600101202	2		Washer,Spring
17	MA-F1540110020	1		Bolt,w/Washer
18	MA-F1540110025	2		Bolt,w/Washer
19	MA-F1540112030	4		Bolt,w/Washer
20	MA-A3030110002	1		Nut
21	MA-A3600101002	1	/P	Washer,Spring
22	MA-F5000-16000	1		Plug
23	MA-A0500110030	4		Bolt 7T
24	MA-07410005801	1		C-Ring
25	MA-10281111000	1		Cover Assy
26	MA-19571111000	1		Disk,Clutch
27	MA-F1540108020	6		Bolt,w/Washer
28		0		Housing,Clutch Not used on this model.
29		0		Hub,Release Not used on this model.
30		0		Disk,Clutch Not used on this model.
31	MA-14061178000	2		Bushing
32		0		Seal Cap Not used on this model.




7530 Tractor
Cooling

Page 21 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-30H45-00101	1	/P	Gasket,Water
2	MA-MF244860	3	S	Bolt,w/Washer
3	MA-MF244863	1		Bolt,w/Washer
	MA-30H45-00200	1		Pump Assy,Water Includes 4-7
4	MA-MF240031	2		Bolt,w/Washer
5		1		Body,Water Pump
6	MA-MM409326	1		Gasket,Water
7	MA-MM409327	1		Plate,Water
8	MA-30H46-01300	1		Joint,Water
9	MA-MM316248	1		Plug,Drain
10	MA-30636-25901	1	S	Gasket
11	MA-MM431970	1		Fitting,Thermo
12	MA-MM409-31301	1		Cover,Thermo
13	MA-MD000551	2	S	Gasket,Water
14	MA-MF241267	2		Bolt,w/Washer
15	MA-30A46-00700	1	/P	Thermostat
16	MA-30H46-01600	1		Joint,Water
17	MA-MM316248	1		Plug,Drain
18	MA-30636-25901	1	S	Gasket
19	MA-MS470059	1		Clip
20	MA-31A48-01100	1	/P	Spacer,Fan
21	MA-05317-50161	2		Clamp,Hose
22	MA-30H46-02300	1		Hose Assy,Water
23	MA-MS603031	1		Hose,Fuel
24	MA-MF240051	1		Bolt,w/Washer
25	MA-30H46-01700	1		Connector
26	MA-ME049274	1		Switch,Thermo
27	MA-MD009014	1	/P	Fan,Cooling
28	MA-MM434493	1		Spacer,Fan
29	MA-MM405460	1		Pulley,Water
30	MA-MF241238	4		Bolt,w/Washer
31	MA-MD041704	1		V Belt
32	MA-30A46-01200	1	/P	Joint,Temp Gage
33	MA-MD001380	1		Gage,Unit Water

7530 Tractor
Crankcase


Page 22 of 160



7530 Tractor
Crankcase

Page 23 of 160


Ref #	Part Number	Qty	S/P/F	Description
1	MA-MS471105	2		Bushing,Knock
2	MA-MS471110	2		Bushing,Knock
3	MA-MS661142	1		Plug,Taper
4	MA-MS661141	1		Plug,Taper
5	MA-MD040338	1		Plug,Taper
6	MA-30H07-02100	1		Plug,Cam
7	MA-MM409645	2		Pin,Dowel
8	MA-MM430113	1		Shaft,Idler
9	MA-MS471104	2		Bushing,Knock
10	MA-MM406228	4		Seal,Side
11	MA-30H07-15200	1		Plate,Front
12	MA-30H07-00300	1		Gasket,Front
13	MA-MM412662	1		Case,Oil Seal
14	MA-30H07-00201	1	/P	Gasket,Oil Seal
15	MA-MM431338	1		Seal,Oil
16	MA-MM438283	1		Joint,Water Drain
17	MA-MF240051	4		Bolt,w/Washer
18	MA-MF240054	7		Bolt,w/Washer
	MA-30H07-10090	1	S	Block Sub Assy Includes 19-24
19	MA-MD000245	1	S	Cap,Sealing
20	MA-MF665543	2	S	Cap,Sealing
21		1		Cap Assy
22	MA-MM406217	8		Bolt,Bearing
23	MA-MM406237	1		Bushing,Cam
24		1		Block,Cylinder
25	MA-30H07-06200	1		Guide,Oil Level
26	MA-30H07-02300	3		Pipe,Oil Jet
27	MA-30H09-00010	1		Bearing Set
28	MA-30H09-00020	1		Bearing Set
29	MA-30H09-00030	1		Bearing Set
30	MA-30H09-00040	1		Bearing Set
31	MA-30H12-00800	1		Plate,Rear
32	MA-MM408240	2		Pin,Knock
33	MA-MF241308	6	S	Bolt,w/Washer
34	MA-MF402635	2		Stud
35	MA-30H12-00101	1	/P	Gasket,Rear
36	MA-30H42-00100	1		Gage,Oil Level
37	MA-MD024256	1		Plug,Taper



7530 Tractor
Crankshaft, Piston & Flywheel

Page 25 of 160


Ref #	Part Number	Qty	S/P/F	Description
1	MA-30H17-06010	3	S	Piston,Pin Set
2	MA-30H17-06020	3		Piston,Pin Set
3	MA-30H17-06030	3		Piston,Pin Set
4	MA-30H17-06040	3	S	Piston,Pin Set
5	MA-MM300140	6		Clip,Piston Pin
6	MA-30H17-07010	3		Ring Set,Piston
7	MA-30H17-07020	3		Ring Set,Piston
8	MA-30H17-07030	3		Ring Set,Piston
9	MA-30H17-07040	3		Ring Set,Piston
10	MA-MM438669	3	S	Bearing Set
11	MA-MM438670	3	S	Bearing Set
12	MA-MM438671	3	S	Bearing Set
13	MA-MM438672	3		Bearing Set
	MA-30H19-00030	3	/P	Rod Assy,Connecting Includes 14-18
14	MA-MD006704	6		Nut,Con Rod
15		3		Cap
16	MA-MM412869	6		Bolt,Con Rod
17	MA-30A19-05100	3		Bearing
18		3		Con Rod
	MA-30H20-00010	1		Crankshaft Ass'y. Includes 19-25
19		1		Crankshaft
20	MA-MM430859	1		Gear,Crankshaft
21	MA-MF430731	1	S	Nut,Jam
22	MA-MF450011	1		Washer
23	MA-MF450411	1	S	Washer,Spring
24	MA-MF476215	2		Key
25	MA-30H20-00400	1		Pulley,Crank
26	MA-MD952231	5	S	Bolt
	MA-30H21-12050	1		Flywheel Assy Includes 27-29
27	MA-MD040556	1		Gear,Ring
28		1		Flywheel
29	MA-MD002613	1	S	Bearing,Ball
30	MA-MF472443	3	S	Pin,Dowel
	MA-30H21-12030	0		Flywheel Assy Includes 31,32,29
31	MA-MD040556	0		Gear,Ring
32		0		Flywheel



7530 Tractor
Cylinder Head

Page 27 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-30A01-03300	3		Bolt,Cyl Head
2	MA-30A01-03200	8		Bolt,Cyl Head
3	MA-F1035-10016	2		Bolt
4	MA-MM408470	2		Hanger,Engine
5	MA-MS661140	1		Plug,Taper
	MA-30H01-01051	1		Head Assy,Cyl Includes 6-9
6	MA-MD000427	1	S	Cap,Sealing
7	MA-MF665538	2	S	Cap,Sealing
8		1		Cylinder Head
9	MA-30H01-17100	6		Guide,Valve
10	MA-30H01-00300	1	/P	Gasket,Cyl Head
	MA-30H04-00011	1		Cover Assy,Rocker Includes 11,12
11		1		Pipe
12		1		Cover,Rocker
13	MA-30H04-00101	1	/P	Gasket,Rocker
14	MA-MF100065	3		Bolt
15	MA-MF100069	5	S	Bolt
16	MA-MD008784	1		Cap,Oil Filter
17	MA-30H43-00300	1		Hose,Air Breather
18	MA-MS660164	1		Clip,Hose
19	MA-MS470059	1		Clip




7530 Tractor
Dash Panel

Page 29 of 160

Ref #	Part Number	Qty	S/P/F	Description
	MA-19572931000	1		Panel Assy Includes 1-20
1	MA-19572935000	1		Panel
2	MA-10253501300	1		Packing
3	MA-19562833000	1		Cover,Panel
	MA-19572932000	1		Meter Assy Includes 4-9
4	MA-10442853100	1		Glass Assy
5	MA-10442853300	1		F.T Assy
6	MA-19572932100	1		Case Assy
7	MA-19572932700	1		Tacho Meter Ass'y
8	MA-10402857000	8		Bulb Assy
9	MA-10442853800	2		Bulb Assy
10	MA-35180813900	4		Screw,Tapping
	MA-19572933000	1		Starter Switch Assy Includes 11,12
11	MA-19572933100	1		Starter Switch
12	MA-19572933200	2		Key
13	MA-19572933500	1		Cap
14	MA-19572934000	1		Plate
15	MA-19572936000	1		Switch,Combinat
16	MA-19562837000	1		Plate
	MA-19572937000	1		Switch,Hazard Includes 17,18
17	MA-19572937100	1		Switch
18	MA-35530807200	1		Cap
19	MA-19572938000	1		Mark R
20	MA-19572939000	1		Mark L
21	MA-H1640106016	2		Bolt,w/Washer
22	MA-A2520706016	2		Screw


7530 Tractor
Decals



7530 Tractor
Decals

Page 31 of 160


Ref #	Part Number	Qty	S/P/F	Description
1	MA-19572701000	1		Label Speed G
2		0		Label Speed H Not used on this model.
3	MA-19572711000	1		Label Main
4	MA-19572712000	1		Label Shuttle
5	MA-19572715000	1		Label Sub G
6		0		Label Sub H Not used on this model.
7	MA-19572719000	1		Label PTO
8	MA-19572731000	1		Label Brake
9		0		Label Brake-Sp Not used on this model.
10	MA-19572722000	1		Label Tilt
11	MA-19572721000	1		Label Declutch
12	MA-19692723000	1		Label D.R.Cont
13	MA-19632731000	1		Label,MFD
14	MA-19692718000	1		Label Diff Lock
15	MA-19672725000	1		Label Propositi
16	MA-19572726000	1		Label,Warning
17	MA-19042746000	1		Label,Warning
18	MA-19042759000	1		Label,Warning
19	MA-19042761000	1		Label,Warning
20	MA-19042765001	1		Label Warning
21	MA-10382767000	1		Mark,Center
22	MA-04322104012	1		Screw,Tapping
23	MA-19692728000	1		Mark Fuel
24	MA-19572727000	1		Label Start G
25		0		Label Start H Not used on this model.
26	MA-19572729000	1		Label Ind
27		0		Mark Not used on this model.
28	MA-19572753000	1		Label Side LH
29	MA-19572754000	1		Label Side RH
30	MA-19572755000	1		Label M
31	MA-19572757000	2		Label Model G
32		0		Label Model H Not used on this model.
33	N/A	1		Name Plate
34	MA-04800135060	2		Rivet Screw
35	MA-27573551000	2		Mark,Plug
36	MA-19562714000	1		Label LH,Side
37	MA-19562715000	1		Label K,Side
38	MA-19572752000	1		Label,Steering
39	MA-19572881BD0	1		Bracket,SMV
40	MA-F1540108020	2		Bolt,w/Washer
41	MA-H2420106016	2		Screw,w/Washer
42	779-3618	1	S	Emblem,SMV



7530 Tractor
Drawbar

Page 33 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-05220110000	2		Pin,Snap
2	MA-19573113AG0	1		Drawbar
3	MA-10390221000	4		Cap
4	MA-19573111AG0	1		Bracket,Drawbar
5	MA-A0400114035	6		Bolt 7T
6	MA-A3600101402	6		Washer, Spring
7	MA-F1540112040	2		Bolt,w/Washer
8	MA-19573121000	1		Pin
9	MA-19633041000	1		Pin,Snap




7530 Tractor
Electrical Equipment

Page 35 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-MM409427	1		Bolt, Starter
2	MA-31B66-00101	1		Starter Assy
3	MA-MF241282	1		Bolt, w/Washer
4	MA-MF450406	1	S	Washer, Spring
5	MA-30H66-06100	3	/P	Plug, Glow
6	MA-31A68-00402	1	/P	Alternator Ass'y.
7	MA-30H68-00400	1	S	Plate, Adjusting
8	MA-31A68-20300	1		Bolt, Alternator
9	MA-MD001521	1		Washer
10	MA-MF140026	1		Bolt, Flange
11	MA-MF241251	1		Bolt, w/Washer
12	MA-MF430005	1		Nut
13	MA-MF450405	1		Washer, Spring
14	MA-MS450035	1		Washer, Plain
15	MA-30H66-06300	1		Plate, Connect
16	MA-30H66-02100	1		Controller, Glow

7530 Tractor
Electrical System (Part 1)

Page 36 of 160




7530 Tractor
Electrical System (Part 1)

Page 37 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-19572952000	1		Harness Wire (Includes Ref.no.2-6)
1A		0		Harness Wire (Includes Ref.no.2-6); Not used on this model.
2	MA-35770855200	1		Diode
3	MA-10375581200	2		Fuse
4	MA-10382815200	1		Fuse
5	MA-09801001006	3		Fuse
6	MA-09801001506	4		Fuse
7	MA-19572953000	1		Mark Fuse
8	MA-10442812000	1		Fuse Holder
9	MA-A3000106002	2		Nut
10	MA-F3000106000	1		Nut,flange
11	MA-HA121403000	1		Bolt
12	MA-00511032070	3		Band,wire
13	MA-00511070070	6		Band,wire
14		0		Band,wire Not used on this model.

7530 Tractor
Electrical System (Part 2)


Page 38 of 160



7530 Tractor
Electrical System (Part 2)

Page 39 of 160


Ref #	Part Number	Qty	S/P/F	Description
1	MA-35440895AG0	1		Battery Clamp
2	MA-19822884000	2		L-Bolt
3	MA-F3000106011	2		Nut,Flange
4	MA-19562804000	1		Cord,Plus
5	MA-19682927000	1		Fuse Box (Includes Ref. no. 6 & 7)
6	MA-19682927200	1		Fuse
7	MA-19682927300	2		Bolt
8	MA-35590895000	1		Terminal
9	MA-10382816000	1		Cap
10	MA-F3010108000	3		Nut,Flange
11	MA-19632945000	1		Harness M
12	MA-10402803000	1		Cord,Minus
13	MA-HA121403000	1		Bolt
14	MA-H1440106012	4		Bolt,w/Washer
15	MA-F3000106000	1		Nut,flange
16	MA-19562808AG0	1		Cover
17	MA-H1440106012	2		Bolt,w/Washer
18	MA-19562811000	1		Front Lamp Assy (Includes Ref. no. 19)
19	MA-19562811400	2		Bulb
20	MA-10192849001	6		Spring
21	MA-F3000105000	6		Nut,Flange
22	MA-19572905000	1		Lead Wire
23	MA-10442921000	1		Seal
24	MA-00502119105	1		Clamp
25	MA-10442993000	2		Clip
26	MA-04322104010	2		Screw,Tapping
27	MA-00511032070	1		Band,Wire
28	MA-19572911000	1		Hazard Unit
29	MA-H1440106016	1	/P	Bolt,w/Washer
30	MA-19572917000	1		Relay Assy
31	MA-H2420104016	2		Screw
32	MA-F3000104000	2		Nut,Flange
33	MA-35720952000	1		Switch
34	MA-19562819000	1		Cable,Flexible
35	MA-19572914AG0	1		Plate,S.W.
36	MA-H1640106020	2		Bolt,w/Washer
37	MA-19562808000	1		Cover
38	MA-H1440106012	2		Bolt,w/Washer
39	MA-19572918000	0		Relay Assy
40	725-3174	1	S	Battery



7530 Tractor
Electrical System (Part 3)

Page 41 of 160


Ref #	Part Number	Qty	S/P/F	Description
	MA-19672942000	2		Lamp,Signal Includes 1-6
1	MA-19672942100	2		Body Assy
2	MA-10356281200	2	S	Bulb
3	MA-19672942200	4		Lens
4	MA-04322104025	12		Screw,Tapping
5	MA-A3030112003	2		Nut
6	MA-03700112000	2		Washer,Tooth
7	MA-19672943000	2		Lead Wire
8	MA-19572906BD0	1		Bracket L
9	MA-19572907BD0	1		Bracket R
10	MA-F3000106000	2		Nut,Flange
11	MA-19572908000	1		Bracket L
12	MA-19572909000	1		Bracket R
13	MA-H1440106020	4	/P	Bolt,w/Washer
14	MA-H1440106012	4		Bolt,w/Washer
15	MA-00502110083	2		Clamp
16	MA-10366169000	2		Grommet
	MA-19615008000	2	/P	Lamp,Tail Includes 17-21
17	MA-19615008100	2	S	Lens
18	MA-19615008200	2		Holder
19	MA-09808121001	2		Bulb
20	MA-F3000105001	4		Nut,Flange
21	MA-A2420105020	4		Screw
22	MA-10192279000	4		Reflector
23	MA-F3000106000	4		Nut,Flange
	MA-19572916000	1		Switch,Ind Includes 24-26
24	MA-10412833100	1		Switch Assy
25	MA-10412833200	1		Knob Assy
26	MA-19572916300	1		Lead Wire
27	MA-10442993000	3		Clip
28	MA-04322104010	3		Screw,Tapping
29	MA-10402821000	1		Switch,Safety
30	MA-19572913AG0	1		Plate
31	MA-H1740108020	2		Bolt,w/Washer
32	MA-19572956000	1		Harness B (Includes Ref.No.33)
33	MA-35770855200	1		Diode
34	MA-00502110083	1		Clamp
35	MA-00502114103	3		Clamp
36	MA-00511032070	6		Band,Wire
37	MA-00511070070	1		Band,Wire
38	MA-19572957000	0		Harness B



7530 Tractor
Engine Control

Page 43 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-19570201AG0	1	S	Lever,Control
2	MA-06910012258	1		Grip
3	MA-60223314000	1		Spring
4	MA-27722323000	1		Washer
5	MA-A3010112002	2		Nut
6	MA-02001250120	1		Pin,Split
7	MA-19560203000	1		Wire,Accel
8	MA-19560219000	1		Bracket
9	MA-00511032070	2		Band,Wire
10	MA-F3000106000	1		Nut,Flange
11	MA-19560238000	1		Joint
12	MA-05210106000	1		Pin,Snap
13	MA-03500130615	2		Washer
14	MA-H2420106012	1		Screw,w/Washer
15	MA-10190235000	1		Spring
16	MA-19560204000	1		Wire,Foot Accel
17	MA-10320228000	1		Cover,Pedal
18	MA-03500150622	1		Washer
19	MA-10440215001	1		Pedal,Accele
20	MA-27942740401	2		Spring
21	MA-05210108000	1		Pin,Snap
22	MA-03500130815	2		Washer
23	MA-03500130615	1		Washer
24	MA-05200125012	1		Pin,Split
25	MA-F1440106016	2		Bolt,w/Washer




7530 Tractor
Fender & Step

Page 45 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-10443502BD0	1		Fender LH
2	MA-10443504BD0	1		Fender RH
3	MA-F1540112035	8		Bolt,w/Washer
4	MA-10383509000	2		Grip,Assist
5	MA-F3000106001	4		Nut,Flange
6	MA-A2520706020	2		Screw
7	MA-03500150622	2		Washer
8	MA-19573511BD0	1		Cover,Front
9		0		Cover,Front Not used on this model.
10	MA-19573515BD0	1		Cover,Rear
11	MA-H1540108016	10		Bolt,w/Washer
12	MA-F3010108000	3		Nut,Flange
13	MA-H1540108025	2		Bolt,w/Washer
14	MA-19563551000	1		Plate LH
15	MA-19563552000	1		Plate RH
16	MA-H1440106020	4	/P	Bolt,w/Washer
17	MA-19573521000	1		Cover LH,Fender
18	MA-19573522000	1		Cover Rh,Fender
19	MA-H1440106020	4	/P	Bolt,w/Washer
20	MA-19573525BD0	1		Step LH
21	MA-19573526BD0	1		Step RH
22	MA-10311826000	3		Rubber
23		0		Step RH Not used on this model.
24	MA-11930439000	6		Grommet
25	MA-10382241000	6		Collar
26	MA-F0500108025	2		Bolt,Flange
27	MA-F3010108000	4		Nut,Flange
28	MA-10443529000	2		Rubber
29	MA-10443531BD0	2		Step,Sub
30	MA-H1540108020	6		Bolt,w/Washer
31	MA-F3010108000	6		Nut,Flange
32	MA-19573529000	2		Plate
33	MA-H1540108020	4		Bolt,w/Washer
34	MA-F3010108000	2		Nut,Flange
35	MA-10443525AG0	1		Bracket LH,Step
36	MA-10443527AG0	1		Bracket RH,Step
37		0		Bracket RH,Step Not used on this model.
38	MA-H1540110020	4		Bolt,w/Washer
39	MA-00502114103	1		Clamp
40	MA-19573535000	1		Mat,Step
41		0		Mat,Step Not used on this model.
42	MA-10406313000	14		Clip
43	MA-19573541000	2		Bolt
44	MA-A3000116003	2		Nut

7530 Tractor
Frame And Front Axle

Page 46 of 160




7530 Tractor
Frame And Front Axle

Page 47 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-19572111AG0	1	S	Bracket,Front
2	MA-F9450112035	12		Bolt
3	MA-H1540112035	4		Bolt,w/Washer
4	MA-19562113AG0	1		Bracket,Weight
5	MA-10302124AG1	1		Bracket,Front
	MA-19572151000	A/R		Shim Set Includes 6-8
6	MA-10302141001	A/R		Shim
7	MA-10302142001	A/R		Shim
8	MA-10302143001	A/R		Shim
9	MA-07961030300	1		Bushing
10	MA-08300200300	2		O-ring
11	MA-10352122AG0	1		Bracket,Rear
12	MA-F1540112045	4		Bolt,w/Washer
13	MA-08300200650	2		O-Ring
14	MA-05605-06540	1		Bushing
15	MA-69542-62701	1		Liner F
16	MA-69526-07200	1		Nut
17	MA-A0400114045	4		Bolt 7T
18	MA-A3600101402	4		Washer, Spring
19	MA-A19562101001	1		Front Axle Ass'y.

7530 Tractor
Front Axle (Part 1)

Page 48 of 160




7530 Tractor
Front Axle (Part 1)

Page 49 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-19562116AG0	1		Case A,Center
2	MA-10252178001	1	S	Pipe
3	MA-11190621000	1	/P	Breather,Air
4	MA-F5000-16000	1		Plug,Drain
5	MA-08331001600	1		Washer,Seal
6	MA-10352119AG0	1		Case B,Center
7	MA-11911211000	1		Cap,Oil
8	MA-10401337000	1		Bolt
9	MA-08300501500	1		O-Ring
10	MA-A9400110030	7		Bolt
11	MA-A3600101003	8		Washer,Spring
12	MA-27403214200	1		Plug
13	MA-08331000800	1		Washer,Seal
14	MA-10232115AG2	1		Case,Front Axle
15	MA-08300500600	1		O-Ring
16	MA-F1540110030	4		Bolt,w/Washer
	MA-19642120000	A/R		Shim Set Includes 17-19
17	MA-10232136001	A/R		Shim
18	MA-10232137001	A/R		Shim
19	MA-10232138001	A/R		Shim
20	MA-10212171000	1		Bushing
21	MA-08300200250	1		O-Ring
22	MA-08401035529	1		Seal,Oil
23	MA-10302123000	1		Nut
24	MA-10302126AG1	1		Holder,Arm
25	MA-08300200250	1		O-Ring
26	MA-F1540110030	4		Bolt,w/Washer
27	MA-10212141000	1		Bearing,Roller
28	MA-07700130205	1		Bearing,Taper

7530 Tractor
Front Axle (Part 2)

Page 50 of 160




7530 Tractor
Front Axle (Part 2)

Page 51 of 160

Ref #	Part Number	Qty	S/P/F	Description
	MA-19562120000	1		Diff Case Assy Includes 1-10
1	MA-10312121000	1		Case,Diff
2	MA-10191412000	2		Pinion,Mate
3	MA-10191413000	2		Gear,Side
4	MA-10191414000	1		Shaft,Pinion
5	MA-10191415000	2		Washer,Thrust
6	MA-10191416000	2		Washer,Thrust
7	MA-19562122000	1		Gear,Ring
8	MA-12186568000	8		Bolt
9	MA-05500006040	1		Pin,Spring
10	MA-19562121000	1		Shaft,Pinion
11	MA-10352128000	2		Shaft,Diff
12	MA-10312129000	2		Gear 14t
13	MA-07500062060	2		Bearing,Ball
14	MA-07500060100	2		Bearing,Ball
	MA-10190623000	A/R		Liner Set Includes 15-17
15	MA-10070618000	A/R		Liner
16	MA-10070618100	A/R		Liner
17	MA-10070618200	A/R		Liner
	MA-19562127000	1		6-35 Set (Exchange Parts) Includes 18,19
18	MA-19562122000	1		Gear,Ring
19	MA-19562121000	1		Shaft,Pinion
20	MA-35402909100	1		Liner
	MA-10211321000	A/R		Shim Set Includes 21-25
21	MA-67700-30300	A/R		Shim
22	MA-07310003004	A/R		Liner
23	MA-07310003008	A/R		Liner
24	MA-07310103010	A/R		Liner
25	MA-07310103012	A/R		Liner
26	MA-10251535000	1		Liner

7530 Tractor
Front Axle (Part 3)

Page 52 of 160




7530 Tractor
Front Axle (Part 3)

Page 53 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-19562136AG0	2		Case,King Pin
2	MA-A9400110035	10		Bolt
3	MA-10401337000	2		Bolt
4	MA-A3600101003	12		Washer, Spring
5	MA-19562138000	2		Shaft
6	MA-07500563044	2		Bearing, Ball
7	MA-08300500800	2		O-Ring
8	MA-A0500110040	2		Bolt 7T
9	MA-A3010110002	2		Nut
10	MA-10212120AG0	2		Holder
11	MA-F1540110025	8		Bolt,w/Washer
	MA-19632139000	A/R		Liner Set Includes 12-14
12	MA-07300005201	A/R		Liner
13	MA-07300005202	A/R		Liner
14	MA-07300005203	A/R		Liner
15	MA-19562133000	2		Gear 18T
16	MA-27403214200	2		Plug
17	MA-08331000800	2		Washer, Seal
18	MA-19562142000	2		Gear 12T
19	MA-07600051106	2		Bearing, Thrust
20	MA-07500263040	2		Bearing, Ball
21	MA-F1540108020	8		Bolt,w/Washer
22	MA-07961050300	2		Bushing
23	MA-19562144000	2		Seal Oil
24	MA-10070638AG1	2		Cover
	MA-19632139000	A/R		Liner Set Includes 25-27
25	MA-07300005201	A/R		Liner
26	MA-07300005202	A/R		Liner
27	MA-07300005203	A/R		Liner
28	MA-08331000800	2		Washer, Seal
29	MA-10352146AG1	1		Case L.H Gear
30	MA-10352147AG1	1		Case R.H Gear
31	MA-27403214200	2		Plug

7530 Tractor
Front Axle (Part 4)


Page 54 of 160



7530 Tractor
Front Axle (Part 4)

Page 55 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-08300501450	2		O-Ring
2	MA-10401337000	2		Bolt
3	MA-A3600101003	2		Washer, Spring
4	MA-F1540110025	10		Bolt, w/Washer
5	MA-10402121000	2	S	Shaft
6	MA-19562143000	2		Gear 32T
7	MA-07500063060	2		Bearing, Ball
8	MA-07500063050	2		Bearing, Ball
9	MA-08412406213	2		Seal, Oil
10	MA-10352153000	2		Si Sleeve
	MA-10212158000	A/R		Liner Set Includes 11-15
11	MA-11353016000	A/R		Liner
12	MA-07310002504	A/R		Liner
13	MA-07310002508	A/R		Liner
14	MA-07310102510	A/R	/P	Liner
15	MA-07310102512	A/R		Liner
16	MA-07400102500	2	S	C-ring
17	MA-19803186000	4		Bolt
18	MA-A3600101202	4		Washer, Spring
19	MA-F1540112025	4		Bolt, w/Washer
20	MA-07961025250	2		Bushing
21	MA-08300100240	2		O-Ring
	MA-10212157000	A/R		Liner Set Includes 22-25
22	MA-14381319300	A/R		Liner F, Thrust
23	MA-14381319400	A/R		Liner G, Thrust
24	MA-14381319500	A/R		Liner H, Thrust
25	MA-14381319600	A/R		Liner J, Thrust
	MA-10212159000	A/R		Liner Set Includes 26-30
26	MA-07310003001	A/R		Liner
27	MA-07310003004	A/R		Liner
28	MA-07310003008	A/R		Liner
29	MA-07310103010	A/R		Liner
30	MA-07310103012	A/R		Liner
31	MA-07410107201	2		C-ring
32	MA-19562171AG0	1		Knuckle Arm L.H
33	MA-19562172AG0	1		Knuckle Arm R.H
34	MA-10352148AG0	2		Cover




7530 Tractor
Fuel Delivery

Page 57 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-30H61-02300	3		Grand, Nozzle
2	MA-MM432045	3		Gasket, Nozzle
3	MA-MF241259	3		Bolt, w/Washer
4	MA-30H61-06200	3		Nozzle Assy
5	MA-MM430703	2		Clamp A
6	MA-MM430614	2		Clamp B
7	MA-MF243628	2		Bolt, w/Washer
8	MA-30H61-02700	1		Pipe No 1
9	MA-30H61-02800	1		Pipe No 2
10	MA-30H61-02900	1		Pipe No 3
	MA-30H61-13600	1		Hose Assy, Fuel Includes 11-19
11	MA-MM100088	2		Joint
12	MA-MM100089	9		Clamp, Hose
13	MA-MM413103	1		Pipe, Rubber
14	MA-MM413105	1		Pipe, Rubber
15	MA-MM413108	1		Pipe, Rubber
16	MA-MM413132	2		Pipe, Rubber
17	MA-MM437198	1		Joint T
18	MA-30H61-04800	1		Hose
19	MA-30H61-13700	1		Pipe, Rubber
20	MA-MK661-14000	2		Washer, Seal
21	MA-05946-01001	2	S	Washer, Sealing
22	MA-MM409040	A/R		Shim, t=0.2
23	MA-MM409041	A/R		Shim, t=0.3
24	MA-MM409042	A/R		Shim, t=0.4
25	MA-MM409043	A/R		Shim, t=0.5
26	MA-MM409044	A/R		Shim, t=0.6
27	MA-MM409045	A/R		Shim, t=0.7
28	MA-MM409046	A/R		Shim, t=0.8
29	MA-MM409047	A/R		Shim, t=0.9
30	MA-MM409048	A/R		Shim, t=1.0
31	MA-31A65-00500	1		Collar, Union
32	MA-MF100055	4	S	Bolt
33	MA-MM436-73901	1		Pump Assy, Fuel
	MA-30H61-06300	1		Hose Assy, Fuel Includes 34-38
34	MA-30H61-04800	1		Hose
35	MA-MM100089	4		Clamp, Hose
36	MA-MM413110	1		Pipe, Rubber
37	MA-MM433480	1		Pipe, Rubber
38	MA-MM437198	1		Joint
39	MA-31A65-00200	1		Collar, Union
40	MA-31A65-00300	1		Screw
41	MA-31A65-00400	1		Valve Assy, Check
42		0		Nozzle Assy Not used on this model.

7530 Tractor
Fuel Filter

Page 58 of 160



7530 Tractor
Fuel Filter


Page 59 of 160

Ref #	Part Number	Qty	S/P/F	Description
	MA-30A62-00100	1	/P	Filter Assy,Fuel
1	MA-30A62-00110	1		Body Sub Assy
2		1		Valve
3	MA-MM404873	1		Spring,Valve
4	MA-MM404874	1	S	O-Ring
5	MA-MM404871	1		Lever
6	MA-MM404875	1		Screw
7	MA-MM404884	1		Packing
8	MA-30A62-00105	2		Screw
	MA-MM409892	1	/P	Service Kit, Filter Includes 9-11
9	MA-MM404881	1	S	O-Ring
10	MA-MM404879	1	S	Element
11	MA-MM404878	1		O-Ring
12	MA-MM400889	1	/P	Cup,Filter
13	MA-MM404877	1		Nut

7530 Tractor
Fuel Injection Pump

Page 61 of 160


Ref #	Part Number	Qty	S/P/F	Description
	MA-094500-8250	1		Pump Ass'y. Includes 1-29
1	MA-47X01-17900	1		Housing Sub Ass'y.
1A		1		Housing Sub Ass'y. NOT USED ON THIS MODEL
2	MA-47X01-13200	3		Holder,Delivery
3	MA-47X01-13300	3		Spring,Delivery
4	MA-MM501856	3	S	Gasket,Delivery
5	MA-47X01-07700	3		Valve Sub Ass'y.
6	MA-47X01-17000	3		Element Sub Ass'y.
7	MA-MM500229	3	S	Sleeve,Control
8	MA-MM501098	3		Seat,Spring
9	MA-MM500360	3	S	Spring,Plunger
10	MA-MM500230	3	S	Tappet Sub Ass'y.
11	MA-MM501311	1	S	Rack Assy,Control
12	MA-MM500316	3	S	Seat,Spring
13	MA-MM500438	3	S	O-Ring
14	MA-MM500231	3	S	Pin,Tappet
15	MA-MM501162	1	S	Plate
16	MA-MM514109	2	S	Plate,Adjusting
17	MA-MM514195	2		Bolt,Washer Head
18	MA-MM501152	2		Screw,Air Bleed
19	MA-MM500446	1		Screw,Hollow
20	MA-MM500578	2		Washer,Pipe Union
21		A/R		Plate,Tappet Shim
22	MA-MM501247	1		Spring,Smoke Set
23	MA-MM501496	1		E-Ring
24	MA-MM500507	1		E-Ring
25	MA-MM514131	1		Spring,Angleich
26		A/R		Plate,Angleich
27		A/R		Plate,Smoke Set
28		1		Plate,Name
29	MA-MM500429	2		Rivet,Serration
30		0		Plate,Name Not used on this model.



7530 Tractor
Fuel Line

Page 63 of 160

Ref #	Part Number	Qty	S/P/F	Description
	MA-19560102000	1		Tank Fuel Assy Includes 1-5
1	MA-19560103000	1		Tank Fuel
2	MA-10440116000	1		Fuel Unit
3	MA-A3000104002	5		Nut
4	MA-A3600100402	5		Washer, Spring
5	MA-03500120410	5		Washer
6	MA-19560101000	1		Cap, Tank
7	MA-09806000001	1		Filter
8	MA-19560108000	1		Tray, Fuel
9	MA-09804100502	1		Pipe, Vinyl
10	MA-19560106000	1		Hose
11	MA-00501100710	1		Clamp, Hose
12	MA-00505000900	1		Clamp, Hose
13	MA-19560124000	2		Rubber, Cushion
14	MA-19560141000	1		Hose
15	MA-HA230108000	2		Clip, Hose
16	MA-19560139000	1		Seal, Fuel
17	MA-19560126000	2		Bracket
18	MA-H1440106012	4		Bolt, w/Washer
19	MA-03500150822	4		Washer
20	MA-F3010108000	2		Nut, Flange
21	MA-09810060355	1		Hose
22	MA-09810060280	1		Hose
23	MA-09810040300	1		Hose
24	MA-00504110005	2		Clamp, Hose
25	MA-00504112005	4		Clamp, Hose
26	MA-19560107000	1		Joint, Pipe
27	MA-19560133003	1	S	Plate
28	MA-H1440106012	2		Bolt, w/Washer
29	MA-00511070070	2		Band, Wire
30	MA-19560105AG0	1		Joint
31	MA-35011788000	1		Rubber




7530 Tractor
Governor

Page 65 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-30L63-02600	1		C-Ring
2	MA-30L63-02400	1		Cover
3	MA-30L63-00030	1		Bolt
4	MA-30H63-04200	1		Shaft Assy
5	MA-30A63-02600	1		Tie Rod
6	MA-30H63-06010	1		Lever Assy,Governor
7	MA-30H63-15200	1		Lever,Tension
8	MA-30L63-00700	1		C-Ring
9	MA-F2850-03020	2	S	Pin, Spring
10	MA-30H63-15700	1		Shaft,Governor
11	MA-MM407-03502	2		Lever,Governor
12	MA-30A63-00101	1		Gasket,Tie Rod
13	MA-MM409182	1		Spring,Tie Rod
14	MA-K8712630	1		Pin,Governor
15	MA-MM409239	1		Pin,Governor
16	MA-MF241222	3		Bolt,w/Washer
17	MA-30L63-00800	1		Cover,Torque
18	MA-MF241224	4		Bolt,w/Washer
19	MA-MF244826	2	S	Bolt,w/Washer
20	MA-MF430004	1		Nut
21	MA-MF430725	2		Nut,Jam
22	MA-MF450405	2		Washer, Spring
23	MA-MF520002	1		O-Ring
24	MA-MM438592	1		Spring,Governor
	MA-MM409213	1		Cover Assy,Tie Includes 25-27
25	MA-MM409167	1		Screw,Adjusting
26	MA-MF660031	1		Gasket
27	MA-MM409168	1		Nut,Special
28	MA-30H63-10010	1		Weight Assy,Governor
29	MA-30H63-04060	1		Lever Assy,Speed
30	MA-30H63-15800	1		Bolt
31	MA-MF660064	1	S	Gasket
32	MA-30H63-08700	1		Spring
	MA-30L63-00020	1	S	Screw Assy,Rack Includes 33,34
33	MA-30L63-00600	1		Nut,Torque
34	MA-31A63-05601	1	/P	Screw,Pack Set
35	MA-MM409169	1		Cap,Sealing
36	MA-30H63-05600	1		Lever,Tor Set
37	MA-MM401082	1		Bolt,Low

7530 Tractor
HST Assembly

Page 66 of 160



7530 Tractor
HST Assembly


Page 67 of 160

Ref #	Part Number	Qty	S/P/F	Description
	MA-19571301000	1		HST Unit Includes 1-54
1	MA-19571301150	1		Swash Plate
2	MA-19641301170	1		Plate,Thrust
3	MA-19571301170	1		Shaft
4	MA-19571301180	1		Shaft
5	MA-19571301190	1		Cover
6	MA-19571301210	1		Cover
7	MA-19571301220	1		Cover
8	MA-19571301230	1		Cap
9	MA-07410103500	4		C-Ring
10	MA-19571301240	1		Plate,Valve
11	MA-19571301250	1		Plate,Valve
12	MA-19631301470	1		Valve
13	MA-19631301430	1		Spring
14	MA-19571301280	1		Gasket
15	MA-19571301290	8		Bolt
16	MA-A5440708020	4		Bolt
17	MA-A2220106014	6		Screw
18	MA-19571301320	2		Spring
19	MA-19571301330	2		Seal,Oil
20	MA-19571301340	1		O-Ring
21	MA-08300200650	2		O-Ring
22	MA-07410106500	1		C-Ring
23	MA-19571301350	1		Collar
24	MA-19571301360	2		Bearing,Ball
25	MA-19571301370	2		Bearing,Needle
26	MA-07400102500	2	S	C-Ring
27	MA-19571301380	1		Seal,Oil
28	MA-19571301390	2		Pin
29	MA-19571301410	2		Bushing
30	MA-19571301420	2		Popet
31	MA-19571301430	2		Plug
32	MA-19571301440	2		Spring
33	MA-08301100140	2		O-Ring
34	MA-19571301450	1		Valve Assy
35	MA-19571301460	4		Pin
36	MA-19571301470	5		Plug
37	MA-08301100110	5		O-Ring
38	MA-19571301480	1		Plug
39	MA-19571301490	1		Seal,oil
40	MA-19571301510	1		Plug
41	MA-19571301520	1		Plate,Thrust
42	MA-08300200600	1	/P	O-Ring
43	MA-19571301530	2		Pin
	MA-19571301560	2		Cyl Block Assy Includes 44-52
44		2		Cylinder Block Order Part Number MA-19571301560
45		18		Piston Order Part Number MA-19571301560
46		2		Plate,Retainer Order Part Number MA-19571301560
47		2		Holder,Retainer Order Part Number MA-19571301560

7530 Tractor
HST Assembly

Page 68 of 160


Ref #	Part Number	Qty	S/P/F	Description
48		2		Holder, Spring Order Part Number MA-19571301560
49		2		Holder, Spring Order Part Number MA-19571301560
50		2		C-Ring Order Part Number MA-19571301560
51		2		Pin Order Part Number MA-19571301560
52		2		Spring Order Part Number MA-19571301560
53		1		Case Order Part Number MA-19571301000
54		1		Block Order Part Number MA-19571301000
	MA-19571301550	1		Kit, Repair Includes 55-63
55	MA-19571301280	1		Gasket
56	MA-19571301330	2		Seal, Oil
57	MA-19571301340	1		O-Ring
58	MA-08300200650	2		O-Ring
59	MA-19571301380	1		Seal, Oil
60	MA-08301100140	2		O-Ring
61	MA-08301100110	5		O-Ring
62	MA-19571301490	1		Seal, Oil
63	MA-08300200600	1	/P	O-Ring



7530 Tractor
HST Control

Page 70 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-19572301AG0	1		Pedal, HST
2	MA-11931812000	1		Cover, Pedal
3	MA-10320228000	1		Cover Pedal
4	MA-07961025200	2		Bushing
5	MA-35402291000	1		Plate
6	MA-19572302AG0	1		Arm, Trunnion
7	MA-19632304000	1		Bolt Set
8	MA-A3030110003	1	/P	Nut
9	MA-19572303000	1		Arm, Neutral - Before S/N 15867
9	MA-19572303001	1		Arm, Neutral - S/N 15867 & After Replaces MA-19572303000 by also ordering MA-A0500110040 and MA-A3010110002
10	MA-07963030250	1		Bushing
11	MA-07500560004	1		Bearing, Ball
12	MA-07400101000	1	S	C-Ring
13	MA-A0500108040	1		Bolt - Before S/N 15867
13	MA-A0500110040	1		Bolt - S/N 15867 & After
14	MA-A3010108002	1		Nut - Before S/N 15867
14	MA-A3010110002	1		Nut - S/N 15867 & After
15	MA-19572304000	1		Shaft, Holder
16	MA-A5340108045	1		Bolt 7T, Reamer
17	MA-03500150822	1		Washer
18	MA-19572308000	1		Joint, Front
19	MA-19572309000	1		Joint, Rear
20	MA-19572311000	2		Cushion
21	MA-A0540110080	1		Bolt 7T
22	MA-03500151026	1		Washer
23	MA-A3010110002	1		Nut
24	MA-03500140818	2		Washer
25	MA-05200125016	2	S	Pin, Split
26	MA-19572312AG0	1		Bracket
27	MA-F1540108020	2		Bolt, w/Washer
28	MA-35747891000	1		Adjuster
29	MA-A3010108002	2		Nut
30	MA-19572316000	1		Spring
31	MA-A0500108045	2		Bolt 7T
32	MA-A3010108002	2		Nut
33	MA-19572313000	1		Damper
34	MA-19572315AG0	1		Bracket
35	MA-F1540108020	1		Bolt, w/Washer
36	MA-03500140818	1		Washer
37	MA-05200125016	1	S	Pin, Split
38	MA-19572342000	1		Bolt, Set
39	MA-27086158000	1		Collar
40	MA-A3600100802	1		Washer, Spring




7530 Tractor
HST Drive

Page 72 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-19571305000	1	S	Shaft,Drive
2	MA-07500562054	1		Bearing,Ball
3	MA-07410105200	1	S	C-Ring
4	MA-07400102500	1	S	C-Ring
5	MA-10441214000	1		Boss,Spline
6	MA-19571371000	1		Clutch A
7	MA-07972020150	1		Bushing
8	MA-19831272000	1		Clutch B
9	MA-19571341000	1		Shaft
10	MA-19571351000	1		Spring
11	MA-10411392000	1		Collar
12	07500062050	1		Bearing,Ball
13	19571301000	1		Hst Unit

7530 Tractor Hydraulic Lift (Part 1)

Page 73 of 160




7530 Tractor
Hydraulic Lift (Part 1)

Page 74 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-19572401AG0	1		Housing,Hydraul
2	MA-F1540110040	3		Bolt,w/Washer
3	MA-A0540110110	5		Bolt 7T
4	MA-A0540110130	1		Bolt 7T
5	MA-A3600101002	6	/P	Washer,Spring
6	MA-HA430102000	3		Plug
7	MA-HA430103000	1		Plug
8	MA-05401010020	2		Pin,Dowel
9	MA-19562404000	1		Piston
10	MA-08320100650	1		Ring
11	MA-08300100650	1		O-Ring
12	MA-19562405000	1		Rod,Piston
13	MA-07972022200	1		Bushing
14	MA-19632418000	1		Pin
15	MA-HA130401000	1		Screw
16	MA-19562406000	1		Arm,Power
17	MA-HA130401000	1		Screw
18	MA-19562407000	1		Shaft,Hydraulic
19	MA-07961040400	2		Bushing
20	MA-08300120400	2		O-Ring
21	MA-10212421000	2		Collar
22	MA-19562408AG0	2		Arm,Lift
23	MA-07400104001	1		C-Ring
24	MA-10442409000	2		Pin,Lift Arm
25	MA-A3600101602	2		Washer,Spring
26	MA-A3030116002	2		Nut
27	MA-10322427000	1		Knob
28	MA-A3010108002	1		Nut
29	MA-05500005016	1		Pin,Spring
30	MA-07420101000	1	S	E-Ring
31	MA-03500151226	1		Washer
32	MA-534A1407000	1		Spring
33	MA-10442411000	1		Screw
34	MA-08301100050	1		O-Ring
35	MA-08000001200	1		Ball
36	MA-19611906000	1		Spring
37	MA-10442413000	1		Sleeve
38	MA-08301100140	1		O-Ring
39	MA-08301100200	1		O-Ring
40	MA-10252425000	1		Breather
41	MA-00504110005	1		Clamp,Hose
42	MA-09804071003	1		Pipe,Vinyl
43	MA-A3010108002	2		Nut
44	MA-10442426000	1		Joint
45	MA-10442449000	1		Plate
46	MA-10382476000	1		Pin,Spring
47	MA-07420100600	1		E-Ring
48	MA-F1540110025	1		Bolt,w/Washer

7530 Tractor
Hydraulic Lift (Part 2)


Page 75 of 160



7530 Tractor
Hydraulic Lift (Part 2)

Page 76 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-03500140818	1		Washer
2	MA-05210108000	1		Pin,Snap
3	MA-10442427000	1		Adjuster
4	MA-10442429AG0	1		Plate
5	MA-08300100140	4		O-Ring
6	MA-F1540108020	2		Bolt,w/Washer
7	MA-10352405000	1		Valve,Control
8	MA-F1540108055	2		Bolt,w/Washer
9	MA-F3010108000	2		Nut,Flange
10	MA-10442431001	1		Link Assy
11	MA-35011105000	1		Spring
12	MA-10442434000	1		Arm Pac
13	MA-10442436000	2		Arm,Feed Back
14	MA-10442438000	1		Arm,P/C
15	MA-10442441000	1		Pin
16	MA-08300100070	1		O-Ring
17	MA-07420100800	1		E-Ring
18	MA-19572443000	1		Lever,P/C
19	MA-19572444AG0	1		Arm
20	MA-F1540108025	1		Bolt,w/Washer
21	MA-19572446AG0	1		Boss
22	MA-10442447000	1		Link,Feed Back
23	MA-07961008080	1		Bushing
24	MA-10382476000	3		Pin,Spring
25	MA-19041264000	1		Lining,Brake
26	MA-03560101201	4		Spring,Conical
27	MA-A3030112002	1		Nut
28	MA-03500151226	2		Washer
29	MA-10442454000	1		Pipe,Lubricate
30	MA-HA430103000	1		Plug
31	MA-10442457AG0	1		Block
32	MA-F1540108030	1		Bolt,w/Washer
33	MA-08301100101	2		O-Ring
34	MA-08301100220	1		O-Ring
35	MA-F1540108060	2		Bolt,w/Washer
36	MA-10442461000	1		Arm,P/C
37	MA-A3010112002	2		Nut
38	MA-31212559000	2	S	Liner
39	MA-07972012150	1		Bushing
40	MA-19572414AG0	1		Bracket
41	MA-A9400114040	4		Bolt
42	MA-A3600101402	4		Washer,Spring
43	MA-10412416000	1		Pin
44	MA-08300100210	1		O-Ring




7530 Tractor
Hydraulic Lift (Part 3)

Page 78 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-19572451AG0	1		Lever,P/C
2	MA-10442475000	1		Tube
3	MA-10302444000	1		Grip
4	MA-H1840108016	2		Bolt,w/Washer
5	MA-19572489000	1		Lever Guide RH
6	MA-F3000106000	1		Nut,Flange
7	MA-H1440106016	3	/P	Bolt,w/Washer
8	MA-19613597000	1		Mark Y
9	MA-19572491000	1		Label,Lift
10	MA-F0500408020	1		Bolt,Flange
11	MA-A6000101700	1		Plug,Taper
12	MA-10212438000	1		Grip
13	MA-05200120012	1		Pin,Split
14	MA-10402455000	2		Stopper
15	MA-10312476000	2		Plate,Stopper

7530 Tractor
Hydraulic Line Assemblies

Page 79 of 160




7530 Tractor
Hydraulic Line Assemblies

Page 80 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-19682518AG0	1		Pipe B Pressure Assy
2	MA-19572591AG0	1		Pipe A Pressure Assy
3	MA-19572592AG1	1		Pipe B Pressure Assy
4	MA-19572594AG1	1		Pipe B Return Assy
5	MA-19572595AG0	1		Pipe B HST Assy
6	MA-19572596AG1	1		Pipe C HST Assy
7	MA-19572597AG0	1		Pipe D HST Assy
8	MA-19572598AG0	1		Pipe Ind Assy
9	MA-19572589AG0	1		Pipe C Return Assy

7530 Tractor
Hydraulic Lines (Part 1)

Page 81 of 160



7530 Tractor
Hydraulic Lines (Part 1)

Page 82 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-10302501002	1	/P	Pump,Hydraulic
2	MA-10302539002	1	/P	Pump
3	MA-67700-20101	2		Packing
4	MA-F3010108001	8		Nut,Flange
5	MA-19572505AG0	1		Pipe A,Suction
6	MA-08300100240	1		O-Ring
7	MA-H1540108020	3		Bolt,w/Washer
8	MA-19942525000	1		Hose A
9	MA-HA230101000	2		Clip,Hose
10	MA-19562506AG1	1		Pipe B,Suction
11	MA-19642509000	1		Filter
12	MA-11762527000	1		Hose
13	MA-HA230101000	2		Clip,Hose
14	MA-19562507AG0	1		Pipe C,Suction
15	MA-08300100200	1		O-Ring
16	MA-F1440106050	3		Bolt,w/Washer
17	MA-19672515000	1		Hose
18	MA-00505000280	2		Clamp,Hose
19	MA-19672514000	1		Joint
20	MA-08331002200	2		Washer,Seal
21	MA-19672516000	1		Bolt,Eye
22	MA-19642522000	1		Joint
23	MA-08301100180	1		O-Ring
24	MA-F1440106020	3		Bolt,w/Washer
25	MA-06205115170	1		Elbow (Includes Ref.No.26)
26	MA-08301100140	1		O-Ring
27	MA-19682518AG0	1		Pipe B,Pressure
28	MA-06203115170	1		Nipple (Includes Ref.No.29)
29	MA-08301100140	1		O-Ring
	MA-19572520AG0	1		Block Assy Includes 30-48
30	MA-19632524000	1		Block
31	MA-A6010101000	3	/P	Plug,Taper
32	MA-19632525000	1		Shaft
33	MA-19632526000	1		Plate
34	MA-08300100160	2	/P	O-Ring
35	MA-F3000106011	1		Nut,Flange
36	MA-F1540108016	1		Bolt,w/Washer
37	MA-A6000101700	3		Plug,Taper
38	MA-10052405120	1		Plug
39	MA-08300500160	1		O-Ring
40	MA-10052405170	1		Spring
41	MA-10052405130	A/R		Shim
42	MA-10052405140	A/R		Shim
43	MA-10052405150	A/R		Shim
44	MA-10052405160	A/R		Shim
45	MA-10052405180	1		Poppet
46	MA-10052405191	1	/P	Housing
47	MA-03500140618	1		Washer
48	MA-HA430103000	1		Plug
49		1		Washer,Seal Not used on this model.
50		1		O-Ring Not used on this model.
51		1		O-Ring Not used on this model.
52	MA-F1540108016	1		Bolt,w/Washer


7530 Tractor
Hydraulic Lines (Part 1)

Page 83 of 160

Ref #	Part Number	Qty	S/P/F	Description
53		1		Pipe,Return HST Not used on this model.
54		1		Bolt,Eye Not used on this model.
55	MA-00511070070	1		Band,Wire

7530 Tractor
Hydraulic Lines (Part 2)

Page 84 of 160



7530 Tractor
Hydraulic Lines (Part 2)

Page 85 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-06203115170	1		Nipple (Includes Ref.No. 2)
2	MA-08301100140	1		O-Ring
3	MA-19572591AG0	1		Pipe A,Pressure
4	MA-08331001600	2		Washer,Seal
5	MA-10302534000	1		Bolt,Eye
6	MA-19572511000	1		Clamp
7	MA-19672226000	1		Cushion
8	MA-19572594AG1	1		Pipe B,Return
9	MA-08331001600	2		Washer,Seal
10	MA-10302534000	1		Bolt,Eye
11	MA-06205115170	1		Elbow (Includes Ref.No.12)
12	MA-08301100140	1		O-Ring
13	MA-06313117130	1		Elbow 90 (Includes Ref.No.14)
14	MA-08301100140	1		O-Ring
15	MA-19562526001	1		Hose A
16	MA-06311113130	3		Adapter (Includes Ref.No.17)
17	MA-08301100110	3		O-Ring
18	MA-60001125000	1		Adapter (Includes Ref.No.19)
19	MA-08301100110	1		O-Ring
20	MA-19572531000	1		Hose C
	MA-19572550AG0	1		Ind Valve Assy Includes 21-33
21	MA-19572551000	1		Block
22	MA-19572552000	1		Cover
23	MA-19572553000	1		Relief Valve Ass'y.
24	MA-19572554000	1		Filter
25	MA-19612534000	1		Poppet
26	MA-19612536000	1		Sleeve
27	MA-10402551000	1		Valve
28	MA-HA430101000	3		Plug
29	MA-10411349000	2		Plug
30	MA-F1540108045	2		Bolt,w/Washer
31	MA-08301100101	3		O-Ring
32	MA-08301100220	1		O-Ring
33	MA-08301100120	2	/P	O-Ring
34	MA-F1540108045	1		Bolt,w/Washer
35	MA-00511070070	1		Band,Wire
36	MA-A0540108120	1		Bolt 7T
37	MA-A3600100802	1		Washer
38	MA-19572561AG0	1		Pipe Ind, Pressure
39	MA-08331001200	4		Seal Washer
40	MA-11742443001	2		Bolt,Eye
41	MA-19572598AG0	1		Pipe Ind,Lub
42	MA-06203110130	1		Nipple (Includes Ref.No.43)
43	MA-08301100110	1		O-Ring
44	MA-08331001200	2		Seal Washer
45	MA-11742443001	1		Bolt,Eye
46	MA-06203112170	1		Nipple (Includes Ref.No.47)
47	MA-08301100140	1		O-Ring
48	MA-11352474000	2		Cushion
49	MA-H1540108025	1		Bolt,w/Washer
50	MA-F3010108001	1		Nut, Flange
51	MA-10352535000	1		Clamp
52	MA-11802163000	1		Cushion


7530 Tractor
Hydraulic Lines (Part 2)

Page 86 of 160

Ref #	Part Number	Qty	S/P/F	Description
53	MA-19572589AG0	1		Pipe C,Return

7530 Tractor
Intake & Exhaust Manifold


Page 87 of 160



7530 Tractor
Intake & Exhaust Manifold

Page 88 of 160


Ref #	Part Number	Qty	S/P/F	Description
1	MA-30H30-02400	1		Mainfold,Intake
2	MA-30H30-03300	1		Gasket,Intake
3	MA-MF101287	4	S	Bolt
4	MA-MF241261	4		Bolt,w/Washer
5	MA-MF241251	4		Bolt,w/Washer
6	MA-30H66-03300	1		Heater,Air
7	MA-30H30-01700	3		Gasket,Air Heat
8	MA-30H30-02701	1		Cover
9	MA-30H32-13100	1		Mainfold,Exhaus
10	MA-30F32-03400	1		Gasket,Exhaust
11	MA-F1035-10055	5		Bolt
12	MA-MD041256	3		Stud
13	MA-32B32-00901	6	S	Spacer
14	MA-30H32-03300	6		Washer
15	MA-30H66-13100	1		Controller,Heat
16	MA-30H66-03200	1		Relay
17	MA-F1035-10050	1		Bolt
18	MA-K9644880	1		Clamp
19	MA-10402919000	1		Wire,Lead



7530 Tractor
Lubrication

Page 90 of 160


Ref #	Part Number	Qty	S/P/F	Description
1	MA-30L07-00800	1		Connector
2	MA-30H35-00101	1		Gasket,Oil Pump
3	MA-MF244865	3	S	Bolt,w/Washer
4	MA-MF244867	1		Bolt,w/Washer
5	MA-F3153-06000	1	S	O-Ring
6	MA-MM409893	1		Service Kit,Relief
7	MA-30A97-00038	1		Service Kit,Rotor
	MA-MM436-14601	1		Pump Assy Oil Includes 8-17
8	MA-MD000312	1		Gasket,Oil
9	MA-MD001402	1		Plunger,Relief
10	MA-MD001404	1		Plug,Drain
11	MA-MM409204	1		Spring
12	MA-F3153-07500	1		O-Ring
13	MA-MM407131	1		Rotor Assy,Oil
14	MA-MM434572	1		Body,Oil Pump
15	MA-MM409373	2	S	Pin
16	MA-MM436073	1		Cover,Oil Pump
17	MA-MS661120	1	S	Plug,Taper
18	MA-30A39-00100	1		Cooler,Oil
19	MA-MM436194	1		Bolt
20	MA-F3150-04500	1		O-Ring
21	MA-31B35-00101	1		Cover,Oil Pump
22	MA-MM430178	1		Screen Assy,Oil
23	MA-MF430729	1		Nut,Jam
24	MA-MF660036	1		Gasket
25	MA-31A90-10100	1	S	Switch,o Il Pressure
26	MA-30H35-00200	1		Hose,Water
27	MA-05317-50161	2		Clamp,Hose
	MA-MM430-59801	1		Driven Unit Includes 28-32
28	MA-MD701788	1		O-Ring
29	MA-MF472535	1	S	Pin,Spring
30	MA-MF520012	1	S	O-Ring
31	MA-MM407171	1	S	Gear,Speed
32	MA-MM430-41901	1	S	Sleeve,Speed
33	MA-MM437308	1		Joint,Oil Pipe
34	MA-MF660068	1	S	Gasket
35	MA-MD701789	1		Plate,Locking
36	MA-MF241224	1		Bolt,w/Washer



7530 Tractor
MFD PTO

Page 92 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-19561901000	1		Shaft,Propeller
2	MA-10231915000	1	S	Joint,Front
3	MA-10291943000	1		Joint
4	MA-07400102000	1		C-Ring
5	MA-19561904AG0	1		Cover A,shaft
6		0		Cover A,Shaft Not used on this model.
7	MA-H1540108020	2		Bolt,w/Washer
8	MA-19561905AG0	1		Cover B,Shaft
9	MA-00505000500	1		Clamp,Hose
10	MA-19561906000	1		Pipe
11		0		Shaft,Propeller Not used on this model.




7530 Tractor
Mid PTO

Page 94 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-12181241AG0	1		Mid PTO Assy (Includes Ref.No.2-20)
2	MA-12181242000	1		Case Mid PTO
3	MA-10250808000	1		Plug
4	MA-08331001200	1		Seal Washer
5	MA-08300201100	1		O-Ring
6	MA-12181243000	1		Shaft
7	MA-12181244000	1		Gear 24T
8	MA-07500062050	1		Bearing,Ball
9	MA-07500063040	1		Bearing,Ball
10	MA-10391285000	1		Bushing
11	MA-08300200250	1		O-Ring
12	MA-08412355212	1		Seal,Oil
13	MA-13521608000	1		Ring
14	MA-07400102500	2	S	C-Ring
15	MA-07410105201	1	S	C-Ring
16	MA-19871852000	1		Shaft A
17	MA-05500005050	1		Pin, Spring
18	MA-12181245000	1		Gear 41T
19	MA-07500063040	2		Bearing,Ball
20	MA-07410105201	1	S	C-Ring
21	MA-19803186000	1		Bolt
22	MA-A3600101202	1		Washer, Spring
23	MA-F1540112035	1		Bolt,w/Washer
24	MA-19631607000	1		Cover
25	MA-H1540108016	4		Bolt,w/Washer
26	MA-10441769000	1		Grip
27	MA-10441768000	1		Tube
28	MA-12181248AG0	1		Lever,Mid PTO
29	MA-H1840108025	2		Bolt,w/Washer
30	MA-12181249AG0	1		Arm,Mid PTO
31	MA-07400102000	1		C-Ring
32	MA-03500140818	1		Washer
33	MA-05200125020	1		Pin, Split
34	MA-12181251AG0	1		Link,Mid PTO
35	MA-10381725000	1		Pin, Spring
36	MA-10253505001	1	/P	Switch,Safety

7530 Tractor
Muffler


Page 95 of 160



7530 Tractor
Muffler

Page 96 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-195603110K1	1	S	Muffler
2	MA-H1540108016	2		Bolt,w/Washer
3	MA-195603150K0	1		Plate




7530 Tractor
Nozzle & Nozzle Holder

Page 98 of 160

Ref #	Part Number	Qty	S/P/F	Description
1 1A	MA-30H61-06200	3		Nozzle Holder Ass'y. Includes 1-43
	MA-09310-07630	3		Holder Ass'y. Includes 1-42
	MA-09311-07630	3		Body Sub Ass'y.
		1		Body Sub Ass'y. NOT USED ON THIS MODEL
2	MA-09317-52180	A/R		Washer, t=1.000
3	MA-09317-52190	A/R	/P	Washer, t=1.050
4	MA-09317-52200	A/R	/P	Washer, t=1.100
5	MA-09317-52210	A/R	/P	Washer, t=1.150
6	MA-09317-52220	A/R	/P	Washer, t=1.200
7	MA-09317-52230	A/R	/P	Washer, t=1.250
8	MA-09317-52240	A/R	/P	Washer, t=1.300
9	MA-09317-52250	A/R	/P	Washer, t=1.350
10	MA-09317-52260	A/R	/P	Washer, t=1.400
11	MA-09317-52270	A/R	/P	Washer, t=1.450
12	MA-09317-52280	A/R	/P	Washer, t=1.500
13	MA-09317-52290	A/R	/P	Washer, t=1.550
14	MA-09317-52300	A/R	/P	Washer, t=1.600
15	MA-09317-52310	A/R	/P	Washer, t=1.650
16	MA-09317-52320	A/R	/P	Washer, t=1.700
17	MA-09317-52330	A/R	/P	Washer, t=1.750
18	MA-09317-52340	A/R		Washer, t=1.800
19	MA-09317-52350	A/R	/P	Washer, t=1.850
20	MA-09317-52360	A/R	/P	Washer, t=1.900
21	MA-09317-52370	A/R	/P	Washer, t=1.950
22	MA-09317-52380	A/R	/P	Washer, t=2.000
23	MA-09317-52390	A/R	/P	Washer, t=2.050
24	MA-09317-52400	A/R	/P	Washer, t=2.100
25	MA-09317-52410	A/R		Washer, t=2.150
26	MA-09317-52420	A/R	/P	Washer, t=1.275
27	MA-09317-52430	A/R	/P	Washer, t=1.325
28	MA-09317-52440	A/R	/P	Washer, t=1.375
29	MA-09317-52450	A/R	/P	Washer, t=1.425
30	MA-09317-52460	A/R	/P	Washer, t=1.475
31	MA-09317-52470	A/R	/P	Washer, t=1.525
32	MA-09317-52480	A/R	/P	Washer, t=1.575
33	MA-09317-52490	A/R	/P	Washer, t=1.625
34	MA-09317-52500	A/R	/P	Washer, t=1.675
35	MA-09317-52510	A/R	/P	Washer, t=1.725
36	MA-09317-52520	A/R	/P	Washer, t=1.775
37	MA-09317-52530	A/R		Washer, t=0.950
38	MA-09312-70410	3	/P	Spring, Pressure
39	MA-09312-10480	3		Pin, Pressure
40	MA-09322-10150	3	/P	Packing, Tip
41	MA-94908-23160	6	S	Pin, Straight
42	MA-09316-41020	3	/P	Nut, Nozzle Retaining
43	MA-09340-08110	3		Nozzle Ass'y.
43A		0		Nozzle Ass'y. NOT USED ON THIS MODEL

7530 Tractor
Oil Pan & Gear Case


Page 99 of 160



7530 Tractor
Oil Pan & Gear Case

Page 100 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-30H11-00301	1	S	Housing,Gear
2	MA-30H11-00101	1	/P	Gasket,Housing
3	MA-MM408233	1		Cover,Governor
4	MA-30H11-03201	1		Cover,Gear Case
5	MA-30A11-00301	1	S	Gasket,Governor
6	MA-30H11-03300	1		Gasket,Gear
7	MA-MM406420	1		Bearing,Needle
8	MA-MM406421	1		Bearing,Needle
9		1		Case,Gear
10	MA-30H11-03100	1		Gasket,Gear
11	MA-30A11-00800	1		Seal,Front Oil
12	MA-K7910451	2		Cover,Oil Pump
13	MA-30A11-00101	2		Gasket
14	MA-MF100064	9		Bolt
15	MA-MF240051	12		Bolt,w/Washer
16	MA-MF241255	2		Bolt,w/Washer
17	MA-MS401434	2		Stud
18	MA-MS401426	6		Stud
19	MA-MF430005	8		Nut
20	MA-MM401205	1	S	Cover,Oil Pump
21	MA-MF450405	8		Washer,Spring
22	MA-30H13-00101	1		Gasket,Oil
	MA-MM435538	1		Pan Assy,Oil Includes 23-25
23		1		Pan Sub Assy
24	MA-MD000312	1		Gasket,Oil
25	MA-MD000318	1		Plug,Oil
26	MA-MF240051	16		Bolt,w/Washer




7530 Tractor
PTO Control (Part 1)

Page 102 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-10441769000	1		Grip
2	MA-10441768000	1		Tube
3	MA-19571771AG0	1		Lever,Rear PTO
4	MA-H1840108025	2		Bolt,w/Washer
5	MA-19571772000	1		Arm,Rear PTO
6	MA-19571773000	1		Shaft,PTO
7	MA-03500140818	1		Washer
8	MA-05200125020	1		Pin,Split
9	MA-19571774AG0	1		Link,Rear PTO
10	MA-10381725000	1		Pin,Spring
11	MA-19571785000	1		Lever Guide LH
12	MA-H1440106016	3	/P	Bolt,w/Washer
13	MA-F3000106000	1		Nut,Flange
14	MA-19613597000	1		Mark Y
15	MA-07400102000	1		C-Ring
16	MA-19571786000	0		Lever Guide LH

7530 Tractor
PTO Control (Part 3)


Page 103 of 160



7530 Tractor
PTO Control (Part 3)

Page 104 of 160


Ref #	Part Number	Qty	S/P/F	Description
1	MA-19571731000	1		Rail,PTO
2	MA-07400101600	1	S	C-ring
3	MA-19571732000	1		Spacer
4	MA-19571733000	1		Fork,Rear PTO
5	MA-08000000900	1		Ball
6	MA-10371764001	1		Spring
7	MA-19571652000	1		Shifter,PTO
8	MA-08300100120	1	S	O-Ring
9	MA-08340016050	1		Cap,Seal
10	MA-19571735AG0	1		Cover
11	MA-37001063000	2		Bolt,Reamer
12	MA-F1540108025	2		Bolt,w/Washer
13	MA-A3600100802	2		Washer,Spring
14	MA-10251109001	1		Plate
15	MA-F1540108016	1		Bolt,w/Washer
16	MA-19571651000	1		Fork,Mid PTO
17	MA-08000000900	1		Ball
18	MA-10371764001	1		Spring
19	MA-19571652000	1		Shifter,PTO
20	MA-08300100120	1	S	O-Ring
21	MA-08340016050	1		Cap,Seal



7530 Tractor
Radiator

Page 106 of 160

Ref #	Part Number	Qty	S/P/F	Description
	MA-19560411000	1		Radiator Assy Includes 1-4
1	MA-19560411100	1		Radiator C Comp
2	MA-35230551200	1		Cap
3	MA-35230551400	1		Hose
4	MA-68201-01814	2		Clip
5	MA-09810080600	1		Hose
6	MA-00502113086	1		Clamp
7	MA-10440435000	2		Clamp
8	MA-H1040106012	2		Bolt,w/Washer
9	MA-19560417000	1		Hose,Upper
10	MA-19560418000	1		Hose,Lower
11	MA-00501100380	2		Clamp,Hose
12	MA-00501100450	2		Clamp,Hose
13	MA-00511070070	2		Band,Wire
14	MA-19560414AG0	1		Net,Radiator
15	MA-H1540108020	1		Bolt,w/Washer
16	MA-69501-06613	2		Clamp
17	MA-60432031000	2		Cushion
18	MA-19560422000	2		Spacer
19	MA-19560424000	2		Cushion
20	MA-19560421AG0	1		Shroud,Fan
21	MA-F0500108090	2		Bolt
22	MA-A3010108002	2		Nut
23	MA-H1440106016	6	/P	Bolt,w/Washer
24	MA-10440424000	2		Cushion
	MA-19080445000	1		Sub Tank Assy Includes 25,26
25	MA-19080445100	1		Sub Tank
26	MA-19080445200	1		Cap Assy
27	MA-19560415AG0	1		Bracket,Radiator
28	MA-19560425000	1		Weather Strip
29	MA-19560428AG0	1		Plate
30	MA-H1640106016	2		Bolt,w/Washer
31	MA-H1540108020	4		Bolt,w/Washer
32	MA-H1440106016	2	/P	Bolt,w/Washer
33	MA-60221832000	2		Grommet




7530 Tractor
Repair Gasket Kit

Page 108 of 160

Ref #	Part Number	Qty	S/P/F	Description
	MA-30H94-22010	1		Gasket Kit Includes 1-28
1	MA-MD000312	2		Gasket,Oil Drain
2	MA-MD000551	2	S	Gasket,Water
3	MA-30H11-03300	1		Gasket,Gear
4	MA-30A11-00800	1		Seal,Front Oil
5	MA-MM406228	4		Seal,Side
6	MA-30H30-03300	1		Gasket,Intake Manifold
7	MA-30H30-01700	2		Gasket,Air Heat
8	MA-MM413060	6		Seal,Valve Stem
9	MA-MM432045	3		Gasket,Nozzle
10	MA-34336-04100	1		Gasket
11	MA-30A11-00101	1		Gasket,Oil Pump
12	MA-30A11-00301	1	S	Gasket,Governor
13	MA-49172-17300	1		Gasket
14	MA-30A63-00101	1		Gasket,Tie Rod
15	MA-MF660063	4	S	Gasket
16	MA-30H01-00300	1	/P	Gasket,Cylinder
17	MA-30H04-00101	1	/P	Gasket,Rocker
18	MA-30H07-00201	1	/P	Gasket,Oil Seal
19	MA-30H07-00300	1		Gasket,Front
20	MA-F3153-06000	1	S	O-Ring
21	MA-30H11-03100	1		Gasket,Gear
22	MA-F3150-04500	1		O-Ring
23	MA-30H13-00101	1		Gasket,Oil Pan
24	MA-30H32-03400	1		Gasket,Exhaust
25	MA-30H35-00101	1		Gasket,Oil Pump
26	MA-30H45-00101	1	/P	Gasket,Water
27	MA-MF660036	1		Gasket
28	MA-30636-25901	2	S	Gasket

7530 Tractor
Safety Frame


Page 109 of 160



7530 Tractor
Safety Frame

Page 110 of 160


Ref #	Part Number	Qty	S/P/F	Description
1	MA-19573901AG0	1		Rollbar
2	MA-19812822000	1		Plug
3	MA-10443903AG1	1		Bracket LH
4	MA-10443904AG1	1		Bracket RH
5	MA-F1540112030	8		Bolt,w/Washer
6	MA-10443921001	2		Pin
7	MA-10443922000	2		Spring
8	MA-07400101600	2	S	C-Ring
9	MA-07310101510	2		Liner
10	MA-A0540116080	2		Bolt 7T
11	MA-10443923000	2		Nut,Lock
12	MA-10443924000	2		Rubber
13	MA-19573905AG0	1		Support,Bracket
14	MA-19573913BD0	2		Frame
15	MA-A0540112070	2		Bolt 7T
16	MA-35150657200	2		Washer
17	MA-10383932000	4		Rubber Cushion
18	MA-19573915000	2		Collar
19	MA-19573917AG0	1		Bracket LH,Rear
20	MA-19573918AG0	1		Bracket RH,Rear
21	MA-F1540110025	4		Bolt,w/Washer
22	MA-A9450116070	2		Bolt 10.9
23	MA-10383944000	2		Washer
24	MA-19633915000	2		Collar
25	MA-10383946000	4		Rubber,Cushion
26	MA-10383943000	4		Collar
27	MA-10443926000	2		Washer
	MA-19633919000	1	/P	Seat Belt Assy Includes 28-30
28	MA-19633919100	1	S	Seat Belt Assy
29	MA-19633919400	2		Bolt
30	MA-19633919500	2		Nut
31	MA-19573925000	1		Plate,ROPS
32	MA-19042742000	2		Rivet



7530 Tractor
Seat

Page 112 of 160


Ref #	Part Number	Qty	S/P/F	Description
1	703-2640	1		Track, Seat Slide
2	703-2641	1		Track. Seat Slide Adjustment
3	710-0528	4	/P	Screw, HHC, 5/16-18 x 1.25 GR5
4	712-3077	8	/P	Nut, Hex, M8 x 1.25 GR8.8
5	736-0119	12	S	Washer, Lock, 5/16
6	736-0275	4	S	Washer, Flat, .344 x .688 x .065
7	750-3230	4		Spacer, .387 x .875 x .54
8	757-04008	1	S	Seat



7530 Tractor
Seat Base

Page 114 of 160


Ref #	Part Number	Qty	S/P/F	Description
1	MA-19573401AG0	1		Bracket,Rail
2	MA-19573403AG0	1		Bracket,Seat
3	MA-19573406000	1		Bracket
4	MA-19633415000	2	S	Spring
5	MA-03500160826	2		Washer
6	MA-F3010108000	2		Nut,Flange
7	MA-19633417000	2		Rubber
8	MA-F3010108000	12		Nut,Flange
9	MA-H1540108016	4		Bolt,w/Washer
10	MA-10303421000	1		Adjuster,Seat
11	MA-37353706000	1		Adjuster,Seat
12	MA-19633411000	1		Pin
13	MA-07420100800	2		E-Ring
14	MA-F0500108016	2		Bolt,Flange



7530 Tractor
Starter

Page 116 of 160

Ref #	Part Number	Qty	S/P/F	Description
	MA-31B66-00101	1		Starter Ass'y Includes 1-22
1	MA-M414X-00474	1	S	Screw Set
2	MA-M641X-B2371	1		Bracket Ass'y
3	MA-M864X-09771	1	S	Lever Set
4	MA-M371X-71973	1	S	Switch Ass'y
5	MA-S409S-00008	1		Ball
6	MA-M578X-31771	1	S	Packing
7	MA-M106X-59371	1		Armature Set
8	MA-M981X-73275	1	S	Bolt
9	MA-M357X-92671	1	S	Shaft Ass'y,Clutch
10	MA-M605X-98571	1		Pinion Set
11	MA-M385X-06171	1	S	Stopper Set
12	MA-M385X-05371	1	S	Stopper Set
13	MA-M191X-17971	1	S	Clutch,Over Run
14	MA-M135X-03071	1	S	Gear Ass'y,Internal
15	MA-M357X-67671	1		Shaft Ass'y,Gear
16	MA-M230X-00471	3	S	Gear Ass'y
17	MA-M800X-63075	1	S	Yoke Ass'y
18	MA-M647X-00571	1	S	Brush Ass'y
19	MA-M649X-01271	1	S	Holder Ass'y,Brush
20	MA-M391X-03271	2	S	Spring,Brush
21	MA-M391X-03371	2	S	Spring,Brush
22	MA-M642X-30773	1		Bracket Ass'y




7530 Tractor
Steering (Part 1)

Page 118 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-19572202AG0	1		Mast,Steering
2	MA-19572203000	1		Shaft,Steering
3	MA-10442204000	1		Joint
4	MA-07400102200	1		C-ring
5	MA-07310102016	1		Liner
6	MA-07310102016	1		Liner
7	MA-08300100160	3	/P	O-ring
8	MA-07500560044	1		Bearing,Ball
9	MA-07410104201	1	S	C-ring
10	MA-07400101900	2	S	C-ring
11	MA-07400101900	1	S	C-ring
12	MA-08300100180	1	/P	O-ring
13	MA-39510814000	1		Spring
14	MA-10401295000	1		Liner
15	MA-10442291000	1	S	Bushing Column
	MA-10442205000	1	/P	Wheel,Steering Includes 16,17
16	MA-10442206000	1	S	Steering Wheel
17	MA-10442207000	1		Cap,Center
18	MA-A3600101402	1		Washer,Spring
19	MA-10366076000	8		Rubber
20	MA-10373021000	4		Collar
21	MA-A0620110025	2		Bolt,Stud
22	MA-F3010110000	2		Nut,Flange
23	MA-F1540110035	2		Bolt,w/Washer
24	MA-A3030114002	1		Nut
25	MA-03500151026	4		Washer
26	MA-19572255AG0	1		Lever
27	MA-A0520112060	1		Bolt 7T
28	MA-A3010112002	1		Nut
29	MA-27722333010	1		Spring
30	MA-19572201AG0	1		Bracket,Mast
31	MA-19572218000	1		Boot,Steering
32	MA-14212284000	1		Grip
33	MA-19572216000	1		Bolt
34	MA-A3010112003	2		Nut
35	MA-07310102010	2		Liner
36	MA-19572258AG0	1		Plate
37	MA-H1640406016	2		Bolt,w/Washer
38	MA-19572217000	1		Bolt
39	MA-35447219102	1		Cushion

7530 Tractor
Steering (Part 2)


Page 119 of 160



7530 Tractor
Steering (Part 2)

Page 120 of 160


Ref #	Part Number	Qty	S/P/F	Description
1	MA-19562231002	1		Steering Unit
2	MA-F1550110020	3		Bolt,w/Washer
3	MA-19562241000	1		Hose L
4	MA-19562242000	1		Hose R
5	MA-00511032070	1		Band,Wire
6	MA-00511070070	2		Band,Wire
7	MA-00502103104	1		Clamp
8	MA-H1540108020	1		Bolt,w/Washer
9	MA-06301113130	2		Adapter
	MA-10352210AG0	1		Cylinder Assy Includes 10-19
10	MA-10352211000	1		Tube,Cylinder
11	MA-10352213000	1		Rod,Cylinder
12	MA-08301100390	1		O-Ring
13	MA-08320100390	2		Ring,Backup
14	MA-10302274003	2		Case,Packing
15	MA-07963030250	2		Bushing
16	MA-10302276000	2		Packing U
17	MA-10302277000	2		Seal,Dust
18	MA-08300100400	2		O-Ring
19	MA-08300500480	2		O-Ring
20	MA-05401010020	1		Pin,Dowel
21	MA-A9400112035	4		Bolt 10.9
22	MA-HA174401000	4		Washer
23	MA-10312212000	2		Rod End
24	MA-A0730120003	2		Nut
25	MA-10302278000	2		Rod
26	MA-10312217000	2		Bolt
27	MA-A3130102001	2		Nut
28	MA-05200140036	2		Pin,Split
	MA-10302158000	1	S	Rod End LH Includes 29-33
29	MA-10302158100	1		Body
30	MA-10302157200	1	/P	Cover,Dust
31	MA-10302157300	1		Nipple,Grease
32	MA-10302157400	1		Nut
33	MA-10302157500	1		Pin,Split
34	MA-11762216000	1	S	Socket Assy (Includes Ref. no. 35-38)
35	MA-10302157200	1	/P	Cover,Dust
36	MA-11762216300	1		Nipple,Grease
37	MA-10302157400	1		Nut
38	MA-10302157500	1		Pin,Split



7530 Tractor
T/M Control (Part 2)

Page 122 of 160


Ref #	Part Number	Qty	S/P/F	Description
1	MA-19571717000	1		Rail,Sub
2	MA-10441718001	1		Fork,Sub
3	MA-08000000900	1		Ball
4	MA-10371764001	1		Spring
5	MA-19571719000	1		Shifter,Sub
6	MA-08300100160	1	/P	O-Ring
7	MA-10251304000	3		Plate
8	MA-F1540108020	2		Bolt,w/Washer
9	MA-19571723000	1		Shifter,4WD
10	MA-08300100160	1	/P	O-Ring
11	MA-08340020070	3		Cap,Seal
12	MA-10251109001	1		Plate
13	MA-F1540108020	2		Bolt,w/Washer



7530 Tractor
T/M Control (Part 3)

Page 124 of 160


Ref #	Part Number	Qty	S/P/F	Description
1	MA-06930014460	1		Grip
2	MA-10351749000	1		Pipe
3	MA-19571751AG0	1		Lever,Main
4	MA-H1540108016	2		Bolt,w/Washer
5	MA-10441752AG0	2		Arm,Main
6	MA-10441753AG0	1		Crank
7	MA-07963020200	2		Bushing
8	MA-07961020150	2		Bushing
9	MA-10301724AG0	1		Boss
10	MA-10251127004	1		Spring
11	MA-A5140110080	1		Bolt,Reamer
12	MA-03500141022	1		Washer
13	MA-10251120001	1		Collar
14	MA-07971010150	2		Bushing
15	MA-A3010110002	2		Nut
16	MA-19571754000	1		Rod,Main(1-2)
17	MA-19571755000	1		Rod,Main(3-4)
18	MA-10251135000	2		Joint,Ball
19	MA-F3010108000	2		Nut,Flange
20	MA-A3032110002	2		Nut
21	MA-37041577000	2		Joint,Ball
22	MA-F3010108000	2		Nut, Flange
23	MA-A3030110002	2		Nut
24	MA-10441756AG0	1		Link,Main(1-2)
25	MA-10441757AG0	1		Link,Main(3-4)
26	MA-10381725000	2		Pin,Spring
27	MA-10392491000	1		Grip
28	MA-10442476000	1		Tube
29	MA-19571761AG0	1		Lever,Sub
30	MA-07972020100	2		Bushing
31	MA-10441762001	1		Shaft,Main.Sub
32	MA-A3010116003	1		Nut
33	MA-07400102000	1		C-Ring
34	MA-43561209000	1		Collar
35	MA-10441763000	1		Rod,Sub
36	MA-08300100080	2		O-Ring
37	MA-03500150822	2		Washer
38	MA-05200125020	2		Pin,Split
39	MA-19571764AG0	1		Link,Sub
40	MA-10381725000	1		Pin,Spring
41	MA-35773623000	1		Grip
42	MA-19571781AG0	1		Lever,4WD
43	MA-07961020250	1		Bushing
44	MA-07400102000	1		C-Ring
45	MA-03500140818	1		Washer
46	MA-05200125020	1		Pin,Split
47	MA-19571782AG0	1		Link,4WD
48	MA-10381725000	1		Pin,Spring
	MA-19571791000	A/R	S	Liner Set Includes 49,50
49	MA-07310102004	A/R		Liner
50	MA-07310102002	A/R		Liner



7530 Tractor
T/M Control (Part 4)

Page 126 of 160


Ref #	Part Number	Qty	S/P/F	Description
1	MA-10392491000	1		Grip
2	MA-10442476000	1		Tube
3	MA-19571762AG0	1		Lever,Sub
4	MA-07972020100	2		Bushing
5	MA-10441762001	1		Shaft,Main.Sub
6	MA-A3010116003	1		Nut
7	MA-07400102000	2		C-Ring
8	MA-07310102010	2		Liner
9	MA-03500140818	1		Washer
10	MA-05200125020	1		Pin,Split
11	MA-19571765AG0	1		Link,Sub
12	MA-10381725000	1		Pin,Spring
13	MA-35773623000	1		Grip
14	MA-19571784AG0	1		Lever,4WD
15	MA-07961020250	1		Bushing
16	MA-07400102000	1		C-Ring
17	MA-03500140818	1		Washer
18	MA-05200125020	1		Pin,Split
19	MA-19571783AG0	1		Link,4WD
20	MA-10381725000	1		Pin,Spring



7530 Tractor
T/M Control (Part 6)

Page 128 of 160


Ref #	Part Number	Qty	S/P/F	Description
1	MA-19572321000	1		Plate,Speed Con
2	MA-19572322AG0	1		Link,Speed Con
3	MA-19572323AG0	1		Arm,Speed Con
4	MA-05500006032	2		Pin,Spring
5	MA-03500130815	1		Washer
6	MA-05200125016	1	S	Pin,Split
7	MA-19632311000	1		Shaft,Pedal
8	MA-19632312000	1		Shaft
9	MA-19632313000	1		Arm,Lock
10	MA-19632317000	1		Spring
11	MA-19632334000	1		Arm,Brake
12	MA-07972020200	1		Bushing
13	MA-19632336000	1		Shoe
14	MA-05620108025	1		Pin,Clevis
15	MA-05200125016	1	S	Pin,Split
16	MA-19572325AG0	1		Plate
17	MA-F1540108020	1		Bolt,w/Washer
18	MA-14212284000	1		Grip
19	MA-19572331AG0	1		Lever,Speed Con
20	MA-19572332000	1		Rod,Speed Con
21	MA-19572335000	1		Plate
22	MA-A3000106002	2		Nut
23	MA-05200125016	2	S	Pin,Split
24	MA-03500140818	1		Washer
25	MA-05200125016	1	S	Pin,Split
26	MA-19571779000	1		Cover



7530 Tractor
T/M Controls

Page 130 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-10441423001	1		Shifter
2	MA-08300100110	1		O-Ring
3	MA-07420101200	1	S	E-Ring
	MA-10191806000	A/R		Liner Set Includes 4,5
4	MA-07310001504	A/R		Liner
5	MA-07310101512	A/R		Liner
6	MA-F3010108001	1		Nut,Flange
7	MA-10441427AG0	1		Pedal,Diff Lock
8	MA-10441426AG0	1		Plate
9	MA-H1840108025	2		Bolt,w/Washer
10	MA-10441431AG0	1		Plate
11	MA-10441429000	1		Shaft
12	MA-07310102004	1		Liner
13	MA-07400102000	1		C-Ring
14		0		Pedal,Difflock Not used on this model.
15		0		Shaft Not used on this model.
16		0		Pin,Spring Not used on this model.
17		0		Seal,Oil Not used on this model.
18		0		Arm Not used on this model.
19		0		Arm Not used on this model.
20		0		Plate Not used on this model.
21		0		Pin,Split Not used on this model.
22		0		Washer Not used on this model.
23		0		Ball Joint Not used on this model.
24		0		Nut Not used on this model.
25		0		Rod Not used on this model.
26		0		Ball Joint Not used on this model.
27		0		Nut Not used on this model.
28		0		Nut,Flange Not used on this model.
29		0		Liner Not used on this model.
30		0		C-Ring Not used on this model.
31	MA-10441424AG1	1		Arm,Diff Lock



7530 Tractor
TM Control (Part 1)


Page 132 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-10441701000	1		Rail,Main
2	MA-10441702000	1		Fork 1-2,Main
3	MA-10441703000	1		Fork 3-4,Main
4	MA-08000000900	2		Ball
5	MA-67428-01700	2		Spring
6	MA-10441704000	1		Shifter A,Main
7	MA-10441705000	1		Shifter B,Main
8	MA-08300100160	2	/P	O-Ring
9	MA-10251109001	1		Plate
10	MA-F1540108020	1		Bolt,w/Washer
11	MA-10441708000	1		Rail,Shuttle
11	MA-19571708000	1		Rail, Shuttle - 7530 from S/N10138
12	MA-10441709000	1		Fork A,Shuttle
13	MA-08000000900	1		Ball
14	MA-10301791000	1		Spring
15	MA-10441712000	1		Shifter,Shuttle
16	MA-08300100160	1	/P	O-Ring
17	MA-10251304000	1		Plate
18	MA-F1540108020	1		Bolt,w/Washer
19	MA-19571716000	1		Rail,Sub
20	MA-10441718001	1		Fork,Sub
21	MA-08000000900	1		Ball
22	MA-10371764001	1		Spring
23	MA-19571719000	1		Shifter,Sub
24	MA-08300100160	1	/P	O-Ring
25	MA-10251304000	3		Plate
26	MA-F1540108020	2		Bolt,w/Washer
27	MA-19571721000	1		Fork,4WD
28	MA-19571722000	1		Shifter,4WD
29	MA-08300100160	1	/P	O-Ring
30	MA-F1540108020	2		Bolt,w/Washer
31	MA-10251109001	1		Plate
32	MA-08340020070	3		Cap,Seal

7530 Tractor
TM Control (Part 5)

Page 134 of 160


Ref #	Part Number	Qty	S/P/F	Description
1	MA-06970012609	1		Grip
2	MA-A2220104008	2		Screw
3	MA-19571788AG1	1		Lever, Shuttle
4	MA-19571789AG0	1		Arm, Shuttle
5	MA-07972020100	2		Bushing
6	MA-03500150822	4		Washer
7	MA-10311716000	1		Spring
8	MA-A5140110060	1		Bolt, Reamer
9	MA-A3010110002	2		Nut
10	MA-03500151026	2		Washer
11	MA-19571799AG0	1		Plate, Guide
12	MA-H1540108020	2		Bolt, w/Washer
13	MA-10441787000	1		Rod, F.R
14	MA-10441796000	1		Joint
15	MA-10401817000	1		Joint
16	MA-A3010110002	1		Nut
17	MA-A3012110001	1		Nut
18	MA-10441791AG0	1		Link, F.R
19	MA-10441793AG0	1		Link, Shuttle
20	MA-10381725000	2		Pin, Spring
21	MA-10441795000	1		Rod F.R
22	MA-10441797000	1		Shaft, F.R
23	MA-07961020150	2		Bushing
24	MA-08400020325	2		Seal, Oil
25	MA-03500162040	1		Washer
26	MA-05620108028	2		Pin, Clevis
27	MA-05200125020	4		Pin, Split
28	MA-05620108025	1		Pin, Clevis
29	MA-19571795000	1	/P	Rubber



7530 Tractor
Transmission

Page 136 of 160


Ref #	Part Number	Qty	S/P/F	Description
	MA-19571401000	1		Diff Case Assy Includes 1-10
	MA-19571411000	0		Diff Case Assy (Includes Ref.No.26); Includes 1-9
1	MA-10441404000	1		Diff Case
2	MA-10191412000	2		Pinion,Mate
3	MA-10191413000	2		Gear,Side
4	MA-10191414000	1		Shaft,Pinion
5	MA-10191415000	2		Washer,Thrust
6	MA-10191416000	2		Washer,Thrust
7	MA-05500006040	1		Pin,Spring
8	MA-10321411000	1		Gear,Ring
9	MA-12186568000	8		Bolt
10	MA-19571402000	1		Shaft,Pinion
	MA-19571403000	1		6-35 Set(Exchange Parts) Includes 11,12
11	MA-10321411000	1		Gear,Ring
12	MA-19571402000	1		Shaft,Pinion
13	MA-10441421000	1		Sleeve
14	MA-10441416000	1		Holder LH
15	MA-10441417000	1		Holder RH
16	MA-F1540108025	12		Bolt,w/Washer
17	MA-07500060100	3		Bearing,Ball
18	MA-11351416000	1		Spring
19	MA-07410108001	2		C-Ring
	MA-10190623000	A/R		Liner Set Includes 20-22
20	MA-10070618000	A/R		Liner
21	MA-10070618100	A/R		Liner
22	MA-10070618200	A/R		Liner
	MA-19571413000	0		6-35 Set(Exchange Parts) Includes 23,24
23	MA-10321411000	0		Gear,Ring
24	MA-19571412000	0		Shaft,Pinion
25	MA-10251535000	2		Liner
26	MA-19571412000	0		Shaft,Pinion



7530 Tractor
Transmission (Part 1)

Page 138 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-19571201AG0	1		Housing, Transmission
2	MA-19571206AG0	1		Holder, Bearing
3	MA-19571204000	1	S	Cover - Mod. 7530 before S/N 10138
3	MA-19571204001	1	/P	Cover - Mod. 7530 S/N 10138 & after Replaces MA-19571204000 by also ordering MA-19571291001 (PTO Clutch Assy) and MA-19571708000 (Shuttle Rail)
4	MA-19571203AG0	1	S	Housing, Diff
5	MA-05401010020	4		Pin, Dowel
6	MA-A0540110125	12		Bolt
7	MA-A3600101002	14	/P	Washer, Spring
8	MA-A3010110002	2		Nut
9	MA-10441595000	2		Stud
10	MA-10250808000	3		Plug
11	MA-08331001200	3		Washer, Seal
12	MA-19571205AG0	1		Cover, PTO
13	MA-05401010020	2		Pin, Dowel
14	MA-F1540112040	8		Bolt, w/Washer
15	MA-19812472002	1		Plug, Oiling
16	MA-08300100280	1		O-Ring
17	MA-F1540110050	10		Bolt, w/Washer
18	MA-05401010020	2		Pin, Dowel
19	MA-10311382000	1		Cap P.T.O
20	MA-A1400600812	2		Bolt, Wing
21	MA-10401337000	2		Bolt
22	MA-A0500110030	2		Bolt 7T
23	MA-03550161021	4		Washer
24	MA-10411349000	6		Plug
25	MA-10441207AG0	1		Cover
26	MA-F1540108025	5		Bolt, w/Washer



7530 Tractor
Transmission (Part 2)


Page 140 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-10441215000	1		Shaft, Back Idle
2	MA-08300100160	1	/P	O-Ring
3	MA-03500151226	AR		Washer
4	MA-A3100101201	1		Nut
5	MA-05200125020	1		Pin, Split
6	MA-10441216000	1	S	Gear 22T - Before S/N10398
	MA-10441216001	1	/P	Gear 22T - Model 7530 S/N 10398 & after. Replaces MA-10441216000 when inventory is gone.
7	MA-07802202617	1		Bearing, Needle
8	MA-13521406000	2		Liner B, Thrust
9	MA-07400102000	2		C-Ring
10	MA-07310101210	AR	S	Liner
11	MA-19571277000	1		Shaft, Pipe
12	MA-07500560064	1		Bearing, Ball
13	MA-07400103000	2	S	C-ring
14	MA-07410105501	1		C-ring
15	MA-19571278000	1		Shaft, Drive
16	MA-07963020200	2		Bushing
17	MA-19631276000	1		Seal, Oil
18	MA-19571281000	1		Shaft, Shuttle
19	MA-08401020307	1		Seal, Oil
20	MA-07500060060	1		Bearing, ball
21	MA-07500060070	2		Bearing, Ball
22	MA-19571279000	1		Boss, Spline
23	MA-07500060050	1		Bearing, Ball
24	MA-19571285000	1		Shaft
25	MA-07500560054	1		Bearing, Ball
26	MA-19571283000	1		Boss, Spline
	MA-19571291000	1		PTO Clutch Assembly, Mod 7530 before S/N 10138 (C00175) (Incl Item 27-42)
	MA-19571291001	1		PTO Clutch Assembly -Model 7530 S/N 10138 & after (Incl Item 27-42)
27	MA-19571291100	1		Case - Model 7530 Before S/N 10138 (C00175)
27	MA-19571291111	1		Case - Model 7530 S/N10138 & after
28	MA-19611261120	1		Piston - Model 7530 Before S/N 10138 (C00175)
28	MA-19571291120	1		Piston - Model 7530 S/N10138 & after
29	MA-19611261130	1		Ring, Seal
30	MA-19611261140	2		Ring, Seal
31	MA-19611261150	1		Spring
32	MA-19611261160	1		Ring, Seal
33	MA-19611261170	3		Plate, Drive - Model 7530 Before S/N 10138 (C00175)
33	MA-19571291170	3		Plate, Drive - Model 7530 S/N 10138 & after
34	MA-19611261180	3		Plate, Disk
35	MA-19611261190	1		Plate, Back - Model 7530 Before S/N 10138 (C00175)
35	MA-19571291190	1		Plate, Back - Model 7530 S/N10138 & after

7530 Tractor
Transmission (Part 2)

Page 141 of 160


Ref #	Part Number	Qty	S/P/F	Description
36	MA-19611261210	1		Ring - Model 7530 Before S/N 10138 (C00175)
36	MA-19571291210	1		Ring - Model 7530 S/N10138 & after
37	MA-19611261220	1		Washer
38	MA-19611261230	1		Ring
39	MA-19611261240	2		Disk, Brake
40	MA-19611261250	2		Plate, Brake - Model 7530 Before S/N 10138 (C00175)
40	MA-19571291250	2		Plate, Brake - Model 7530 S/N S/N10138 & after
41	MA-19611261260	1		Ring
42	MA-10371339000	1		Spring, Belleville - Model 7530 before S/N 10138 (C00175)
42	MA-19571291270	1		Spring - Model 7530 S/N S/N10138 & after
43	MA-08401030428	1		Seal, Oil
44	MA-07400103000	1	S	C-Ring
45	MA-35211303200	1		Liner



7530 Tractor
Transmission (Part 3)

Page 143 of 160


Ref #	Part Number	Qty	S/P/F	Description
1	MA-19571217000	1		Shaft
2	MA-07500062050	1		Bearing,Ball
3	MA-07510660070	1		Bearing,Ball
4	MA-07410106201	2		C-Ring
5	MA-08340062100	1		Cap,Seal
	MA-10211318000	A/R		Liner Set Includes 6-8
6	MA-07300006202	A/R		Liner
7	MA-07300006206	A/R		Liner
8	MA-07300106210	A/R		Liner
9	MA-07802253117	1		Bearing,Needle
10	MA-19571296000	1		Gear 34T
11	MA-07802303517	1		Bearing,Needle
12	MA-19561208000	1		Hub,Synchronize
13	MA-19561209000	1		Sleeve,Synchronize
14	MA-19561215000	2		Ring,Synchroniz
15	MA-19561216000	3		Key,Synchronize
16	MA-19561217000	2		Spring,Synchronize
17	MA-10441235000	1		Liner
18	MA-10441228001	1		Gear 25T
19	MA-10441229000	1		Gear 20T
20	MA-07400104501	1		C-Ring
21	MA-19561227000	1		Gear 16T
22	MA-07400103000	1	S	C-Ring
23	MA-10441239000	1		Collar
24	MA-11351304011	2	S	Liner,Thrust
25	MA-07400102500	1	S	C-Ring
26	MA-10441241000	1		Shaft,Main
27	MA-07500063040	1		Bearing,Ball
28	MA-10351289001	2		Hub
29	MA-10441209000	2		Sleeve
30	MA-10441244000	1		Gear 19T
31	MA-10441247000	1		Gear 24T
32	MA-10441248000	1		Gear 29T
33	MA-19561229000	1		Gear 33T
34	MA-07802253117	1		Bearing,Needle
35	MA-07802303517	2		Bearing,Needle
36	MA-07802323920	1		Bearing,Needle
37	MA-11741299000	1		Spacer
38	MA-07410105201	2	S	C-Ring
	MA-19071547000	A/R		Liner Set Includes 39,40
39	MA-07300005202	A/R		Liner
40	MA-07300005206	A/R		Liner
41	MA-19571233000	1		Joint
42	MA-10441252000	1		Retainer
43	MA-07500062070	1		Bearing,Ball
44	MA-10441232000	1		Gear 30T
45	MA-19561297000	1		Gear 33T
46	MA-08340052100	1		Cap,Seal



7530 Tractor
Transmission (Part 4)

Page 145 of 160


Ref #	Part Number	Qty	S/P/F	Description
1	MA-07500063050	1		Bearing,Ball
2	MA-19571236000	1		Shaft,Sub
3	MA-07500063040	1		Bearing,Ball
4	MA-19571231000	1		Gear 28-33T
5	MA-07802303720	1		Bearing,Needle
6	MA-10411291000	1		Collar
7	MA-10301328000	1		Liner
8	MA-10441259001	1		Collar
9	MA-19571237000	1		Gear 34-19T
10	MA-07700030304	1		Bearing,Taper
11	MA-19571298000	1		Bearing,Taper
12	MA-07410105201	1	S	C-Ring
13	MA-10441226001	1		Nut
	MA-10212158000	A/R		Liner Set Includes 14-17
14	MA-07310002501	A/R		Liner
15	MA-07310002502	A/R		Liner
16	MA-07310002504	A/R		Liner
17	MA-07310002508	A/R		Liner
18	MA-19571242000	1		Gear 25T
19	MA-07400102500	2	S	C-Ring
20	MA-19571272000	1		Shaft,4WD
21	MA-19571274000	1		Gear 35T
22	MA-08000000800	2		Ball
23	MA-10351293000	1		Spring
24	MA-07500060040	1		Bearing,Ball
25	MA-07410104201	1	S	C-Ring
26	MA-07500063050	1		Bearing,Ball
27	MA-07972020100	1		Bushing
28	MA-07400104201	1	S	C-Ring
29	MA-08401020328	1		Seal,Oil
30	MA-19571238000	1		Gear 14T
31	MA-19571239000	1		Gear 28T
	MA-10211318000	A/R		Liner Set Includes 32-34
32	MA-07300006202	A/R		Liner
33	MA-07300006206	A/R		Liner
34	MA-07300106201	A/R		Liner



7530 Tractor
Transmission (Part 5)

Page 147 of 160


Ref #	Part Number	Qty	S/P/F	Description
1	MA-19571216000	1		Boss,Spline
2	MA-10311363001	1		Ring
3	MA-19571247000	1		Shaft,PTO Drive
4	MA-07500063045	1		Bearing,Ball
5	MA-07520663050	1		Bearing,Ball
	MA-19571261000	A/R		Liner Set Includes 6-9
6	MA-07310002001	A/R		Liner
7	MA-07310002002	A/R		Liner
8	MA-07310002004	A/R		Liner
9	MA-07310102010	A/R		Liner
10	MA-07500062060	1		Bearing,Ball
11	MA-10251405000	1		Bushing
12	MA-08300100300	1		O-Ring
13	MA-10211314000	1		Seal,Oil
14	MA-07410106201	2		C-Ring
15	MA-19571252000	1		Gear 44T
16	MA-10411237000	2		Liner
17	MA-35596104100	1		Sleeve
18	MA-07802354220	1		Bearing,Needle
19	MA-07400103000	1	S	C-Ring
20	MA-19571249000	1		Gear 46T
	MA-10190625000	A/R	/P	Liner Set Includes 21-25
21	MA-07310003001	A/R		Liner
22	MA-07310003002	A/R		Liner
23	MA-07310003004	A/R		Liner
24	MA-07310003008	A/R		Liner
25	MA-07310103010	A/R		Liner
26	MA-07400102500	1	S	C-Ring
27	MA-19571248000	1		Gear 19T
28	MA-19571254000	1		Shaft,PTO
29	MA-07500063045	1		Bearing,Ball
30	MA-19571257000	1		Gear 33T
31	MA-07520663050	1		Bearing,Ball
32	MA-07410106201	1		C-Ring
33	MA-19571253000	1		Collar



7530 Tractor
Transmission (Part 6)

Page 149 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-05401006012	2		Pin,Dowel
2	MA-A0540112060	4		Bolt 7T
3	MA-A3600101202	4		Washer, Spring
4	MA-08300500630	2		O-Ring
5	MA-19571302AG0	1		Case, Center
6	MA-19571304AG0	1		Case, HST
7	MA-F1540112040	8		Bolt, w/Washer
8	MA-05401010020	2		Pin, Dowel
9	MA-08301100140	1		O-Ring
10	MA-F1540112035	8		Bolt, w/Washer
11	MA-05401010020	2		Pin, Dowel
12	MA-A0540110065	7		Bolt 7T
13	MA-A0630110060	7		Stud
14	MA-A3600101002	14	/P	Washer, Spring
15	MA-05401010025	4		Pin, Dowel
16	MA-A3010110002	7		Nut
17	MA-19571306AG0	1	S	Holder, Bearing
18	MA-19571203AG0	1	S	Housing, Diff
19	MA-19571205AG0	1		Cover, PTO
20	MA-F1540110050	10		Bolt, w/Washer
21	MA-05401010020	2		Pin, Dowel
22	MA-10311382000	1		Cap, PTO
23	MA-A1400600812	2		Bolt, Wing
24	MA-19571307AG0	1		Cover
25	MA-F1540108025	5		Bolt, w/Washer
26	MA-10250808000	3		Plug
27	MA-08331001200	3		Washer, Seal
28	MA-67472-10601	1		Plug, Oil
29	MA-08300100280	1		O-Ring
30	MA-19641319000	1		Gage, Oil
31	MA-F1540112045	2		Bolt, w/Washer




7530 Tractor
Transmission (Part 7)

Page 151 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-19571311000	1		Gear 40T
2	MA-19571312000	1		Boss,Spline
3	MA-07500060060	2		Bearing,Ball
4	MA-07410105501	1		C-Ring
5	MA-19571314000	1		Gear 32-25T
6	MA-07500060050	2		Bearing,Ball
7	MA-19571345000	1		Shaft
8	MA-08401020358	1		Seal,Oil
9	MA-07400102000	1		C-Ring
10	MA-07500062040	1		Bearing,Ball
11	MA-07410104701	1	S	C-Ring
12	MA-19571315000	1		Collar
13	MA-19571347000	1		Gear 31T
14	MA-08000000800	1		Ball
15	MA-10351293000	1		Spring
16	MA-07500060040	2		Bearing,Ball
17	MA-07400102000	1		C-Ring
18	MA-19571317000	1		Shaft
19	MA-19571318000	1		Gear 36T
20	MA-19571316000	1		Collar
21	MA-19611314000	1		Liner
22	MA-10411316000	1		Collar
23	MA-07802404820	1		Bearing,Needle
24	MA-19571319000	1		Gear 35-30T
25	MA-10391258000	1		Liner
26	MA-07500062070	1		Bearing,Ball
27	MA-07500062060	1		Bearing,Ball
28	MA-19571321000	1		Shaft,Sub
29	MA-19571322000	1		Gear 18T
30	MA-10441298001	1		Collar
31	MA-19571324000	1		Gear 25-34T
32	MA-07500063040	1		Bearing,Ball
33	MA-10441226001	1		Nut
34	MA-19571331000	1		Gear 22T
35	MA-07700030304	1		Bearing,Taper
36	MA-19571334000	1		Collar
37	MA-19571335000	1		Gear 30T
38	MA-07520662040	1		Bearing,Ball
39	MA-07410104701	1	S	C-Ring
40	MA-19571332000	1		Gear 23T
41	MA-19571333000	1		Gear 14T
42	MA-07400104201	1	S	C-Ring
43	MA-07700032205	1	S	Bearing,Taper
44	MA-07410105201	1	S	C-Ring
	MA-10212158000	A/R		Liner Set Includes 45-48
45	MA-07310002501	A/R		Liner
46	MA-07310002502	A/R		Liner
47	MA-07310002504	A/R		Liner
48	MA-07310002508	A/R		Liner

7530 Tractor
Transmission (Part 8)

Page 152 of 160



7530 Tractor
Transmission (Part 8)


Page 153 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-19561551AG1	1		Axle Case L.H
2	MA-19561552AG1	1		Axle Case R.H
3	MA-05401010020	4		Pin,Dowel
4	MA-F1540110040	12		Bolt,w/Washer
5	MA-F1540112045	4		Bolt,w/Washer
6	MA-A3600101002	6	/P	Washer, Spring
7	MA-A0540110060	2		Bolt 7T
8	MA-19571576AG0	2	S	Bracket
9	MA-F1540110030	8		Bolt,w/Washer
10	MA-19571565000	2		Gear 95T
11	MA-19561568AG1	2		Shaft,Axle
	MA-19071547000	A/R		Liner Set Includes 12,13
12	MA-07300005202	A/R		Liner
13	MA-07300005206	A/R		Liner
14	MA-10381515000	2		Seal,Oil
15	MA-07500062100	2		Bearing,Ball
16	MA-07500063080	2		Bearing,Ball
17	MA-19561571001	2		Collar
18	MA-07400104801	2	S	C-Ring
19	MA-19561554AG0	2		Cover,Axle
20	MA-05401010020	4		Pin,Dowel
21	MA-F1540110040	18		Bolt,w/Washer
22	MA-F1540110045	6		Bolt,w/Washer
23	MA-10221733000	2		Bolt
24	MA-08331001000	2	/P	Washer, Seal
25	MA-F1540112035	4		Bolt,w/Washer
	MA-10441556000	1		Brake Assy L.H Includes 26-35
26	MA-10441556100	1		Plate LH,Cam
27	MA-10391501200	2		Plate
28	MA-10381501300	3		Plate,Disk
29	MA-10441556400	1		Cam
30	MA-08300100160	1	/P	O-Ring
31	MA-10321501400	3		Ball
32	MA-10321501500	2		Spring
33	MA-10441556900	1		Ring
34	MA-10441556800	2		Pin
35	MA-10441509AG0	1		Arm,Brake
	MA-10441557000	1		Brake Assy R.H Includes 36-45
36	MA-10441557100	1		Plate RH,Cam
37	MA-10391501200	2		Plate
38	MA-10381501300	3		Plate,Disk
39	MA-10441556400	1		Cam
40	MA-08300100160	1	/P	O-Ring
41	MA-10321501400	3		Ball
42	MA-10321501500	2		Spring
43	MA-10441556900	1		Ring
44	MA-10441556800	2		Pin
45	MA-10441509AG0	1		Arm,Brake
46	MA-19571561000	1		Shaft Diff L.H
47	MA-19571562000	1		Shaft Diff R.H
48	MA-07520663050	2		Bearing,Ball
49	MA-07520662060	2		Bearing,Ball
50	MA-10441558000	2		Holder

7530 Tractor
Transmission (Part 8)

Page 154 of 160


Ref #	Part Number	Qty	S/P/F	Description
51	MA-10441517000	2		Ring
52	MA-07400103000	1	S	C-Ring
53	MA-F1440106025	2		Bolt,w/Washer
54	MA-A0540110120	4		Bolt 7T



7530 Tractor
Transmission (Part 9)

Page 156 of 160


Ref #	Part Number	Qty	S/P/F	Description
1	MA-19571602AG0	1		Cover
2	MA-F1540112035	2		Bolt,w/Washer
3	MA-08300201100	1		O-Ring



7530 Tractor
Turbocharger

Page 158 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-F4010-12015	1		Hose,Rubber
2	MA-30H33-10200	1		Pipe Assy,Oil
3	MA-30H33-00400	1		Pipe,Oil Return
4	MA-34336-04100	1		Gasket,Oil Pipe
5	MA-49172-17300	1		Gasket,Turbo
6	MA-49173-04410	1		Turbocharger
7	MA-30A30-01600	1		Hose,Air
8	MA-MD041209	3	S	Nut
9	MA-MD041192	3		Washer,Plain
10	MA-MF241224	3		Bolt,w/Washer
11	MA-MF650102	2		Bolt,Eye
12	MA-MF660063	4	S	Gasket
13	MA-05317-50221	2		Clamp,Hose
14	MA-05317-50401	2		Clamp,Hose
15	MA-32B32-00901	1	S	Spacer
16	MA-F1825-10040	1		Bolt,w/Washer
17	MA-MD041236	4		Stud
18	MA-MM436867	8		Nut
19	MA-49172-17200	1		Gasket
20	MA-30H30-03400	1		Pipe,Air Heat
21		0		Turbocharger Not used on this model.
22		0		Stud Not used on this model.



7530 Tractor
Valves & Timing

Page 160 of 160

Ref #	Part Number	Qty	S/P/F	Description
1	MA-MM435527	1		Shaft Assy,Rocker
2	MA-K7231220	6		Screw,Adjusting
3	MA-MD000963	2		Spring,Rocker
4	MA-MF241225	2		Bolt,w/Washer
5	MA-MF430726	6	S	Nut,Jam
6	MA-MF522010	2	S	Ring,Snap
7	MA-MM413043	3		Stay,Rocker
8	MA-MM406732	6		Arm,Rocker
9	MA-MM406745	2		Washer
10	MA-MM433510	6		Cap,Valve
11	MA-30H04-14100	3		Valve,Intake
12	MA-30H04-04600	3	/P	Valve,Exhaust
13	MA-MM432350	6		Spring,Valve
14	MA-MD008761	6		Retainer,Valve
15	MA-MD008760	12		Lock,Valve
16	MA-MM413060	6		Seal,Valve
17	MA-MM402737	6	S	Tappet
18	MA-K7331230	6		Rod,Push
19	MA-MF241293	2		Bolt,w/Washer
20	MA-MF244891	1		Bolt,w/Washer
21	MA-30H23-00300	1		Gear,Camshaft
22	MA-MF476215	1		Key
23	MA-30H05-00300	1		Camshaft
24	MA-30405-31403	1		Plate,Thrust
25	MA-MF240051	2		Bolt,w/Washer
26	MA-30H65-08800	1		Shaft,Fuel
27	MA-MD000425	1	S	Washer
28	MA-30H65-08200	1		Gear,Injection
29	MA-MM40666101	1		Gear Assy,Idler
30	MA-MD703856	1		Bearing
31	MA-MF241251	1		Bolt,w/Washer
32	MA-MF476018	1		Key
33	MA-30A26-00500	1		Gear,Pressure Oil Pump
34	MA-30A26-00200	1		Bearing,Ball
35	MA-MD712517	1		Bearing