





i1050 Tractor 2007 & Before
Air Filter Intake Manifold

Page 2 of 48


Ref #	Part Number	Qty	S/P/F	Description
1	KH-24-164-51-S	1	S	Manifold, Intake
2	KH-24-041-52-S	1	/P	Gasket, Carburetor
3	KH-24-153-27-S	1	/P	O-Ring, Intake Port
4	KH-32-094-04-S	1	/P	Base, Air Cleaner w/Gasket, Latch
5	KH-24-041-14	1	/P	Gasket, Air Cleaner Base
6	KH-32-344-02-S	1		Latch, Air Cleaner Element
7	KH-32-083-03-S	1	S	Element, Air Filter
8	KH-X-25-63	1	/P	Washer, Flat, 1/4
9	KH-M-651040-S	1		Screw, Flange, M6 x 1.0 x 40
10	KH-32-083-05-S	1	S	Pre-Cleaner, Element



i1050 Tractor 2007 & Before
Blower Housing Baffles

Page 4 of 48

Ref #	Part Number	Qty	S/P/F	Description
1	KH-32-027-03-S	1		Kit, Blower Hsng (Incl. Ref.2 & KH-41-037-10-S)
2	KH-32-096-08-S	1		Cover, Air Cleaner
3	KH-M-545016-S	1	/P	Screw, Flnge Thrd. Frmng M5 x 0.8x 16
4	KH-M-645016-S	1	/P	Screw, Flnge Thrd. Frmng M6 x 1.0 x 16
5	KH-32-146-05-S	1		Plate, Backing
6	KH-32-063-05-S	1		Baffle, Cyl. Barrel - #2 Side
7	KH-M-545010	1	S	Screw, Flnge Thrd. Frmng M5 x 0.8x 10
8	KH-32-063-02-S	1		Baffle, Valley #2 Side
9	KH-32-063-03-S	1		Baffle, Valley #1 Side
10	KH-32-063-06-S	1		Baffle, Cylinder Barrel - #1 Side
11	KH-24-086-12	1		Screw, Tap, M6 x 1.7 x 18
	KH-41-037-10-S	1		Nameplate, Service Not Illustrated
	KH-32-113-20-S	1		Decal, Cub Not Illustrated



i1050 Tractor 2007 & Before
Crankcase Crankshaft & Dipstick


Page 6 of 48

Ref #	Part Number	Qty	S/P/F	Description
1	KH-32-038-01-S	1	S	Dipstick Assembly (Incl. Ref.2)
2	KH-25-153-02-S	1		O-Ring, Dipstick
3	KH-M-545013-S	1		Screw, Flnge Thrd. Frmng M5 x .8 x 13
4	KH-12-123-04	1	S	Kit, Oil Fill Tube (Incl. Ref. 5,6)
5	KH-12-153-02-S	1	/P	O-ring, Upper Fill Tube
6	KH-12-153-01-S	1	/P	O-ring, Lower Fill Tube
7	KH-24-126-19	1		Bracket, Fill Tube
8	KH-24-032-01-S	1	S	Seal, Oil
9	N/A	1		Crankcase - Use Short Block
9	KH-32-522-03	1		Short Block
10	KH-24-018-04	1		Retainer, Breather Reed
11	KH-12-402-02	1		Reed, Breather
12	KH-24-380-16-S	1	/P	Pin, Locating
13	KH-24-067-24-S	1	S	Connecting Rod (Std.)
14	KH-32-874-06-S	1		Kit, Piston w/Ring Set (Std.)
14	KH-32-874-28-S	1		Kit, Piston w/Ring Set (.25)
14	KH-32-874-09-S	1		Kit, Piston w/Ring Set (.08)
15	KH-24-018-01-S	1	/P	Retainer, Piston Pin
16	KH-24-108-11-S	1	S	Ring Set (Std. & .08)
16	KH-24-108-06-S	1	S	Ring Set (.25)
17	KH-12-422-07-S	1	/P	Shim, Camshaft (White .028)
17	KH-12-422-08-S	1	/P	Shim, Camshaft (Blue .03)
17	KH-12-422-09-S	1	/P	Shim, Camshaft (Red .032)
17	KH-12-422-10-S	1	/P	Shim, Camshaft (Yellow .034)
17	KH-12-422-11-S	1	/P	Shim, Camshaft (Green .036)
17	KH-12-422-12-S	1	/P	Shim, Camshaft (Gray .038)
17	KH-12-422-13-S	1	/P	Shim, Camshaft (Black .04)
18	KH-32-012-01-S	1		Kit, Camshaft
19	KH-28-032-09-S	1		Seal, Governor Cross Shaft
20	KH-24-018-09-S	1		Retaining Ring
21	KH-M-931010-S	1		Washer, Flat, 9mm
22	KH-24-468-15-S	1		Washer, Flat, 11/32
23	KH-24-144-38-S	1	/P	Shaft, Governor Cross
24	KH-32-014-04-S	1	S	Crankshaft (Incl. Ref. 25)
25	KH-52-139-09-S	1	/P	Plug, Cup
	KH-SV710-0019	1		Engine, Complete Twin Not Shown i1046 2008 & Before
	KH-SV730-0011	1		Engine, Complete 25 HP Not Shown i1050


i1050 Tractor 2007 & Before
Cylinder Head Valve Breather

Page 8 of 48


Ref #	Part Number	Qty	S/P/F	Description
1	KH-24-755-141-S	1	/P	Kit, Rocker Cover Incl. Ref.2 & 4pc Ref. 3
2	KH-24-153-28-S	1	S	O-Ring, Valve Cover
3	KH-M-651030-S	1		Screw, Flnge M6 x 1.0 x 30
4	KH-32-318-01-S	1	S	Kit, #1 Cylinder Head Incl. 4pc Ref. 26 and KH-24-841-03-S
5	KH-12-755-03	1	/P	Kit, Retainer
6	KH-12-173-01	1	/P	Cap, Valve Spring
7	KH-24-089-02	1	/P	Spring, Valve
8	KH-235011-S	1	/P	Retainer, Spring
9	KH-66-032-05-S	1	/P	Seal, Valve Stem
10	KH-24-017-01	1	/P	Valve, Intake (Std.)
11	KH-24-016-01	1	/P	Valve, Exhaust (Std.)
12	KH-32-326-04-S	1		Kit, Breather Hose, (Incl. 1pc Ref. 13)
13	KH-25-237-14-S	1	/P	Clamp, Hose
14	KH-32-081-02-S	1		Kit, Breather Housing (Incl. 15,16)
15	KH-M-547050-S	1		Nut, Lock, M5 x 0.8
16	KH-32-468-01-S	1		Washer, Sealing
17	KH-32-072-02-S	1		Stud, Breather Cover
18	KH-32-019-01-S	1	S	Kit, Tappet
19	KH-32-411-02-S	1	/P	Rod, Push Serial No. 3633510943 & Before
19	KH-32-411-04-S	1	/P	Rod, Push Serial No. 3633510943 & After
20	KH-24-841-03-S	1	/P	Kit, Cylinder Head Gasket Incl. Head Mtg.Hardware and KH-24-041-49-S and KH-24-153-27-S
21	KH-32-318-02-S	1	S	Kit, #2 Cylindre Head Incl. 4pc Ref. 26 and KH-24-841-03-S
22	KH-32-186-02-S	1	S	Arm, Rocker
23	KH-32-100-04-S	1		Nut, M10 x 0.75
24	KH-32-086-03-S	1		Screw, Set
25	KH-24-599-02-S	1	/P	Pivot, Rocker Arm
26	KH-12-086-16	1	S	Screw, Flange, M10 x 1.5 x 90
27	KH-32-086-04-S	1	/P	Screw, Flange, M6 x 1.0 x 45
28	KH-32-096-06-S	1		Kit, Breather Valve Cover (Incl. 1pc Ref.2)
29	KH-24-445-01	1	S	Strap, Lifting
30	KH-M-645016-S	1	/P	Screw, Flnge Thrd. Frmng M6 x 1.0 x 16
31	KH-32-096-04-S	1		Kit, Breather Cover (Incl. Ref. 32)
32	KH-32-041-01-S	1		Gasket, Breather Cover
33	KH-32-050-01-S	1		Filter, Breather
	KH-24-041-49-S	1	/P	Gasket, Exhaust Not Illustrated
	KH-24-153-27-S	1	/P	O-Ring Not Illustrated



Ref #	Part Number	Qty	S/P/F	Description
1	KH-24-211-03-S	1		Bolt, Carriage, M6 X 1.0 X 25
2	KH-24-090-33-S	1	S	Lever, Governor
3	KH-M-641060-S	1	/P	Nut, Flange, M6 x 1.0
4	KH-24-089-01	1		Spring, Linkage
5	KH-25-158-08	1	/P	Bushing, Linkage Retainer
6	KH-24-079-04	1		Linkage, Throttle
7	KH-25-158-11	1	/P	Bushing, Throttle Linkage
8	KH-M-545016-S	1	/P	Screw, Flng. Thrd. Frmng, M5 x 0.8 x 16
9	KH-M-547050-S	1		Nut, Lock, M5 x 0.8
10	KH-24-089-03	1		Spring, Choke Return
11	KH-24-126-161-S	1	S	Bracket, Control
12	KH-M-645016-S	1	/P	Screw, Flng Thrd. Frmng M6 x 1.0 x 16
13	KH-47-237-02	1	S	Clamp, Dual Conduit
14	KH-24-086-43-S	1		Screw, Torx Hd. Ctsk, M5 x 0.8 x 16
15	KH-24-079-22-S	1		Linkage, Choke
16	KH-24-112-27-S	1		Spacer, Control Assembly
17	KH-24-090-47-S	1		Lever, Throttle Actuator
18	KH-24-090-13	1		Lever, Throttle Control
19	KH-24-468-01	1		Washer, Flat, 5.5mm
20	KH-M-545020-S	1		Screw, Flng. Thrd. Frmng, M5 x 0.8 x 20
21	KH-41-468-03	1		Washer, Spring, 1/4
22	KH-24-090-05	1		Lever, Choke
23	KH-M-403025	1		Screw, Hex Cap, M4 x 0.7 x 25
24	KH-M-446030-S	1	/P	Nut, M4 x 0.7
25	KH-24-468-20-S	1		Washer, Flat, 5mm
26	KH-24-089-55-S	1		Spring, Governor
27	KH-24-089-18	1	/P	Spring, Governor, Model i1046 ONLY
27	KH-24-089-25-S	1	/P	Spring, Governor, Model i1050 ONLY




Ref #	Part Number	Qty	S/P/F	Description
1	683-04256	1	S	Shield, Muffler
2	710-0227	1	/P	Screw, Hex Wash Hd. Tapp, #8-18 x .5
3	710-0599	1	/P	Screw, Hex Wash Hd. Tapp, 1/4-20 x .5
4	710-0642	1	/P	Screw, Hex Wash Hd. Tapp, 1/4-20 x .75
5	710-0654A	1	/P	Screw, Hex Sems Tapp, 3/8-16 x 1.0
6	712-3005	1	S	Nut, Hex Flange Lock, 3/8-16 Gr5
7	725-0157	1	/P	Tie, Cable
8	726-0154	1	S	Tie, Push Mount Cable
9	726-0205	1	/P	Clamp, Hose
10	728-04000	1		Rivet, Pop, .188 x .3
11	736-0300	1	S	Washer, Flat, .406 x .875 x .059
12	751-0564B	1	/P	Deflector, Muffler
13	751-10006	1		Pipe, Exhaust RH
14	751-10007	1		Pipe Exhaust LH
15	751-10161	1		Muffler, Dual Inlet
16	751-10349	1		Hose, Fuel ; Low Permeation, 51 inches
17	751-10353	1		Deflector, Muffler
18	751-10517	1	S	Oil Drain
19	751-3141	1	S	Hose, Oil Drain Extension
21	783-04783A	1	/P	Shield, Heat
22	783-04870	1	S	Bracket, Muffler LH
23	783-04872	1	S	Bracket, Muffler RH
	737-3030A	1	/P	Oil, 10W30 Engine not shown



i1050 Tractor 2007 & Before
Flywheel Electrical

Page 14 of 48


Ref #	Part Number	Qty	S/P/F	Description
1	KH-32-162-03-S	1		Screen, Grass
2	KH-12-086-14	1		Screw, Flange, M10 x 1.5 x 45
3	KH-12-468-03	1	/P	Washer, Flat 13/32
4	KH-20-146-02-S	1	S	Plate, Fan Mounting
5	KH-32-157-01-S	1		Fan
6	KH-32-025-08-S	1	S	Flywheel
7	KH-X-42-15	1	/P	Key, 3/16 x 5/8
8	KH-236602-S	1	S	Connector (3 Contact)
9	KH-M-551016-S	1		Screw, Flange, M5 x 0.8 x 16
10	KH-41-403-09	1	S	Rectifier-Regulator
11	KH-237878	1	/P	Kit, 15 Amp Stator
12	KH-235173	1		Clip, Cable
13	KH-M-548025-S	1	/P	Screw, Thrd. Frmng M5 x 0.8x 25
14	759-3336	1	/P	Plug, Spark
15	KH-24-584-45-S	1	/P	Module, Ignition
16	KH-M-545020-S	1		Screw, Flnge Thrd. Frmng M5 x 0.8x 20
	KH-25-454-03-S	1		Tie, Wire Not Illustrated
	KH-32-176-02-S	1	S	Harness, Wiring Not Illustrated



i1050 Tractor 2007 & Before
Frame PTO & Battery

Page 16 of 48


Ref #	Part Number	Qty	S/P/F	Description
1	683-04305A	1	S	Frame Assembly
2	683-04333	1	S	Frame Assembly, Seat
3	683-04351	1	S	Bracket, Running Board Support
4	710-0451	1	/P	Screw, Carriage, 5/16-18 x .75 Gr.1
5	710-0599	1	/P	Screw, Hex Wash. Hd. Tapp, 1/4-20 x .5
7	710-0726	1	/P	Screw, Hex Wash. Hd. Tapp, 5/16-12 x .75
8	710-0642	1	/P	Screw, Hex Wash. Hd. Tapp, 1/4-20 x .75
9	710-04379A	1		Screw, Hex Cap Lock, 7/16-20 x 3.5 Gr5
10	710-04484	1		Screw, TT, 5/16-18 x .75
11	710-3005	1	/P	Screw, Hex Cap, 3/8-16 x 1.25 Gr5
12	712-0271	1	/P	Nut, Hex Sems, 1/4-20
13	712-3087	1	/P	Nut, Wing, 1/4-20
14	712-04063	1	/P	Nut, Hex Flange Insert Lock, 5/16-18
15	712-04064	1	/P	Nut, Hex Flange Insert Lock, 1/4-20 GrF
16	712-04065	1	/P	Nut, Hex Flange Insert Lock, 3/8-16 GrF
17	717-04174A	1	S	Clutch, Electric PTO
18	725-04439	1		Solenoid, Start
19	731-05659	1		Bushing, Steering Shaft
20	736-0171	1	S	Washer, Lock, 7/16
21	736-0222	1	S	Washer, External Lock, 1/4
22	738-0143	1	/P	Bolt, Shoulder, .496 x .336:3/8-16
23	738-1132	1		Screw, Shoulder, .25 x .15:1/4-20
24	738-04058	1		Screw, Shoulder, .38 x 1.0 x .7
25	747-04215	1	S	Strap, Battery
26	750-04763	1		Spacer, 1.37 x 1.00 x .25
27	756-0978B	1	/P	Pulley, Engine
28	783-1447C	1		Bracket, Battery Support
29	783-04419B	1	S	Bracket, Clutch
30	783-04467	1		Bracket, Deck Up Stop
31	783-04806	1		Bracket, Pivot Bar
32	783-04844	1		Bracket, Pivot Support RH
33	783-04845	1		Bracket, Pivot Support LH
34	783-04868	1	S	Bracket, Steering Support
35	783-04910A	1	S	Bracket, Support Fender
36	925-1707D	1	/P	Battery - Dry
37	725-04513	1		Wire, Ground Jumper
38	725-0157	1	/P	Cable Tie
	725-04375A	1	S	Harness, Main Wire not shown



i1050 Tractor 2007 & Before
Fuel System Carburetor

Page 18 of 48

Ref #	Part Number	Qty	S/P/F	Description
1	KH-32-853-03-S	1	S	Kit, Carburetor (Incl. 2-3) Model i1046 ONLY
1	KH-32-853-04-S	1	S	Kit, Carburetor (Incl. 2-3) Model i1050 ONLY
2	KH- 24-041-52-S	1		Gasket, Carburetor
3	KH-24-041-14	1	/P	Gasket, Air Cleaner Base
4	KH-M-629105-S	1		Stud, M6 x 1.0 x 106
5	KH-M-641060-S	1	/P	Nut, Flange, M6 x 1.0
6	KH-25-237-14-S	1	/P	Clamp, Spring Hose 1/2
7	KH-25-111-34-S	1		Line, Fuel (24"- Cut to Length
8	KH-25-431-10-S	1		Sleeve, Anti Abrasion
9	KH-32-326-02-S	1	S	Kit, Fuel Pump Hose w/Clamp (Incl. 10)
10	KH-25-237-01-S	1		Clamp, Hose
11	KH-24-086-12	1		Screw, Tap, M6 x 1.7 x 18
12	KH-24-393-16	1	/P	Pump, Fuel
13	KH-25-050-22-S1	1	/P	Filter, Fuel
14	KH-47-154-01-S	1	/P	Clip, Cable
	KH-24-086-05	1		Screw, Throttle Stop - Model i1046 ONLY Not Illustrated
	KH-X-25-63	1	/P	Washer, Flat, 1/4 Not Illustrated
	KH-24-757-36-S	1		Service Kit, Choke Repair Not Illustrated
	KH-24-757-38-S	1		Service Kit, Gasket Not Illustrated
	KH-24-757-44-S	1		Kit, Float Repair Not Illustrated
	KH-24-757-45-S	1	/P	Kit, Solenoid Valve Repair Not Illustrated



i1050 Tractor 2007 & Before
Hood Dash Panel & Fuel Tank

Page 20 of 48

Ref #	Part Number	Qty	S/P/F	Description
1	683-04219A	1	S	Bumper Assembly
2	710-0192	1	/P	Screw, Truss Hd. Mach., 10-24 x .375
3	710-0599	1	/P	Screw, Hex Wash Hd. Tapp, 1/4-20 x .5
4	710-0604A	1	/P	Screw, Hex Wash Hd. Tapp, 5/16-18 x .625
5	710-0607	1	/P	Screw, Hex Wash Hd. Tapp, 5/16-18 x .5
6	710-0642	1	/P	Screw, Hex Wash Hd. Tapp, 1/4-20 x .75
7	710-0726	1	/P	Screw, Hex Wash Hd. Tapp, 5/16-12 x .75
8	710-0895	1		Screw, Hex Wash Hd. Tapp, 1/4-15 x .75
9	710-1611B	1	/P	Screw, Pan Hd. Tapp, 5/16-18 x .75
10	710-3217	1	/P	Screw, Truss Hd. Mach., #8-32 x .375
11	712-0142	1	/P	Nut, Hex, 8-32
12	712-04065	1	/P	Nut, Hex Flange Insert Lock, 3/8-16 GrF
13	725-0157	1	/P	Tie, Cable
14	725-0963	1	S	Bulb, 12V Light
15	725-1649	1	S	Receptacle, Light
16	725-2003	1		Receptacle, 12V Power
17	725-2054	1	S	Key, Ignition Switch
18	725-04022B	1	S	Meter, Indicator/Service Monitor
19	725-04258	1	/P	Switch, PTO
20	725-04227	1	S	Switch, Ignition/Module
21	726-3046	1	/P	Clip, Ratchet
22	731-04213	1		Lever, Dash Brake
23	731-05368	1		Cap, Bumper
24	731-05406	1		Panel, Dash
25	731-05434	1		Hood
26	731-05435	1		Plenum, Hood
27	731-05525	1		Lense, Head Light LH
28	731-05526	1		Lense, Head Light RH
29	731-3161A	1	S	Knob, Throttle Control
30	735-0271A	1	/P	Bumper
31	735-04075	1		Deflector, Rubber Hood
32	735-04076	1		Net, Storage
33	736-0463	1	S	Washer, Flat, .25 x .63 x .0515
34	738-0143	1	/P	Bolt, Shoulder, .496 x .336:3/8-16
35	738-04091	1	S	Screw, Shoulder, .43 x .29:TT5/16-18
36	746-1100	1	S	Cable, Throttle Control
37	746-04120	1		Cable, Choke Control
38	747-1155	1		Rod, Brake Lock Pivot
39	777X42426	1		Label, Reflector
40	777X42427	1		Label, Reflector
41	783-04285D	1	S	Support, Dash, R.H.
42	783-04323D	1		Support, Dash, L.H.
43	783-04506A	1	S	Plate, Dash Support
44	783-04606B	1		Bracket, Hood Pivot
45	783-04840	1		Bracket, Hood Pivot RH
46	783-04841	1		Bracket, Hood Pivot LH
47	783-05162	1	S	Bracket, Hood Support
48	651-04174	1	/P	Tank Assembly, Fuel
49	735-0149	1	S	Bushing, Fuel Tank
50	735-04081	1		Grommet, Rubber
51	751-10441	1		Valve, Rollover
52	751-10442	1		Fitting, Fuel Pick Up
53	751-10447	1		Cap, Fuel Tank

i1050 Tractor 2007 & Before
Label i1050

Page 21 of 48

777I22679
Top Of Engine



777I22702
On Dash Cluster



777D01782
On Rear
Hitch Plate



777D10608
Centered Over 777S32771



777S32771



For Headlight
777X42426
Right Lens

777X42427
Left Lens



(QTY 2) 777I22708
Aside Trans.
Release Rods




777D10491
On Rear Fender



777I22707
Right Of
Gas Gauge



777S32815
On Hitch Plate



777X42474
UNDER HOOD

MODEL	REPLACEMENT PARTS
777I22679	777I22679
777I22679	777I22679
777I22679	777I22679
777I22679	777I22679
777I22679	777I22679
777I22679	777I22679
777I22679	777I22679
777I22679	777I22679
777I22679	777I22679
777I22679	777I22679

(QTY2) 777D10609
Front Of Deck



Gear Top



(QTY2) 777S32807
On Both
Gear Tops



777D10501



777D10494
In Molded On Hood



(QTY2) 777D10623
On Both Sides Place
As Shown



777I22485



777S30015



777S30503



(QTY2) 777D10624
Near Each Nozzle




i1050 Tractor 2007 & Before
Label i1050

Page 22 of 48

Ref #	Part Number	Qty	S/P/F	Description
777I22679	777I22679	1		Top of Engine
777I22702	777I22702	1		On Dash Cluster
777D01782	777D01782	1	/P	On Rear Hitch Plate
777D10608	777D10608	1		Centered Over 777S32771
777S32771	777S32771	1		Warning Label
777X42426	777X42426	1		For Headlight Right Lens
777X42427	777X42427	1		For Headlight Left Lens
777D10496	777D10496	1		In Molded On Hood
777D10494	777D10494	1		In Molded On Hood
777D10623	777D10623	2		On Both Sides Place As Shown
777I22708	777I22708	1		Aside Trans. Release Rods.
777D10491	777D10491	1		On Rear Fender
777I22707	777I22707	1		Right Og Gas Guage
777S32815	777S32815	1		On Hitch Plate
777X42474	777X42474	1		Under Hood
777S32807	777S32807	2		On Both Gear Tops
777D10501	777D10501	1		Centered on Hood
777D10624	777D10624	2		Near Each Nozzle
777S30503	777S30503	1	/P	Danger on Deck
777D10609	777D10609	2		Front of Deck
777I22485	777I22485	1		On Deck
777S30015	777S30015	1		On Deck

i1050 Tractor 2007 & Before Mowing Deck 50 Inches

Page 23 of 48



i1050 Tractor 2007 & Before
Mowing Deck 50 Inches


Page 24 of 48

Ref #	Part Number	Qty	S/P/F	Description
1	16606	1	S	Bracket, Hook Retainer
2	618-04126A	1	S	Spindle Assembly
3	683-0254B	1	/P	Bracket, Deck Hanger LH
4	683-04336	1	S	Deck Assembly
5	703-3279	1		Bracket, Chute Stop
6	703-3511A	1	S	Guard, Finger
7	710-0347	1	/P	Screw, Hex Cap, 3/8-16 x 1.75 Gr5
8	710-0528	1	/P	Screw, Hex Cap, 5/16-18 x 1.25 Gr5
9	710-0599	1	/P	Screw, Hex Wash. Hd. Tapp, 1/4-20 x .5
10	710-0607	1	/P	Screw, Hex Wash. Hd. Tapp, 5/16-18 x .5
11	710-1260A	1	/P	Screw, Hex Wash. Hd. Tapp, 5/16-18 x .75
12	710-3005	1	/P	Screw, Hex Cap, 3/8-16 x 1.25 Gr5
13	710-3103	1	/P	Screw, Hex Cap, 5/16-18 x 2.0 Gr5
14	710-3168	1	/P	Screw, Carriage, 3/8-16 x 1.0
15	710-3178	1	/P	Screw, Carriage, 3/8-16 x .75
16	711-0332	1	S	Pin, Clevis, .5 x .78
17	711-1737	1		Pin, Roller, .5 x 10.06
18	712-0206	1	S	Nut, Hex, 1/2-13 Gr5
19	712-0229	1		Nut, Push, 3/8
20	712-04063	1	/P	Nut, Hex Flange Insert Lock, 5/16-18 GrF
21	712-04065	1	/P	Nut, Hex Flange Insert Lock, 3/8-16 GrF
22	712-0417A	1	/P	Nut, Hex Flange, 5/8-18
24	712-0641	1	S	Nut, Hex, M16-1.5
25	712-3010	1	S	Nut, Hex, 5/16-18 Gr5
26	712-3083	1	/P	Nut, Hex Insert Lock, 1/2013
27	714-0111	1	S	Pin, Cotter, 3/32 x 1.0
28	714-0145	1	S	Pin, Click, .092 x 1.64
29	714-0162	1	/P	Pin, Cotter, 5/32 x 1.25
30	714-0470	1	S	Pin, Cotter, 1/8-1.25
31	715-0108	1	/P	Pin, Spring, 1/4 x 1.0
32	717-04074	1	S	Gear, Deck Adjust
33	721-04041	1	S	Adapter, Water Nozzle
34	731-05679	1		Roller, Front
35	732-0306A	1	S	Spring, Compression, .531 x 1.75
36	732-0459C	1	/P	Spring, Extension, .94 x 6.74
37	734-04155	1		Wheel, Deck Ball, 5.0
38	736-0119	1	S	Washer, Lock, 5/16
39	736-0225	1	/P	Washer, Internal Tooth Lock, 5/8
40	736-0300	1	S	Washer, Flat, .406 x .875 x .059
41	737-04003C	1	S	Nozzle, Deck Wash
42	738-04162A	1	/P	Spacer, Shoulder, .884 x .190
43	738-04235	1	S	Shaft, .5 x 20.8
44	738-3056	1	S	Bolt, Shoulder, .496 x 2.5:3/8-16
45	942-04053B	1	S	Blade, 2 in 1 Star, 17.9
46	747-1116	1	/P	Rod, Deck Release
47	747-1324	1		Rod, Deck Front Hanger
48	750-0151	1	S	Spacer, .55 x .75 x 1.125
49	750-1206	1		Spacer, .542 x .75 x .5
50	754-04077	1	S	V-Belt, B Sec., 134 in.
51	756-04129	1	S	Pulley, Idler, 4.25 Dia.
52	783-04399	1		Cover, Belt, LH
53	783-04400	1		Cover, Belt, RH
54	783-04414	1	S	Skirt, Deck Center

i1050 Tractor 2007 & Before
Mowing Deck 50 Inches

Page 25 of 48

Ref #	Part Number	Qty	S/P/F	Description
55	783-04415	1		Skirt, Deck RH
56	783-05303	1	S	Bracket, Idler,
57	783-05411	1	S	Bracket, Height Adjust
58	731-04651	1		Plug, Mulch
59	736-0315	1	/P	Washer, Flat, .76 x 1.5 x .12
60	737-3000	1	S	Fitting, Lube
61	738-1010A	1	/P	Shaft, Spindle
62	741-0919	1	S	Bearing, Ball
63	750-1000	1		Spacer, .80x 1.10 x 1.322
64	750-1349	1	S	Spacer, .79 x 1.84 x .55
65	756-1171	1		Pulley, Deck
66	631-04070A	1	/P	Chute Assembly, Discharge
66	711-04565	1		Pin, Hinge, .3125 x 14.06 not shown
66	732-04372	1		Spring, Torsion, .44 x 2.1 not shown
66	783-05030	1		Bracket, Chute Mounting not shown




i1050 Tractor 2007 & Before
Oil Pan Filter

Page 27 of 48

Ref #	Part Number	Qty	S/P/F	Description
1	KH-32-199-02-S	1	S	Pan Assembly, Oil (Incl. Ref. 2-15)
2	KH-32-086-01-S	1		Screw, Flnge Thrd. Frmng M6 x 1.0 x 26.5
3	KH-32-393-10-S	1	/P	Pump Assembly, Oil
4	KH-24-043-12	1	/P	Kit, Governor Gear w/Pin (Incl. Ref. 5)
5	KH-12-380-01	1	/P	Pin, Governor Regulating
6	KH-24-448-02-S	1		Tab, Locking
7	KH-12-144-02	1		Shaft, Governor Gear
8	KH-52-032-08-S	1	S	Seal, Oil (PTO End)
9	KH-32-123-01-S	1		Tube, Oil Feed - Filter to Pan
10	KH-32-123-03-S	1		Tube, Oil Feed - Pan to Filter
11	KH-24-153-01	1	/P	O-Ring, Oil Pick-up
12	KH-32-029-07-S	1	S	Kit, Oil Filter Adapter
13	KH-25-139-60-S	1	/P	Plug, Pipe, 1/8
14	KH-32-153-04-S	1		O-Ring, Oil Filter Adapter
15	KH-32-136-03-S	1		Nipple, Oil Filter
16	KH-25-099-27-S	1	/P	Switch, Oil Pressure
17	KH-52-050-02-S	1	/P	Filter, Oil
18	KH-24-086-17-S	1	/P	Screw, Flange, M8 x 1.25 x 45
19	KH-25-139-57-S	1	/P	Plug, Sq. Hd. Pipe, 3/8 NOT USED Replaced by Oil Drain Valve



Ref #	Part Number	Qty	S/P/F	Description
	759-3336	1	/P	Spark Plug
	KH-32-883-03-S1	1	/P	Air Filter & Pre-Cleaner
	KH-52-050-02-S	1	/P	Oil Filter
	KH-25-050-22-S1	1	/P	Fuel Filter
	KH-24-584-45-S	1	/P	Ignition Module
	KH-41-403-09	1	S	Voltage Regulator
	KH-24-393-16	1	/P	Fuel Pump
	KH-24-757-46-S	1	/P	Carb Kit
	KH-24-757-45-S	1	/P	Carburetor Solenoid
	754-04134	1	S	Drive Belt (Hydro Trans)
	N/A	1		P.T.O. Belt
	754-04077	1	S	Deck Belt
	742-04053A	3	S	Blades
	712-0417A	1	/P	Blade Nut
	618-04126A	1	S	Spindle Assy. w/Pulley
	734-04155	1		Deck Wheels (Front)
	731-3005	1	/P	Roller (Front)
	731-3005	1	/P	Roller (Back) (Qty. 3)
	721-04041	1	S	Water Nozzle Adapter
	723-04035	1		Ball Joints (RH Thrd)
	723-04036	1		Ball Joints (LH Thrd)
	725-04039	1	S	Brake Switch
	751-10447	1		Fuel Cap
	725-04439	1		Solenoid
	725-2054	1	S	Ignition Key
	725-04227B	1	S	Ignition Switch Module
	725-04258	1	/P	P.T.O. Switch
	717-04174A	1	S	P.T.O. Clutch
	KH-25-357-05-S	1	S	Engine Oil
	737-3121	1	/P	Transmission Fluid
	490-900-0041	1		Deck Leveling Gauge
	490-900-0005	1	S	Grease Gun with one tube of grease Not Shown
	490-900-0006	1	S	Replacement tubes if grease (3 Pack) Not Shown



i1050 Tractor 2007 & Before
Seat Fender & Deck Lift


Page 31 of 48

Ref #	Part Number	Qty	S/P/F	Description
1	783-05515	1		Bracket, RH Seat Lift
2	647-04095A	1	S	Shaft, Lift
3	683-04313A	1	S	Seat Slide
4	710-04482	1		Screw, Hex Flange, 3/8-16 x .875 Gr5
5	710-04484	1		Screw, TT 5/16-18 x .75
6	710-0451	1	/P	Screw, Carriage, 5/16-18 x 75
7	710-0599	1	/P	Screw, Hex Wash Hd. Tapp, 1/4-20 x .5
8	710-0726	1	/P	Screw, Hex Wash Hd. Tapp, 5/16-12 x .75
9	710-0895	1		Screw, Hex Wash Hd. Tapp, 1/4-15 x .75
10	711-0332	1	S	Pin, Clevis, .5 x .78
11	711-04626	1		Pin, Seat Index
12	712-04063	1	/P	Nut, Hex Flange Insert Lock, 5/16-18 GrF
13	712-04065	1	/P	Nut, Hex Flange Insert Lock, 3/8-16 GrF
14	710-04187	1	/P	Screw, Hex Wash Hd. H/L, 1/4-15 x .5
15	714-0104	1	S	Pin, Internal Cotter
16	714-0111	1	S	Pin, Cotter, 3/32 x 1.0
17	714-04023	1	S	Pin, Internal Cotter
18	716-0106A	1		E-ring, .625 Shaft
19	720-0311	1		Grip, Handle
20	726-3046	1	/P	Clip, Ratchet
21	731-04074	1		Spacer, Seat Adjustment
22	731-05477	1		Cover, Rear Fender RH
23	731-05518	1		Cover, Rear Fender LH
24	732-04035	1		Spring, Compression
25	732-04386	1		Spring, Seat Adjust
26	732-04459	1		Spring, Lift Torsion
27	732-0826A	1	/P	Spring, Extension, .865 x 4.68
28	732-1184	1	/P	Spring, Extension, .84 x 4.6
29	735-04078	1		Pad, Foot RH
30	735-04079	1		Pad, Foot LH
31	726-0221	1	/P	Nut, Speed, .5
32	736-0272	1	S	Washer, Flat, .51 x 1.0 x .06
34	736-0192	1	S	Washer, Flat, .535 x .93 x .09
35	736-3078	1	/P	Washer, Flat, .344 x 1.0 x .063 HT
36	738-0138A	1	/P	Bolt, Shoulder, .496 x 2.5:3/8-16
37	738-0380	1	S	Bolt, Shoulder, .5 x .27:3/8-16
38	738-0966A	1	/P	Bolt, Shoulder, .5 x .925:3/8-16
39	738-1011A	1	/P	Bolt, Shoulder, .5 x 2.23:3/8-16
40	738-0296	1	S	Bolt, Shoulder, .447 x .268:5/16-18
41	741-0225	1	S	Bearing, Hex Flange,
42	746-04369	1		Cable, Lift, 16.16 Lg
43	746-0968	1		Cable, Lift, 16.16 Lg
44	747-04701	1		Handle, Lift
45	756-1154	1		Pulley, Roller
46	757-04053	1		Seat, High Back
47	783-05546	1	S	Link, Deck Lift
48	783-0720C	1	/P	Bracket, Front Deck Adjust
49	783-04901	1	S	Fender, Rear
50	783-04977A	1	S	Plate, Deck Lift
51	783-05307	1	S	Pedesta, Seat
52	783-05272A	1	S	Plate, Seat Pivot
53	710-0227	1	/P	Screw, Hex Wash Hd. Tapp, #8-18 x .5
54	726-0279	1		Plate, Insulator

i1050 Tractor 2007 & Before
Seat Fender & Deck Lift

Page 32 of 48


Ref #	Part Number	Qty	S/P/F	Description
55	725-1303	1	S	Switch, Outer Seat Spring
56	725-1439	1		Switch, Inner Seat Spring
57	726-0278	1		Plate, Insulator Boss
58	736-0326	1	S	Washer, Flat, .510 x 1 x .125



i1050 Tractor 2007 & Before
Starter Motor

Page 34 of 48

Ref #	Part Number	Qty	S/P/F	Description
1	KH-M-839080	1	S	Screw, Flange, M8 x 1.25 x 80
2	KH-32-098-01-S	1	S	Starter Assembly
3	KH-12-755-39-S	1		Kit, Drive
4	KH-12-755-38-S	1		Kit, Drive Parts (Incl. Ref. 5)
5	KH-32-141-01-S	1		Ring, Retaining Ring
6	KH-32-211-01-S	1		Bolt, Thru
7	KH-12-243-04-S	1		Commutator, End Cap




Ref #	Part Number	Qty	S/P/F	Description
1	618-04430	1	S	Steering Assembly, Steering/Hydro
1	759-04284	1		Kit, Replacment Steering Gear Box (Incl. LH & RH Cams, 1 Tube, 2 Pins & 2 Washers)
2	631-04008A	1	/P	Wheel, Steering
3	N/A	1		Wheel Assembly
3	734-1731	1		Tire, 15 x 6 x 6 Not shown
3	634-04104A	1	S	Rim Assembly Not shown
3	737-0224	1		Grease Fitting Not shown
3	941-04137	1	/P	Bearing, Ball Not shown
3	934-0255	1	/P	Valve, Tubeless Air Not shown
4	647-04062	1	S	Axle Assembly, LH
5	647-04063	1	S	Axle Assembly, RH
6	647-04080A	1	S	Rod, Fender Support
7	710-0599	1	/P	Screw, Hex Wash Hd. Tapp, 1/4-20 x .5
8	683-04282A	1		Arm, Steering, RH
8	759-04220	1		Service Kit RH
9	683-04284A	1		Arm, Steering, LH
9	759-04221	1		Service Kit LH
10	683-04332	1		Link, Steering Box/Hydro
11	710-0597	1	/P	Screw, Hex Cap, 1/4-20 x 1.0 Gr5
12	710-0195	1	S	Screw, Hex Cap, 1/4-28 x .625 Gr5
13	710-0528	1	/P	Screw, Hex Cap, 5/16-18 x 1.25 Gr5
14	710-0642	1	/P	Screw, Hex Wash Hd. Tapp, 1/4-20 x .75
15	710-0650	1	/P	Screw, Hex Wash Hd. Tapp, 5/16-18 x .875
16	710-04187	1	/P	Screw, Hex Wash Hd. Hi/Lo, 1/4-15 x .5
17	710-3015	1	/P	Screw, Hex Cap, 1/4-20 x .75 Gr5
18	710-0520	1	/P	Screw, Hex Cap, 3/8-16 x 1.5 Gr5
19	710-3085	1	/P	Screw, Hex Cap, 3/8-16 x 3.5 Gr5
20	710-3119	1	/P	Screw, Hex Cap Lock, 3/8-16 x .75 Gr5
21	710-3144	1	/P	Screw, Hex Cap, 3/8-16 x 2.0 Gr5
22	710-3296	1		Screw, Hex Cap Lock, 1/4-20 x .75 Gr5
23	710-04006	1		Screw, Hex Wash Hd. Tapp, 5/16-18 x 2.0
24	710-04389	1		Screw, Hex Wash Hd. Tapp, 5/16-18 x 2.25
25	710-04484	1		Screw, TT, 5/16-18 x .75
26	711-04722	1		Pin, Clevis, .375 x .969 HT
27	711-04472	1		Link, Drag
28	711-04562	1		Shaft, Steering Pivot Gear
29	712-0312A	1		Nut, Jam, 3/8-24 LH Thrd
30	712-0365	1		Nut, Hex Lock, M8 x 1.25 Gr9
31	712-0375	1	/P	Nut, Hex Lock, 3/8-16
32	712-04063	1	/P	Nut, Hex Insert Flange Lock, 5/16-18 GrF
33	712-04064	1	/P	Nut, Hex Insert Flange Lock, 1/4-20 GrF
34	712-04065	1	/P	Nut, Hex Insert Flange Lock, 3/16-16 GrF
35	712-3001	1	S	Nut, Hex Jam, 3/8-24 Gr2
36	713-04037	1	S	Link, Connecting
37	714-0104	1	S	Pin, Internal Cotter
38	736-0286	1	S	Washer, Sping, .39 x .75 x .010
39	714-04039	1		Pin, Cotter, 5/32 x 1.25
40	717-04274	1	S	Gear, Spur, 12T
41	717-04275	1	S	Gear, Spur, RH 13T
42	717-04282	1	S	Gear, Spur, LH 13T
43	719-04170A	1	/P	Axle, Pivot Bar

i1050 Tractor 2007 & Before
Steering Control & Front Axle

Page 37 of 48


Ref #	Part Number	Qty	S/P/F	Description
44	723-04035	1		End, Ball Joint Rod
45	723-04036	1		End, Ball Joint Rod, LH Thrd.
46	737-3000	1	S	Fitting, Grease
47	727-0626A	1	S	Cylinder, Damper
48	731-04532A	1	/P	Cover, Steering Wheel
49	731-05476	1		Cover, Steering Gear, RH
50	731-05618	1		Cover, Steering Gear, LH
51	736-0185	1	S	Washer, Flat, .375 x .738.063
52	736-0270	1	/P	Washer, Bell, .265 x .75 x .062
53	736-0315	1	/P	Washer, Flat, .76 x 1.5 x .12
54	736-0866	1		Washer, Flat, .755 x 1.92 x .060
55	736-0452	1	S	Washer, Bell, .396 x 1.14 x .095
56	736-3004	1	S	Washer, Flat, .406 x .875 x .105
57	738-04189	1		Shaft, Steering, .625 x 17.281
58	738-04240	1		Nut, Shoulder, .375 x .5
59	747-04496	1		Rod, 3/8-24 x 14.4 Lg
60	748-04139	1		Block, Steering Shaft
61	750-04676	1		Spacer, .385 x .63 x .75
62	750-04776	1		Spacer, .380 x .625 x .265
63	750-04777	1		Spacer, .26 x .372 x .33
64	783-04798	1	S	Bracket, Steering Support, LH
65	783-04799	1	S	Bracket, Steering Support, Upper
66	783-05140	1	S	Bracket, Steering Support, RH
67	783-05184	1	S	Plate, Base Cover, RH
68	783-05185	1	S	Plate, Base Cover, LH
69	783-05380	1	S	Link, Steering/Hydro RH
70	783-05381	1		Bracket, Hydro/Steering Adjustment
71	783-05404	1	S	Link, Steering/Hydro LH
72	783-05446	1	S	Bracket, Steering Link
73	731-3020	1	S	Hub Cap
74	736-0222	1	S	Washer, Lock
	490-900-0005	1	S	Grease Gun with one tube of grease Not shown
	490-900-0006	1	S	Replacement tubes of grease (3 pack) Not shown



i1050 Tractor 2007 & Before
Steering Gear Box

Page 39 of 48

Ref #	Part Number	Qty	S/P/F	Description
1	607-04243	1		Bracket, Steering Box Return
2	617-04036	1	S	Gear, Bevel LH
3	617-04037	1	S	Gear, Bevel RH
4	619-04153	1		Housing, Steering Lower
4	737-0148	1	S	Grease, Darina not shown
5	619-04154A	1	S	Housing, Steering Upper
6	647-04083	1		Arm, Hydro LH
7	647-04084	1		Arm, Hydro RH
8	647-04085	1		Cam, Hydro LH
9	647-04086	1		Cam, Hydro RH
10	703-2441	1		Arm, Neutral
11	710-0599	1	/P	Screw, Hex Wash Hd. Tapp, 1/4-20 x .5
12	710-04040	1	/P	Screw, Shoulder, .497 x .75 : 3/8-16
13	710-0778	1	/P	Screw, Hex Wash Hd. Tapp, 1/4-20 x 1.5
14	710-0809	1		Screw, Hex Wash Hd. Tapp, 1/4-20 x 1.25
15	711-04587A	1	S	Shaft, Steering
16	712-3005	1	S	Nut, Hex Flange Lock, 3/8-16 Gr5
17	716-0102	1	S	Ring, Snap, 1.0 Dia. Shaft
18	716-0111	1	/P	Ring, External Retaining, .875 Shaft
19	716-0114	1	S	Ring, Retaining, .56 Dia. Shaft
20	716-0115	1	S	Ring, Retaining, .56 Dia. Shaft
21	716-04066	1		Ring, Retaining, .31125 Dia. Shaft
22	717-04318	1		Gear, Pinion, 7T
23	717-04319	1		Gear, Synchro Rack
24	717-04328	1	S	Gear, Steering, 17T
25	717-04330	1	S	Gear, Steering, 26T
26	718-04229	1		Tube, Coupler
27	718-04269	1	S	Cam, Hydro Steering
28	721-04186	1		O-Ring, .625 x .07
29	741-04257	1		Bearing, Caster
30	732-1162	1		Spring, Extension, .56 x 2.31 x .105
31	736-0369	1	S	Washer, Flat, .508 x 1.0 x .02
32	736-04237	1		Washer, Flat, .508 x 1.32 x .04
33	736-04257	1	/P	Washer, Flat, 1.015 x 1.375 x .005
34	736-04258	1	/P	Washer, Flat, 1.015 x 1.375 x .010
35	736-04259	1		Washer, Flat, 1.015 x 1.375 x .015
36	736-04260	1		Washer, Flat, 1.015 x 1.375 x .030
37	736-0864	1	S	Washer, Thrust, .375 x .812 x .06
39	736-3067	1	/P	Washer, Flat, 1.88 x .437 x .042
40	741-04203	1		Bearing, Flange, .5 x .7
41	741-04204	1		Bearing, Sleeve, .437 x .3425
42	741-04206	1		Bearing, Sleeve, .623 x .5025 x .25
43	741-04231	1		Bearing, Sleeve, 1.2 x 1.0
44	741-04235	1		Bearing, Flange, .625 x .875
45	741-0747	1		Bearing, Ball, .5625 x 1.375 x .4375
46	710-0642	1	/P	Screw, TT: 1/4-20 x .750
47	712-3001	1	S	Jam Nut, 3/8-24
48	710-1810	1		Screw, HH Cap, 3/8-24 x 1.75



i1050 Tractor 2007 & Before
Transmission Assembly LH


Page 41 of 48

Ref #	Part Number	Qty	S/P/F	Description
1	HG-71030L	1		Housing Assembly, Main RH
2	HG-71031L	1		Side Assembly, RH
4	HG-70723	1	/P	Block Kit - 7 Piston
5	HG-51949	1		Spacer, .32 x 1.005 x .179
6	HG-70331	1	/P	Block Assembly, Cylinder
7	HG-9005110-5600	1	/P	Plug, Straight Thread
8	HG-9004800-2506	1	/P	Pin
9	HG-51190	1	/P	Screw, Hex Flange
10	HG-70719	1	/P	Seal, Oil
13	HG-51626	1		Seal, Lip
14	HG-51628	1	/P	Ring, Retaining, .375 Ext.
15	HG-51625	1		Rod, Bypass
16	HG-51627	1		Ring, Retaining, .75 Int.
19	HG-51048	1	/P	Swashplate, Trunnion
20	HG-51140	1	/P	Seal, Lip
23	HG-52681	1		Arm, Control
24	736-0371	1	/P	Washer, Flat, .34 x .88 x .06
25	HG-51812	1	/P	Screw, 5/16-24 x 1.0
27	HG-2003014	1	/P	Spring, Block
28	HG-2003017	1	/P	Washer, Thrust
29	HG-51062	1	/P	Shaft, Input
30	HG-50315	1		Bearing, Ball
31	HG-2000022	1	/P	Ring, Retaining
32	HG-50951	1	/P	Spacer
33	HG-51161	1	/P	Seal, Lip
34	HG-50329	1	/P	Ring, Retaining
35	HG-50551	1	S	Bearing, Thrust
36	HG-44371	1	/P	Washer, Flat, 5/8 x 1.0 x .05
37	HG-44145	1		Ring, Retaining
38	HG-51767	1		Gear, Pinion, 12T
39	HG-52579	1		Shaft, Motor
40	HG-51069	1		Washer, Motor Shaft
41	HG-50132	1	/P	Washer, HT
42	HG-51766	1		Gear, 10T/49T
43	HG-51043	1	/P	Gear, 10T Jackshaft
44	HG-51083	1		Pin, Jackshaft
45	HG-52531	1		Ring, Retaining
46	HG-52541	1		Gear, Bull, 52T
47	HG-52532	1		Washer, 1.018 x 1.57 x .105
48	HG-52542	1		Bearing, Sleeve
49	HG-52683	1		Shaft, Axle
50	HG-51517	1	/P	Bearing, Sleeve
51	HG-51518	1	/P	Seal, Lip
53	HG-70868L	1		Plate Kit, Expansion
57	HG-71529	1		Kit, Center Section
59	HG-71357	1		Kit, Bypass Arm RH
61	HG-71497	1	/P	Filter Assembly
73	HG-44433	1		Screw, Hex
74	HG-44094	1	/P	Arm, Brake
75	HG-50884	1	/P	Spring, Brake
100	HG-52473	1		Rotor, Brake
131	HG-51616	1	S	Screw, Patch, 5/16-24 x 1
134	HG-51950	1		Washer, 3/4 x 1.5 x .062

Ref #	Part Number	Qty	S/P/F	Description
135	HG-52401	1	/P	Spring, Extension
138	HG-71510	1	/P	Kit, Breather
140	HG-51945	1		Arm, Neutral
141	HG-52432	1		Kit, Scissors Arm
150	917-0678	1	/P	Puck, Brake
151	917-0682	1	/P	Plate, Puck
153	HG-62589	1	/P	Assembly, Brake Yoke
154	HG-23711	1		Spacer, Torsion Spring
155	941-0343	1	/P	Pin, Actuating
156	HG-50919	1	/P	Spring, Brake
157	HG-51146	1		Bolt, Special Flange
158	936-0371	1	S	Washer, Flat
159	712-0335	1	S	Nut, Castle, 5/16-24
160	914-0507	1	/P	Pin, Cotter, 3/32 x .75
	HG-50928	1	/P	Sealant not shown
	HG-70853	1	/P	Seal Kit not shown

i1050 Tractor 2007 & Before Transmission Assembly RH

Page 43 of 48




i1050 Tractor 2007 & Before
Transmission Assembly RH

Page 44 of 48

Ref #	Part Number	Qty	S/P/F	Description
1	HG-71585	1		Housing Assembly, Main RH
2	HG-71586	1		Side Assembly, RH
4	HG-70723	1	/P	Block Kit - 7 Piston
5	HG-52527	1		Spacer, .32 x 1.005 x .179
6	HG-70331	1	/P	Block Assembly, Cylinder
7	HG-9005110-5600	1	/P	Plug, Straight Thread
8	HG-9004800-2506	1	/P	Pin
9	HG-51190	1	/P	Screw, Hex Flange
10	HG-70719	1	/P	Seal, Oil
13	HG-51626	1		Seal, Lip
14	HG-51628	1	/P	Ring, Retaining, .375 Ext.
15	HG-51625	1		Rod, Bypass
16	HG-51627	1		Ring, Retaining, .75 Int.
19	HG-51048	1	/P	Swashplate, Trunnion
20	HG-51140	1	/P	Seal, Lip
23	HG-52682	1		Arm, Control
24	736-0371	1	/P	Washer, Flat, .34 x .88 x .06
25	HG-51812	1	/P	Screw, 5/16-24 x 1.0
27	HG-2003014	1	/P	Spring, Block
28	HG-2003017	1	/P	Washer, Thrust
29	HG-51062	1	/P	Shaft, Input
30	HG-50315	1		Bearing, Ball
31	HG-2000022	1	/P	Ring, Retaining
32	HG-50951	1	/P	Spacer
33	HG-51161	1	/P	Seal, Lip
34	HG-50329	1	/P	Ring, Retaining
35	HG-50551	1	S	Bearing, Thrust
36	HG-44371	1	/P	Washer, Flat, 5/8 x 1.0 x .05
37	HG-44145	1		Ring, Retaining
38	HG-51767	1		Gear, Pinion, 12T
39	HG-52579	1		Shaft, Motor
40	HG-51069	1		Washer, Motor Shaft
41	HG-50132	1	/P	Washer, HT
42	HG-51766	1		Gear, 10T/49T
43	HG-51043	1	/P	Gear, 10T Jackshaft
44	HG-51083	1		Pin, Jackshaft
45	HG-52531	1		Ring, Retaining
46	HG-52541	1		Gear, Bull, 52T
47	HG-52532	1		Washer, 1.018 x 1.57 x .105
48	HG-52542	1		Bearing, Sleeve
49	HG-52683	1		Shaft, Axle
50	HG-51517	1	/P	Bearing, Sleeve
51	HG-51518	1	/P	Seal, Lip
53	HG-70868R	1		Plate Kit, Expansion RH
57	HG-71530	1		Kit, Center Section RH
59	HG-71006	1		Kit, Bypass Arm RH
61	HG-71497	1	/P	Filter Assembly
73	HG-44433	1		Screw, Hex
74	HG-44094	1	/P	Arm, Brake
75	HG-50884	1	/P	Spring, Brake
100	HG-52473	1		Rotor, Brake
131	HG-51616	1	S	Screw, Patch, 5/16-24 x 1
134	HG-51950	1		Washer, 3/4 x 1.5 x .062

Ref #	Part Number	Qty	S/P/F	Description
135	HG-52401	1	/P	Spring, Extension
138	HG-71510	1	/P	Kit, Breather
140	HG-51946	1		Arm, Neutral, RH
141	HG-52432	1		Kit, Scissors Arm
150	917-0678	1	/P	Puck, Brake
151	917-0682	1	/P	Plate, Puck
153	HG-62589	1	/P	Assembly, Brake Yoke
154	HG-23711	1		Spacer, Torsion Spring
155	941-0343	1	/P	Pin, Actuating
156	HG-50919	1	/P	Spring, Brake
157	HG-51146	1		Bolt, Special Flange
158	936-0371	1	S	Washer, Flat
159	712-0335	1	S	Nut, Castle, 5/16-24
160	914-0507	1	/P	Pin, Cotter, 3/32 x .75
	HG-50928	1	/P	Sealant not shown
	HG-70853	1	/P	Seal Kit not shown



Ref #	Part Number	Qty	S/P/F	Description
1	17840	1	S	Bracket, Transmission Mounting
2	618-04317	1	S	Hub, Wheel
3	N/A	1		Wheel Assembly order components
3	734-1730	1		Tire, 20 x 8 x 8
3	634-0246A	1	S	Rim Assembly, Rear
3	934-0255	1	/P	Valve, Tubeless Air
4	647-04061	1		Shaft Assembly, Brake Control
5	647-04094	1		Shaft Assembly, Hydro Control Pedal
6	683-0267C	1	/P	Pedal Assembly, Hydro Control
7	683-04314A	1	S	Bracket, Pedal
9	710-0514	1	/P	Screw, Hex Cap, 3/8-16 x 1.0 Gr5
10	710-0607	1	/P	Screw, Hex Wash Hd. Tapp, 5/16-18 x .5
11	710-0726	1	/P	Screw, Hex Wash Hd. Tapp, 5/16-12 x .75
13	710-1266	1	/P	Screw, Hex Cap, 5/16-18 x 3.5 Gr5
14	710-1325	1	/P	Screw, Hex Wash Hd. Tapp, 1/4-20 x 1.625
15	710-3073	1	S	Screw, Hex Cap, 5/16-18 x 2.25 Gr5
16	710-3119	1	/P	Screw, Hex Cap Lock, 3/8-16 x .75 Gr5
17	710-04484	1		Screw, Hex Wash Hd. Tapp, 5/16-18 x .75
18	710-04648	1		Screw, Hex Cap, 7/16-14 x 8.5 Gr5
19	711-04554	1		Spacer, .479 x .75 x 4.97
20	711-0832	1	S	Ferrule, 3/8-24 x .375 Dia.
21	712-0346	1	S	Nut, Hex Jam Insert Lock, 1/2-20 Gr5
22	712-0431	1	S	Nut, Hex Flange Top Lock, 3/8-16 GrF
23	712-3004A	1	/P	Nut, Hex Flange Lock, 5/16-18 Gr5
24	712-0290	1	/P	Nut, Hex Lock, 7/16-14 GrA
25	712-3050	1	/P	Nut, Lug, 7/16-14
26	712-04063	1	/P	Nut, Hex Flange Insert Lock, 5/16-18 GrF
27	712-04065	1	/P	Nut, Hex Flange Insert Lock, 3/8-16 GrF
28	712-0375	1	/P	Nut, Hex Lock, 3/8-16
29	714-0104	1	S	Pin, Internal Cotter
30	714-0111	1	S	Pin, Cotter, 3/32 x 1/0
31	715-0143	1	S	Pin, Spirol, .25 x 1.25
32	726-0214	1	/P	Cap, Push, 5/8
33	731-05846	1	/P	Fan, Hydro
34	732-0209	1	S	Spring, Extension, .48 x 2.03
35	732-0335	1		Spring, Compression, .405 x 1.17
36	732-0716C	1	S	Spring, Extension, .59 x 4.0
37	732-0814	1		Spring, Extension, .56 x 5.52
38	735-0239	1	/P	Pad, Foot, 4.0 in. Lg
39	735-0662	1		Pad, Hydro Control Pedal
40	736-3027	1		Washer, Flat, .531 x 1.75 x .09
41	736-0227	1	S	Washer, Flat, .39 x 1.5 x .134
42	736-0290	1	/P	Washer, Flat, .625 x 1.0 x .067 HT
43	736-3010	1	/P	Washer, Flat, .407 x .812 x .135 HT
44	736-3039	1	S	Washer, Flat, .406 x 1.5 x .105
45	736-3050	1	/P	Washer, Flat, .406 x .812 x .051
46	736-04263	1		Washer, Hydro Lock
47	738-0129	1	/P	Bolt, Shoulder, 3/8-16: .5 x 2.0
48	738-0143	1	/P	Bolt, Shoulder, .496 x .336: 3/8-16
49	738-0155	1	S	Bolt, Shoulder, .435 x .160 : 5/16-18
50	738-0347	1	S	Spacer, Shoulder, .625 ID x .169
51	741-0225	1	S	Bearing, Hex Flange
52	741-3065B	1	/P	Bearing, Hex Flange, .625 ID Split

Ref #	Part Number	Qty	S/P/F	Description
53	747-04562	1		Rod, Park Brake
54	747-04584A	1	/P	Rod, Brake
55	747-04598A	1		Rod, Drive Engage
56	747-04629	1	S	Bracket, Brake Pedal
57	747-04649A	1		Rod, Hydro Dump
58	748-04155	1		Spacer, T-Axle
59	750-04776	1		Spacer, .38 x .625 x .265
61	750-04456	1		Spacer, .26 x .372 x 1.42
62	754-04134	1	S	V-Belt, 88.4
63	756-04209	1	/P	Pulley, V Type Drive, 3.06
64	756-04274	1		Pulley, V Type, 4.5
65	756-0981B	1	S	Pulley, Flat Idler, 2.75
66	783-04570A	1	S	Arm, Idler
67	783-04881A	1	S	Bracket, Foot Pedal Support
68	783-04981	1		Bracket, Park Brake
69	783-05330A	1	S	Bracket, Support
70	783-05473	1	S	Bracket, Belt Keeper Mounts & secured to top of trans.
70	783-05332	1	S	Bracket, Belt Keeper Mounts to the top but secured by trans. side cover bolts.
71	918-04339A	1	/P	Transmission, Hydro RH
72	918-04342A	1	/P	Transmission, Hydro LH
73	17962	1		Plate, Switch
74	710-0224	1	S	Screw, Hex Wash Hd. Tapp, #10-16 x .5
75	710-0227	1	/P	Screw, Hex Wash Hd. Tapp, #8-18 x .5
76	725-04039	1	S	Switch, Brake
77	725-1644	1		Switch, Reverse
78	726-0320	1	S	Plate, Insulator Nut
79	725-04374	1		Harness, Reverse Jumper
80	710-0599	1	/P	Screw, Hex Wash. Hd. Tapp, 1/4-20 x .5
81	710-3144	1	/P	Screw, Hex Head Cap, 3/8-16 x 2
82	714-04040	1	/P	Cotter Pin, Bow Tie
83	710-1611B	1	/P	Screw, TT, 5/16-18 x .750
84	725-0157	1	/P	Cable Tie