


430 4x2 Utility Vehicle (37AR430-710)
Cables

Page 1 of 58




430 4x2 Utility Vehicle (37AR430-710)
Cables

Page 2 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	707-04196A	2	/P	Plate, Arm Brake
2	707-04199	1		Mount,Cable
3	707-04200	1		Bracket, Equalizer
4	710-04027	1		Screw, Shoulder, .375 x .375
5	710-1266	1	/P	Screw, 5/16-18 x 3.5
6	710-0599	2	/P	Screw, Self-Tapping
7	710-1238	4	/P	Washer, 5/16-18 x .875
8	711-0173	1	/P	Pin, Clevis 375 x .969
9	711-04024	1	S	Pin, Clevis .625 OD x 1.37
10	711-0653	2	/P	Pin, Clevis .312 OD x 1.0
11	712-0256	2	/P	Nut, Jam 5/16-24
12	712-3010	1	S	Nut, Hex 5/16-18
13	712-3004A	4	/P	Nut, Flange Lock 5/16-18
14	712-3007	1	/P	Nut, Jam 5/16-18
15	712-3009	1	S	Hexlock Nut, 5/16-18
16	714-0104	1	S	Pin, Cotter, .072 x 1.13
17	714-0507	2	S	Pin, Cotter 3-32 x .750
18	719-0104	2		E-Ring for .500 Dia Shaft
19	716-0106A	2		E-Ring.625 Shaft
20	719-3018	2		Yoke, 5/16-24
21	726-04000	2		Clamp
22	732-0470A	1	S	Extension Spring
23	736-0159	1	S	Washer, .349 x .879 x .063
24	736-0355	2	/P	Flat Washer, 1.0 x .56 x .040
25	746-04002	1	S	Cable, Control, Choke
26	746-04042	1	S	Cable, Control, Throttle
27	746-04124	1	S	Cable, Control, Brake
28	750-04194	1		Spacer, .466 OD x .443
29	736-04099	10		Washer, Belleville, .937 x .328 x .07

430 4x2 Utility Vehicle (37AR430-710)
Diff Lock And Rear Suspension

Page 3 of 58




430 4x2 Utility Vehicle (37AR430-710)
Diff Lock And Rear Suspension

Page 4 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	607-04025	1		Link Assembly
2	707-04119	4		Plate, Shackle
3	707-04120A	2		Bracket, Spring Leaf
4	710-0347	4	/P	Hex Screw, 3/8-16 x 1.75
5	710-04119	4	/P	U-Bolt 3/8-16
6	710-04128	1	/P	Hex Screw, M12-1.75
7	710-04129	1	/P	Hex Screw, 5/8-11 x 2.5
8	710-0599	4	/P	Screw, Self Tapping 1/4-20
9	712-0130	4	/P	Locknut, Nylon, 3/8-16
10	712-0459	6	/P	Hexlock Nut
11	713-3016	1		Hexlock Nut, Flange, 5/8 -11
12	712-3103	1		Hexlock Nut, M12 x 1.75
13	731-04016	2		Bumper, Suspension
14	732-04043	2	S	Shock Absorber, 2.50 Stroke
15	732-04055	2	S	Spring, Leaf 4 x 2
16	738-04035	4	S	Shoulder Screw, .550 x 2.29
17	738-04042	2	S	Shoulder Screw, .550 x 2.13
18	741-0405	8	S	Bearing, .56 ID x 1.25 OD x .06
19	750-04137	2	S	Bushing, .75 OD x .562 ID x 1.75 LG
20	710-04022	2		Screw, M8 x 1.25:20
21	737-04013	1		Valve, Oil Drain
22	751-0544	1	S	Spark Arrestor
23	751-0854A	1	S	Muffler, Honda GXV
24	618-04062	1	S	Clutch Assembly, Engine
25	618-04063	1	S	Clutch Assembly, Transmission
26	736-04009	1		Washer, Flat, 1.03 x 1.625 X .12
27	738-04002A	1		Spacer, .39 x 1.0
28	754-04018A	1	S	Belt, Cogged
29	607-04022	1		Engine/Trans. Cradle
30	918-04080A	1	/P	Transmission Ass'y, Diff-Lock
30	DC-4170693P	1	/P	Brake Shoes (per axle) Not shown
31	710-0314	4	/P	Hex Screw, 7/16-20 x 1.0
32	710-04019	1		Hex Screw, 3/8-24 x 3.00
33	710-04167	1	/P	Hex Screw, 1/2-20 x 2.25
34	710-3144	4	/P	Hex Screw, 3/8-16 x 2.00
35	714-04030	1	S	Key, Square 1875 x 3.25
36	731-04707	2		Plug, Tube
37	736-0133	4	S	Washer, Flat, .510 x 1.00 x .125
38	736-04019	1		Washer, Flat, .531 ID x 1.25 X 1.00
39	712-3050	10	/P	Lug Nut, 7/16-14
40	634-0351	2		Wheel Assembly, 25 x 12 x 9, Turf
	737-04039	22		Transmission Oil (80W-90) Not shown

430 4x2 Utility Vehicle (37AR430-710)
Diff Lock Shifter (Part 1)

Page 5 of 58




430 4x2 Utility Vehicle (37AR430-710)
Diff Lock Shifter (Part 1)

Page 6 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	707-04133	1		Mounting Bracket, Vacuum Actuator
2	707-04140	1		Bracket, Shift
3	707-04146	1		Bracket, Vac Relay
4	710-04030	2		Screw, 1/4-20 x.5
5	710-04164	1	/P	Screw, Hex. #8 - 18 .375
6	710-04169	1	/P	Screw, Set, 5/16-24 x .50 LG
9	710-3008	2	/P	Screw, 5/16-18 x .75 Hex
10	711-04142	1		Pin, Yoke 1/4
12	714-0127	1	/P	Pin, Cotter 1/16x.750
13	719-04065	1	S	Yoke, 1/4-28
15	759-04258	1	/P	Solenoid, Kit Vacuum Actuator Replaces 725-3278
16	726-04024	4	/P	Self Threading Nut
17	726-0465	4		Clip, Panel Retainer
18	726-0470	2		Cable Tie
19	731-04289	1		Arm, Shift
20	731-04295	1	S	Hose
21	731-04296	1	S	Hose, Manifold Vacuum
22	731-04297	1	S	Hose, Actuator Vacuum
23	731-04298	1	S	Hose, Actuator Vacuum
24	731-04310	1	S	Reservoir, Air
25	731-04333	1	S	Actuator, Vac Differential Lock
26	731-04334	1	S	Hose, Vac Differential Lock, Vent
27	731-04335	1	S	Hose, Vac Differential Lock Supply
28	735-04030	1		Grommet, .58 x .25
29	735-04034	1		Cover, Solenoid
30	736-0278	2		Flat Washer, .330 x .687 x .030
31	736-3067	1	/P	Flat, Washer, .188 x .437 x .042
32	751-0876	1		Actuator, Vacuum Shift

430 4x2 Utility Vehicle (37AR430-710)
Diff Lock Shifter (Part 2)

Page 7 of 58




430 4x2 Utility Vehicle (37AR430-710)
Diff Lock Shifter (Part 2)

Page 8 of 58

Ref #	Part Number	Qty	S/P/F	Description
7	710-0607	1	/P	Screw, 5/16-18
8	710-0896	2	/P	Screw, 1/4-14
11	712-04048	1	S	Nut, Hex 9/16-18
14	725-04049	1	S	Switch, Neutral
32	751-0876	1		Actuator, Vacuum Shift


430 4x2 Utility Vehicle (37AR430-710)
Electrical Schematic (Part 1)

Page 9 of 58




430 4x2 Utility Vehicle (37AR430-710)
Electrical Schematic (Part 2)

Page 10 of 58



430 4x2 Utility Vehicle (37AR430-710) Electrical System (Part 1)

Page 11 of 58




430 4x2 Utility Vehicle (37AR430-710)
Electrical System (Part 1)

Page 12 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	16606	1	S	Bracket, Retainer Hook
3	629-04060	2		Harness Assembly, Motor Ground
4	710-04030	2		Screw, 1/4-20 x .50
5	710-0599	3	/P	Screw, Self-tapping, 1/4-20 x 0.500
7	710-0703	2	/P	Screw, Hex Carriage, 1/4-20 x .75
9	710-3009	8	/P	Screw, #10-24 x 0.75
10	712-0271	2	/P	Nut, Hex Sems, 1/4-20
11	721-3049	1	/P	Cover, Protective
12	723-3064	1		Strap, Battery
13	725-0157	2	/P	Cable Tie, 3/16 x .05 x 7.4
14	725-04059A	1	/P	Control, Shaft
15	725-04065	1	S	Harness, Utility Main
16	725-04066	1	S	Harness, Motor
18	725-1657A	2	S	Switch
19	725-1738	1	S	Battery
20	726-0470	8		Cable Tie, .19 x 8.39 Tree Mount
23	31620-ZG5-003	1	S	Rectifier Assembly, Regulator (20A)
24	726-0465	2		Retainer Clip, .250 x .267

430 4x2 Utility Vehicle (37AR430-710)
Electrical System (Part 2)

Page 13 of 58




430 4x2 Utility Vehicle (37AR430-710)
Electrical System (Part 2)

Page 14 of 58


Ref #	Part Number	Qty	S/P/F	Description
2	629-04054	1	S	Harness Assembly, Starter
13	725-0157	2	/P	Cable Tie, 3/16 x .05 x 7.4
15	725-04065	1	S	Harness, Utility Main
16	725-04066	1	S	Harness, Motor
17	725-04069	1	S	Control, Reverse
20	726-0470	8		Cable Tie, .19 x 8.39 Tree Mount

430 4x2 Utility Vehicle (37AR430-710)
Electrical System (Part 3)

Page 15 of 58



VIEW-UNDER SEATS/GAS TANK



VIEW-BEHIND PASSENGER SEAT


430 4x2 Utility Vehicle (37AR430-710)
Electrical System (Part 3)

Page 16 of 58

Ref #	Part Number	Qty	S/P/F	Description
8	710-0788	2	/P	Screw, Self-tapping, 1/4-20 x 1.000
9	710-3009	8	/P	Screw, #10-24 x 0.75
17	725-04069	1	S	Control, Reverse
20	726-0470	8		Cable Tie, .19 x 8.39 Tree Mount
22	736-0329	2	S	Lock Washer, 1/4

430 4x2 Utility Vehicle (37AR430-710)
Engine - Camshaft

Page 17 of 58




430 4x2 Utility Vehicle (37AR430-710)
Engine - Camshaft

Page 18 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	12209-ZE8-003	2		Seal, Valve Stem
2	14100-ZJ1-842	1		Camshaft Assembly
3	14410-ZJ1-840	4		Rod, Push
4	14431-ZE2-010	4		Arm, Valve Rocker
5	14451-ZE1-013	4		Pivot, Rocker Arm
6	14568-ZJ1-841	1		Spring, Weight Return
7	14576-ZJ1-840	1		Pin, Decompression
8	14711-ZE3-000	2		Valve, In
9	14721-ZE3-000	2		Valve, Ex
10	14730-ZJ1-840	1		Lifter Ass'y., Valve
11	14751-ZE2-003	4		Spring, Valve
12	14760-ZJ1-840	1		Shaft, Valve Lifter
13	14764-ZJ1-840	2		Spring, Valve Lifter
14	14771-ZE2-000	2		Retainer, In. Valve Spring
15	14773-ZE2-000	2		Retainer, Ex. Valve Spring
16	14775-ZE2-010	2		Seat, Valve Spring
17	14781-ZE2-000	2		Rotator, Valve
18	14791-ZE2-010	2		Plate, Push Rod Guide
19	90005-896-000	1		Bolt, Flange (5x16)
20	90012-ZE0-010	4		Bolt, Pivot (8mm)
21	90206-ZE1-000	4		Nut, Pivot Adj
22	90446-357-000	1		Washer, Thrust (17.2mm)
23	90602-ZE1-000	2		Clip, Governor Holder
24	94301-08120	1		Pin A, Dowel (8x12)
25	94101-06800	4		Washer, Plain (6mm)
26	94305-60282	1		Pin, Spring (6x28)
27	95701-06025-00	1		Bolt, Flange (6x25)

430 4x2 Utility Vehicle (37AR430-710)
Engine - Carburetor

Page 19 of 58




430 4x2 Utility Vehicle (37AR430-710)
Engine - Carburetor

Page 20 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	12357-ZJ1-840	1		Tube, Breather
2	15772-551-000	1		Clip, Breather Tube
3	16010-ZG8-000	1		Gasket Set
4	16011-KCK-910	1		Valve Set, Float
5	16013-ZV4-005	1		Float Set
6	16015-ZJ1-841	1		Chamber Set, Float
7	16016-ZJ1-010	1		Screw Set
8	16024-124-760	1		Screw Set, Drain
9	16028-ZG8-000	1		Screw Set
10	16100-ZJ1-841	1	S	Carburetor Assembly. (Bg22g A)
11	16148-141-881	1		Cap, Choke Lever Dust
12	16150-ZJ1-841	1		Jet Set (#52)
13	16166-ZJ0-000	1		Nozzle, Main
14	16178-548-004	1		O-ring (5.8x1.9)
15	16198-ZJ1-840	1		Tube, Drain
16	16200-ZJ1-841	1	S	Valve Assembly., Solenoid
17	16211-ZJ0-830	1		Insulator, Carburetor
18	16221-ZJ1-840	2		Gasket, Carburetor
19	17228-ZG8-003	1		Gasket, Air Cleaner
20	17410-ZJ1-840	1		Elbow, Air Cleaner
21	90314-ZJ1-840	2		Nut, Insert (6mm)
22	90682-959-661	1		Clip B, Cable
23	91402-ZJ1-841	1		Clip, Purse Lock
24	93892-04014-08	4		Screw-washer (4x14)
	93892-04014-18	4		Screw-washer (4x14)
25	93892-05012-08	2		Screw-washer (5x12)
26	95002-02080	1		Clip, Tube (B8)
27	95801-06120-00	2		Bolt, Flange (6x120)
28	99201-ZG8-	1		Jet Set, Main (#110)

430 4x2 Utility Vehicle (37AR430-710)
Engine - Control

Page 21 of 58




430 4x2 Utility Vehicle (37AR430-710)
Engine - Control

Page 22 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	16263-883-W10	1		Joint, Rod
2	16500-ZJ1-861	1		Control Assembly
3	16534-ZJ1-840	1		Spring, Starter
4	16551-ZJ1-840	1		Arm, Governor
5	16555-ZJ1-840	1		Rod, Governor
6	16561-ZJ4-830	1		Spring, Governor
7	16562-ZJ1-840	1		Spring, Throttle Return
8	16576-891-000	2		Holder, Cable
10	16584-883-300	2		Spring, Control Adjusting
11	16592-ZJ1-000	2		Spring, Cable Return
12	16617-ZJ1-840	2		Holder, Cable
14	16611-ZJ1-840	1		Rod, Choke Control
18	90014-952-000	2		Bolt, Flange (6x14)
21	92301-05016-0A	2		Bolt, Slot (5x16)
23	92301-05025-0A	1		Bolt, Slot (5x25)
24	92301-04006-0H	2		Bolt, Recessed (4x6)
25	93500-05025-0A	1		Screw, Pan (5x25)
26	94050-06000	1		Nut, Flange (6mm)

430 4x2 Utility Vehicle (37AR430-710)
Engine - Crankcase Cover

Page 23 of 58




430 4x2 Utility Vehicle (37AR430-710)
Engine - Crankcase Cover

Page 24 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	NLA	1		Cover Assembly, Crankcase 11300-ZJ1-840
2	11381-ZJ1-840	1		Gasket, Case Cover
4	15120-ZJ1-000	1		Cover Assembly, Oil Pump
5	15124-ZJ1-003	1		Rotor, Oil Pump (Outer)
6	15232-ZJ1-000	1		Spring, Relief Valve
7	15348-ZJ1-840	1		Cover, Oil Filter
8	15400-PLM-A01PE	1	/P	Filter, Oil Replaces 15400-P0H-305PE
10	15411-ZJ1-840	1		Base, Oil Filter
11	15427-ZJ1-000	1		Screen, Oil Filter
12	15655-ZJ1-840	1		Dipstick, Oil
13	16510-ZJ1-840	1		Governor Assembly
14	16511-ZJ1-840	3		Weight, Governor
15	16512-ZJ1-840	1		Holder, Governor Weight
16	16513-ZE2-000	3		Pin, Governor Weight
17	16531-ZOA-000	1	/P	Slider, Governor Replaces 16531-ZE2-000
20	90015-883-000	3		Bolt, Flange (6x28)
21	90018-PN3-000	1		Holder, Oil Filter
22	90473-147-000	1		Washer (6x16)
23	90602-ZE1-000	1		Clip, Governor Holder
24	91202-ZJ1-841	1		Oil Seal (38x58x9)
25	91320-MJ6-003	2		O-ring (11.8x2.4)
26	94101-06800	1		Washer, Plain (6mm)
27	94301-08140	2		Pin A, Dowel (8x14)
28	95701-06020-00	3		Bolt, Flange (6x20)
29	95701-08050-00	9		Bolt, Flange (8x50)
30	96211-12000	1		Ball, Steel (#12) (3/8)
31	96600-06016-00	2		Bolt, Socket (6x16)
32	13310-ZJ1-840	1		Crankshaft

430 4x2 Utility Vehicle (37AR430-710)
Engine - Cylinder Barrel

Page 25 of 58




430 4x2 Utility Vehicle (37AR430-710)
Engine - Cylinder Barrel

Page 26 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	12000-ZJ1-841	1	/P	Cylinder Assembly
2	12356-ZJ1-000	1		Cover, Breather
3	12358-ZJ1-000	1		Gasket, Breather Cover
4	12372-ZE2-300	1		Valve, Breather
5	15558-ZJ1-	1		Valve, Drain (14x1.5)
6	16541-ZJ1-840	1		Shaft, Governor Arm
8	31511-ZJ1-000	1		Clamp, Wire
10	37240-ZG3-E01	1		Switch, Oil Pressure
11	90002-ZG5-004	1		Screw-washer (4x8)
12	90029-888-000	2		Bolt, Flange (6x16)
13	90031-ZE1-000	2		Bolt, Flange (6x32)
14	91001-ZJ1-841	1		Bearing, Needle (8x12.7x11.1)
15	91002-ZJ1-841	1		Bearing, Needle (8x12x10)
16	91201-ZE9-003	1		Oil Seal (8x14x5)
17	91201-ZJ1-841	1		Oil Seal (38x58x9)
18	91302-MB6-830	1		O-ring (13x3.0)
20	92800-14000	2		Bolt, Drain Plug (14mm)
22	94102-08800	3		Washer, Plain (8mm)
23	94109-14000	2		Washer, Drain Plug (14mm)
24	94251-08000	2		Pin, Lock (8mm)
26	96140-60030-10	1		Bearing, Radial Ball (6003)

430 4x2 Utility Vehicle (37AR430-710)
Engine - Cylinder Head

Page 27 of 58




430 4x2 Utility Vehicle (37AR430-710)
Engine - Cylinder Head

Page 28 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	11911-ZJ1-840	2		Hanger, Engine
2	12204-ZE2-306	2		Guide, Valve (OS)
3	12205-ZJ1-405	2		Guide, Ex. Valve (OS)
4	12210-ZJ1-840	1	S	Cylinder Head (#1)
5	12216-ZE2-300	4		Clip, Valve Guide
6	12220-ZJ1-840	1		Cylinder Head (#2)
7	12251-ZJ1-841	2		Gasket, Cylinder Head
8	12311-ZJ1-840	1		Cover, Head
9	12314-ZJ1-840	1		Cover, Head Filler
10	12391-ZE2-020	2		Gasket, Cylinder Head Cover
11	15611-MB0-000	1		Cap, Oil Filler
12	15625-ZJ1-840	1		Gasket, Oil Filler Cap
13	17101-ZJ1-840	1		Manifold, In
14	17151-ZJ1-841	2		Gasket, In. Manifold
15	18333-ZE3-800	2		Gasket, Ex. Pipe
16	19682-ZJ1-840	2		Shroud, Head
17	90011-ZJ1-841	4		Bolt, Socket (8x45)
18	90014-ZE2-000	2		Bolt, Head Cover
19	90014-952-000	2		Bolt, Flange (6x14)
20	90018-ZJ1-840	4		Bolt, Stud (8x22)
21	90441-ZE2-010	2		Washer, Head Cover
22	94050-08000	4		Nut, Flange (8mm)
23	94301-12200	4		Pin A, Dowel (12x20)
24	95701-08020-00	2		Bolt, Flange (8x20)
25	95701-10080-00	8		Bolt, Flange (10x80)
26	98079-52876	2		Spark Plug (BPR2ES) (NGK)

430 4x2 Utility Vehicle (37AR430-710)
Engine - Fan Cover

Page 29 of 58




430 4x2 Utility Vehicle (37AR430-710)
Engine - Fan Cover

Page 30 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	16715-ZJ1-840	1		Cover, Fuel Pump
5	19611-ZJ1-860ZB	1		Cover, Fan (Bright Red)
6	19612-ZJ1-840	1		Plate, R. Side
7	19614-ZJ1-840	1		Plate, L. Side
8	19631-ZJ1-840	1		Shroud, R
9	19632-ZJ1-840	1		Shroud, L
14	33713-GC2-000	6		Collar B, Taillight
16	80101-310-000	1		Rubber, Rr. Fender Cushion
17	90013-883-000	10		Bolt, Flange (6x12) (Ct200)
18	90018-ZE1-000	2		Bolt, Flange (6x23)
19	90042-ZJ1-840	4		Bolt, Stud (6x71)
20	90313-ZJ1-840	2		Nut, Square (5mm)
23	93913-25580	2		Screw, Tapping (5x20)
25	94050-06000	4		Nut, Flange (6mm)
27	95701-06008-00	2		Bolt, Flange (6x8)

430 4x2 Utility Vehicle (37AR430-710)
Engine - Flywheel

Page 31 of 58




430 4x2 Utility Vehicle (37AR430-710)
Engine - Flywheel

Page 32 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	19511-ZJ1-000	1		Fan, Cooling
2	19513-ZJ1-000	1		Plate, Cooling Fan Setting
4	28452-ZJ1-811	1		Grid, Screen
6	28454-ZJ1-801	1		Holder, Screen Grid
7	31110-ZJ1-840	1		Flywheel
10	90201-ZG3-000	1		Nut, Flange (20mm)
11	90401-ZG3-000	1		Washer (20mm)
12	90741-ZE2-000	1		Key, Special Woodruff (25x18)
14	95701-08016-00	1		Bolt, Flange (8x16)
17	95701-08016-00	1		Bolt, Flange (8x16)

430 4x2 Utility Vehicle (37AR430-710)
Engine - Ignition Coil

Page 33 of 58





430 4x2 Utility Vehicle (37AR430-710)
Engine - Ignition Coil

Page 34 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	30500-ZJ1-841	1	S	Coil Assembly., R. Ignition
2	30518-ZJ1-000	2		Grommet, Ignition Wire
3	30550-ZJ1-841	1	S	Coil Assembly., L. Ignition
4	30700-ZJ1-841	2		Cap Assembly., Noise Suppressor
6	31630-ZJ1-801	1	S	Coil Assembly., Charge (12V/20A)
7	31740-ZJ1-841	1		Diode Assembly., Engine Stop
8	63312-ZA7-000	1		Grommet, Tool
10	90031-ZE1-000	6		Bolt, Flange (6x32)
11	90031-ZE1-000	2		Bolt, Flange (6x32)
15	95701-06008-00	1		Bolt, Flange (6x8)
16	32763-PA0-000	1		Clamp, Wire

430 4x2 Utility Vehicle (37AR430-710)
Engine - Piston

Page 35 of 58




430 4x2 Utility Vehicle (37AR430-710)
Engine - Piston

Page 36 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	13010-ZJ1-841	2		Ring Set, Piston (Std)
	13011-ZJ1-841	2		Ring Set, Piston (OS 0.25)
	13012-ZJ1-841	2		Ring Set, Piston (OS 0.50)
	13013-ZJ1-841	2		Ring Set, Piston (0.75)
2	13101-ZJ1-840	2		Piston (Std)
	13102-ZJ1-840	2		Piston (OS 0.25)
	13103-ZJ1-840	2		Piston (OS 0.50)
	13104-ZJ1-840	2		Piston (0.75)
3	13111-ZJ1-840	2		Pin, Piston
4	13200-ZJ1-841	2		Rod Assembly, Connecting
6	90001-ZN1-000	4		Bolt, Connecting Rod (6x37)
7	94601-18000	4		Clip, Piston Pin (18mm)

430 4x2 Utility Vehicle (37AR430-710)
Engine - Starter Motor


Page 37 of 58



430 4x2 Utility Vehicle (37AR430-710)
Engine - Starter Motor

Page 38 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	30201-PH9-004	1		Ring, Snap (Denso)
2	30202-PZ1-003	1		Collar Set, Clutch Stop
3	31200-ZJ1-841	1	S	Motor Assembly., Starter
4	31203-PH9-004	1		Lever, Pinion Drive
5	31204-ZJ1-H01	1	S	Switch Assembly., Magnet
6	31206-ZG4-801	1		Armature
7	31207-ZJ1-H01	1		Clutch, Overrunning
8	31211-PH9-004	4		Brush
9	31212-PH9-004	4		Spring, Brush
10	31213-P64-N01	1		Cover
11	31214-PH9-004	2		Bolt, Through
12	31216-ZJ1-H01	1		Yoke
13	31220-PH9-004	1		Nut, Hex. (8mm)
14	31223-PA0-006	2		Nut, Flange (5mm)
15	31231-PH9-004	1		Holder, Brush
16	31233-PH9-004	1		Insulator, Brush Holder
17	31234-ZJ1-H01	1		Cover, Terminal
18	91002-ZG4-801	2		Bearing A
19	94001-08000-0S	1		Nut, Hex. (8mm)
20	94111-08000	1		Washer, Spring (8mm)
21	94301-10120	2		Pin, Dowel (10x12)
22	95701-08110-00	2		Bolt, Flange (8x110)




430 4x2 Utility Vehicle (37AR430-710)
Engine Accessory

Page 40 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	710-04022	2		Screw, M8
2	752H638700	1		Engine, Honda GX618K1
3	737-04013	1		Valve, Oil Drain
4	751-0544	1	S	Spark Arrestor
5	751-0854A	1	S	Muffler, Honda GX620
	17210-ZJ1-842	1		Element, Air Cleaner Not shown
	17218-ZJ1-840	1		Element, Pre Cleaner Not shown
	16910-ZE8-015	1		Filter, Fuel Not shown

430 4x2 Utility Vehicle (37AR430-710)
Front End

Page 41 of 58



430 4x2 Utility Vehicle (37AR430-710)
Front End


Page 42 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	607-04004	1		Axle Assembly, Right-front (Incl. Ref 12 - 15)
	607-04005	1		Axle Assembly, Left-front (Incl. Ref 12 - 15)
2	710-0347	2	/P	Hex Screw, 3/8-16 x 1.75
3	710-04012	2		Hex Screw, 1/2-13 x 7.0, Gr5
4	710-04120	2		Hex Screw, 5/8-11 x 11.13, Gr5
5	710-3011	2	/P	Hex Screw, 3/8-16 x 2.25
6	712-0130	2	/P	Nut, Hex Lock, Nylon, 3/8-16, Gr5
7	712-3016	2	/P	Nut, Hex Lock, Nylon, 5/8-11, Gr5
8	712-3022	2	/P	Nut, Hex Lock, 1/2-13
9	723-0618	1		Steering Control Knuckle, RH
	723-0619	1		Steering Control Knuckle, LH
10	732-04176	2	S	Shock Absorber, 2.9 Stroke
11	750-1388	2		Tube, .875 x .50 x 4.75
12	737-04006	1	/P	Grease Fitting
13	741-0758	2		Bearing, .63 ID x 1.19 OD
14	741-0762	2		Bushing, Steering
15	750-1357	1		Spacer, .645 ID x 1.063 OD
16	607-0037	1	S	Front Bumper Assembly
17	710-0514	6	/P	Hex Screw, 3/8-16 x 1.0
18	736-0300	4	S	Flat Washer, .406 x .875 x .059
19	710-3181	2	/P	Hex Screw, 1/2-13 x 1.50, Gr5
20	731-04029	2		Dust Cap
21	736-04019	2		Flat Washer, .531 x 1.25 x .181
22	634-0350	2	S	Wheel Assembly, 22.5 x 10 x 8, Turf
23	731-04406	1	S	Panel Assembly, Right Fender, Yellow
24	731-04407	1	S	Panel Assembly, Left Fender, Yellow
25	731-04749	1	S	Panel Assembly, Hood, Yellow
26	710-0376	14	/P	Hex Screw 5/16-18 x 1.00 Gr 5
27	710-3008	2	/P	Hex Screw, 5/16-18 x .75
28	736-04004	6		Flat Washer, .350 x 1.25 x .06
29	735-04003	2		Mud Flap
30	736-0356	14	S	Washer, Bell, .39 x 1.38 x .062
31	736-0400	6	S	Flat Washer, .194 x .62 x .063
32	625-04017	2	S	Headlamp Assembly
33	707-04165	1	S	Bracket, Hood Mounting
34	711-04139	1		Rod, Hood Mounting
35	712-0324	4	/P	Nut, Hex Lock, 1/4-20
36	714-0101	1	S	Cotter Pin, Internal, 1.42
37	736-3020	4	S	Washer, Flat, .271 x .63 x .065
38	710-3015	4	/P	Hex Screw, 1/4-20 x .75
39	607-04062	1	S	Dash Support Frame Assembly
40	607-04065	1	S	Upper Dash Frame Assembly
41	712-0703A	12	/P	Insert Nut, 5/16-18
42	710-0216	6	/P	Hex Screw, 3/8-16 x .75
43	710-0599	7	/P	Screw, Self-tapping, 1/4-20 x .5
44	731-04016	2		Suspension Bumper

430 4x2 Utility Vehicle (37AR430-710)
Labels

Page 43 of 58

777S32162
RIGHT SIDE ON CARGO BOX
ON BACK OF LOAD GUARD




777S32159
LEFT SIDE ON CARGO BOX
ON BACK OF LOAD GUARD




777I22123
ON SHIFT BRACKET,



777S32055
LEFT SIDE OF CARGO BOX
ON FRONT PANEL



777S32158
DRIVERS SIDE FENDER



777D06804



777D06799
REAR FENDER




777D06065




777I22099
BETWEEN SEATS
ACROSS BOTTOM OF CARGO BED


Operating Weight	Gross Vehicle Weight
1088 Lb. / 481 KG Includes Battery and Fluids.	2258 Lb. / 1026 KG Includes Operating IVL and Total Load Capacity.
Total Load Capacity - MAX. 1,200 Lb. (Includes 200 Lb. / 91 KG operator; 200 Lb. / 91 KG passenger and 800 Lb. / 362 KG cargo box capacity.)	



777I22044
UNDER THE HOOD,
ON THE DRIVERS SIDE PANEL



777I22113
UNDER THE HOOD,
NEAR THE RELAY CENTER



777D06803
DRIVERS RIGHT SIDE



777D06802
DRIVERS LEFT SIDE




777D06066



777I22098




777S32157
PASSENGER SIDE FENDER




777D07435
TOP RIGHT, BOTTOM LEFT



777D07436
TOP LEFT, BOTTOM RIGHT



777D07434
MID GRILL




777I22082



777I22263



777I22097



777I22131




430 4x2 Utility Vehicle (37AR430-710)
Labels

Page 44 of 58

Ref #	Part Number	Qty	S/P/F	Description
777S32162	777S32162	1		LABEL-TOW LOAD
777S32159	777S32159	1		LABEL-BED LOAD
777I22123	777I22123	1		LABEL-MANUAL SHAFT
777S32055	777S32055	1		LABEL-BED LOAD
777S32158	777S32158	1		LABEL-ROLL & FALL
777D06804	777D06804	1		LABEL-HOOD
777D06799	777D06799	1	S	LABEL-TAIL GATE
777S32241	777S32241	1		LABEL-HOT SURFACE
777D06065	777D06065	1		LABEL-GRILLE LOGO
777I22044	777I22044	1		LABEL-FUSE CHART
777I22113	777I22113	1		LABEL-RELAY CHART
777I22099	777I22099	1		LABEL-OPERATING WGHT
777D06803	777D06803	1		LABEL-RIGHT SIDE BED
777D06802	777D06802	1		LABEL-LEFT SIDE BED
777D06066	777D06066	1		LABEL-POWERED BY
777I22082	777I22082	1		LABEL-INST PANEL
777I22263	777I22263	1		LABEL
777I22098	777I22098	1		LABEL-FWD N REV
777D07435	777D07435	1	S	LABEL-GRILLE RECESS
777D07434	777D07434	1	S	LABEL-GRILLE RECESS
777D07436	777D07436	1	S	LABEL-GRILLE RECESS
777S32157	777S32157	1		LABEL-RIDER FALL
777I22131	777I22131	1		LABEL-SHIFT FAULT
777I22101	777I22101	1		LABEL-DIFF LOCK
777I22097	777I22097	1		LABEL-PARKING BRAKE

430 4x2 Utility Vehicle (37AR430-710)
Pedals And Dash

Page 45 of 58




430 4x2 Utility Vehicle (37AR430-710)
Pedals And Dash

Page 46 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	625-04006	1	S	Instrument Panel
2	725-04000	1	S	Switch, Key
3	725-04006	2		Rocker Switch
4	725-04060	1	S	Switch, Green
5	725-04061	1	S	Switch, Yellow
6	725-04062	1	S	Switch, Red
7	725-04204	1		Accessory Harness, Diff Lock
8	731-1346	1		Nut, Ignition Switch, 5/8-32
9	731-1347	1		Cap, Ignition Switch
10	725-2003	1		Power Receptacle, 12V
11	726-0293	1		Nut, Retainer, 1/8
12	731-04010	2		Switch
13	731-04023	2		Plug, Horn Switch
14	731-04621	1	S	Dash Panel
15	725-04005	1	S	Hour Meter w/ Retainer Clip
16	607-04044	1		Lever , Parking Brake
17	607-04076	1		Pedal Assembly, Brake
18	607-04082	1		Pedal Assembly, Throttle
19	607-04083	1		Pedal Arm Assembly, Throttle
20	707-04206	1		Plate, Brake Switch
21	710-04030	2		Screw, Hi-Lo, 1/4-20 x .5
22	736-0463	2	S	Washer, Flat .25 x .630 x .0515
23	710-0809	2		Screw, Self-Tapping, 1/4-20x1.25
24	710-0875	3		Screw, Self-tapping, 1/4-20, .75
25	710-1237	2		Screw, Self-tapping, #10-32 x .625
26	710-3168	2	/P	Bolt, Carriage, 3/8-16 x 1.0
27	711-04067	1	S	Pin, Clevis .50 x 3.25
28	711-1765	1		Rod, Brake Lock
29	712-0324	1	/P	Nut, Hexlock, 1/4-20 GR 8
30	712-0431	2	S	Nut, Flange Lock, 3/8-16
31	735-3049	1	S	Pad, Brake Pedal
32	714-0147	3	/P	Pin, Cotter, .125 x 1.75
33	714-0127	2	/P	Pin, Cotter, 1/16
34	732-1187	1		Spring, Extension, .637 x 2.972
35	720-04001	1	/P	Knob, Ball
36	721-3049	1	/P	Cover, Protective
37	725-1657A	1	S	Snap Mount Switch, Interlock

430 4x2 Utility Vehicle (37AR430-710)
Rear Fenders And Cargo Bed

Page 47 of 58




430 4x2 Utility Vehicle (37AR430-710)
Rear Fenders And Cargo Bed

Page 48 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	607-04028	1	S	Tailgate Assembly
2	607-04074	1	S	Bed Assembly
3	710-0599	4	/P	Screw, Self-tapping, 1/4-20 x 0.500
4	712-0130	2	/P	Nut, Nylon Hex Lock, 3/8-16
5	714-0104	8	S	Cotter Pin, .072 Dia x 1.13
6	720-04036	4		Plug Cap
7	731-04016	4		Bumper, Extension Suspension
8	732-0306	4	S	Compression Spring, .406 x .531 x
9	735-0271	4	S	Bumper, .62Dia x .3
10	736-0162	2	/P	Washer, Flat, .64 ID x 1.0 x .12
11	736-3008	2	S	Washer, Flat, .344 x .750 x .120
12	736-3010	4	/P	Washer, Flat, .407 x .812 x .135
13	738-3056	2	S	Screw, Shoulder, 1/2 x 2.5
14	746-0968	2		Cable, Lift 16.16 LG
15	747-1116	4	/P	Handle, Deck Release
16	748-0331	2	S	Spacer, Shoulder .625 Dia x .324 Dia
17	707-04060	1		Bracket, Bed Latch Base
18	710-04166	2	/P	Stud, Ball 5/16-18
19	710-3025	1	/P	Hex Screw, 5/16-18 x .625, Gr5
20	712-0264	2		Nut, Acorn 1/4-20 w/o Lock
21	712-0324	2	/P	Nut, Hex Lock, 1/4-20
22	712-0703A	3	/P	Nut, Insert 5/16-18
23	726-04005	1		Latch
24	728-0123	4	S	Pop Rivet, 3/16
25	731-04174	1		Handle, Bag w/Screw
26	732-04109	1	S	Spring, Gas .91 Stroke
27	736-0176	2	S	Washer, Flat .265 x .938 x .120
28	736-0231	2	S	Washer, Flat .344 x 1.125 x .120
29	741-0248	4		Flange Bearing, .51
30	728-04004	10	S	Pop Rivet, .188
31	731-04408	1	S	Fender, Rear RH, Yellow
32	731-04409	1	S	Fender, Rear LH, Yellow
33	736-0400	10	S	Flat Washer, .194 x .62 x .063

430 4x2 Utility Vehicle (37AR430-710)
Seats And Fuel Tank

Page 49 of 58




430 4x2 Utility Vehicle (37AR430-710)
Seats And Fuel Tank

Page 50 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	607-0034	1		Bracket Assembly, Fuel Tank
2	631-04097	1		Tank Assembly, Fuel (Incl. valve, grommets, cap, switch & fitting)
2	16910-ZE8-015	1		Filter, Fuel Not shown
3	710-3008	1	/P	Hex Screw, 5/16-18 x .75
4	711-1768	1		Hold-down Rod, Fuel Tank
5	712-0265	1	/P	Sems Nut, 5/16-18
6	712-3027	1	S	Nut, Flange Lock, 1/4-20
7	721-04006	1		Gasket, Fuel Tank (11")
8	726-0205	1	/P	Clamp, Hose
9	736-0159	1	S	Washer, .349 x .879 x .063
10	751-0852	1	S	Cap, Fuel
11	707-04061A	1	S	Plate, Seat, LH
12	712-3004A	8	/P	Nut, Flange Lock, 5/16-18, Gr5
13	750-0258	2	/P	Spacer, Seat
14	757-0389	1		Track Assembly, Seat
15	757-04008A	2	/P	Seat
16	735-0271	6	S	Bumper
17	738-0140	4	S	Shoulder Screw, .435 x .178-5/16
18	707-04062A	1	S	Plate, Seat, RH
19	710-0376	4	/P	Hex Screw, 5/16-18 x 1.0
20	649-04002	2	S	Tube, Grab Handle
21	710-0216	4	/P	Hex Screw, 3/8-16 x .75
22	712-0130	4	/P	Nut, Hex Lock Nylon, 3/8-16

430 4x2 Utility Vehicle (37AR430-710) Steering

Page 51 of 58




430 4x2 Utility Vehicle (37AR430-710)
Steering

Page 52 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	631-04100	1		Dash Assembly
2	707-04252	2		Hood Mounting Plate
3	707-04337	1	S	Cover, Bed-to-Seat
4	710-0176	2	/P	Hex Screw, 5/16-18 x 2.75
5	710-3015	1	/P	Hex Screw, 1/4-20 x .75, Gr5
6	712-0324	1	/P	Hex Lock Nut, Nylon, 1/4-20
7	712-0429	2	S	Hex Lock Nut, Nylon, 5/16-18
8	721-04070	1		Trim, Bulb Seal, 1/4
9	723-3069	4	S	Foot Pad, Abrasive
10	728-0173	10	S	Rivet, Pop, .187
11	728-04004	4	S	Rivet, Pop, .188
12	731-04033A	1	S	Container, Bulkhead
13	731-04225	1	S	Panel, Shift Cover
14	731-2648	1		Console, Cup Holder
15	735-04038	2	S	Handle, Latch
16	735-0199A	4	S	Bumper, Rubber
17	736-0159	2	S	Washer, Flat, .349 x .879 x .063
18	736-0400	4	S	Washer, Flat, .194 x .62 x .063
19	736-0463	1	S	Washer, Flat, .25 x .630 x .0515
20	707-04278	1		Plate, Console Support
21	710-0599	4	/P	Screw, Self-tapping, 1/4-20 x .5
22	617-0075A	1	S	Gear Assembly, Steering
23	707-04074	1	S	Steering Bracket, Sector Clamp
24	707-0417	1		Bracket, Steering Mounting
25	710-0514	4	/P	Hex Screw, 3/8-16, 1.00, Gr5
26	710-0520	3	/P	Hex Screw, 3/8-16, 1.50, Gr5
27	712-0431	6	S	Nut, Flange Lock, 3/8-16
28	735-0801	1		Grommet, Steering Shaft
29	741-0763	1		Bushing, Rubber
30	631-04008	1	S	Wheel, Steering
31	710-1880	1	/P	Hex Screw, 5/16-18, .75, Gr5, Patch
32	710-3008	4	/P	Hex Screw, 5/16-18, .75, Gr5
33	711-04231	1		Shaft, Steering, 5/8 Spline
34	711-1774	2		Collar, .75
35	712-0130	1	/P	Nut, Hex Lock Nylon, 3/8-16
36	712-3004A	4	/P	Nut, Flange Lock, 5/16-18
37	731-04532	1	S	Cover, Steering Wheel
38	731-0954	1	S	Bellow, Steering, 4.75 Lg
39	736-0275	1	S	Washer, Flat, .344 x .688 x .065
40	741-04000	2		Bearing, Flange, .75 ID, Self-Aligning

430 4x2 Utility Vehicle (37AR430-710)
Transmission - Brake Assembly

Page 53 of 58




430 4x2 Utility Vehicle (37AR430-710)
Transmission - Brake Assembly

Page 54 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	DC-012HH128	1		Seal, Oil
2	DC-012TA350-1	1	S	Assembly, Tube
3	DC-070HM282	12		Screw, Flange Head
4	DC-A20HM102	8		Screw, Socket Head
5	DC-A20HH101	2		Seal, Oil
6	DC-536A1	2		Ring, Retainer
7	DC-585907	2		Ass'y, Bearing, Tapered Roller
8	DC-018WD119	1		Assembly, Brake RH
8	DC-4170693P	1	/P	Brake Shoes (per axle) Not shown
9	DC-515A7	2		Seal, Oil
10	DC-012HN126	8		Washer, Flat
11	DC-012HN125	8		Nut, Lock
12	DC-012SR166-1	2		Shaft, Axel
13	DC-012HM138-1	10		Bolt, Wheel
14	DC-012WA127	2		Drum, Brake
15	DC-34391-2	2		Nut, Spring
16	DC-012HM110-1	11		Screw, Flange Head
17	DC-012HM110-2	2		Screw, Flange Head
18	DC-012HN140	1		Vent
19	DC-018WD118	1		Assembly, Brake LH
19	DC-4170693P	1	/P	Brake Shoes (per axle) Not shown
20	DC-012HN120	13		Nut, Lock
21	DC-41356	1		Plug, Rubber
22	DC-012TA349-1	1	S	Assembly, Tube
23	DC-012TF238	1		Bracket, Differential Lock Actuator
24	DC-012HM137	6		Screw, Flange Head
25	DC-012SR149-4	1		Shaft, Axel

430 4x2 Utility Vehicle (37AR430-710)
Transmission - Differential Lock Assembly

Page 55 of 58




430 4x2 Utility Vehicle (37AR430-710)
Transmission - Differential Lock Assembly

Page 56 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	DC-585994	1	F	Bearing, Ball
2	DC-012GS216	1	F	Gear, Helical (Ring)
3	DC-012DA118X	1	/P	Assembly, Differential
4	DC-012HN138	4		Nut, Lock
5	DC-012HM128	4		Bolt, Hex
6	DC-012HD142	1	F	Bearing, Ball
7	DC-012DC123	1	/P	Flange, Half, Differential
8	DC-012HM136	6		Screw, Socket Head
9	DC-026HS104	1		Gear, Clutch Differential Lock
10	DC-012CH119	1		Housing, Differential Lock
11	DC-3112	1		Seal Oil
12	DC-012SV117X	1		Assembly, Shift Shaft
13	DC-314004	1		Lever, Actuating
14	DC-4150221	1		Screw, Hex Head
15	DC-4150223	1		Nut, Lock
16	DC-012HM110-2	2		Screw, Flange Head
17	DC-012HN140	1		Vent
18	DC-012HM110-1	11		Screw, Flange Head

430 4x2 Utility Vehicle (37AR430-710)
Transmission - Input Shaft Assembly

Page 57 of 58



430 4x2 Utility Vehicle (37AR430-710)
Transmission - Input Shaft Assembly

Page 58 of 58

Ref #	Part Number	Qty	S/P/F	Description
1	DC-012CH254-3	1	F	Housing, Axle, w/Idler Shaft
2	DC-012CH240	1	F	Housing, Axle, Finished
3	DC-012LK133	1		Kit, Detent
4	DC-012HH122	1		Seal, Oil
5	DC-012GV164X	1		Assembly, Actuator
6	DC-012SV112X	1		Assembly, Shift Rod
7	DC-012HH128	3		Seal, Oil
8	DC-585965	1	F	Bearing, Ball
9	DC-012GS307	1	F	Shaft, Input
10	DC-012LK134	2		Kit, Shim Use Shim(s) as required to maintain proper clearances.
11	DC-012HD111	1	F	Bearing, Ball
12	DC-012HN120	13		Nut, Lock
13	DC-41356	1		Plug, Rubber
14	DC-012HD129	2	F	Bearing, Ball
15	DC-012HS121	2		Spacer, Flat,
16	DC-012GS202X	1	F	Gear Assembly, Forward
17	DC-012GS200	1		Shaft, Intermediate
18	DC-012GS204X	1	F	Gear Assembly, Reverse
19	DC-012GS215	1	F	Gear, Helical (Pinion)
20	DC-012HR128	1		Ring Retaining
21	DC-012HP120	2		Pin, Dowel
22	DC-012HM110-1	11		Screw, Flange Head
23	DC-012HM110-2	2		Screw, Flange Head
24	DC-012HN140	1		Vent
25	DC-012GS302	1		Gear, Clutch
26	DC-012HS126	1		Washer, Thrust
27	DC-012GS207X	1	F	Gear, Assembly, Idler
28	DC-012HS125	1		Washer, Thrust