


For Parts Call 606-678-9623 or 606-561-4983

Expand~~o~~it™
Attachment System


PARTS LIST



Model Nos. UT15520 and UT15520A

www.mymowerparts.com

PRUNER – MODEL NO. UT15520




PRUNER – MODEL NO. UT15520

PARTS LIST

NO.	PART NO.	DESCRIPTION	QTY.
1	A07591	OIL CAP	1
2	82538	SCREW	4
3	PA01332	OIL TANK COVER ASSEMBLY	1
4	983578-001	OIL COVER GASKET	1
5	PA01487	PICK UP TUBE ASSEMBLY	1
6	983884-001	GEAR HOUSING	1
7	PS05448	SCREW (1/4-20 X 1 in.)	1
8	PS05449	SCREW (10-24 X 1/2 in.)	1
9	983887-001	PINION ASSEMBLY	1
10	PS04873	RETAINING RING	1
11	PA01335B	LOWER DRIVE SHAFT ASSEMBLY	1
12	PS02155	HANGER CAP	1
13	PA01334B	INTERMEDIATE DRIVESHAFT ASSEMBLY	1
14	07255	STRAP HANGER	1
15	983886-001	GEAR ASSEMBLY	1
16	PS04872	RETAINING RING	1
17	PS04540	WORM GEAR	1
18	PS04551	OIL PUMP HOUSING	1
19	PS01605	TRUSS HEAD SCREW	2
20	PS04556	SPROCKET	1
21	04939A	CUPPED WASHER	1
22	08981	E-RING	1
23	PA01333	BAR CLAMP ASSEMBLY	1
24	81196	HEX NUT (5/16-18)	1
25	06842	GUIDE BAR ADJUSTMENT PIN	1
26	69599	RETAINING RING	1
27	PS04974	GUIDE BAR PLATE	1
28	06844	GUIDE BAR ADJUSTMENT SCREW	1
29	983606-001	SCABBARD	1
30	UP08687	GUIDE BAR	1
31	PS04554	BAR PAD PLATE	1
32	PS04552	OIL PUMP CAM PIN	1
33	PS04548	GEAR AND PLUNGER	1
34	983888-001	OIL PUMP SEAL	1
35	UP08688	CHAIN	1
36	983608-001	WARNING LABEL	1
37	944701	HARNESS	1
38	09207	COMBINATION WRENCH	1
39	PSO5170	8 oz. BOTTLE OF OIL	1
	PSO4565	OPERATOR'S MANUAL	1
	PS04565R	REPAIR SHEET	1
	9-03		

EXPAND-IT PRUNER – MODEL NO. UT15520A



EXPAND-IT PRUNER – MODEL NO. UT15520A

PARTS LIST

NO.	PART NO.	DESCRIPTION	QTY.
1	A07591	OIL CAP	1
2	82538	SCREW	4
3	PA01332	OIL TANK COVER ASSEMBLY	1
4	983578-001	OIL COVER GASKET	1
5	PA01487	PICK UP TUBE ASSEMBLY	1
6	983884-001	GEAR HOUSING	1
7	PS05448	SCREW (1/4-20 X 1 in.)	1
8	PS05449	SCREW (10-24 X 1/2 in.)	1
9	983887-001	PINION ASSEMBLY	1
10	PS04873	RETAINING RING	1
11	PA01335C	LOWER DRIVE SHAFT ASSEMBLY	1
12	PS02155	HANGER CAP	1
13	PA01334C	INTERMEDIATE DRIVESHAFT ASSEMBLY	1
14	07255	STRAP HANGER	1
15	983886-001	GEAR ASSEMBLY	1
16	PS04872	RETAINING RING	1
17	PS04540	WORM GEAR	1
18	PS04551	OIL PUMP HOUSING	1
19	PS01605	TRUSS HEAD SCREW	2
20	PS04556	SPROCKET	1
21	04939A	CUPPED WASHER	1
22	08981	E-RING	1
23	PA01333	BAR CLAMP ASSEMBLY	1
24	81196	HEX NUT (5/16-18)	1
25	06842	GUIDE BAR ADJUSTMENT PIN	1
26	69599	RETAINING RING	1
27	PS04974	GUIDE BAR PLATE	1
28	06844	GUIDE BAR ADJUSTMENT SCREW	1
29	983606-001	SCABBARD	1
30	UP08687	GUIDE BAR	1
31	PS04554	BAR PAD PLATE	1
32	PS04552	OIL PUMP CAM PIN	1
33	PS04548	GEAR AND PLUNGER	1
34	983888-001	OIL PUMP SEAL	1
35	UP08688	CHAIN	1
36	983608-001	WARNING LABEL	1
37	944701	HARNESS	1
38	09207	COMBINATION WRENCH	1
39	983877-001	8 oz. BOTTLE OF OIL	1
	983000-218	OPERATOR'S MANUAL	1
	983000-218R	REPAIR SHEET	1
	9-03		