


18 Volt Cordless Line Trimmer UT-31810
Cordless Line Trimmer-18 Volt



Ref #	Part Number	Qty	S/P/F	Description
1	6625001	2		SCREW (M35 X 8 mm PAN HD) Purchase Locally
2	300180007	1	/P	SPOOL ASSEMBLY
3	230090001	1		MOTOR/INSERT SHAFT ASSEMBLY
4	200205001	1		FRONT MOTOR HOUSING ASSEMBLY
5	690439001	2		MOTOR MOUNT
6	300908001	1		TUBING
7	200207001	1		COLLECTING CAP ASSEMBLY
8	300909006	1		TUBING
9	200206001	1		FRONT HANDLE ASSEMBLY
10	660206001	14		SCREW (M35 X 18 mm) Purchase Locally
11	5205506	1		TRIGGER
12	670942001	1	S	TRIGGER SPRING
13	200181012	1	/P	HANDLE HOUSING ASSEMBLY
14	270011077	1		SWITCH ASSEMBLY
15	5912701	1		SAFETY LEVER
16	1323701	1		BATTERY
17	1425701	1	S	BATTERY CHARGER
18	300906002	1		GUARD COVER ASSEMBLY
19	6796001	1		SPRING WASHER
20	670703001	1		COMPRESSION SPRING
21	940260078	1		DATA PLATE
22	940263035	1		LOGO PLATE
23	940230024	1		WARNING LABEL
24	940230025	1		WARNING LABEL, ICON
25	6623501	1		MOUNTING SCREW
26	940230043	1		WARNING LABEL (LOWER GUARD)
	983000-010	1	S	OPERATOR'S MANUAL
	983000-010R	1		REPAIR SHEET

18 Volt Cordless Line Trimmer UT-31810
Wiring Diagram

