


HK18 String Trimmer UT-18003
A-98550-36 Carburetor

Ref #	Part Number	Qty	S/P/F	Description
1	A9855137	1		Repair Kit
2	A9855137	1		Repair Kit
3	A9855137	1		Repair Kit
4	A9855137	1		Repair Kit
5	A9855137	1		Repair Kit
6	A9855137	1		Repair Kit
7	A9855137	1		Repair Kit
8	A9855137	1		Repair Kit
9	A9855137	1		Repair Kit
10	A9855137	1		Repair Kit
11	A9855137	1		Repair Kit
12	A9855137	1		Repair Kit
13	A9855137	1		Repair Kit
	A9855138	1		Gasket/Diaphragm Kit
14	A9855137	1		Repair Kit
	A9855138	1		Gasket/Diaphragm Kit
15	A9855137	1		Repair Kit
	A9855138	1		Gasket/Diaphragm Kit
16	A9855137	1		Repair Kit
	A9855138	1		Gasket/Diaphragm Kit
17	A9855137	1		Repair Kit
	A9855138	1		Gasket/Diaphragm Kit
18	A9855137	1		Repair Kit
	A9855138	1		Gasket/Diaphragm Kit


HK18 String Trimmer UT-18003
Boom & Head



HK18 String Trimmer UT-18003
Boom & Head

Page 4 of 9

Ref #	Part Number	Qty	S/P/F	Description
1	9855090	1		LEAD- Wire
	A9855072	1		CLUTCH CASE ASSEMBLY
2	9855074	1		DRUM- Clutch
3	9855109	1		RING- Stop
4	9855075	1		BEARING- Ball
5	9855076	1	/P	RING- Stop
6	9855073	1		CASE- Clutch
7	9855079	1		WASHER- Wave
8	9855078	1		SCREW
9	9855080	1		WASHER- Flat
10	9855077	1		BOLT
11	9855081	4		BOLT
12	9855085	1		GRIP
13	9855089	1		LEVER Throttle
14	9855087	1		RING- Hanger
15	9855088	1		SPACER
16	9855130	1		SCREW
17	9855086	1		HANGER
18	9855091	1		U-HANDLE
19	9855112	1		WASHER- Spring
20	9855113	1	S	NUT
21	9855081	2		BOLT
22	9855092	1		BRACKET- Top
23	9855093	1		BRACKET- Upper
24	9855094	1		SPACER
25	9855095	1		BRACKET- Lower
26	A9855082	1		DRIVE SHAFT HOUSING
27	9855084	1		SHAFT- Drive
28	A9855098	1		GEAR CASE ASSEMBLY
29	9855115	1		SCREW
30	9855114	1		SCREW
31	9855080	1		WASHER- Flat
32	9855110	2		BOLT
	9855112	2		WASHER- Spring (see Fig. 19)
	9855113	2	S	NUT (see Fig. 20)
33	9855118	2		SCREW
34	9855117	2		STAY
35	9855116	1		DEFLECTOR
36	9855119	1		SHIELD
37	9855120	3		SCREW
38	9855121	1		FLANGE- Upper
39	9855122	1		FLANGE- Lower
40	9855123	1		WASHER- Special
41	9855124	1		NUT- Blade
42	A9855136	1		STRING HEAD ASSEMBLY
43	98512	1		BLADE- Brush (8" 4T accessory)
44	9855097	1		HARNESS
45	A9855128	1		TOOL SET




Ref #	Part Number	Qty	S/P/F	Description
1	9806036	2		PIN- Clutch
2	9806038	1		SPRING- Clutch
3	9806037	2		SHOE- Clutch
4	9806039	2		WASHER
5	9855286	4		SCREW- (M5 x 16)
6	9855288	1		BRACKET- Tank
7	9855025	1		BRACKET- Cable
8	9806080	1		NUT- (M6 mm)
9	9806082	1		WASHER- Spring
10	9806081	1		WASHER
11	9855029	1		FLYWHEEL
12	9855033	1		TUBE
13	9855030	1		COIL- Ignition
14	9855293	2		BOLT- (M5 x 24)
15	9806043	2		PIN- Dowel
16	9855017	1		CRANKCASE
17	9855362	1		SCREW- (M4 x 8)
18	9806070	4		DAMPER
19	9855290	1		DAMPER
20	A9855021	1		FUEL TANK (Incl. item #22 & 23)
21	9855027	1		BAND- Tank
22	9806066	1		CAP- Tank
23	9806067	1		BREATHER
24	9855028	1		DAMPER
25	A9855277	1		FILTER ASSEMBLY
26	9806063	1		CLIP
27	9855279	1		TUBE
28	9855022	1		JOINT
29	9855282	2		CLIP
30	9855023	1		TUBE
31	9855007	1		SCREW (M4 x 14)
32	9855005	1		CAP- Air cleaner
33	9855006	1		PLATE- Air Cleaner
34	9855003	1		ELEMENT
35	9855004	1		PLATE- Air cleaner
36	9855008	2		BOLT
37	9855450	2		WASHER- Spring
38	9855002	1		CASE- Air filter
39	9855009	1		SPACER
40	9855010	1		SCREEN
41	9855011	1		GASKET
42	A9855036	1		CARBURETOR ASSEMBLY
43	9855132	1		CABLE- Throttle
44	9855011	1		GASKET
45	9855019	1		INSULATOR
46	9855271	1		GASKET
47	9855034	4		SCREW (M5 x 18)
48	9855026	1		BRACKET- Tank
49	9855035	1		GASKET
50	9806080	1		NUT- (M6 MM)
51	9806081	1		WASHER- (M6)
52	9855018	1		CRANKCASE
53	9806045	4		SCREW

HK18 String Trimmer UT-18003
Engine & Peripherals

Page 7 of 9

Ref #	Part Number	Qty	S/P/F	Description
54	9855268	2		PIN- Dowel
55	9855266	1		GASKET
56	9806048	2		SEAL- Oil
57	9806047	1		BEARING- Ball (6000C3)
58	A9806029	A/R		SHIM ASSEMBLY
59	A9855016	1		CRANK SHAFT ASSEMBLY
60	9855263	1		BEARING- Plain
61	9806083	1		KEY
62	9806046	1		BEARING- Ball (6200C3)
63	A9855258	1		PISTON ASSEMBLY
64	9855261	2		RING- Snap
65	9855259	1		RING- Piston
66	9855249	1		GASKET
67	9855032	1		CAP- Plug
68	9806091	1		SPRING
69	63710S	1	S/P	SPARK PLUG (DJ7Y)
70	9855248	1		CYLINDER
71	9855250	2		SCREW
72	9806022	4		SCREW (M4 x 10)
73	9855294	1		CLAMP
74	98125	1		LABEL
75	9855284	1		SHROUD
76	9855256	1		GASKET
77	A9855012	1		MUFFLER ASSY
78	9855133	1		SPARK ARRESTOR
79	9855131	1		HOUSING- Fan
80	9855257	1		STUD
81	9806017	2		WASHER
82	9806016	2		NUT
83	9855013	1		COVER- Muffler
84	9806017	1		WASHER
85	9806078	1		IGNITER
	A98059	1		PULLER- Rotor (Accessory)



HK18 String Trimmer UT-18003
 Recoil Starter Assy.

Page 9 of 9

Ref #	Part Number	Qty	S/P/F	Description
1	A9855068	1		RECOIL STARTER ASSEMBLY
2	9855071	1		WASHER
3	9855330	1		HANDLE- Recoil starter
4	9855329	1		ROPE (3 x 890 MM)
5	9855328	1		SPRING- Spiral
6	9855327	1		REEL- Recoil
7	9855326	1		WASHER (M5)
8	9855070	1		SCREW (M5 x 8)
9	A9855069	1		PULLEY
10	9855301	1		PAWL- Recoil
11	9855303	1		SPRING- Return
12	9855302	1		E-RING
13	9855034	1		SCREW
14	98528	1		DECAL