


For Husqvarna Parts Call 606-678-9623 or 606-561-4983




IPL, Rider 16 H, 2000-02, 106 25 74-62

Rider 16 H (Non-USA)

Spare parts	Replaces	
Ersatzteile	Ersetzt	
Pièces détachées	Remplace	
Reserve onderdelen	Vervangt	
Repuestos	Reemplaza	
Reservdelar	Ersätter	106 25 74-61


106 25 74-62

A




B

*compl 506 98 46-02




XXX XX XX-XX = New part

D 15,5 hp B & S Diamond plus




xxx xx xx-xx = New part

E




xxx xx xx-xx = New part


G




F






H




XXX XX XX-XX = New part






C




xxx xx xx-xx = New part

K




X BioClip 90




xxx xx xx-xx = New part

T Rear 97, BioClip 103




V Side 97



xxx xx xx-xx = New part

J *compl 506 75 11-01 Yttre. Outer. Exterior. Äusser. Ulko.
 *compl 506 75 11-04 Mitten. Centre. Centre. Zentrum. Keski.

Rear 97




xxx xx xx-xx = New part

U

*compl 506 75 11-01 Yttre. Outer. Exterior. Äusser. Ulko.
 *compl 506 75 11-04 Mitten. Centre. Centre. Zentrum. Keski.

Side 97




xxx xx xx-xx = New part

S

*compl 506 75 11-07 (a)
*compl 506 75 11-06 (b)


BioClip 103



(a) = Yttre. Outer. Exterieur. Äusser. Ulko.
(b) = Mitten. Center. Centre. Zentrum. Keski.

xxx xx xx-xx = New part

Y BioClip 90



xxx xx xx-xx = New part