


For Husqvarna Parts Call 606-678-9623 or 606-561-4983



IPL, 232L, 232R, 232RD, 232RJ, 235R, 240L, 240RJ, 2000-04, 106 26 29-61

# 232L,R,RD,RJ, 235R, 240L,240RJ

Spare parts

Ersatzteile

Pièces détachées


Reserve onderdelen

Repuestos


Reservdelar




106 26 29-61

**A**




**B**








**F**

232R/RD  
235R




**G**

232L  
240L,RJ



\*compl 503 78 05-03


**H**




|          |              |
|----------|--------------|
| (235 R)  | 502 21 26-01 |
| (232 R)  | 502 21 26-02 |
| (232 L)  | 502 21 26-04 |
| (232 RD) | 502 21 26-03 |
| (232 RJ) | 502 21 26-08 |
| (240 L)  | 537 03 36-01 |
| (240RJ)  | 537 03 36-09 |

**J**


\*compl 503 72 80-01 (232)  
\*compl 503 69 46-01 (235, 240))




**K**




**L**




**M**



**N**




**P**




**Q**

235




**R**

232  
240




**S**

\*compl 503 79 06-01




**T**


\*compl 502 18 95-01



**U**



**V**



# For Husqvarna Parts Call 606-678-9623 or 606-561-4983

| Part number  | Square | Note | Part number  | Square | Note | Part number  | Square | Note | Part number  | Square | Note |
|--------------|--------|------|--------------|--------|------|--------------|--------|------|--------------|--------|------|
| 501 27 82-01 | P      |      | 503 11 70-01 | U      |      | 503 74 53-01 | V      |      | 537 04 24-03 | P      |      |
| 501 46 69-01 | U      |      | 503 16 13-02 | L      |      | 503 75 00-01 | EG     |      | 537 05 27-01 | NU     |      |
| 501 46 84-01 | U      |      | 503 20 02-10 | C      |      | 503 75 34-01 | R      |      | 537 07 71-01 | G      | N    |
| 501 46 85-01 | U      |      | 503 20 02-20 | QR     |      | 503 75 84-01 | QR     |      | 725 23 79-51 | C      |      |
| 501 46 87-01 | U      |      | 503 20 02-25 | BCQR   |      | 503 75 89-01 | Q      |      | 725 23 81-51 | DEG    |      |
| 501 48 54-02 | S      |      | 503 20 02-30 | AL     |      | 503 77 39-01 | V      |      | 725 53 72-55 | P      |      |
| 501 60 02-03 | V      |      | 503 20 02-35 | F      |      | 503 77 53-01 | T      |      | 731 23 14-01 | ABN    |      |
| 501 66 61-01 | U      |      | 503 20 25-16 | S      |      | 503 77 63-01 | V      |      | 731 71 14-51 | N      |      |
| 501 66 78-01 | U      |      | 503 20 29-63 | K      |      | 503 78 04-03 | G      |      | 735 31 11-00 | R      |      |
| 501 76 83-24 | P      |      | 503 21 06-25 | LT     |      | 503 78 05-03 | G      |      | 735 31 14-00 | Q      |      |
|              |        |      |              |        |      |              |        |      |              |        |      |
| 502 28 59-01 | V      |      | 503 21 07-16 | BV     |      | 503 78 51-02 | C      | N    | 735 31 25-10 | R      |      |
| 502 03 10-03 | Q      |      | 503 21 07-22 | FG     |      | 503 78 52-01 | C      |      | 735 31 28-10 | Q      |      |
| 502 03 55-05 | V      |      | 503 21 07-45 | E      |      | 503 79 05-01 | S      | N    | 735 31 31-10 | R      |      |
| 502 04 55-01 | Q      |      | 503 21 29-06 | T      |      | 503 79 06-01 | S      |      | 735 31 33-10 | Q      |      |
| 502 10 30-01 | U      |      | 503 21 44-25 | H      |      | 503 79 41-01 | G      |      | 735 58 08-10 | C      |      |
| 502 10 31-01 | U      |      | 503 21 77-16 | T      |      | 503 79 56-01 | B      |      | 737 44 10-00 | J      |      |
| 502 11 46-02 | V      |      | 503 22 10-11 | S      |      | 503 79 94-01 | V      |      | 738 21 01-10 | Q      |      |
| 502 18 94-02 | L      |      | 503 22 72-01 | P      |      | 503 81 24-01 | S      |      | 738 21 99-00 | R      |      |
| 502 18 94-03 | L      |      | 503 23 01-01 | S      |      | 503 81 29-01 | S      |      | 738 22 01-19 | R      |      |
| 502 18 95-01 | T      |      | 503 23 51-08 | J      |      | 503 82 80-04 | P      |      | 738 22 01-25 | M      |      |
|              |        |      |              |        |      |              |        |      |              |        |      |
| 502 18 95-03 | T      | N    | 503 24 44-01 | S      |      | 503 84 00-02 | P      |      | 738 22 02-19 | Q      |      |
| 502 18 96-01 | A      |      | 503 25 11-01 | M      | N    | 503 84 35-01 | Q      |      | 740 43 15-00 | C      |      |
| 502 18 98-01 | F      |      | 503 28 90-27 | J      |      | 503 88 94-01 | A      |      |              |        |      |
| 502 19 36-01 | Q      |      | 503 41 41-01 | JM     |      | 503 88 95-01 | B      |      |              |        |      |
| 502 19 46-01 | Q      |      | 503 44 32-01 | P      |      | 503 88 96-01 | C      |      |              |        |      |
| 502 19 58-13 | F      |      | 503 52 12-04 | L      |      | 503 88 96-02 | C      |      |              |        |      |
| 502 19 60-01 | DF     |      | 503 52 42-01 | U      |      | 503 89 52-01 | V      |      |              |        |      |
| 502 19 71-01 | A      |      | 503 57 42-01 | U      |      | 503 89 67-01 | U      |      |              |        |      |
| 502 19 84-01 | N      |      | 503 68 64-02 | J      |      | 503 90 46-02 | K      | N    |              |        |      |
| 502 19 86-02 | N      |      | 503 69 46-01 | J      |      | 503 90 47-02 | K      |      |              |        |      |
|              |        |      |              |        |      |              |        |      |              |        |      |
| 502 19 90-03 | F      |      | 503 69 63-01 | QR     |      | 503 90 61-01 | H      |      |              |        |      |
| 502 19 91-05 | F      |      | 503 69 67-01 | R      |      | 503 90 67-01 | M      |      |              |        |      |
| 502 19 92-01 | F      |      | 503 70 07-01 | R      |      | 503 91 07-01 | M      |      |              |        |      |
| 503 79 41-01 | F      |      | 503 70 29-02 | R      |      | 503 91 25-01 | K      |      |              |        |      |
| 502 19 94-01 | F      |      | 503 70 55-01 | R      |      | 503 91 34-01 | M      |      |              |        |      |
| 502 19 97-01 | D      |      | 503 70 80-01 | C      |      | 503 91 39-01 | U      |      |              |        |      |
| 502 20 06-01 | T      |      | 503 71 40-01 | L      |      | 503 91 40-01 | U      |      |              |        |      |
| 502 20 11-01 | N      |      | 503 71 43-01 | B      |      | 503 91 51-01 | U      |      |              |        |      |
| 502 20 31-01 | A      |      | 503 71 43-02 | C      |      | 503 91 54-01 | U      |      |              |        |      |
| 502 20 32-03 | AB     |      | 503 71 48-01 | R      |      | 503 91 57-01 | U      |      |              |        |      |
|              |        |      |              |        |      |              |        |      |              |        |      |
| 502 20 33-01 | A      |      | 503 71 54-01 | C      |      | 503 91 58-01 | U      |      |              |        |      |
| 502 20 38-01 | CDEG   |      | 503 71 63-01 | N      |      | 503 92 23-01 | U      |      |              |        |      |
| 502 20 40-01 | N      |      | 503 71 82-01 | FG     |      | 503 93 66-01 | N      |      |              |        |      |
| 502 20 65-01 | N      |      | 503 72 10-03 | E      |      | 503 98 81-01 | P      |      |              |        |      |
| 502 20 69-01 | F      |      | 503 80 45-01 | E      |      | 503 99 44-01 | U      |      |              |        |      |
| 502 20 88-01 | J      |      | 503 72 12-01 | G      |      | 503 99 45-01 | U      |      |              |        |      |
| 502 21 12-01 | F      |      | 503 72 13-01 | G      |      | 503 99 46-01 | U      |      |              |        |      |
| 502 21 23-01 | N      |      | 503 72 14-01 | G      |      | 503 99 47-01 | U      |      |              |        |      |
| 502 21 26-01 | H      |      | 503 72 15-01 | G      |      | 503 99 48-01 | U      |      |              |        |      |
| 502 21 26-02 | H      |      | 503 72 18-01 | B      |      | 504 13 08-07 | U      |      |              |        |      |
|              |        |      |              |        |      |              |        |      |              |        |      |
| 502 21 26-03 | H      |      | 503 72 24-01 | B      |      | 504 13 09-06 | U      |      |              |        |      |
| 502 21 26-04 | H      |      | 503 72 29-01 | EG     |      | 504 21 00-49 | U      |      |              |        |      |
| 502 21 26-08 | H      |      | 503 72 43-03 | E      |      | 504 21 00-50 | U      |      |              |        |      |
| 502 21 28-04 | M      |      | 503 72 49-01 | V      |      | 505 30 51-25 | T      |      |              |        |      |
| 502 21 32-01 | U      |      | 503 72 77-01 | C      |      | 505 31 67-17 | U      |      |              |        |      |
| 502 21 33-01 | U      |      | 503 72 80-01 | J      |      | 502 11 96-01 | U      |      |              |        |      |
| 502 21 35-01 | U      |      | 503 73 40-01 | V      |      | 505 31 67-54 | U      |      |              |        |      |
| 502 21 37-01 | U      |      | 503 73 41-02 | V      |      | 505 31 67-82 | U      |      |              |        |      |
| 502 21 43-02 | J      |      | 503 73 42-01 | G      |      | 505 52 01-10 | U      |      |              |        |      |
| 502 21 57-01 | L      |      | 503 73 43-01 | G      |      | 505 52 01-25 | U      |      |              |        |      |
|              |        |      |              |        |      |              |        |      |              |        |      |
| 502 21 58-01 | V      |      | 503 73 45-01 | A      |      | 505 52 01-27 | U      |      |              |        |      |
| 502 21 60-01 | V      |      | 503 73 47-02 | B      |      | 506 02 81-01 | U      |      |              |        |      |
| 502 21 70-01 | D      |      | 503 73 58-01 | P      |      | 530 02 98-05 | J      |      |              |        |      |
| 502 21 92-04 | R      |      | 503 73 63-03 | V      |      | 537 00 84-01 | T      |      |              |        |      |
| 502 02 28-02 | V      |      | 503 73 63-04 | V      |      | 537 02 48-01 | N      |      |              |        |      |
| 502 26 23-01 | V      |      | 503 74 16-01 | V      |      | 537 02 76-02 | ABC    |      |              |        |      |
| 502 28 61-01 | AB     |      | 503 74 16-02 | V      |      | 537 03 36-01 | H      |      |              |        |      |
| 502 51 27-01 | V      |      | 503 74 29-01 | V      |      | 537 03 36-09 | H      | N    |              |        |      |
| 503 10 47-01 | U      |      | 503 74 40-01 | V      |      | 537 03 85-01 | S      |      |              |        |      |
| 503 10 87-01 | U      |      | 503 74 50-04 | V      |      | 537 04 24-02 | N      |      |              |        |      |