


22HB 28HBV




1. 1988
Spare parts
Pièces détachées

PARTS LIST NO. 530-067369 - 8/29/88		HUSQVARNA PARTS LIST	BLOWER MODEL: 22HB BLOWER/VAC MODEL: 28HBV
Page No. 1	Replaces None		


A. Carburetor Assembly

⚠ WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



KEY NO.	PART NO.	DESCRIPTION
1	530-035197	Valve Throttle
2	530-035015	Screw-Throttle Valve
3	530-035132	Shaft Ass'y.-Throttle
4	530-035156	Idle Speed Screw
5	530-035138	Spring-Throttle Return
7	530-035200	Spring-High Speed Mixture Needle
8	530-035198	Needle-High Speed Mixture
9	530-035162	* Plug-5/16 Dia. Welch
11	530-035017	Screw-Pump Cover
12	530-035191	Cover-Fuel Pump
13	530-035164	+ *Gasket-Fuel Pump
14	530-035166	+ *Diaphragm-Fuel Pump
15	530-035178	Screen-Fuel Inlet
18	530-035007	Ring-Throttle Retainer
19	530-035106	* Valve-Inlet Needle
20	530-035139	* Spring-Metering Lever
21	530-035031	* Lever-Metering
22	530-035028	* Pin-Metering Lever
23	530-035016	* Screw-Metering Lever Pin
24	530-035151	+ *Gasket-Metering Diaphragm
25	530-035014	+ *Diaphragm-Metering
26	530-035003	Cover-Metering Diaphragm
27	530-035021	Screw Ass'y.-Metering Cover
28	530-035199	Kit-Carb. Kwik Repair (+ Indicates Contents)
29	530-035186	Kit-Carb. Gasket/Diaphragm (*Indicates Contents)


B. Blower Assembly



KEY NO.	PART NO.	DESCRIPTION
1	530-069271	Blower Tube Kit
Not Shown	-	Operator's Manual
	530-067366	Model 22HB
	530-067367	Model 28HBV

✓ = Part Change

PARTS LIST NO. 530-067369 - 8/29/88		HUSQVARNA PARTS LIST	BLOWER MODEL: 22HB
Page No. 2	Replaces None		BLOWER/VAC MODEL: 28HBV
Note: Illustrations may differ from actual models due to design changes			



✓ = Part Change

PARTS LIST NO. 530-067369 - 8/29/88		HUSQVARNA PARTS LIST	BLOWER MODEL: 22HB
Page No. 3	Replaces None		BLOWER/VAC MODEL: 28HBV
Note: Illustrations may differ from actual models due to design changes			


KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	530-015635	Screw	31	530-026776	Heat Deflector
2	530-094212	Handle Cover	32	530-010824*	Shroud (Incl. #12 & 45)
3	530-010827	Handle Ass'y.	33	530-069269	Blower Hsg. Kit (Incl. #36, 46-49,55, & Vac. Tubes)
4	530-027157	Static Ground Wire			
5	530-026994	Handle Isolator	34	530-094215	Impeller
6	530-015343	Isolator Spacer (Front)	35	530-015661	Screw
7	530-026163	Isolator Cup	36	530-015495	Screw
8	530-015629	Washer	37	530-001543	Nut
9	530-015628	Screw	38	530-015367	Screw
10	530-015561	Screw	39	530-015644	Nut
11	530-015342	Isolator Spacer (Rear)	40	530-015441	Washer
12	530-032091*	Ball Bearing (Shroud)	41	530-015626	Washer
13	530-015700	Screw	42	530-015632	Screw
14	530-024371	Air Filter	43	530-015682	Washer
15	530-015687	Screw	44	530-015168	Screw
16	530-015123	Washer	45	530-001516	Shroud Bearing Retainer
17	530-029081	Fan Housing	46	530-015667	Spring-Tension (Right)
18	530-042023	Starter Pulley Spring	47	530-015647	Pivot Pin
19	530-026780	Air Baffle	48	530-015672	Spring-Tension (Left)
20	530-069200	Pulley Replacement Kit	49	530-094241	Inlet Door Ass'y.
21	530-015479	Screw	50	530-015638	Screw
22	530-015123	Washer	51	530-015637	Fuel Tank Retainer
23	530-015544	Screw	52	530-026781	Fuel Tank Cushion
24	530-069232	Rope Kit	53	530-010897	Fuel Pick-Up Ass'y
25	530-026735	Starter Rope Handle	54	530-069247	Line Kit
26	530-027175	Ground Wire	55	530-015382	Washer
27	530-069252	"T" Handle Kit	56	530-010729	Fuel Cap Ass'y. (Incl. O-Ring)
28	530-094222	Blower Tube Clamp	57	530-010815	Fuel Tank Ass'y. (Incl. #53,54 & 56)
29	530-015197	Nut			
30	530-015636	Screw	59	530-015683	Screw
			60	530-027350	Fuel Tank Shield
			Decals		
			A	530-029034	Instruction Decal
			B	-	Fan Housing Decal (Left & Right)
				530-029031	Model 22HB
				530-029032	Model 28HBV
			C	530-027334	Blower/Vac Warning Decal

* When removing or installing the bearing (#32091), the area of the shroud (#10824) receiving the bearing must be heated to approximately 300°F. to avoid damaging the shroud.

✓ = Part Change

PARTS LIST NO. 530-067369 - 8/29/88		HUSQVARNA PARTS LIST	BLOWER MODEL: 22HB BLOWER/VAC MODEL: 28HBV
Page No. 4	Replaces None		

Note: Illustrations may differ from actual models due to design changes



✓ = Part Change

PARTS LIST NO. 530-067369 - 8/29/88		HUSQVARNA PARTS LIST	BLOWER MODEL: 22HB
Page No. 5	Replaces None		BLOWER/VAC MODEL: 28HBV
Note: Illustrations may differ from actual models due to design changes			


KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	-	Cylinder	36	530-026818	Carburetor Case
	530-012168	Model 22HB	37	* 530-019157	Carburetor Gasket
	530-012192	Model 28HBV	38	530-026981	Fuel Line Fitting
2	*530-019111	Cylinder Gasket	39	530-010875	Fuel Line & Fitting Ass'y.
3	-	Piston Ring	40	530-026797	Choke Guide Plate
	530-026413	Model 22HB	41	530-026772	Choke Shutter
	530-026681	Model 28HBV	42	530-015674	Screw
4	530-015162	Wrist Pin Retainer	43	530-035196	Carburetor
5	530-015239	Screw	44	530-015254	Wave Washer
7	530-069245	Muffler Ass'y.	45	530-015673	Spacer
9	530-024903	Muffler Attachment Spring	46	530-015630	Screw
10	-	Piston Kit (Incl. #3,4 & Pin)	47	530-015654	Retaining Ring
	530-010753	Model 22HB	48	530-015147	Wave Washer
	530-069203	Model 28HBV	49	530-015407	Screw
11	530-069242	Shaft Kit	50	530-026773	Choke Actuator
12	530-012145	Shaft Coupling	52	530-026764	Carb. Case Cover
13	530-094243	Plastic Coupling	53	530-023807	Choke Knob
14	530-626605	Flywheel Nut	54	530-015675	Screw
15	530-023817	Starter Dog Spring	55	530-015660	Screw
16	530-015004	Screw	56	530-015123	Washer
18	-	Crankshaft & Rod Ass'y.	57	530-015614	Throttle Knob
	530-027273	Model 22HB	58	530-023575	Grounding Switch Nut
	530-010853	Model 28HBV	59	530-024569	Washer
19	530-032092	Piston Pin Bearing Model 28HBV Only	60	530-069204	Toggle Switch Kit (Incl. #58 & 59)
20	530-015351	Washer	61	530-026771	Throttle Wire Ass'y.
21	530-032029	Crankshaft Bearing	62	530-026951	Ignition Wire
22	530-010757	Crankcase Ass'y. (Incl. #21, 23 & 28)	63	530-026829	Ground Wire
23	*530-019059	Crankcase Seal	64	530-024435	Plug Wire Grommet
26	530-001717	Coupling Washer	65	530-015128	Screw
27	530-015126	Flywheel Key	66	530-039124	Ignition Module
28	530-015168	Screw	67	530-030058	Spark Plug (RCJ-8)
29	530-039111	Flywheel Ass'y.	68	530-003933	Spark Plug Lead Connector
30	530-015127	Flywheel Washer	69	530-003934	Spark Plug Boot
31	530-024438	Reed Valve	70	530-039082	High Tension Lead Wire
32	*530-019108	Carburetor Case to Crankcase Gasket	71	530-039103	High Tension Lead Ass'y. (Incl. #68,69 & 70)
33	*530-019105	Carburetor Case Seal	72	530-030054	Crankcase Sealant (Not Supplied With Unit)
34	530-015241	Screw	73	530-069219	Engine Gasket Kit(*Indicates Contents)
35	530-023367	Washer			

*Indicates Engine Gasket Kit Contents


PARTS LIST NO. 530-067369 - 8/29/88		HUSQVARNA PARTS LIST	BLOWER MODEL: 22HB BLOWER/VAC MODEL: 28HBV
Page No. 6	Replaces None		

VAC ATTACHMENT KIT #952-703529

KEY NO.	PART NO.	DESCRIPTION
1	530-094654	Elbow
2	530-069272	Vacuum Bag Kit(Incl. #1)
3	530-010850	Rear Handle Ass'y.
4	530-094660	Spacer
5	530-069270	Vacuum Tube Kit (Incl. #4)



GUTTER ATTACHMENT KIT #952-703530



KEY NO.	PART NO.	DESCRIPTION
1	530-062003	Goggles
2	530-351416	Coupler
3	530-094426	Nozzle
4	530-094425	Extension Tube
5	530-094424	Pivot Tube
6	530-094518	Elbow
A	530-029036	Warning Decal

✓ = Part Change