



 **Husqvarna**



18H



1.1992

Spare parts

Ersatzteile

Pièces détachées


Repuestos

Reservdelar


MODEL NUMBER 18H

PARTNUMBER	SQUARE	PARTNUMBER	SQUARE
530 01 41-99	D	530 02 99-46	A
530 01 43-07	C	530 02 99-48	H
530 01 43-60	C	530 02 99-54	E
530 01 43-84	D	530 02 99-56	E
530 01 43-95	C	530 03 21-21	H
530 01 43-96	J	530 03 21-23	H
530 01 43-97	G	530 03 21-24	C
530 01 45-09	A	530 03 21-25	C
530 01 45-10	H	530 03 50-14	L
530 01 45-12	J	530 03 50-31	L
530 01 51-62	G	530 03 51-39	L
530 01 54-96	J	530 03 51-64	L
530 01 56-35	D	530 03 51-66	L
530 01 57-70	E	530 03 52-23	L
530 01 57-75	D,E	530 03 52-36	L
530 01 58-05	H	530 03 52-50	L
530 01 58-14	H	530 03 53-06	D,L
530 01 58-28	F	530 03 53-31	L
530 01 58-49	D	530 03 53-32	L
530 01 58-82	F,J	530 03 60-46	H
530 01 58-86	J	530 03 61-23	E
530 01 59-30	F	530 03 61-45	F
530 01 59-34	E,H	530 03 61-80	K
530 01 59-35	B,D	530 03 62-28	H
530 01 59-40	E	530 03 64-43	E
530 01 59-41	F	530 03 64-54	B
530 01 59-45	C	530 03 64-57	D
530 01 59-53	G	530 03 65-20	J
530 01 59-54	F	530 03 65-23	A
530 01 59-55	A	530 03 65-25	E
530 01 59-63	J	530 03 65-26	E
530 01 91-79	C	530 03 65-28	E
530 01 91-80	G	530 03 65-29	A
530 01 91-81	C	530 03 65-30	D
530 01 91-82	J	530 03 65-31	D
530 01 91-83	D	530 03 91-34	F
530 01 91-85	D	530 03 91-49	F
530 02 44-75	D	530 04 81-13	H
530 02 61-19	D	530 06 92-16	D
530 02 93-95	J	530 06 92-32	J
530 02 99-14	K	530 06 92-47	D
530 02 99-15	K	530 06 93-50	G
530 02 99-16	H	530 06 93-52	K
530 02 99-24	G	530 06 93-53	J
530 02 99-29	C	530 06 93-54	G
530 02 99-30	K	530 06 93-55	H
530 02 99-33	K	530 09 49-91	H
530 02 99-34	D		
530 02 99-39	F		
530 02 99-40	F		


A




B




C






F




D






J



K



L

compl 530 03 53-06 - WT - 221

