




Illustrated Parts List	1994-07
	19402019

# 51 MD

954065801A




Repair Parts Manual

Walk Mower

# REPAIR PARTS

## 20" ROTARY LAWN MOWER - - MODEL NO. 51md (954065801A)



# REPAIR PARTS

## 20" ROTARY LAWN MOWER - - MODEL NO. 51md (954065801A)

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532850735	Control Bar	34	532055187	Thread Cutting Screw 5/16-18 x 3/4
2	532850724	Handle Grip	35	532851084	Hex Head Screw 3/8-24 x 1-3/8
3	532132001	Rope Guide	36	532850263	Helical Lockwasher 3/8
4	532125295	Upper Handle	37	532851074	Hardened Washer
5	532125293	Lower Handle	38	532134871	20" Blade
6	532131959	Handle Bolt 5/16-18 x 1-3/4	39	532851514	Blade Adapter
7	532063601	Locknut 1/4-20	42	532751649	Deflector Rod
8	532125162	Up-Stop Bracket	43	532140544	Rear Deflector
9	532750097	Hex Washer Head Screw #10-24 x 1/2	44	532700279	Retainer Clip
10	532130861	Engine Zone Control Cable	45	532700417	Throttle Control
11	532144929	Hex Washer Head Screw 1/4-20 x 2.12	46	532085723	Washer
12	532051793	Hairpin Cotter	47	532213146	* Cable Clamp
13	532136376	Handle Knob	48	532083816	Thread Rolling Screw #10-32 x 5/8
14	532850845	Hubcap	49	-----	* Engine - Briggs & Stratton - Model No. 128802
15	532083923	Hex Locknut 3/8-16	50	532800547	Trim Plate
16	532057143	Washer	51	532850998	Hex Head Screw, Self Tap. 3/8 - 16 x 1.1
17	532800333	Wheel & Tire Assembly	52	873510400	Keps Locknut 1/4-20
18	532142748	Shoulder Bolt	53	532063601	Locknut
19	532062335	Belleville Washer	54	812000014	External E-Ring
20	532125066	Selector Spring	55	532087589	Torsion Spring
21	532132800	Selector Knob	56	532087590	Hinge Rod
22	532125061	Axle Arm Assembly	57	532130737	Housing Assembly Bracket
23	532141934	Lawn Mower Housing (Includes Key No. 29)	58	532140862	Mulcher Door
24	532036953	Screw	59	532140864	Door Latch
25	532084920	Spacer	60	532140648	Decal
26	532800370	Wheel Adjusting Bracket (R.F./L.R.)	61	532751399	Chute Mounting Bracket
27	532800368	Wheel Adjusting Bracket (L.F./R.R.)	62	532752118	Mulcher Deflector
28	532140465	Handle Bracket Assembly (Right)	63	874180410	Truss Head Screw
29	532107339	Danger Decal	--	532145629	Owner's Manual (English/French)
30	532140466	Handle Bracket Assembly (Left)	--	532800569	Decal (Engine)
31	532085436	Screw	--	532142184	Decal (Housing)
32	532751592	Locknut 3/8-16	--	532850788	Trim Plate Decal
33	532066426	Wire Tie			

\* These parts must be purchased through an authorized Briggs & Stratton dealer.