


For Husqvarna Parts Call 606-678-9623 or 606-561-4983




# 21LCN



**1.1995**  
**Spare parts**  
**Pièces détachées**

**⚠ WARNING**  
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.




# For Husqvarna Parts Call 606-678-9623 or

Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530 09 46-71	Drive Shaft-45"	20.	630 09 48-75	Hub Ass'y.
2.	530 09 46-73	"D" Handle	21.	530 09 48-30	Spring.
3.	530 03 65-14	Throttle Hsg. (Left)	22.	530 09 48-27	Release Button
4.	530 03 65-15	Throttle Hsg. (Right)	23.	952 71 55-44	Spool w/Line
5.	530 03 65-56	Throttle Lever	24.	530 09 48-28	Cover
6.	530 01 59-66	Screw- Throttle Hsg.	25.	530 09 20-62	Washer-Handle
7.	530 09 13-73	Wing Nut-Handle	Not Shown		
8.	530 09 47-42	Clamp-Handle			
9.	530 01 58-20	Bolt-Handle			
10.	530 09 45-43	Dust Cup			
11.	530 01 53-37	Screw-Line Limiter			
12.	530 09 45-70	Line Limiter		530 04 70-65	Carton Contents Bag
13.	534 79 05-00	Locknut-Line Limiter		108 08 33-89	Operator Manual
14.	530 01 61-07	Screw-Shield		530 03 89-07	Shaft Warning Decal
15.	530 02 93-73	Shield Bracket		530 08 52-80	Carton
16.	530 03 11-59	Hex Wrench (5/32)			
17.	530 06 92-99	Shield Kit Ass'y.			
18.	530 09 53-32	Drive Shaft Hsg.			
19.	952 71 55-40	Cutting Head Ass'y. (Incl. 20-24)			

✓ = NEW PART NUMBER FOR THIS IPL

★ = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)


[www.mymowerparts.com](http://www.mymowerparts.com)



For Husqvarna Parts Call 606-678-9623 or 606-561-4983								
Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530 02 93-95	starter spring	27.	530 03 65-78	Muffler Body	54.	530 06 95-71	Fuel Line-Prim./Tnk
2.	530 01 57-75	screw-pulley	28.	530 03 65-77	Muffler Cover	55.	530 01 43-47	Fuel Cap Ass'y.
3.	530 02 75-23	Retainer-pulley	29.	530 03 86-02	Muffler Baffle-Exit	56.	530 01 43-62	Fuel Pickup Ass'y.
4.	530 01 59-34	Screw-Shrd/Fan Hsg.	30.	530 03 65-79	Muffler Baffle-First	57.	530 06 96-25	Engine Gasket Kit († Indicates Content)
5.	530 02 75-69	Starter Handle	31.	530 02 99-30	Muffler Spring	58.	530 01 47-29	C'case & C'shaft Assy. (Incl. 10,19,22-26)
6.	530 01 58-10	Screw-Fan Housing	32.	530 04 73-25	Shroud & Tank AMY.	59.	530 03 81-14	Switch
7.	530 01 91-85	Gasket-Cylin./Carb.	33.	530 01 91-81	Gasket-C'case	60.	530 01 59-53	Screw-Cylinder
8.	530 03 00-75	Spark Plug-RCJ-8Y	34.	530 06 96-19	Cylinder	61.	530 01 60-72	Screw-Pinch Clamp
9.	530 01 91-94	Gasket-Carb.	35.	530 06 95-64	Carb. Adaptor	62.	530 01 57-68	Locknut-Pinch Clmp
10.	530 01 59-45	Retainer-Crankcase	36.	530 01 60-14	Straw-Carb. Adaptor	63.	530 06 96-75	Fan Housing/Shroud Ass'y.
11.	530 01 46-63	Lead Wire	37.	530 01 92-23	Gasket-Cylinder	64.	530 06 92-32	Rope Kit
12.	530 01 46-62	Ground Wire	38.	530 06 96-47	Carburetor w/Limiter Cap	65.	530 01 60-80	Screw-Rope Retain.
13.	530 03 91-48	Flywheel	39.	530 03 89-44	Air Box	66.	530 06 94-00	Starter Pulley Kit (Incl 65)
14.	530 03 91-63	Ignition Module	40.	530 03 73-26	Choke Plate	67.	530 06 93-80	Spark Arrestor Kit
15.	530 03 61-45	Spacer-Ignition Mod.	41.	530 03 81-02	Choke Shutter	68.	530 01 51-62	Piston Pin Retainer
16.	530 01 59-54	Straw-Ignition Mod.	42.	530 01 52-54	Wave Washer	69.	530 06 96-21	Piston Kit (Incl. 21, 68 & Pin)
17.	530 01 58-28	Washer-Flywheel	43.	530 01 58-52	Choke Spacer	70.	530 06 96-60	Muffler Kit
18.	530 02 79-53	Drive coupling	44.	530 01 58-87	Screw-Carb.	71.	530 01 58-82	Screw-Flywheel
19.	530 01 45-32	Crankshaft Ass'y.	45.	530 03 74-13	Filter Plate	72.	530 01 60-90	Screw-Primer Ass'y
20.	530 06 96-15	connecting Rod Ass'y	46.	530 03 73-31	Air Filter Foam	73.	530 03 79-72	Primer Bulb Ass'y.
21.	530 03 64-04	Piston Ring	47.	530 03 72-92	Air Falter Cover	74.	530 06 92-47	Fuel Line-Carb./Tank
22.	530 01 48-61	Crankcase Ass'y. and. 10 & 23-25)	48.	530 01 59-66	straw-Fdter cover	75.	530 02 99-39	Starter Dog
23.	530 03 21-25	Inner Bearing	49.	530 03 67-44	Throttle Cable Ass'y.	76.	530 03 77-30	Starter Dog Spring
24.	530 03 21-24	Outer Bearing	50.	530 01 58-14	Screw-Carb. Adaptor	77.	530 06 92-16	Fuel Line-Carb./Prim
25.	530 01 91-79	C'case seal	51.	530 02 61-19	Check Valve			
26.	530 01 59-41	Retain. Ring-C'shaft	52.	530 02 97-17	Element-Falter			
			53.	530 02 96-96	Retainer			

✓ = NEW PART NUMBER FOR THIS IPL ★ = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)

**Carburetor Assembly Kit Number #530 05 96-47 - WA - 218**



For Ref.	Husqvarna Part No.	Description
1.	530 03 <del>84-04</del>	8 0623 Or Idle Needle
2.	530 03 53-41	
3.	<del>530 03</del> 53-45	Spring Idle Needle
4.	530 06 96-68	Carburetor Repair Kit (● Indicates Contents)