For Husqvarna Parts Call 606-678-9623 or 606-561-4983





2	
B0400016	

English 1 (1)

SB, 334 T, 336, 338 XPT, 339 XP, 357 XP, 335 XPT California, 338 XPT California, Autodecompression valve, 2004-01

There are two different types of decompression valve. The difference between them is in the spring pressure.

Models 357XP, 335XPT California and 338XPT California have a valve with a high spring pressure (1.8N) marked with a B or AB, see diagram below. The part number that will be used is 537 12 68-03.

Models 334T, 336, 338XPT and 339XP have a valve with a low spring pressure (0.9N) marked with an A. The part number that will be used is 537 12 68-04.

357XP, 335XPT California, 338XPT California

334T, 336, 338XPT, 339XP



