



MODELS 181 XP/281 XP

NEW SHORT-CIRCUIT SWITCH – BETTER LEADS (w. 619)

| <u>New Ref. No.</u> | <u>Denomination</u> | <u>Excluded Ref. No.</u> | <u>Remark</u> |
|---------------------|-----------------------|--------------------------|---|
| 501 63 38-01 | Short-circuit switch | 501 81 52-01 | Remains as a spare part |
| 723 12 24-55 | Screw | | |
| 731 23 10-05 | Nut | | |
| 501 83 98-03 | Grounding lead-module | 501 83 98-02 | Changing from black to blue colour, -02 remains as a spare part |

Lead module-ignition coil Ref. No. 501 83 97-02 is only changing colour, from yellow to red.

NOTE!

Switch Ref. No. 501 63 38-01 (154) has a terminal with the width 4.8 mm and the switch Ref. No. 501 81 52-01 has a terminal with the width 6.3 mm. The spade terminals on the lead have the corresponding width, Ref. No. 501 83 98-03 and the lead 501 83 98-02. To be able to mount the switch Ref. No. 501 63 38-01 on older saws, the screw, nut and new lead must be ordered separately to the stop switch.

Also two holes ϕ 6 mm and ϕ 3.3 mm must be drilled in the crankcase, according to the ill. See below.

