

Model T 255R

Procedure of adjustment of T 255R (Reverse clutch position on tillers serial number 7016631-7018140)

- 1 Take off the belt cover.
- 2 Verify that the distance between the centres of the pulleys is maximum 314 mm.
- 3 Verify the distance between the back of the reverse belt and the lower guide. This distance should be not more than 0 mm maximum by contact and easy pressure on the back of the belt.
- 4 Verify the other adjustments of the belt guide, as mentioned on the picture below.
- 5 Put the cover back.
- 6 After having filled up petrol and oil, start the tiller.
- 7 Then try it during 10 minutes switching gears forward / reverse.

- 1 - Pulley forward
- 2 - Pulley reverse
- 3 - Receptive pulley forward
- 4 - Belt tensioner reverse
- 5 - Belt tensioner forward
- 6 - Receptive pulley reverse

