

No
Diagram
Available


Parts List
Only

Ref #	Part Number	Qty	Description
	214207		Spike
	94972		Scrench
	93797		Wrench/Screwdriver
	214194		Lubri-Gun
	91226		Holder - Flywheel
	94365		Kit - Carrying Case, 14"
	92977		Scabbard, 14"
	94364		Kit - Carrying Case, 16"
	214202		Scabbard, 16"
	85702		Lubricant - Custom, 6-oz. Can
	85703		Lubricant - Custom, 6-oz. Cans, 1-6 pack
	216113		Key - Socket 3mm
	216107		Key - Socket 4mm
	214212		Kit - Tool
	216805		Kit - Spark Arrester Screen
	94416		Adaptor - Intake (Cylinder)
	94415		Adaptor - Intake (Air Box)
	68917		Adaptor - Exhaust
	85229		Kit - Fuel Tank Plug
	215432		Tool - Pressure Test
	63094		Driver - Wrist Pin
	501334		Tester - Ignition
	67537		Loctite
	69794		Locquic
	110083		R.T.V. Sealant
	110706		Tool - Handle/Throttle Screw


No
Diagram
Available

Parts List
Only


Ref #	Part Number	Qty	Description
	214235		Bar - 14" Mini Pro (Sprocket Tip)
	91730		Bar - 14" Mini Mac
	90771		Bar - 14" Mac 6
	214919N		Chain - 14" MP 370 GL
	214236		Bar - 16" Mini Pro (Sprocket Tip)
	90772		Bar - 16" Mac 6
	214925N		Chain - 16" MP 370 GL



Ref #	Part Number	Qty	Description
	94496	1	Carburetor Assembly (Zama)
1		1	Shaft Asy - Throttle
2		1	Spring - Throttle Return
3		1	Plate - Throttle
4		1	Screw - Plate (M3)
5		1	"E" Ring
6		1	Kit - Diaphragm & Gaskets
7		1	Cover Asy - Pump
8		1	Screw - Idle Speed
9		1	Insert - Friction
10		4	Screw - Pump Cover (M4)
11		1	Needle - Inlet
12		1	Spring - Lever
13		1	Lever - Inlet Needle
14		1	Pin - Lever
15		1	Screw - Lever Pin (M3)
16		1	Diaphragm Asy - Metering
17		1	Cover - Diaphragm
18		4	Screw - Diaphragm Cover (M3)
19		1	Screw - Idle Adjust
20		1	Screw - Main Adjust
21		2	Spring - Needle
22		1	Screen - Filter
23		1	Gasket - Metering Diaphragm
24		1	Welsh Plug
25		1	Orifice - Main Fuel




Ref #	Part Number	Qty	Description
1	216527	1	Lever - Flag Brake
2	216276	1	Screw - Btn hd 1/4-20 x 13/16
3	216542	1	Washer - Lock
4	216541	1	Washer - Plain
5	216256	1	Nut - Brake Handle
6	216267	1	CHAIN BRAKE Assembly
7	216540	1	Screw - Fil hd 8-32 x 5/8
8	94709	1	Band - Brake
9	215758	1	Kit - Latch
10		1	Spring - Compression
11	93602	1	Pivot - Latch
12	214368	1	Bearing - Roller
13	213907	1	Pin - Roller
14	213052	1	Screw - Adjusting
15	110907	1	Ring - Retaining
16	84929	1	Nut - Bar Adjusting
17	105673	1	Pin - Roll 3/32 x 9/16
18	93528A	1	Cover




Ref #	Part Number	Qty	Description
1	216476	1	Nut - Hx Flg M6 x 1.0
2			CHAIN BRAKE Assembly See "Chain Brake" Assembly illustration and parts list
3			Chain Assembly See "Bar & Chain" Assembly illustration and parts list
4			Bar See "Bar & Chain" Assembly illustration and parts list
5	214207	1	Spike
6	94144	1	Nut - Clutch
7	94243	1	Plate - Dust
8	213278	1	Clutch Assembly
9		1	Rotor
10	93608	1	Spring Assembly - Clutch
11	110957	2	Rivet - Fl 1/8 x .547
12	85064	2	Plate - Clutch Shoe
13	215252	1	Drum/Spkt/Bearing Asy
14	91222	1	Bearing
15	215259	1	Washer - Sprocket
16	216466	1	Screw - Skt hd M5 x 56 (SEMS)
17	216465	2	Screw - Skt hd M5 x 21 (SEMS)
18	216467	1	Screw - Skt hd M5 x 19 (SEMS)
19	216470	1	Screw - Skt hd M5 x 18 (SEMS)
20	170044	2	Nut - Hx M5 Lock
21	216572	2	Washer - M5
22	213165	1	Screw - Hx hd M5 x 25
23	110989	2	Grommet
24	93152	1	Link
25	93057	2	Spacer - Mount
26	216206	2	Screw - Skt hd M4 x 25 (SEMS)
27	92983A	1	Frame
28	216489	1	Kit - Starter
29	216064	1	Screw - M5 T-head
30	110041	1	Screw - Pan hd 8-32 x .5
31	68497	1	Washer
32	213261	1	Drum/Rope Assembly
33	83203	1	Rope - Starter
34	83078	1	Spring - Starter Rewind
35	216488	1	Housing Assembly - Starter
36	91255	1	Kit - Starter Handle
37	105490	1	Washer - Starter Handle
38	215484	1	Cover Assembly - Air Filter
39	216469	1	Screw - Pan hd M5 x 16
40	215456	1	Filter - Air
41	215487	1	Airbox Assembly
42	213411	1	Plate - Choke
43	215455	1	Bracket - Choke
44	213420	1	Spacer
45	213105	1	Screw - Pan hd M5 x 55
46	213104	1	Screw - Special M5 x 50
47			Carburetor Assembly See "Carburetor Assembly" illustration and parts list
48	215563	1	Kit - Fan Housing/Grommet
49	213542	1	Hose - Pulse

Ref #	Part Number	Qty	Description
50	94501	1	Nut - Hx M5 x 0.8 Thin
51	94302	1	Clip - Spring
52	92747	1	Flange - Carburetor Mounting
53	213211	1	Kit - Carburetor Boot
54	95656	1	Eyelet
55	111002	1	Screw - Pan hd 10-16 x .5
56	93720	1	Pickup - Fuel
57	94491	1	Seal - Fuel Vent
58	93997	1	Hose - Fuel
59	90869	1	Filter - Vent
60	216666	1	Kit - Fuel Tank
61	216098	1	Cap Assembly - Fuel
62			Handle Assemblies See "Handle Assembly" Illustration and parts list
63	216464	4	Screw - Hx Wsh M6 x 17
64	213021	4	Washer - Ramp Conical
65	214152	1	Kit - Top Shroud
66	214350	1	Insulator
67	214154	1	Kit - Bottom Shroud
68	214350	1	Insulator
69	216465	1	Screw - Skt hd M5 x 21 (SEMS)
70	94192	1	Grommet
71	120034	2	Nut - Hx hd M6 x 1.0
72	110999	1	Screw - Hx hd 6-20 x 5/8 WH
73	94540	1	Rod - Oiler
74	100001	1	Washer - Plain
75	93304A	1	Knob - Oiler
76	93634A	1	Spring - Compression
77	216465	2	Screw - Skt hd M5 x 21 (SEMS)
78	216095	1	Cap - Oil
79	93506A	1	Tank Assembly - Oil
80	94405	1	Hose - Oil Pickup
81	93998	1	Spring - Oil Hose
82	92465	1	Pickup - Oil
83	216105	1	Plate - Name Used on Model (PM 355)
83	216149	1	Plate - Name Used on Model (PM 365)
83	216153	1	Plate - Name Used on Model (PM 375)
84			Powerhead Assembly See "Powerhead Assembly" Illustration and parts list



Ref #	Part Number	Qty	Description
1	216468	2	Bolt - Shoulder
2	93530A	4	Spring - Mount
3	92704	1	Mount
4	94038	1	Hub - Mount
	213230		Handle Assembly
	213231		Handle Assembly
5	111032	A/R	Screw - Pan hd 10-26 x 5/8
6	92704	1	Mount
7	94038	1	Hub - Mount
8	213229	1	Handle - Right Half
9	213224	1	Handle - Long Right
10	213228	1	Handle - Left Half
11	213226	1	Handle - Long Left
12	93310	1	Trigger - Safety
13	93515	1	Spring - Trigger
14	213232	1	Trigger - Throttle
15	213234	1	Wire Assembly - Throttle
16	213233	1	Wire Assembly - Throttle
17	110706	1	Screw - Pan hd 8-18 x 1/2
18	62451	1	Contact - Ignition Switch
19	93505A	1	Wire - Stop Switch
20	94039	1	Wire - Stop Switch
21	68846	1	Button - Stop Switch
24			UNKNOWN



Ref #	Part Number	Qty	Description
1	93150	1	Bail
2	83898	1	Connector - Outlet
3	216424	1	Pump Assembly - Chain Oiler
4	215196	1	Connector - Hose
5	94115	1	Valve - Oiler
6	93639	1	Screw - 6-40 x .800
7	215151	1	Cap - Oil Pump
8	93301	1	Plunger - Oil Pump
9	105614	1	"O" Ring - .239 x .070
10	93632	1	Spring
11		1	Piston Assembly - Oiler
12		1	Ring - Oil Pump Piston
13		1	"O" Ring - .114 x .070
14	83891	1	Spring - Return
15		1	Sleeve - Oil Pump
16		1	Eyelet
	216426		Repair Kit - Oil Pump
17	110653	1	"O" Ring
18	215871	2	Nut - Muffler
19	215471	1	Plate - Lock
20	215472	1	Deflector - Exhaust
21	215774	1	Cover
22	215776	1	Baffle
23	213369	1	Screw - Hx hd M6 x 1
24	215757	2	Bolt - Shoulder
25	215773	1	Base
26	213169	1	Nut - Hx Flg M8 x 1.25
27	94737	1	Flywheel/Pawl Assembly
28	68796	2	Pin - Starter Pawl
29	67814	2	Spring - Pawl
30	94493	2	Pawl - Starter
31	102164	1	Key - Woodruff
32	120027	1	Screw - Pan hd M5 x 18 (SEMS)
33	120112	2	Screw - Skt hd M5 x 40
34	24236	1	Washer - Special
35	93514A	1	Wire Assembly - Ground
36	216599	1	Electronic Ignition Assembly
37	102556	1	Connector - Spark Plug
38	95266	1	Boot - Spark Plug
39	214356	1	Spacer - Coil
40	215601	1	Manifold - Carburetor
41	92778	1	Gasket - Insulator
42	216205	4	Screw - Skt hd M5 x 25
43	215943	1	Kit - Cylinder
44	92777	1	Bolt - Bar Mounting
45	94660	1	Piston Assembly
46	94136	1	Ring Set
47	92836	1	Pin - Piston
48	111026	2	Ring - Snap
49	94135	1	Connecting Rod Assembly
50	94654	2	Screw - Connecting Rod
51	110984	1	Bearing - Needle
52	68095	1	Roller - Needle (Set of 20)
53	92750	1	Crankshaft
54	213282	2	Bearing - Crankshaft

Ref #	Part Number	Qty	Description
55	83859	2	Seal - Crankshaft Oil
56	214223	1	Spark Plug