

No
Diagram
Available


Parts List
Only

Ref #	Part Number	Qty	Description
	214207		Spike
	94972		Scrench
	93797		Wrench - Screwdriver
	214194		Lubri - Gun
	91226		Holder - Flywheel
	93095		Bracket - AUTO - SHARP
	95168		Grinder Assembly - AUTO - SHARP
	94365		Kit - Carrying Case, 14"
	92977		Scabbard - 14"
	94364		Kit - Carrying Case, 16"
	214202		Scabbard - 16"
	85702		Lubricant - Custom, 6 oz. can
	85703		Lubricant - Custom,6 oz. cans, 6-pack
	214212		Kit - Tool
	95169		Kit - Spark Arrester Screen
	94416		Adaptor - Intake (Cyl.)
	94415		Adaptor - Intake (Air Box)
	68917		Adaptor - Exhaust
	85229		Kit - Pressure Test
	215432		Tool - Pressure Test
	501334		Tester - Ignition
	67537		Loctite
	69794		Locquic
	63094		Driver - Wrist Pin
	110083		R.T.V. Sealant
	110706		Tool - Handle/Throttle Trigger Screw


No
Diagram
Available

Parts List
Only


Ref #	Part Number	Qty	Description
	214919N		Chain - MP 370GL
	214235		Bar - 14" Mini Pro
	214656N		Chain - AS 370G
	214230N		Chain - 370G
	214136		Bar - 16" Mini Pro
	214925N		Chain - MP 370GL




Ref #	Part Number	Qty	Description
	94496A	1	Carburetor Asy - Walbro (WA-52)
1	94749	1	Ring - Shaft retainer
2	94752	1	Shaft Asy - Throttle
3	94765	1	Spring - Throttle return
4	83755	1	Screw - Valve
5	94753	1	Valve - Throttle
6	94766	1	Needle - Idle adjust
7	94767	1	Needle - Hi speed
8	94763	1	Spring - Idle needle
9	67502	1	Spring - Hi speed needle
10	94762	1	Screw - Idle adjust
11	67504	1	Spring - Friction
12	94760	1	Screw - Pump cover
13	94751	1	Cover - Pump
14	94754	1	Gasket - Pump
15	94758	1	Diaphragm - Pump
16	94769	1	Screen - Inlet
17	80529	4	Screw - Diaphragm cover
18	94750	1	Cover - Metering diaphragm
19	94759	1	Diaphragm Asy - Metering
20	94755	1	Gasket - Metering diaphragm
21	94761	1	Screw - Circuit plate
22	94771	1	Plate - circuit
23	94756	1	Gasket - circuit
24	67500	1	Screw - Metering lever
25	94770	1	Pin - Metering lever
26	94772	1	Lever - Metering
27	94764	1	Spring - Metering lever
28	67491	1	Valve - Inlet needle
	94775		Kit - Gasket/Diaphragm
	94774		Kit - Repair



Ref #	Part Number	Qty	Description
	94496	1	Carburetor Assembly (Zama)
1		1	Shaft Asy - Throttle Not available separately.
2		1	Spring - Throttle Return Not available separately.
3		1	Plate - Throttle Not available separately.
4		1	Screw - Plate (M3) Not available separately.
5		1	"E" Ring Not available separately.
6		1	Kit - diaphragm & Gaskets Not available separately.
7		1	Cover Asy - Pump Not available separately.
8		1	Screw - Idle Speed Not available separately.
9		1	Insert - Friction Not available separately.
10		4	Screw - Pump Cover (M4) Not available separately.
11		1	Needle - Inlet Not available separately.
12		1	Spring - Lever Not available separately.
13		1	Lever - Inlet Needle Not available separately.
14		1	Pin - Lever Not available separately.
15		1	Screw - Lever Pin (M3) Not available separately.
16		1	Diaphragm Asy - Metering Not available separately.
17		1	Cover - Diaphragm Not available separately.
18		4	Screw - Diaphragm Cover(M3) Not available separately.
19		1	Screw - Idle Adjust Not available separately.
20		1	Screw - Main Adjust Not available separately.
21		2	Spring - Needle Not available separately.
22		1	Screen - Filter Not available separately.
23		1	Gasket - Metering Diaphragm Not available separately.
24		1	Welch Plug Not available separately.
25		1	Orifice - Main Fuel Not available separately.
	217081		Repair Kit
	217089		Gasket/Diaphragm Kit
	216804		Needle Kit




Ref #	Part Number	Qty	Description
	214373	1	CHAIN BRAKE Assembly
1	111047	1	Screw - Fil hd 8-32 x 5/8
2	94709	1	Band - Brake
3	215758	1	Kit - Latch
4		1	Spring - Compression Not available separately.
5	93602	1	Pivot - Latch
6	92482	1	Pivot - Lever
7	93159	1	Lever - Actuating
8	214368	1	Bearing - Roller
9	213907	1	Pin - Roller
10	90658	1	Screw - Adjusting
11	110907	1	Ring - Retaining
12	84929	1	Nut - Bar Adjusting
13	215589	1	Housing - Brake
13	94181	1	Housing - Brake
14	935284	1	Cover - AUTO-SHARP




Ref #	Part Number	Qty	Description
1	215662	1	Kit - Grinder Asy - AUTO-SHARP
2	215447	1	Knob
3	216707	1	Wheel Asy - grinding
4	216134	1	Washer
5	216133	1	Pin - Cotter
6	215208	1	Bracket - AUTO-SHARP
7	120025	2	Screw - Pan hd M5 x 10
8	120029	2	Nut - Hx Flg M6 x 1.0
9		1	CHAIN BRAKE Assembly Not available separately. See "Chain Brake Assembly" illustration and parts list.
10		1	Chain Not available separately.See "Bar & Chain Combinations" parts list.
11		1	Bar Not available separately.See "Bar & Chain Combinations" parts list.
12	214207	1	Spike
13	93148	1	Spacer - Bar Pad
14	215695	1	Screw - Hx hd M5 x 50 ST (SEMS)
15	120028	1	Screw - Hx hd M6 x 20
16	93021A	1	Lever - Wraparound
17	94244	1	Nut - Clutch
18	94243	1	Plate - Dust
19	213278	1	Kit - Clutch
20	94242	1	Rotor
21	93608	1	Spring Assembly - Clutch
22	110957	2	Rivet - Fl 1/8 x .547
23	85064	2	Plate - Clutch Shoe
24	215252	1	Drum/Sprocket/Bearing Asy
25	91222	1	Bearing
26	215259	1	Washer - Sprocket
27	120096	1	Screw - WH M5 x 55 ST
28	120095	2	Screw - WH M5 x 20 ST
29	120098	1	Screw - WH M5 x 18
30	216816	1	Kit - Frame
31	216064	1	Screw - M5 T-Head
32	216585	1	Nut - Hx M5 Lock
30	216504	1	Frame Assembly
31	216064	1	Screw - M5 T-Head
32	93057	1	Nut - Hx M5 Lock
33	111011	2	Screw - Pn hd 10-16 x 7/8
34	95141	1	Weight - Frame
35	216585	1	Nut - Hx M5 Lock
36	120045	2	Washer - M5
37	110989	2	Grommet
38	93152	1	Link
39	93057	2	Spacer - Mount
40	120036	2	Screw - Pn M4 x 25 (SEMS)
41	216491	1	Kit - Starter Assembly
42	216064	1	Screw - M5 T-Head
43	91255	1	Kit - Starter Handle
44	105490	1	Washer - Starter Handle
45	110041	1	Screw - Pn hd 8-32 x .5
46	68497	1	Washer
47	213261	1	Drum/Rope Assembly
48	83203	1	Rope - Starter

Ref #	Part Number	Qty	Description
49	83078	1	Spring - Starter Rewind
50	216494	1	Housing Assembly - Starter
51	93527	1	Cover Assembly - Air Filter
52	93626	1	Screw - Pan hd M5 x .80
53	94970	1	Filter - Air
54	94608	1	Cover Assembly - Air Box
55	214316	1	Rod Assembly - Choke
56	94721	1	Seal - Air
57	120049	2	Screw - Pan hd M5 x 40
58	94905	1	Kit - Choke Plate & Bracket
59		2	Washer - Flat Not available separately.
60		1	Washer - Wavy Not available separately.
61	93151	1	Hose - Pulse
62		1	Carburetor See "Carburetor Assembly (Zama)" illustration and parts list and "Carburetor Assembly (Walbro)" illustration and parts list.
63	93101A	1	Housing - Fan
64	94302	1	Clip - Spring
65	92747	1	Flange - Carburetor Mounting
66	213211	1	Kit - Carburetor Boot
67	95656	1	Eyelet
68	111002	1	Screw - Pan hd 10-16 x .5
69	94501	1	Nut - Hx M5 x 0.8 Thin
70	93720	1	Pickup - Fuel
71	94491	1	Seal - Fuel Vent
72	93997	1	Hose - Fuel
73	90869	1	Filter - Vent
74	95301	1	Kit - Fuel Tank
75	95300	1	Cap Assembly - Fuel
76			Handle Assemblies Not available separately. See "Handle Assemblies" illustration and parts list.
77	213166	4	Screw - Hx Wsh M6 x 16
78	102523	4	Washer - Lock
79	105043	4	Washer - 1/4 Plain
80	214152	1	Kit - Top Shroud
81	214350	1	Insulator
82	214154	1	Kit - Bottom Shroud
83	214350	1	Insulator
84	120095	1	Screw - WH M5 x 20 ST
85	94192	1	Grommet
86	120034	2	Nut - Hx M6 x 1.0
87	110999	1	Screw - Hx hd 6-20 x 16 WH
88	94540	1	Rod - Oiler
89	100001	1	Washer - Plain
90	93304A	1	Knob - Oiler
91	93634A	1	Spring - Compression
92	120095	2	Screw - WH M5 x 20 ST
93	93274	1	Cap - Oil
94	216696	1	Tank Assembly - Oil
95	94405	1	Hose - Oil Pickup
96	93998	1	Spring - Oil Hose
97	92465	1	Pickup - Oil
98	93856	1	Plate - Name (PM 310)
98	93854	1	Plate - Name (PM 320)

Ref #	Part Number	Qty	Description
98	93858	1	Plate - Name (PM 330)
99	95206	1	Plate - Instruction
100			Powerhead Assembly Not available separately. See "Powerhead Assembly" illustration and parts list.



Ref #	Part Number	Qty	Description
1	93529	2	Bolt - Shoulder
2	93530A	4	Spring - Mount
3	92704	1	Mount
4	94038	1	Hub - Mount
	213230		Handle Assembly
	213231		Handle Assembly
	213235		Handle Assembly
5	111032	A/R	Screw - Pan hd 10-16 x 5/8
6	92704	1	Mount
7	94038	1	Hub - Mount
8	213229	1	Handle - Right half
9	213224	1	Handle - Long right
10	213228	1	Handle - Left half
11	213226	1	Handle - Long left
12	101326	1	Nut - Hx lock 10-24
13	104400	1	Screw - Pan hd 10-24 x 1-1/4
14	95042	1	Weight - Handle
15	93310	1	Trigger - Safety
16	93515	1	Spring - Trigger
17	213232	1	Trigger - Throttle
18	213234	1	Wire Assembly - Throttle
19	213233	1	Wire Assembly - Throttle
20	110706	1	Screw - Pan hd 8-18 x 1/2
21	62451	1	Contact - Ignition switch
22	93505A	1	Wire - Stop switch (PM 310/320)
23	94039	1	Wire - Stop switch (PM 330)
24	68846	1	Button - Stop switch



Ref #	Part Number	Qty	Description
1	93150	1	Bail
2	217168	1	Connector - Outlet
3	216424	1	Pump Assembly - Chain Oiler
4	215196	1	Connector - Hose
5	94115	1	Valve - Oiler
6	93639	1	Screw - 6-40 x .800
7	215151	1	Cap - Oil Pump
8	93301	1	Plunger - Oil Pump
9	105614	1	"O" Ring - .239 x .070
10	93632	1	Spring
11		1	Piston Assembly - Oiler Not available separately.
12		1	Ring - Oil Pump Piston Not available separately.
13		1	"O" Ring - .114 x .070 Not available separately.
14	83891	1	Spring - Return
15		1	Sleeve - Oil Pump Not available separately.
16		1	Eyelet Not available separately.
17	110653	1	"O" Ring
18	215411	1	Muffler/Deflector Assembly
19	110681	2	Screw - Skt hd 10-24 x 1/4
20	92961	1	Deflector - Exhaust
21	215394	2	Screw - Special M6
22	213169	1	Nut - Hx Flg M8 x 1.25
23	94737	1	Flywheel/Pawl Assembly
24	216984	2	Pin - Starter Pawl
25	216982	2	Spring - Pawl
26	216983	2	Pawl - Starter
27	102164	1	Key - Woodruff
28	120027	1	Screw - Pan hd M5 x 18 (SEMS)
29	120112	2	Screw - Skt hd M5 x 40
30	24236	1	Washer - Special
31	93514	1	Wire Assembly - Ground
32	93795	1	Wire Assembly - Ground
33	216599	1	Electronic Ignition Assembly
34	102556	1	Connector - Spark Plug
35	95266	1	Boot - Spark Plug
36	214356	1	Spacer - Coil
37	215601	1	Manifold - Carburetor
38	92778	1	Gasket - Insulator
39	120097	4	Screw - Hx W/H M5 x 25
40	215943	1	Cylinder/Crankcase Assembly
41	92777	1	Bolt - Bar Mounting
42	94660	1	Piston Assembly
43	94136	1	Ring Set
44	92836	1	Pin - Piston
45	111026	2	Ring - Snap
46	94135	1	Connecting Rod Assembly
47	94654	2	Screw - Connecting Rod
48	110984	1	Bearing - Needle
49	68095	1	Roller - Needle (set of 20)
50	92750	1	Crankshaft
51	213282	2	Bearing - Crankshaft
52	83859	2	Seal - Crankshaft Oil
51	93763	1	Sleeve Assembly - Bearing
52	83859	2	Seal - Crankshaft Oil

Ref #	Part Number	Qty	Description
53	93018	1	Spark Plug Used on PM 310, PM 320 and PM 330 with suffix letters B and E.
53	214223	1	Spark Plug Used on PM 310, PM 320 and PM 330 with suffix letters A, D, F, G, H, J, K, M, N, P and U.
	216426		Oil Pump Repair Kit