



Ref #	Part Number	Qty	Description
1	224142-02	1	Carburetor - Primer (WT 211)
2		2	Screw - Pump Cover Not available separately.
3		1	Cover - Primer Pump Not available separately.
4	223077	1	Bulb - Primer
5	223913	1	Cover Asy - Fuel Pump
6		1	Screw - Idle Adjustment Not available separately.
7		1	Spring - Idle Screw Not available separately.
8		1	Gasket - Fuel Pump Not available separately.
9		1	Diaphragm - Fuel Pump Not available separately.
10		1	Screen - Fuel Pump Inlet Not available separately.
11		1	Shaft Assembly Throttle Not available separately.
12		1	Spring - Throttle Return Not available separately.
13		1	Ring - Shaft Retainer Not available separately.
14		1	Needle - Idle Not available separately.
15		1	Needle - High Speed Not available separately.
16		1	Spring - Idle Needle Not available separately.
17		1	Spring - High Speed Needle Not available separately.
18		1	Screw - Valve Not available separately.
19		1	Valve - Throttle Not available separately.
20		1	Screw - Metering Lever Pin Not available separately.
21		1	Pin - Metering Lever Not available separately.
22		1	Lever - Metering Not available separately.
23		1	Valve - Inlet Needle Not available separately.
24		1	Spring - Metering Lever Not available separately.
25		1	Seat Asy Check - Valve Not available separately.
26		1	Plug - Welch 5/16 Not available separately.
27		1	Plug - Welch 1/4 Not available separately.
28		1	Ring - Screen Retainer Not available separately.
29		1	Screen - Check Valve Not available separately.
30		4	Screw - Metering Cover Not available separately.
31		1	Cover - Metering Lever Not available separately.
32		1	Asy - Metering Diaphragm Not available separately.
33		1	Gasket - Metering Diaph. Not available separately.
	224462		Major Repair Kit
	223833		Gasket/Diaphragm Kit




Ref #	Part Number	Qty	Description
1	224327	2	Screw - Pn M5 x 69 TORX SS
2	223196	1	Cover Assembly - Choke
3	219023	2	Insert - A/C Cover
4	223520	1	Kit - Choke Knob
5		1	Lever - Choke Not available separately.
6		1	Lever - Shutter Not available separately.
7	219016	1	Spring - Shutter
8		1	Plate Choke - Shutter Not available separately.
9	219145	1	Filter - Air
10	222758	1	Box - Air
11		1	Carburetor Assembly See "Carburetor Assembly" illustration and parts list.
12	224148	1	Gasket - Spacer
13	223984	1	Insulator - S/T
14	223986	1	Gasket - Shield Insulator
15	219508	2	Screw - Pn M4 x 17 SEMS TORX
16	219079	2	Spacer - Muffler Shield
17	218962	1	Shield - Muffler
18	219194	2	Screw - Pn 5-20 X .438 ST
19	219150	1	Cover - Spark Arrestor Scr.
20	219149	1	Screen - Spark Arrestor
21	222247	2	Nut - Stud
22	219152	1	Muffler - Assembly
23	215515	1	Gasket - Muffler
24	222480	2	Stud - Muffler
25		1	Fan Housing Assemblies See "Fan Housing Assemblies" illustration and parts list.
26	217669	1	Screw - Pn M4 x 25 TORX S
27	216022	2	Screw - Pn M4 x 23.4 TORX
28	217388	1	Starter Assembly
29	223326	1	Housing - Starter Assy
30	218932	1	Guide - Starter Rope
31	219585	2	Spacer - Housing Starter
32	219584	1	Spacer - Muffler Shield
33	215874	1	Screw - Pn M4 x 9.5 TORX
34	216590	1	Washer - Flat M4
35	216092	1	Drum/Rope Assembly
36	216093	1	Rope - Starter (36")
37	216792	1	Handle - Starter
38	218941	1	Washer - Nylon
39	217482	1	Spring - Starter
40	217382	1	Cushion - Fuel Tank
41	222239	1	Tank Assembly - Fuel
42	217264	1	Hose - Fuel
43	216985	1	Pickup - Fuel
44	222238	1	Hose - Fuel Return
45	222347-01	1	Cap - Fuel
46	217390	1	Cushion - Fuel Tank
47	217383	1	Decal - 40:1
48	222506	1	Decal - Storage
49	216583	1	Nut - Hex M8
50	215525	1	Racthet - Assembly
51	222308	1	Flywheel
52	219383	1	Wire Assy - Switch

Ref #	Part Number	Qty	Description
53	218022	2	Screw - Pn M4 x 23.4 TORX
54	219848	1	Ignition Assembly
55	95266	1	Boot - Spark Plug
56	102556	1	Connector - Spark
57	215533-01	1	Grommet - H/T Lead
58	62345	1	Spark - Plug DJ8J
59	213178	1	Screw - Pn M5 x 8.5 SEMS T
60	215540	1	Cover - Cylinder
61	217320	2	Screw - Pn M6 x 18 TORX SE
62	224447	1	Kit - Cylinder (Alum)/Gasket
63	223925	1	Gasket - Cylinder
64	223455	1	Ring - Piston
65	223468	1	Piston Plated - Mach
66	111026	2	Ring - Snap Int.
67	218175	1	Pin - Wrist
68	216027	4	Screw - Pn M5 x 28.5 SEMS
69	223902	1	Crankcase Assembly
70	213191	4	Pin
71	215545	1	Gasket - Crankcase
72	110984	1	Bearing - Needle
73	102164	1	Key - Flywheel
74	213282	2	Bearing - Crankshaft
75	218106-01	1	Crankshaft Assembly
76	83859	2	Seal - Crankshaft Oil
77	223215	1	Decal - Starting
78	215541	1	Grommet



Ref #	Part Number	Qty	Description
1	213177	4	Screw - Pn M4.2 x 18.5 TORX
2	217158	1	Screw Hx M5 x 35
3	216591	2	Washer - Flat M5
4	217159	1	Nut - Hex M5
5	218057	1	Housing Assembly - Fan
6	215534	1	Plate Thrust
7	213186	1	Ring - Retaining
8	213187	1	Bearing - Ball
9	218063	1	Drum - Clutch
10	217554	1	Clutch Assembly
11	215538	1	Rotor Clutch
12	223770	2	Spring - Clutch
13		2	Shoe - Clutch Not available separately.
14	215539	1	Plate - Side
15	219508	4	Screw - Pn M4 x 17 SEMS TORX
16	215874	1	Screw - Pn M4 x 9.5 TORX
17	217672	1	Washer - M4 Flat
18	219558	1	Nut - Square
19	223241	1	Switch - Momentary
20	219595	1	Fan Housing Assembly
21	219024	4	Spacer - Fan Housing
22	219025	1	Clamp - Fan Housing
23	217477	1	Coupling



Ref #	Part Number	Qty	Description
1	217935	2	Screw - Tr 10-24 x .50 TORX
2	218315	2	Nut
3	215337	2	Clamp - Handle
4	217856	1	J Handle Ext/Grip Assy
5	94212	1	Grip - Handle
6	224977	1	Kit - Loop Handle
7	228320	4	Screw - M6 x 0.8 x 45
8	236936	4	Washer
9	227045	1	Loop - Handle
10	227046	1	Clamp - Handle
11	236642	4	Nut
12	224117	1	Spacer - Handle
13	217403	1	Nut - Hx M6 x 1.0
14	216596	2	Washer - Flat M6
15	224144	1	Cable - Throttle
16	218285	1	Shaft - Flex 44"
17	224052	1	Housing Assembly - Outer
	224265	1	Housing Assembly - Outer
	222304	1	Housing Assembly - Outer
18	218282	1	Sleeve
19	215322	1	Grip
20	215323	1	Guide
21	216027	1	Screw - Pn M5 x 28.5 SEMS
22	217159	1	Nut - Hex M5
23	215318	1	Trigger - Throttle
24	222796	1	Housing - Trigger Throttle
25	223200	1	Screw - Self Tapping 10-16
26	218295	1	Decal - Warning
27	217937	1	Screw - Tr 10-24 x 1.00 T
28	218315	1	Nut
29	215874	1	Screw - Pn M4 x 9.5 TORX
30	217672	1	Washer - M4 Flat
31	222468	1	Assy - Kit Spindle Housing
32	217477	1	Coupling
33	222402	1	Washer - Thrust
34	218214	1	Collar
35	216595	1	Screw 4 x M6 x 50
36	215871	1	Nut Hex M6 x 1
37	224273	1	Shield - Grass 45ø
38	224062	1	Shield - Grass 45ø
39	229956	1	Shield - Grass 90ø
40	217935	2	Screw - Tr 10-24 x .50 TORX
41	218315	2	Nut
42	103174	2	Washer - Lock #10
43	224153	1	Knife
44	224499	1	Spacer
45	300110	1	Kit - String Head
46	224305	1	Cover
47	224268	1	Spool W/Line (.095)
48	223740	1	Spring - String Head
49	222403	1	Ring - Retaining
50	224986	1	Washer - Plain
51	224303	1	Housing - Eyelet Assembly
52	223739	1	Eyelets - String Head
53	224998	1	Collar

Ref #	Part Number	Qty	Description
54	222794	1	Housing - Trigger Throttle
55	110706	1	Screw - Pn 8-18 x .50 ST H
56	215320	1	Contact - Switch
57	215319	1	Base - Stop Switch
58	68846	1	Button - Stop Switch
59	224150	4	Harness - Wiring

No
Diagram
Available

Parts List
Only

Ref #	Part Number	Qty	Description
	215437		Tool - Oil Seal
	215441		Tool Clutch Puller
	215439		Tool Piston Driving
	215443		Plate - Pressure Test
	215444		Gasket Intake Pressure Test
	215445		Gasket - Exhaust Pressure Test
	217355		Wrench 8/10 mm (open end)
	218175		Socket - Wrench 9/16
	222785		T-25 TORX Drive 3.5"