


**Model 6-3696
Model 6-3697
Body Section**




Model 6-3696

Model 6-3697

Key No.	Part No.	Description
1	21811	Seat
2	20661	Shoulder Bolt 3/8"-16X7/8"
3	21418	Rear Shroud Ass'y.
4	21435	Hood
5	26X159	Screw #8X3/8" Type A
6	21691	Control Plate
7	26X186	Screw #10X 1/2" Type AB
8	21531	Steering Post Bearing
9	15X68	Flange Nut 3/8"-16
10	21540PA	Remote Control Unit
11	21458	Engine Shroud Ass'y.
12	21485Z	Sealed Beam Retainer
13	21650Z	Grille & Shroud Brace
14	21406	Grill
15	15X82	Flange Nut 1/4"-20
16	26X174	Screw 5/16"X 3/4" Type A
17	1X38	Bolt 1/4"-20X5/8"
18	2X53	Carriage Bolt 5/16"-18X5/8"
19	21569	Mat L.H.
20	21933	Running Board L.H.
22	15X79	Flange Nut 5/16"-18
23	403035	Frame Ass'y.
24	21446	Lower Grill
25	17X47Z	Washer
26	17X37Z	Washer
27	21481Z	Belt Guide
28	21932	Running Board R.H.
32	15X43Z	Locknut 5/16"-18
33	17X47Z	Washer
34	21568	Mat R.H.
35	21547	Support & Clip Ass'y.
36	2X56	Carriage Bolt 3/8"-16X 3/4"
37	21268	Grommet
38	21430	Battery Support
39	21403	Battery Cover
40	17X112	Finishing Washer
41	26X193	Screw #10X3-1/8" Type AB
42	1X78	Bolt 5/16"-18X4 3/4"
43	21438	Seat Bracket
44	26X185	Screw #10X3/8" Type AB
46	21411	Shroud Support
47	1X88	Bolt 1/2"-13X7/8"
48	19X36	Shakeproof Washer
49	21439Z	Seat Hinge
50	1X45	Bolt 5/16"-18X5/8"
51	21404	Tool Box
52	15X84	Lock Nut 3/8" - 16
53	21441	Front Axle Assembly
54	21469	Front Axle Spacer
55	21534	Front Axle Hanger
56	2X60	Carriage Bolt 3/8"-16X3"

**Model 6-3696
Model 6-3697
Steering Section**




Model 6-3696

Model 6-3697

Key No.	Part No.	Description
1	21688	Steering Wheel
2	21303	Steering Wheel Cap
3	15X76	Keps Nut 5/16"-18
4	1X75	Bolt 5/16"-18X1 3/4"
5	21486C	Steering Post
6	1X73Z	Screw 5/16"-18X7/8"
7	21493	Steering Gear & Coupling Ass'y.
8	15X84	Locknut 3/8"-16
9	20587	Bearing
10	21692	Steering Arm Gear & Brkt. Ass'y.
11	21426	Shoulder Bolt
12	15X77	Locknut 3/8"-24
13	21031	Ball Joint
14	15X61	Hex Nut 3/8"-24
15	21482	Drag Link Rod
16	30X49	Cotter Pin 1 1/4"
17	17X83Z	Washer
18	21401	Spindle Bearings
19	21476	Spindle Ass'y. L.H.
20	21475	Tie Rod Ass'y.
21	21479	Spindle Ass'y. R.H.
22	21527	Front Wheel & Tire
	403000	Rim Only
	403001	Tire Only
	400162	Valve Stem & Cap
	403010	Front Wheel Bearing
24	15X43Z	Locknut 5/16"-18
25	15X79	Flange Nuts 5/16-18
26	21693	Steering Bracket
27	1X45	Bolt 5/16-18X5/8"
28	17X115	Washer
	21622	Parts Bag

Model 6-3696 Drive Section




Model 6-3696

Key No.	Part No.	Description	Key NO.	Part No.	Description
1	21651	Cap	35	21473	Transaxle Clamp
2	21652	Oil Drain Extension	36	15X43Z	Lock Nut 5/16"-18
3	----	Engine†	37	21526	Wheel & Tire 18X9.50-8
4	6X66	Hex Socket Screw 1/4"-20X5/8"		21648	Wheel & Tire 18X8.50-8
5	21630	Muffler Extension		403004	Wheel Only
6	----	Muffler†		403005	Tire 18X9.50-8
7	21663Z	Heat Shield		403007	Tire 18X8.50-8
8	403030	Frame Ass'y.		400162	Valve Stem & Cap
9	20662	Woodruff Key #6	39	21432	E-Ring
10	15X84	Lock Nut 3/8"-16	40	21521	Washer
11	19X8	Lock Washer	41	21553	Square Key
12	20103	Engine Bolt 3/8" - 16X1"	42	21539	Woodruff Key
13	20684	Spring	43	----	Transaxle #
14	21681	Clutch Link Rod	44	20844	Knob
15	21428	Idler Bracket & Stud Ass'y.	45	21615	Drive Belt ½"X95"
16	21409	Idler Pulley	46	21447	Input Pulley
17	21426	Shoulder Bolt 3/8" - 16X7/8"	47	18X30	Lockwasher
18	20613	Idler Pulley	48	1X38	Bolt ¼"-20X5/8"
19	15X84	Flange Lock Nut 3/8-16	49	18X15	Lock Washer
20	17X47Z	Washer	50	1X73	Bolt 5/16"-18X7/8"
21	30X20	Cotter Pin ¾"	51	2X57	Carriage Bolt 3/8"-16X7/8"
22	21415Z	Stack Pulley	52	21440Z	Transaxle Support Bracket
23	10851Z	Washer	53	2X56	Carriage Bolt 3/8"-16X¾"
24	19X39	Shakeproof Washer	54	21683	Belt Guide
25	1X20	Bolt 3/8"-24X1"	55	15X68	Lock Nut 3/8"-16
26	21950	Clutch Lever Ass'y.	56	1X84	Bolt 5/16"-18X1"
27	26X174	Screw	57	21678Z	Brake Rod Support
28	21946	Brake Lever Ass'y.	58	26X185	Screw # 10X ½" Type AB
29	21484Z	Parking Brake Arm	59	20682	Spring
30	21434	Grip	60	15X79	Lock Nut
31	21544	Pedal	61	20619	Belt Guide
32	21535	Cap	62	17X115	Washer
33	21472Z	Brake Rod	63	15X66	Hex Nut 1/4"-20
34	21675	Spring			

†NOTE: Your Engine Model, Type and Code Number is stamped on Blower Housing.

#NOTE: Transaxle parts available through Tecumseh Dealer's only. Complete illustration shown on page 83.

**Model 6-3697
Drive Section**




Model 6-3697

Key No.	Part No.	Description	Key No.	Part No.	Description
1	21651	Cap	34	21675	Spring
2	21652	Oil Drain Extension	35	21473	Transaxle Clamp
3	----	Engine †	36	15X43Z	Lock Nut 5/16"-18
4	21616	Lock Nut	37	21526	Wheel & Tire 18X9.50-8
5	21633	Muffler Extension		21648	Wheel & Tire 18X8.50-8
6	----	Muffler†		403004	Wheel Only
7	21664Z	Heat Shield		403005	Tire 18X9.50-8
8	403035	Frame Ass'y.		403007	Tire 18X8.50-8
9	20662	Woodruff Key #6		400162	Valve Stem & Cap
10	15X84	Lock Nut 3/8"-16	39	21432	E-Ring
11	19X8	Lock Washer	40	21521	Washer
12	20103	Engine Bolt 3/8" - 16X1"	41	21553	Square Key
13	20684	Spring	42	21539	Woodruff Key
14	21681	Clutch Link Rod	43	----	Transaxle #
15	21428	Idler Bracket & Stud Ass'y.	44	20844	Knob
16	21409	Idler Pulley	45	21615	Drive Belt ½"X95"
17	21426	Shoulder Bolt 3/8" - 16X7/8"	46	21447	Input Pulley
18	20613	Idler Pulley	47	18X30	Lockwasher
19	15X84	Flange Lock Nut 3/8-16	48	1X38	Bolt ¼"-20X5/8"
20	17X47Z	Washer	49	18X15	Lock Washer
21	30X20	Cotter Pin ¾"	50	1X73	Bolt 5/16"-18X7/8"
22	21415Z	Stack Pulley	51	2X57	Carriage Bolt 3/8"-16X7/8"
23	10851Z	Washer	52	21440Z	Transaxle Support Bracket
24	19X39	Shakeproof Washer	53	2X56	Carriage Bolt 3/8"-16X¾"
25	1X20	Bolt 3/8"-24X1"	54	21683	Belt Guide
26	21950	Clutch Lever Ass'y.	55	15X68	Lock Nut 3/8"-16
27	26X174	Screw	56	1X84	Bolt 5/16"-18X1"
28	21946	Brake Lever Ass'y.	57	21678Z	Brake Rod Support
29	21484Z	Parking Brake Arm	58	26X185	Screw #10X½" Type AB
30	21434	Grip	59	20682	Spring
31	21544	Pedal	60	15X79	Lock Nut
32	21535	Cap	61	20619	Belt Guide
33	21472Z	Brake Rod	62	17X115	Washer

†NOTE: Your Engine Model, Type and Code Number is stamped on Blower Housing.

NOTE; Transaxle parts available through Tecumseh Dealer's only. Complete illustration shown on page 83.


Model 6-3643
Model 6-3663
Model 6-3666
Model 6-3667
Model 6-3697
Blade Housing



KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	21912Z	Pull Pin	39	2X53	Carriage Bolt
2	20692	Hair Pin	41	21189	Torsion Spring
3	17X57Z	Washer	42	21828	Chute Deflector
4	20661	Shoulder Bolt	43	28X23	Push-On-Cap
5	21911	Support Arms	44	21198Z	Pivot Rod
6	30X20	Cotter Pins	45	21953Z	Cable Guide
7	17X47Z	Washer	46	1X38	Bolt 1/4"-20X5/8"
8	21914Z	Clevis	47	20557	Cross Drive Belt 1/2" X 46"
9	29X93	Clevis Pin	48	17X87Z	Washers
10	15X84	Flange Locknut 3/8" - 16	49	20684	Idler Spring
11	21426	Shoulder Bolt 3/8" - 16X7/8"	50	21409	Idler Pulley
12	20613	Idler Pulley	51	21096	Jackshaft Pulley
13	21649	Blade Drive Belt 1/2"X55"	52	21024	Jackshaft - Long
14	21503	Blade Drive Idler Ass'y.	53	21504Z	Belt Guide
15	15X77	Locknut 3/8"-24	54	21915Z	Adjusting Clevis
16	21496	Idler Support Bracket	55	15X2	Hex Nut 5/16" - 18
17	20062	Woodruff Key # 6	56	21500	Lifter Bracket
18	20616	Jackshaft - Short	57	21906	Lifter Ass'y.
19	15X43	Nut 5/16"-18	58	21591Z	Latch
20	21022	Jackshaft Pulley	59	6X46	Shoulder Bolt 1/4"-20X37/64
21	20662	Shoulder Bolt	60	20476	Grip
22	21139Z	Idler Bracket Ass'y.	61	21249	Grip
23	20682	Spring	62	20101	Hair Pin
24	1X84	Bolt 5/16"-18X1"	63	21920	Adjusting Nuts
25	21907	Blade Housing	64	21918Z	Adjusting Rods
26	21913	Lift Cable	65	17X53Z	Washer
27	15X82	Hex Nut 1/4"-20	66	21031	Ball Joint
28	21917Z	Cable Guide	67	15X61	Hex Nut 3/8" - 24
29	21916	Nylon Pulley	68	21517	Link Rod
30	20551	Jackshaft Housing	69	17X67Z	Washer
31	20617	Blade Adapter	70	20934	Bracket
32	21673Z	Washer	71	21515C	Blade Drive Lever Ass'y.
33	20930	Blade	72	20739	Knob
34	20663	Blade Washer	73	15X67	Hex Nut 1/4" - 20
35	18X27	Lockwasher	74	404015	Skid Set
36	15X72	Hex Nut 1/2"-20		404036	Complete Blade Housing Assembly
37	1X90	Bolt 1/4"-20X1-3/4"			

Model 6-3696

Model 6-3697



D-3006

PARTS LIST

Key No.	Part No.	Description
1	----	Engine
2	25X186	Screw
3	26X159	Screw #8X3/8" Type A
4	21549	Safety Switch
5	21612	Jumper Wire
6	21577	Battery Cable
7	26X197	Screw 5/16"X3/4" Type A
8	1X38	Hex Bolt 1/4"-20X5/8"
9	21613	Battery Cable
10	21075	Battery
11	15X66	Keps Nut 1/4"-20
12	21261	Solenoid
13	21609	Wiring Harness
14	21064PA	Switch & Key <i>5 prong</i>
15	21057	Ammeter Ass'y. <i>3 prong #21571</i>
16	21686PA	Light Switch
17	21687	Wiring Harness
18	20837	Seal Beam Light
19	21023	Fuse 15 amp.
	27029	Key Only