


**MODEL 0-2182 21"  
REAR BAGGER  
SELF-PROPELLED**




**MODEL 0-2182 21"  
REAR BAGGER  
SELF-PROPELLED**

Key No.	Part No.	Description	Key No.	Part No.	Description
1	-----	Engine	43	42031	Knob - Door
2	32X64	Spring Pin	44	17X17Z	Washer
3	20411	Sprocket - Engine	45	26X184	Screw
4	42289	Primary Chain Cover	46	42204	Rear Guard
5	26X159	Tapping Screw			Hex Bolt 3/8"-16X3/4"
6	20062	Woodruff Key # 6			Hex Flange Nut 3/8"-16
7	42108	Roller Chain	49	42011	Housing Assembly
8	42088	Pinion Guard	50	20105	Wheel & Tire
9	20066	Drive Pinion	51	400247	Wheel Adjuster Assembly*
10	22974	Bearing Retainer Bracket	52	15X82Z	Flange Nut 1/4"-20
11	20048	Bearing	53	19X8	Shakeproof Washer
12	42063Z	Drive Arm	54	20102	Bolt - Engine Mount
13	22977	Spring - L.H.	55	1X69	Bolt - Blade Mount
14	22976	Spring - R.H.	56	18X31	Spring Lockwasher
15	42256Z	Wheel Connecting Lever Assembly	57	20094Z	Washer
16	15X84Z	Flange Locknut 3/8"-16	58	22860	Blade - 21 Inch
17	17X124	Washer	59	42002	Blade Adapter
18	1X38Z	Hex Bolt 1/4"-20X5/8"	60	42035	Grass Catcher Frame
19	42053Z	Drive Yoke Bracket - L.H.	61	42037	Door Latch
20	42054Z	Drive Yoke Bracket - R.H.	62	42036	Upper Tube
21	4X20	Machine Screw # 10-24X1/2"	63	42033	Grass Catcher Bag
22	42092	Control Cable Assembly	64	22961C	Upper Handle
23	15X51Z	Hex Nut # 10-24	65	42039C	Lower Handle
24	42083Z	Sprocket & Drive Shaft Assembly	66	42029	Handle Bracket LH
25	9X8	Shoulder Bolt	67	1X85Z	Hex Bolt
26	42018	Spring - Extension	68	15X84Z	Hex Nut
27	42003	Spacer	69	42028	Handle Bracket R.H.
28	42087	Sprocket	70	22550	Cable Clip
29	42090Z	Axle Drive Yoke Support	71	20266	Knob - Folding Handle
30	1X45Z	Hex Bolt 5/16"-18X5/8"	72	20129Z	Contour Head Bolt
31	11X8	Retainer Ring	73	42058	Throttle Control
32	17X100Z	Washer	74	3X99	Screw
33	15X76	Keps Nut 5/16"-18	75	15X66	Keps Nut
34	15X43Z	Stover Nut 5/16"-18	76	22975Z	Handle Stop
35	22973	Bracket & Pulley Assembly	77	22957Z	Control Handle
36	9X1	Shoulder Bolt	78	22959	Clutch Cable Hook
37	42052Z	Tie Rod Assembly	79	42069Z	Cable Bracket
38	32X70	Spring Pin	80	42092	Control Cable Assembly
		Handle Bracket - L.H.	81	17X46Z	Washer
		Handle Bracket - R.H.		42070	Parts Bag Assembly
41	42251E	Base Plate & Spacer Assembly		F-4904	Owners Manual
42	42030	Door & Bracket Assembly	82	3X97	Screw

\* Note: See page 86 for Wheel Adjuster Replacement Parts.

**DELUXE WHEEL ADJUSTER ASSEMBLY  
MODEL 400246 & MODEL 400247**

Key No.	Model 400246	Model 400247	Description
1	17X102Z	17X102Z	Washer
2	20101	20101	Hair Pin
3	9X9	9X18	Shoulder Bolt
4	22956Z	22956Z	Arm and Axle Assembly
5	20065	20065	Lever Spring Knob
6	20113Z	42007Z	Index Plate Assembly
7	15X12	15X12	Flange Locknut
1-7	400246	400247	Wheel Adjuster Assembly
8	15X84Z	15X84Z	Locknut



**STANDARD WHEEL ADJUSTER ASSEMBLY  
MODELS 400251 & 400252**

Key No.	Part No.	Description
1	17X102Z	Washer
2	20101	Hair Pin
3	42102Z	Wheel Bracket Assembly - Right Front or Left Rear
	42103Z	Wheel Bracket Assembly - Left Front or Right Rear
4	42104Z	Index Plate Assembly
1-4	400251	Wheel Adjuster Assembly - Right Front or Left Rear
1-4	400252	Wheel Adjuster Assembly - Left Front or Right Rear
5	15X84Z	Flange Locknut

